## Gopal B. Saha

# Basics of PET Imaging

Physics, Chemistry, and Regulations Second Edition



## **Basics of PET Imaging**

Physics, Chemistry, and Regulations

Second Edition

Gopal B. Saha, PhD Department of Nuclear Medicine, The Cleveland Clinic Foundation, Cleveland, Ohio

# **Basics of PET Imaging**

## Physics, Chemistry, and Regulations

Second Edition

With 72 Illustrations



Gopal B. Saha, Ph.D. Department of Nuclear Medicine The Cleveland Clinic Foundation Cleveland, OH 44195 USA

ISBN 978-1-4419-0804-9 e-ISBN 978-1-4419-0805-6 DOI 10.1007/978-1-4419-0805-6 Springer New York Dordrecht Heidelberg London

Library of Congress Control Number: 2009941060

© Springer Science+Business Media, LLC 2010

All rights reserved. This work may not be translated or copied in whole or in part without the written permission of the publisher (Springer Science+Business Media, LLC, 233 Spring Street, New York, NY 10013, USA), except for brief excerpts in connection with reviews or scholarly analysis. Use in connection with any form of information storage and retrieval, electronic adaptation, computer software, or by similar or dissimilar methodology now known or hereafter developed is forbidden.

The use in this publication of trade names, trademarks, service marks, and similar terms, even if they are not identified as such, is not to be taken as an expression of opinion as to whether or not they are subject to proprietary rights.

Printed on acid-free paper

Springer is part of Springer Science+Business Media (www.springer.com)

To my teachers, mentors, and friends

### Preface

Since the publication of this book in 2005, the growth of positron emission tomography (PET) and PET/CT modality has been phenomenal with the discovery of efficient detectors and the addition of sophisticated scanners and powerful software. Because of the vast advancement and changes in technology, and also with great appreciation of the success of the first edition, we thought a second edition of the book would be appropriate.

The book is revised to again fulfill the needs of nuclear medicine professionals such as physicians, technologists, and residents, along with students for their board examination and training. The contents of the book have been kept at the basic level as was in the first edition.

The organization of the book essentially has remained the same. Some chapters have been revised very extensively, while others have only minor changes. No change has been made in Chap. 1 as it is based on basic physics. Extensive revision has been made in Chaps. 2 and 3 to include up-to-date information on detectors, scanners, and data collection. Chapter 4 in the original edition has been divided into Chaps. 4 and 5 to allow for a separate chapter on "Storage, Display, and PACS." Chapter 6 has been updated with new information on NEMA standards on acceptance tests of PET scanners. New PET radionuclides and the list of current available cyclotrons have been added to Chap. 7. Chapter 8 includes a section on Compounding of PET Radiopharmaceuticals, in addition to several new PET radiopharmaceuticals. New regulations concerning the use of PET radiopharmaceuticals, the licensing of physicians and technologists, and the accreditation of PET facilities to be eligible for reimbursement for PET procedures are all included in Chap. 9. Chapter 10 has been revised, focusing on the issues of current reimbursement issues for PET studies. Only minor changes have been made in Chaps. 11 and 12 to include up-to-date information. Questions have been added at the end of each chapter, as appropriate, to reflect the changes in contents.

I thank my colleagues at the Cleveland Clinic Foundation for their support in many ways and Mrs. Diane Griffis for kindly typing and completing the manuscript on time. I sincerely thank Andrew Moyer, editor of radiology and nuclear medicine, at Springer for support and encouragement, and S. Geethalakshmi Srinivasan, Project Manager, at SPi Technologies India Pvt Ltd for excellent production of the book.

Cleveland, OH

Gopal B. Saha

## Contents

1.	Radioactive Decay and Interaction of Radiation with Matter	1
	Atomic Structure	1
	Radioactive Decay	2
	$\alpha$ Decay	2
	$\beta^-$ Decay	3
	Positron ( $\beta^+$ ) Decay	3
	Electron Capture	3
	Isomeric Transition	4
	Radioactive Decay Equations	5
	General Decay Equations	5
	Successive Decay Equations	7
	Units of Radioactivity	9
	Units of Radioactivity in System Internationale	9
	Calculations	9
	Interaction of Radiation with Matter	10
	Interaction of Charged Particles with Matter	10
	Interaction of $\gamma$ Radiation with Matter	12
	Ouestions	15
	References and Suggested Reading	17
2.	PET Scanning Systems	19
	Background	19
	Solid Scintillation Detectors in PET	20
	Photomultiplier Tube	24
	Pulse Height Analyzer	25
	Arrangement of Detectors	25
	PET Scanners	28
	Coincidence Scintillation Cameras	29
	PET/CT Scanners	30
	Small Animal PET Scanner	33
	Mobile PET or PET/CT	36

	Questions       References and Suggested Reading	38 39
3.	Data Acquisition and Corrections	41
	PET Data Acquisition	41
	Time of Flight Method	46
	Two-Dimensional vs. Three-Dimensional	
	Data Acquisition	47
	Factors Affecting Acquired PET Data	49
	Normalization	49
	Photon Attenuation	50
	Attenuation Correction Methods	52
	Random Coincidences	53
	Scatter Coincidences	55
	Correction for Scatter Coincidences	56
	Dead Time	58
	Radial Elongation	59
	PET/CT Data Acquisition	60
	Factors Affecting PET/CT Data	62
	Questions	67
	References and Suggested Reading	68
4.	Image Reconstruction	71
	Simple Backprojection	71
	Filtered Backprojection	72
	The Fourier Method	73
	Types of Filters	75
	Iterative Reconstruction	78
	3D Reconstruction	81
	Partial Volume Effect	83
	Questions	84
	References and Suggested Reading	85
5.	Storage, Display, and PACS	87
	Storage	87
	Display	89
	Software and DICOM	90
	PACS	91
	Teleradiology	94
	Questions	95
	References and Suggested Reading	95
6.	Performance Characteristics of PET Scanners	97
	Spatial Resolution	97
	Sensitivity	101
	Noise Equivalent Count Rate	102
	Scatter Fraction	103
	Contrast	103

	Quality Control of PET Scanners	104
	Daily Quality Control Tests	105
	Weekly Quality Control Tests	105
	Acceptance Tests for PET Scanners	107
	Spatial Resolution	108
	Scatter Fraction	108
	Sensitivity	111
	Count Rate Losses and Random Coincidences	112
	Ouality Control of CT Scanners	113
	Questions	114
	References and Suggested Reading	115
7.	Cyclotron and Production of PET Radionuclides	117
	Cyclotron Operation	117
	Medical Cyclotron	120
	Nuclear Reaction	120
	Target and Its Processing	122
	Equation for Production of Radionuclides	123
	Specific Activity	125
	Production of Positron-Emitting Radionuclides	125
	Fluorine-18	126
	Carbon-11	127
	Nitrogen-13	127
	Oxygen-15	128
	Iodine-124	128
	Strontium-82	128
	Technetium-94m	129
	Germanium-68	129
	Copper-62	129
	Ouestions	129
	References and Suggested Reading	130
8.	Synthesis of PET Radiopharmaceuticals	131
	PET Radiopharmaceuticals	131
	<sup>18</sup> F-Sodium Fluoride	131
	<sup>18</sup> F-Fluorodeoxyglucose	132
	6- <sup>18</sup> F-L-Fluorodopa	133
	<sup>18</sup> F-Fluorothymidine (FLT)	134
	<sup>18</sup> F-BMS-747158-02	135
	<sup>18</sup> F-O-(2-Fluoroethyl)-L-Tyrosine (FET)	135
	<sup>18</sup> F-Fluoromisonidazole (FMISO)	135
	<sup>18</sup> F-1-(5-fluoro-5-deoxy- $\alpha$ -arabinofuranosyl)-	
	2-nitroimidazole (FAZA)	136
	<sup>15</sup> O-Water	136
	n- <sup>15</sup> O-Butanol	136

	<sup>13</sup> N-Ammonia	136
	<sup>11</sup> C-Sodium Acetate	137
	<sup>11</sup> C-Flumazenil	137
	<sup>11</sup> C-Methylspiperone	137
	<sup>11</sup> C-L-Methionine	138
	<sup>11</sup> C-Raclopride	138
	<sup>11</sup> C-Choline	138
	<sup>62</sup> Cu-Pyruvaldehyde-bis(N <sup>4</sup> -	
	methylthiosemicarbazonato)	
	Copper(II) (PTSM)	139
	<sup>82</sup> Rb-Rubidium Chloride	139
	Automated Synthesis Devices	139
	Compounding of PET Radiopharmaceuticals	
	for Human Use	141
	Components, Materials, and Supplies	142
	Compounding Procedure Verification	142
	Dispensing of PET Radiopharmaceuticals	143
	Asentic Technique	143
	Quality Control of PET Radiopharmaceuticals	143
	Methods of Quality Control	144
	USP Specifications for Routine PET	111
	Radionharmaceuticals	147
	<sup>18</sup> F-Fluorodeoxyalucose	147
	$6^{18}$ E. Fluorodopa	1/18
	$1^{3}N_{-}$ A mmonia	1/18
		1/18
	References and Suggested Reading	140
9.	Regulations Governing PET Radiopharmaceuticals	151
	Food and Drug Administration	151
	Exploratory IND	153
	Radioactive Drug Research Committee	155
	Difference Between RDRC and Exploratory IND	155
	Radiation Regulations for PET Radiopharmaceuticals	156
	License or Registration	156
	Accreditation of PET Center	160
	Regulations for Radiation Protection	161
	Definitions	162
	Caution Signs and Labels	163
	Radiation Safety Officer	164
	Occupational Dose Limits	165
	Personnel Monitoring	165
	Receiving and Monitoring of Radioactive Packages	166
	ALARA Program	166
	Radioactive Waste Disposal	167
	-	

	Surveys for Radiation Exposure and Contamination	167
	Syringe and Vial Shields	168
	Use of Dose Calibrator	168
	Radioactive Spill	169
	Record Keeping	170
	Principles of Radiation Protection	170
	Time	170
	Distance	170
	Shielding	171
	Activity	173
	Do's and Don'ts in Radiation Protection Practice	173
	Department of Transportation	173
	Distribution of <sup>18</sup> F-FDG	175
	Ouestions	176
	References and Suggested Reading	177
10.	Reimbursement for PET Procedures	179
	Background	179
	Coverage	179
	Coding	180
	CPT, HCPCS, and APC Codes	180
	Diagnosis Codes	181
	Payment	182
	Hospital Inpatient Services: Medicare	183
	Hospital Outpatient Services: Medicare	183
	Payment for PET Radiopharmaceuticals	183
	Physician's Payment by Medicare	184
	Freestanding Facilities: Medicare	184
	Nonmedicare Payers: All Settings	184
	Billing	185
	Billing Process	185
	Chronology of Reimbursement for PET Procedures	186
	National Oncologic PET Registry	188
	Questions	188
	References and Suggested Reading	189
11	Design and Cast of PET Center	101
11.	Site Planning	· · · 191 101
		103
	PET Center	193
	Scanner Section	193
	Cyclotron Section	· · · 195 104
		194
	Caveat	193 104
	Shielding	190 104
	Cose Study	··· 190 200
		200

Cost of P Question	ET/CT and Cyclotron Operation	201 202
Refere	nces and Suggested Reading	203
12. Procedur	es for PET Studies	205
Whole-B	ody PET Imaging with <sup>18</sup> F-FDG	205
Physici	an's Directive	205
Patient	Preparation	206
Dosage	Administration	206
Scan		206
Recons	struction and Storage	207
Whole-B	ody PET/CT Imaging with <sup>18</sup> F-FDG	207
Physici	an Directive	207
Patient	Preparation	207
Dosage	Administration	207
Scan		208
Recons	struction and Storage	208
Myocardi	al Metabolic PET or PET/CT Imaging	200
wij	$h^{18}E$ EDG	200
Detiont	II I-TDO	209
Fattern		209
Deserve	····	209
Kecons	Struction and Storage	210
Myocardi	al Perfusion PET or PET/CT Imaging	010
wit	$h^{102}$ Rb-RbCl	210
Patient	Preparation	210
Dosage	Administration and Scan	210
Recons	struction and Storage	211
Addendu	m	211
<sup>82</sup> Rb Ir	Ifusion Pump	211
Refere	nces and Suggested Reading	213
Appendix A.	Abbreviations Used in the Text	215
Appendix B.	Terms Used in the Text	217
Appendix C.	Units and Constants	223
4 1' D		
Appendix D.	Administration of <sup>18</sup> F-FDG and <sup>82</sup> Rb-RbCl	225
Appendix E.	Evaluation of Tumor Uptake of <sup>18</sup> F-FDG by PET	227
Appendix F.	Answers to Selected Questions	231
Index		233

## 1 Radioactive Decay and Interaction of Radiation with Matter

#### Atomic Structure

Matter is composed of atoms. An atom consists of a nucleus containing protons (Z) and neutrons (N), collectively called nucleons, and electrons rotating around the nucleus. The sum of neutrons and protons (total number of nucleons) is the mass number denoted by A. The properties of neutrons, protons, and electrons are listed in Table 1.1. The number of electrons in an atom is equal to the number of protons (atomic number Z) in the nucleus. The electrons rotate along different energy shells designated as K-shell, L-shell, *M*-shell, etc. (Fig. 1.1). Each shell further consists of subshells or orbitals, e.g., the K-shell has s orbital; the L-shell has s and p orbitals; the M-shell has s, p, and d orbitals, and the N-shell has s, p, d, and f orbitals. Each orbital can accommodate only a limited number of electrons. For example, the s orbital contains up to 2 electrons; the p orbital, 6 electrons; the d orbital, 10 electrons; and the f orbital, 14 electrons. The capacity number of electrons in each orbital adds up to give the maximum number of electrons that each energy shell can hold. Thus, the K-shell contains 2 electrons; the L-shell 8 electrons, the *M*-shell 18 electrons, and so forth.

A combination of a given number of protons and neutrons in a nucleus leads to an atom called the nuclide. A nuclide X is represented by  ${}^{A}_{Z}X_{N}$ . Some nuclides (270 or so) are stable, while others (more than 2,800) are unstable. The unstable nuclides are termed the radionuclides, most of which are artificially produced in the cyclotron or reactor, with a few naturally occurring. The nuclides having the same number of protons are called the isotopes, e.g.,  ${}^{12}_{6}$ C and  ${}^{12}_{6}$ C; the nuclides having the same number of neutrons are called the isotopes, e.g.,  ${}^{16}_{6}$ O and  ${}^{16}_{7}$ N<sub>8</sub>; the nuclides having the same mass number are called the isobars, e.g.,  ${}^{131}_{11}$  and  ${}^{131}$ Xe; and the nuclides with the same mass number but differing in energy are called the isomers, e.g.,  ${}^{99}$ mTc and  ${}^{99}$ Tc.

This chapter is a brief overview of the materials covered and is written on the assumption that the readers are familiar with the basic concept of these materials.

#### 2 1. Radioactive Decay and Interaction of Radiation with Matter

1110000 1.1.	Characteristics	or creetrons and na	cicono	
Particle	Charge	Mass (amu) <sup>a</sup>	Mass (kg)	Mass (MeV) <sup>b</sup>
Electron	-1	0.000549	$0.9108 \times 10^{-30}$	0.511
Proton	+1	1.00728	$1.6721 \times 10^{-27}$	938.78
Neutron	0	1.00867	$1.6744 \times 10^{-27}$	939.07

TABLE 1.1. Characteristics of electrons and nucleons

 $^{\rm a}$  amu = 1 atomic mass unit = 1.66  $\times$   $10^{-27}\,\rm kg$  = 1/12 of the mass of  $^{12}\rm C$ 

<sup>b</sup> 1 atomic mass unit = 931 MeV



FIGURE 1.1. Schematic structure of a <sup>28</sup>Ni atom. The nucleus containing protons and neutrons is at the center. The *K*-shell has 2 electrons, the *L*-shell 8 electrons, and the *M*-shell 18 electrons.

#### **Radioactive Decay**

Radionuclides are unstable due to the unsuitable composition of neutrons and protons or excess energy and, therefore, decay by emission of radiations such as  $\alpha$  particles,  $\beta^-$  particles,  $\beta^+$  particles, electron capture, and isomeric transition.

#### $\alpha$ Decay

This decay occurs in heavy nuclei such as <sup>235</sup>U, <sup>239</sup>Pu, etc. For example,

$$^{235}_{92}\text{U} \to ^{231}_{90}\text{Th} + \alpha$$
 (1.1)

Alpha particles are a nucleus of helium atom having two protons and two neutrons in the nucleus with two orbital electrons stripped off from the *K*-shell. The  $\alpha$  particles are emitted with discrete energy and have a very short range in matter, e.g., about 0.03 mm in human tissues.

#### $\beta^-$ Decay

 $\beta^-$  Decay occurs in radionuclides that are neutron rich. In the process, a neutron in the nucleus is converted to a proton along with the emission of a  $\beta^-$  particle and an antineutrino,  $\bar{\nu}$ .

$$\mathbf{n} \to \mathbf{p} + \beta^- + \bar{\nu} \tag{1.2}$$

For example,

$$^{131}_{53}\text{I}_{78} \rightarrow ^{131}_{54}\text{Xe}_{77} + \beta^- + \bar{\nu}$$

The energy difference between the two nuclides (i.e., between <sup>131</sup>I and <sup>131</sup>Xe in the above example) is called the decay energy or transition energy, which is shared between the  $\beta^-$  particle and the antineutrino  $\bar{\nu}$ . Because of the random nature of decay,  $\beta^-$  particles are emitted with a spectrum of energy with the transition energy as the maximum energy and with an average energy equal to one-third of the maximum energy.

#### *Positron* ( $\beta^+$ ) *Decay*

When a radionuclide is proton rich, it decays by the emission of a positron  $(\beta^+)$  along with a neutrino v. In essence, a proton in the nucleus is converted to a neutron in the process.

$$p \to n + \beta^+ + \nu \tag{1.3}$$

Since a neutron is one electron mass heavier than a proton, the right-hand side of Eq. (1.3) is two electron mass more than the left-hand side, i.e.,  $2 \times 0.511 \text{ MeV} = 1.022 \text{ MeV}$  more on the right side. For conservation of energy, therefore, the radionuclide must have a transition energy of at least 1.022 MeV to decay by  $\beta^+$  emission. The energy beyond 1.022 MeV is shared as kinetic energy by the  $\beta^+$  particle and the neutrino.

Some examples of positron-emitting nuclides are:

$$\begin{split} {}^{18}_{9}\mathrm{F}_{9} &\to {}^{18}_{8}\mathrm{O}_{10} + \beta^{+} + \nu \\ {}^{82}_{37}\mathrm{Rb}_{45} &\to {}^{82}_{36}\mathrm{Kr}_{46} + \beta^{+} + \nu \end{split}$$

Positron emission tomography (PET) is based on the principle of coincidence detection of the two 511-keV photons arising from positron emitters, which will be discussed in detail later.

#### Electron Capture

When a radionuclide is proton rich, but has energy less than 1.022 MeV, then it decays by electron capture. In the process, an electron from the nearest

shell, i.e., K-shell, is captured by a proton in the nucleus to produce a neutron, and a neutrino v is emitted to conserve energy.

$$\mathbf{p} + e^- \to \mathbf{n} + \mathbf{v} \tag{1.4}$$

Note that when the transition energy is less than 1.022 MeV, the radionuclide definitely decays by electron capture. However, when the transition energy is more than 1.022 MeV, the radionuclide can decay by positron emission and/or electron capture. The greater the transition energy above 1.022 MeV, the more likely the radionuclide will decay by positron emission. Some examples of radionuclides decaying by electron capture are:

$${}^{111}_{49}\text{In} + e^- \to {}^{111}_{48}\text{Cd} + v$$
$${}^{67}_{31}\text{Ga} + e^- \to {}^{67}_{30}\text{Zn} + v$$

#### Isomeric Transition

When a nucleus has excess energy above the ground state, it can exist in excited (energy) states, which are called the isomeric states. The lifetimes of these states normally are very short ( $\sim 10^{-15}$  to  $10^{-12}$ s); however, in some cases, the lifetime can be longer from minutes to years. When an isomeric state has a longer lifetime, it is called a metastable state and is represented by "m." Thus, having an energy state of 140 keV above <sup>99</sup>Tc and decaying with a half-life of 6 h, <sup>99m</sup>Tc is an isomer of <sup>99</sup>Tc.

$${}^{99m}\text{Tc} \rightarrow {}^{99}\text{Tc} + \gamma$$
$${}^{113m}\text{In} \rightarrow {}^{113}\text{In} + \gamma$$

A radionuclide may decay by  $\alpha$ ,  $\beta^-$ ,  $\beta^+$  emissions, or electron capture to different isomeric states of the product nucleus, if allowed by the rules of quantum physics. Naturally, these isomeric states decay to lower isomeric states and finally to the ground states of the product nucleus, and the energy differences appear as  $\gamma$ -ray photons.

As an alternative to  $\gamma$ -ray emission, the excitation energy may be transferred to an electron, preferably in the K-shell, which is then ejected with energy  $E_{\gamma} - E_{\rm B}$ , where  $E_{\gamma}$  and  $E_{\rm B}$  are the  $\gamma$ -ray energy and binding energy of the electron, respectively (Fig. 1.2). This process is called the internal conversion, and the ejected electron is called the conversion electron. The vacancy created in the K-shell is filled by the transition of an electron from an upper shell. The energy difference between the two shells appears as a characteristic K X-ray. Similarly, characteristic L X-ray, M X-ray, etc. can be emitted if the vacancy in the L- or M-shell is filled by electron transition from upper shells. Like  $\gamma$  rays, the characteristic X-ray energy can be emitted as photons or be transferred to an electron in a shell which is then ejected, if energetically possible. The latter is called the Auger process, and the ejected electron is called the Auger electron.



FIGURE 1.2.  $\gamma$ -ray emission and internal conversion process. In internal conversion process, the excitation energy of the nucleus is transferred to a *K*-shell electron, which is then ejected, and the *K*-shell vacancy is filled by an electron from the *L*-shell. The energy difference between the *L*-shell and *K*-shell appears as the characteristic *K* X-ray. The characteristic *K* X-ray energy may be transferred to an *L*-shell electron, which is then ejected in the Auger process.



FIGURE 1.3. The decay scheme of  $^{68}$ Ga. The 87.5% of positrons are annihilated to give rise to 175% of 511-keV photons.

The decay of radionuclides is represented by a decay scheme, an example of which is given in Fig. 1.3.

#### Radioactive Decay Equations

#### General Decay Equations

The atoms of a radioactive sample decay randomly, and one cannot tell which atom will decay when. One can only talk about an average decay of the atoms in the sample. This decay rate is proportional to the number of radioactive atoms present. Mathematically,

$$-\frac{dN}{dt} = \lambda N, \tag{1.5}$$

where -dN/dt is the rate of decay denoted by the term activity A,  $\lambda$  is the decay constant, and N is the number of atoms of the radionuclide present. Thus,

$$A = \lambda N. \tag{1.6}$$

Integrating Eq. (1.5) gives the activity  $A_t$  at time t as

$$A_t = A_0 \mathrm{e}^{-\lambda t},\tag{1.7}$$

where  $A_0$  is the activity at time t = 0. The plot of  $A_t$  vs. t on a semilog scale is shown in Fig. 1.4. If one knows activity  $A_0$  at a given time, the activity  $A_t$  at time t before or later can be calculated by Eq. (1.7).

*Half-life*  $(t_{1/2})$  The half-life of a radionuclide is defined as the time required to reduce the initial activity to one-half. It is unique for every radionuclide and is related to the decay constant as follows:



FIGURE 1.4. Plot of activity  $A_t$  against time on a semilogarithmic graph indicating a *straight line*. The slope of the line is the decay constant  $\lambda$  of the radionuclide. The half-life  $t_{1/2}$  is calculated from  $\lambda$  using Eq. (1.8). Alternatively, the half-life is determined by reading an initial activity and half its value and their corresponding times. The difference in time between the two readings is the half-life.

The half-life of a radionuclide is determined by measuring the radioactivity at different time intervals and plotting them on semilogarithmic paper, as shown in Fig. 1.4. An initial activity and half its value are read from the straight line, and the corresponding times are noted. The difference in time between the two readings gives the half-life of the radionuclide.

The mean life  $\tau$  of a radionuclide is defined by

$$\tau = \frac{1}{\lambda} = \frac{t_{1/2}}{0.693} = 1.44t_{1/2}.$$
(1.9)

A radionuclide decays by 63% in one mean life.

*Effective half-life* Each radionuclide decays with a definite half-life, called the physical half-life, which is denoted by  $T_p$  or  $t_{1/2}$ . When radiopharmaceuticals are administered to patients, analogous to physical decay, they are eliminated from the body by biological processes such as fecal excretion, urinary excretion, perspiration, etc. This elimination is characterized by a biological half-life ( $T_b$ ) which is defined as the time taken to eliminate a half of the administered activity from the biological system. It is related to the decay constant  $\lambda_b$  by

$$\lambda_{\rm b} = \frac{0.693}{T_{\rm b}}.$$

Thus, in a biological system, the loss of a radiopharmaceutical is related to  $\lambda_p$  and  $\lambda_b$ . The net effective rate of loss ( $\lambda_e$ ) is characterized by

$$\lambda_{\rm e} = \lambda_{\rm p} + \lambda_{\rm b}.\tag{1.10}$$

Since  $\lambda = 0.693/t_{1/2}$ ,

$$\frac{1}{T_{\rm e}} = \frac{1}{T_{\rm p}} + \frac{1}{T_{\rm b}},\tag{1.11}$$

$$T_{\rm e} = \frac{T_{\rm p} \times T_{\rm b}}{T_{\rm p} + T_{\rm b}}.$$
(1.12)

The effective half-life is always less than the shorter of  $T_p$  or  $T_b$ . For a very long  $T_p$  and a short  $T_b$ ,  $T_e$  is almost equal to  $T_b$ . Similarly, for a very long  $T_b$  and a short  $T_p$ ,  $T_e$  is almost equal to  $T_p$ .

#### Successive Decay Equations

In a successive decay, a parent radionuclide p decays to a daughter nuclide d, and d in turn decays to another nuclide c, and we are interested in the decay rate of d over time. Thus,

$$p \rightarrow d \rightarrow c.$$

Mathematically,

$$-\frac{dN_d}{dt} = \lambda_p N_p - \lambda_d N_d.$$
(1.13)

On integration,

$$A_{\rm d} = \frac{\lambda_{\rm d}(A_{\rm p})_0}{\lambda_{\rm d} - \lambda_{\rm p}} [\mathrm{e}^{-\lambda_{\rm p}t} - \mathrm{e}^{-\lambda_{\rm d}t}]. \tag{1.14}$$

If the parent half-life is greater than the daughter half-life (say a factor of 10–100), and also if the time of decay (t) is very long, then  $e^{-\lambda_d t}$  is almost zero compared with  $e^{-\lambda_p t}$ . Then

$$(A_{\rm d})_t = \frac{\lambda_{\rm d}}{\lambda_{\rm d} - \lambda_{\rm p}} (A_{\rm p})_t. \tag{1.15}$$

Equation (1.15) represents a *transient equilibrium* between the parent p and the daughter d radionuclides, which is achieved after several half-lives of the daughter. The graphical representation of this equilibrium is shown in Fig. 1.5. It can be seen that after equilibrium, the daughter activity is greater than the parent activity and the daughter appears to decay following the half-life of the parent. The principle of transient equilibrium is applied to many radionuclide generators such as the <sup>99</sup>Mo–<sup>99m</sup>Tc generator.



FIGURE 1.5. The transient equilibrium is illustrated in the plot of activity vs. time on a semilogarithmic graph. The daughter activity increases initially with time, reaches a maximum, then transient equilibrium, and finally appears to follow the half-life of the parent. Note that the daughter activity is higher than the parent activity in equilibrium.

If the parent half-life is much greater than the daughter half-life (by factors of hundreds or thousands), then  $\lambda_p$  is very negligible compared with  $\lambda_d$ . Then Eq. (1.15) becomes

$$(A_{\rm d})_t = (A_{\rm p})_t.$$
 (1.16)

This equation represents a *secular equilibrium* in which the daughter activity becomes equal to the parent activity, and the daughter decays with the half-life of the parent. The  ${}^{82}$ Sr $-{}^{82}$ Rb generator is an example of secular equilibrium.

#### Units of Radioactivity

 $\begin{array}{l} 1~Ci=3.7\times10^{10}~disintegration~per~second~(dps)\\ 1~mCi=3.7\times10^7~dps\\ 1~\mu Ci=3.7\times10^4~dps \end{array}$ 

#### Units of Radioactivity in System Internationale

 $\begin{array}{l} 1 \; Becquerel \; (Bq) = 1 \; dps \\ 1 \; kBq = 10^3 \; dps = 2.7 \times 10^{-8} \; Ci \\ 1 \; MBq = 10^6 \; dps = 2.7 \times 10^{-5} \; Ci \\ 1 \; GBq = 10^9 \; dps = 2.7 \times 10^{-2} \; Ci \end{array}$ 

#### Calculations

#### Problem 1.1

A dosage of <sup>18</sup>F-FDG has 20 mCi at 10 A.M. Wednesday. Calculate the activity of the dosage at 7 A.M. and 2 P.M. that day. The half-life of <sup>18</sup>F is 110 min.

Answer:

$$\lambda \text{ for } {}^{18}\text{F} = rac{0.693}{110} \, \text{min}^{-1}$$

time from 7 A.M. to 10 A.M. = 43 h = 180 mintime from 10 A.M. to 2 A.M. = 4 h = 240 min

Activity of <sup>18</sup>F-FDG at 7 A.M. = 
$$20 \times e^{+\frac{0.93}{110} \times 180}$$
  
=  $20 \times e^{+1.134}$   
=  $62 \text{ mCi} (2.29 \text{ GBq})$   
Activity of <sup>18</sup>F-FDG at 2 P.M. =  $20 \times e^{-\frac{0.693 \times 240}{110}}$   
=  $20 \times e^{-1.512}$   
=  $20 \times 0.22 = 4.4 \text{ mCi} (163.1 \text{ MBq})$ 

#### Problem 1.2

A radioactive sample decays 40% per hour. What is the half-life of the radionuclide?

Answer:

$$\lambda = 0.4 \,\mathrm{h}^{-1} = \frac{0.693}{t_{1/2}}$$
$$t_{1/2} = \frac{0.693}{0.4} = 1.73 \,\mathrm{h}.$$

#### Interaction of Radiation with Matter

Radiations are either particulate type, such as  $\alpha$  particle,  $\beta$  particle, etc., or nonparticulate type, such as high-frequency electromagnetic radiation (e.g.,  $\gamma$  rays, X-rays, etc.), and both kinds are ionizing radiations. The mode of interaction of these two types of radiations with matter is different.

#### Interaction of Charged Particles with Matter

The energetic charged particles such as  $\alpha$  particles and  $\beta$  particles, while passing through matter, lose their energy by interacting with the orbital electrons of the atoms in the matter. In these processes, the atoms are ionized in which the electron in the encounter is ejected or the atoms are excited in which the electron is raised to a higher energy state. In both excitation and ionization processes, chemical bonds in the molecules of the matter may be ruptured, forming a variety of chemical entities.

The lighter charged particles (e.g.,  $\beta$  particles) move in a zigzag path in the matter, whereas the heavier particles (e.g.,  $\alpha$  particles) move in a straight path, because of the heavy mass and charge. The straight line path traversed by the charged particles is called the range R. The range of a charged particle depends on the energy, charge, and mass of the particle as well as the density of the matter it passes through. It increases with increasing charge and energy, while it decreases with increasing mass of the particle and increasing density of the matter. The range of positrons and other properties of common positron-emitters are given in Table 1.2.

A unique situation of the passage of positrons through an absorber is that as a positron loses its energy by interaction with electrons of the absorber atoms and comes to almost rest, it combines with an electron of an absorber atom. At this instant, both particles ( $\beta^+$  and  $e^-$ ) are annihilated as a result of matter–antimatter encounter to produce two photons of 511 keV, which are emitted in opposite directions (~180°) (Fig. 1.6). This process is called the

Radionuclide range	Half-life	$E_{\beta^+,\mathrm{max}}$ (MeV)	Max. $\beta^+$ range (mm) in water	Average $\beta^+$ range (mm) in water
<sup>11</sup> C	20.4 min	0.97	3.8	0.85
<sup>13</sup> N	10 min	1.20	5.0	1.15
<sup>15</sup> O	2 min	1.74	8.0	1.80
<sup>18</sup> F	110 min	0.64	2.2	0.46
<sup>68</sup> Ga	68 min	1.90	9.0	2.15
<sup>82</sup> Rb	75 s	3.35	15.5	4.10

TABLE 1.2. Properties of common positron emitters

Adapted by the permission of the Society of Nuclear Medicine from Brown TF, Yasillo NJ (1997) Radiation safety considerations for PET centers. J Nucl Med Technol 25:98



FIGURE 1.6. A schematic illustration of the annihilation of a positron and an electron in the medium. Two 511-keV photons are produced and emitted in opposite directions ( $180^{\circ}$ ). (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

*annihilation* process. Because the positrons have a residual momentum at the time of annihilation, the two annihilation photons are not emitted exactly at 180°. Detection of the two opposite 511-keV photons in coincidence by two detectors is the basis of PET.

An important parameter related to the interaction of radiations with matter is linear energy transfer (LET). It is the energy deposited by a radiation per unit length of the path in the absorber and is normally given in units of kiloelectron volt per micrometer ( $keV/\mu m$ ). The LET varies with the energy, charge, and mass of the particle. The  $\gamma$  radiations and  $\beta^-$  particles interact with matter depositing relatively less amount of energy per unit length and so have low LET. On the other hand,  $\alpha$  particles, protons, etc. deposit more energy per unit length because of their greater mass and charge and so have higher LET.



FIGURE 1.7. An illustration of photoelectric effect, where a  $\gamma$  ray transfers all its energy  $E_{\gamma}$  to a *K*-shell electron, and the electron is ejected with  $E_{\gamma}-E_{\rm B}$ , where  $E_{\rm B}$  is the binding energy of the electron in the *K*-shell. The characteristic *K* X-ray emission or the Auger process can follow, as described in Fig. 1.2.

#### Interaction of $\gamma$ Radiation with Matter

In the spectrum of electromagnetic radiations,  $\gamma$  radiations are high-frequency radiations and interact with matter by three mechanisms: photoelectric, Compton, and pair production.

**Photoelectric Process:** In this process, a  $\gamma$  radiation, while passing through an absorber, transfers its entire energy primarily to an inner shell electron (e.g., the K-shell) of an absorber atom and ejects the electron (Fig. 1.7). The ejected electron will have the kinetic energy equal to  $E_{\gamma} - E_{\rm B}$ , where  $E_{\gamma}$  is the  $\gamma$ -ray energy and  $E_{\rm B}$  is the binding energy of the electron in the shell. The probability of this process decreases with increasing energy of the  $\gamma$  ray, but increases with increasing atomic number of the absorber. It is roughly given by  $Z^5/E_{\gamma}^3$ . The vacancy in the shell is filled in by the transition of an electron from the upper shell, which is followed by emission of the energy difference between the two shells as characteristic X-rays or by the Auger process described in the internal conversion process.

**Compton Scattering Process:** In a Compton scattering process, a  $\gamma$  radiation with somewhat higher energy interacts with an outer shell electron of the absorber atom transferring only part of its energy to the electron and ejecting it (Fig. 1.8). The ejected electron is called the Compton electron and carries a part of the  $\gamma$ -ray energy minus its binding energy in the shell, i.e.,  $E'_{\gamma} - E_{\rm B}$ , where  $E'_{\gamma}$  is the partial energy of the original  $\gamma$  ray that appears as a scattered photon. Thus, in Compton scattering, a scattered photon and a Compton electron are produced. The scattered photon may again, depending on the energy and location of interaction, encounter a photoelectric process or another Compton scattering process, or leave the absorber without interaction. As the energy of the  $\gamma$  radiation increases, the photoelectric process decreases and the Compton scattering process increases, but the latter



FIGURE 1.8. The Compton scattering process in which a  $\gamma$  ray transfers only a part of its energy to an electron in a shell and is itself scattered with reduced energy. The electron is ejected from the shell with energy,  $E'_{\gamma} - E_{\rm B}$ , where  $E'_{\gamma}$  is the partial energy transferred by the  $\gamma$  ray and  $E_{\rm B}$  is the binding energy of the electron in the shell. The remaining  $\gamma$ -ray energy appears as a scattered photon.

also decreases with photon energy above 1.0 MeV or so. The probability of Compton scattering is independent of the atomic number Z of the absorber.

**Pair Production:** When the  $\gamma$ -ray energy is higher than 1.022 MeV, the photon interacts with the nucleus of an absorber atom during its passage through it and produces a positron and an electron. This is called pair production. The excess energy beyond 1.022 MeV is shared as kinetic energy between the two particles. The probability of pair production increases with increasing photon energy above 1.022 MeV. The positron produced will undergo annihilation in the absorber as described earlier.

Attenuation of  $\gamma$  Radiations: When  $\gamma$  radiations pass through the absorber medium, they undergo one or a combination of the above three processes (photoelectric, Compton, and pair production) depending on their energy, or they are transmitted out of the absorber without any interaction. The combined effect of the three processes is called the *attenuation* of the  $\gamma$  radiations (Fig. 1.9). For a  $\gamma$  radiation passing through an absorber, the linear attenuation coefficient ( $\mu_{\ell}$ ) of the  $\gamma$  radiation is given by

$$\mu_{\ell} = \tau + \sigma + \kappa, \tag{1.17}$$

where  $\tau$  is the photoelectric coefficient,  $\sigma$  is the Compton coefficient, and  $\kappa$  is the pair production coefficient (Fig. 1.10). The linear attenuation coefficient of a radiation in an absorber has the unit of cm<sup>-1</sup> and normally decreases with the energy and increases with the atomic number and density of the absorber. If a photon beam  $I_0$  passes through an absorber of thickness x, then the transmitted beam ( $I_t$ ) is given by

$$I_{\rm t} = I_0 {\rm e}^{-\mu_\ell x}. \tag{1.18}$$



FIGURE 1.9. Illustration of attenuation of a photon beam  $(I_0)$  in an absorber of thickness x. Attenuation comprises photoelectric effect  $(\tau)$ , Compton scattering  $(\sigma)$ , and pair production  $(\kappa)$ . Photons passing through the absorber without interaction constitute the transmitted beam  $(I_t)$ .



FIGURE 1.10. Linear attenuation coefficient of  $\gamma$  rays of different energies in water (equivalent to body tissue). The relative contributions of photoelectric, Compton scattering, and pair production processes are illustrated.

The attenuation of a photon beam in human tissues during imaging is a critical factor to consider in both single photon emission computed tomography (SPECT) or PET, which will be discussed later.

An important quantity in the discussion of photon interaction with matter is the half-value layer (HVL), which is defined as the thickness of the absorber that attenuates an initial photon beam intensity to one-half. The HVL increases with higher energy of the photon and decreases with increasing atomic number of the absorber. Lead is a high atomic number inexpensive metal that has very high absorbing power for  $\gamma$  radiations providing low HVL values and that is why it is commonly used for radiation protection. The HVL

Absorber material	HVL (mm) (narrow beam)	HVL (mm) <sup>a</sup> (broad beam)
Lead	4.1	5.5
Tungsten	-	3.2
Iron	-	16.0
Concrete	33.2	8.7
Tissue	77	-

TABLE 1.3. Half-value layers of 511-keV photons in different absorber materials

<sup>a</sup> Adapted from Townson JEC (2003) Radiation dosimetry and protection in PET. In: Valk PE, Bailey DL, Townsend DW, Maisey MN (eds) Positron emission tomography. Springer, New York

is related to the linear attenuation coefficient as follows:

$$\mu_{\ell} = \frac{0.693}{\text{HVL}}.$$
(1.19)

The HVL for 511-keV photons in some absorbers is given in Table 1.3.

Along the same line, the tenth-value layer (TVL) is defined by the thickness of the absorber that reduces the initial intensity of the photons by a factor of 10. It is given by

$$TVL = \frac{-\ln(0.1)}{\mu_{\ell}} = \frac{2.30}{\mu_{\ell}} = 3.32 \,\text{HVL.}$$
(1.20)

Another quantity called the mass attenuation coefficient  $(\mu_g)$  is given by the linear attenuation coefficient  $(\mu_\ell)$  divided by the density  $(\rho)$  of the absorber and is given in units of cm<sup>2</sup>/g or cm<sup>2</sup>/mg.

Thus,

$$\mu_{\rm g} = \frac{\mu_{\ell}}{\rho}.\tag{1.21}$$

#### Questions

- 1. The total number of nucleons in an atom is designated by (A) N; (B) Z; (C) M; (D) A.
- 2. Isotopes contain the same number of \_\_\_\_\_.
- 3. Isobars contain the same number of \_\_\_\_\_.
- 4. <sup>99m</sup>Tc and <sup>99</sup>Tc are two \_\_\_\_\_.
- 5. Isomeric transition is an alternative to gamma ray emission. True \_\_\_\_\_; False \_\_\_\_\_.

#### 16 1. Radioactive Decay and Interaction of Radiation with Matter

- 6. Gamma ray emission is an alternative to internal conversion. True \_\_\_\_\_; False \_\_\_\_\_.
- 7. Describe the Auger process in radioactive decay.
- 8. Name two nuclear decay processes in which characteristic X-rays are possibly emitted.
- 9. What types of radionuclides are designated as metastable isomers with symbol "m" in the mass number?
- 10. Why is a neutrino needed in the positron decay? In what decay is an antineutrino emitted?
- 11. In a  $\beta^-$  decay, the transition energy is 400 keV. The  $\beta^-$  particle is emitted with 315 keV. What is the energy of the antineutrino?
- 12. Describe the annihilation process.
- 13. Explain why two photons of 511 keV are emitted in positron annihilation.
- 14. If a *K*-shell electron whose binding energy is 25 keV is emitted as a result of internal conversion of a 135-keV photon, what is the energy of the ejected electron?
- 15. What types of radionuclides would decay by  $\beta^-$  and  $\beta^+$  emission and electron capture?
- 16. How long will it take for the decay of three-quarters of a <sup>18</sup>F-FDG ( $t_{1/2} = 110 \text{ min}$ ) sample?
- 17. What are the conditions for transient equilibrium and secular equilibrium in radioactive decay?
- 18. If the activity of <sup>18</sup>F-FDG is 25 mCi at 10 A.M. Wednesday, what is the activity at 2:30 P.M. the same day ( $t_{1/2}$  of <sup>18</sup>F = 110 min)?
- 19. <sup>18</sup>F-FDG dosages are shipped from a vendor 3 h away from the customer. What initial amount should be sent in order to have a 10 mCi dosage for the customer?
- 20. A radioactive sample initially gives 9,500 cpm and 3 h later 2,500 cpm. Calculate the half-life of the radionuclides.
- 21. <sup>18</sup>F-FDG has a biological half-life of 10 h in humans and a physical half-life of 110 min. What is the effective  $t_{1/2}$  of the radiopharmaceutical?
- 22. Define linear energy transfer (LET) and range (R) of charged particles.
- 23. The range of a charged particulate radiation in matter increases:
  - (a) as the mass increases True \_\_\_\_\_; False \_\_\_\_\_
  - (b) as the charge increases True \_\_\_\_\_; False \_\_\_\_\_;
  - (c) as the energy decreases True \_\_\_\_\_; False \_\_\_\_\_;
- 24. Describe photoelectric and Compton scattering processes.
- 25. The photoelectric interaction of a  $\gamma$  ray increases with:
  - (a) energy True \_\_\_\_; False \_\_\_\_;
  - (b) atomic number of the absorber True \_\_\_\_\_; False \_\_\_\_\_;
- 26. A 350-keV  $\gamma$  ray interacts with a *K*-shell electron by the photoelectric interaction. If the binding energy of the *K*-shell electron is 25 keV, what is the kinetic energy of the photoelectron?
- 27. Does Compton scattering depend on the atomic number of the absorber?
- 28. Describe attenuation of a photon beam through an absorber.

- (a) Does it depend on density and atomic number of the absorber?
- (b) Define linear attenuation coefficient and HVL of a  $\gamma$  ray in an absorber.
- 29. If 1 mCi of a radionuclide is adequately shielded by 6 HVLs of lead, how many HVLs would be needed to have equal shielding for (a) 5 mCi and (b) 8 mCi of the radionuclide?
- 30. How many HVLs are approximately equivalent to three-tenth-value layers?
- 31. If 15% of the 511-keV photons of <sup>18</sup>F are transmitted after passing through a lead brick of 7 cm thickness, calculate the HVL of the 511-keV photon in lead.
- 32. Two annihilation photons are emitted exactly at 180°? True \_\_\_\_\_; False \_\_\_\_\_.
- 33. A positron and an electron annihilate because (a) they have the same energy; (b) they have opposite momentum; or (c) it is matter–antimatter encounter?

#### References and Suggested Reading

- Bushberg JT, Seibert JA, Leidholdt EM Sr, Boone JM (2002). The essential physics of medical imaging, 2nd ed. Lippincott, Williams & Wilkins, Philadelphia
- Cherry SR, Sorenson JA, Phelps ME (2003). Physics in nuclear medicine, 3rd ed. W.B. Saunders, Philadelphia
- Friedlander G, Kennedy JW, Miller JM (1981). Nuclear and radiochemistry, 3rd edn. Wiley, New York
- Saha GB (2006). Physics and radiobiology of nuclear medicine, 3rd ed. Springer, New York

## 2 PET Scanning Systems

#### Background

The detection and measurement of radiation is based on the interaction of radiations with matter discussed in Chap. 1. In gases, ionizing radiations, particulate or electromagnetic, interact with gas molecules to produce positive and negative ions, which are then collected as current or count by the application of a voltage. The amount of ionization is proportional to the amount of energy deposited by the radiation. At low voltages, the ionization is measured as current that is proportional to the amount of radiation. Dose calibrators, pocket dosimeters, and ionization chambers operate on this principle at low voltages ( $\sim$ 150 V). At high voltages ( $\sim$ 900 V), ions are multiplied in an avalanche of interactions producing a pulse that is independent of the energy and type of radiation. Each event of interaction is detected as a count, and this principle is applied in Geiger–Müller (GM) counters, which are used as radiation survey meters.

Liquid scintillation detectors operate on the principle of interaction of radiations with a special type of scintillating liquid that emits light upon interaction with radiation. The light is then processed in the same manner as in the case of a solid detector, as discussed below.

Both gas and liquid scintillation detectors have low detection efficiency and, therefore, are not used in PET technology. Interaction of radiations with solid scintillation detectors is the basis of radiation detection in PET technology. These solid detectors have the unique property of emitting scintillation or flashes of light after absorbing  $\gamma$ - or X-ray radiations. The light photons are converted to an electrical pulse or signal by a photomultiplier (PM) tube. The pulse is further amplified by a linear amplifier, sorted by a pulse height analyzer (PHA), and then registered as a count. Different types of radiations are detected by different types of detectors. For example,  $\gamma$ -rays or X-rays are detected by sodium iodide crystal containing a trace amount of thallium, NaI(Tl), whereas organic scintillation detectors such as anthracene and plastic fluor are used for  $\beta^-$  particle detection. PET is based on the detection of two 511-keV photons in coincidence at 180°. These photons are produced by the annihilation process in which a positron emitted by a positron-emitting radionuclide combines with an electron in the medium and is annihilated. Solid scintillation detectors of different materials have been investigated to detect 511-keV photons. The following is a brief description of the properties and uses of solid detectors in PET imaging.

#### Solid Scintillation Detectors in PET

Although many scintillation detectors have been investigated, only a few have been widely used in PET technology. The characteristics of different detectors that have application in PET technology are listed in Table 2.1. The choice of a detector is based on several characteristics, namely:

- 1. Stopping power of the detector for 511-keV photons
- 2. Scintillation decay time
- 3. Light output per keV of photon energy
- 4. Energy resolution of the detector

The stopping power of the detector determines the mean distance the photon travels until complete deposition of its energy and depends on the density and effective atomic number ( $Z_{eff}$ ) of the detector material. The scintillation

TABLE 2.1. Troperties of different solid semiination detectors						
Detectors	Effective	Density	Scintillation	Photon	Linear	Energy
	atomic no	$(g/cm^3)$	decay time	yield (per	attenuation	resolution
	(Z)		(ns)	keV)	coefficient (cm <sup><math>-1</math></sup> )	(% at 511 keV)
					of 511 keV	
NaI(Tl)	51	3.67	250	38	0.34 <sup>a</sup>	7.8
BGO	74	7.13	300	6	0.96	10
BaF2	54	4.89	0.6	2	0.44	11.4
GSO	59	6.71	50	10	0.67	9.5
Anthracene	-	-	26	30	-	-
LSO	66	7.40	40	29	0.87	10.1
YSO	34	4.53	70	46	0.39	12.5
CsI(Tl) <sup>b</sup>	54	4.51	1,000	52	0.483	4.53
LYSO	65	7.2	50	25	0.87	20
YAP	39	5.4	27	18	0.46 <sup>c</sup>	2.5
LaBr <sub>3</sub>	-	5.3	5	61	-	5.3

TABLE 2.1. Properties of different solid scintillation detectors

*BGO* bismuth germinate (Bi<sub>4</sub>Ge<sub>3</sub>O<sub>12</sub>), *BaF*<sub>2</sub> barium fluoride, *LSO* lutetium oxyorthosilicate (Lu<sub>2</sub>SiO<sub>5</sub>:Ce), *YSO* yttrium oxyorthosilicate (Y<sub>2</sub>SiO<sub>5</sub>:Ce), *GSO* gadolinium oxyorthosilicate (Gd<sub>2</sub>SiO<sub>5</sub>:Zr), *LYSO* lutetium yttrium oxyorthosilicate (LuYSiO<sub>5</sub>:Ce), *YAP* yttrium aluminum perovskite (YAlO<sub>3</sub>), *LaBr*<sub>3</sub> : *C* $\epsilon$  lanthanum bromide

<sup>a</sup>The linear attenuation coefficient of 140-keV photons of <sup>99m</sup>Tc in NaI(Tl) is 0.155 cm<sup>-1</sup> <sup>b</sup>Early P, Private communication (2005)

°Of 660 keV

decay time arises when a  $\gamma$  ray interacts with an atom of the detector material, and the atom is excited to a higher energy level, which later decays to the ground state, emitting visible light. Two to sixty light photons are produced per keV of incident energy depending on the type of detector material (Table 2.1). The time of decay is called the scintillation decay time given in nanoseconds (ns) and varies with the material of the detector. The shorter the decay time, the higher the efficiency of the detector at high count rates. A high-light-output detector produces a well-defined pulse resulting in better energy resolution. The intrinsic energy resolution is affected by inhomogeneities in the crystal structure of the detector and random variations in the production of light in it. The energy resolutions at 511 keV in different detectors vary from 5 to 20% (Table 2.1), using routine integration time for pulse formation, which runs around a few microseconds. However, in PET imaging, the integration time is a few hundred nanoseconds in order to exclude random coincidences, and the number of photoelectrons collected for a pulse is small, thus degrading the energy resolution. Consequently, the detectors in PET scanners have relatively poorer energy resolution (15–20%), and these values are given in Table 2.2 for scanners from different manufacturers.

The detection efficiency of a detector is another important property in PET technology. Since it is desirable to have shorter scan times and low tracer activity for administration, the detector must detect as many of the emitted photons as possible. The 511-keV photons interact with detector material by either photoelectric absorption or Compton scattering, as discussed in Chap. 1. Thus, the photons are attenuated (absorbed and scattered) by these two processes in the detector, and the fraction of incident  $\gamma$  rays that are attenuated is determined by the linear attenuation coefficient ( $\mu$ ) given in Chap. 1 and gives the detection efficiency. At 511 keV,  $\mu = 0.92$  cm<sup>-1</sup> for bismuth germanate (BGO), 0.87 cm<sup>-1</sup> for lutetium oxyorthosilicate (LSO), and 0.34 cm<sup>-1</sup> for NaI(Tl) (Melcher, 2000). Consequently, to have similar detection efficiency, NaI(Tl) detectors must be more than twice as thick as BGO and LSO detectors.

For  $\gamma$ -ray detection, NaI(Tl) detectors are most commonly used, as they provide good light output (30–40 light photons per keV of  $\gamma$ -ray energy) and energy resolution. They are most widely used in most gamma cameras for planar or single photon emission computed tomography (SPECT) imaging in nuclear medicine. The NaI(Tl) crystal is hygroscopic and, therefore, hermetically sealed with aluminum foil. It is fragile and needs careful handling. Its major drawback is its poor stopping power, i.e., low density and low linear attenuation coefficient for 511 keV. For this reason, though used in earlier PET systems, it has not received much appreciation for application in PET technology.

BGO detectors are used in most of the PET systems because of its highest stopping power (highest density and linear attenuation coefficient). However, it suffers from its longer scintillation decay time ( $\sim$ 300 ns) and poor light output. The longer decay time increases the dead time of the detector and limits

#### 22 2. PET Scanning Systems

Manufact- urers→ <sup>a</sup>	P	hilips <sup>b</sup>	Siem	nens <sup>c</sup>	GE H	ealthcare <sup>c</sup>	
Models→ Features↓	GEMINI TF Big Bore	GEMINI TF 64 (PET/CT)	Biograph mCT	Biograph TruePoint	Discovery VCT	Discovery PET/CT 600	
Number of detectors	28 Pixelar modules	28 Pixelar modules	192	192	24 Rings	24 Rings	
Number of crystals	28,336	28,336	24,336 32,448 (TrueV)	24,336 32,448 (TrueV)	13,440	12,288	
Detector material	LYSO	LYSO	LSO	LSO	BGO	BGO	
Ring diameter (cm)	90	90	84.2	83	88.6	81	
Patient scan range (cm)	190	190	190	190	160	170	
Crystal size (mm)	$4 \times 4 \times 22$	$4 \times 4 \times 22$	$4 \times 4 \times 20$	$4 \times 4 \times 20$	$\begin{array}{c} 4.7 \times 6.3 \\ \times 30 \end{array}$	$4.7 \times 6.3 \times 30$	
Number of PMTs	420	420	4/block	4/block	280	256	
Energy resol- ution (%)	12%	11.7%	12%	12%	-	-	
Coincidence window (ns)	5	3.8	4.1	4.5	10	10	
Axial FOV (cm)	18	18	16.2/21.6	16.2/21.6	15.7	15.7	
Acquisition mode	3D,4D,TOF	3D,4D,TOF	3D	3D	D,3D,4D	3D,4D	

TABLE 2.2. Features of different PET scanners

<sup>a</sup>Reprinted with permission, Copyright 2009, ECRI institute, http://www.ecri.org, 5200 Butler Pike, Plymouth Meeting, PA 19462, USA. 610-825-6000

<sup>b</sup>Data supplied by Philips Healthcare, USA

<sup>c</sup>Reprinted with permission, Copyright 2009, Imaging Technology News (http://www.itonline. net), Scranton Gillette Communications (http://www.scrantongillete.com) 3030 w. Salt Creek Lane, Suite 201, Arlington Heights, IL 60005-5025, USA. Some of Siemens data were provided by Annemarie Grammens, Siemens Medical Solutions, USA

the count rate that can be detected by the system. The low light output results in poor energy resolution, which is proportional to the square root of the number of scintillation photons and is typically 20% for 511-keV photons.

The three characteristics of cerium-doped LSO, namely high light output, high stopping power (high density and large linear attenuation coefficient), and short scintillation decay time (40 ns) have made it a better detector for PET systems. However, owing to its intrinsic property, its energy resolution is poor despite its high light output. A disadvantage of this detector is that it contains a naturally occurring radioisotope of its own, <sup>176</sup>Lu, with an abundance of 2.6% and a half-life of  $3.8 \times 10^8$  years. This radionuclide decays by emission of  $\beta^-$  rays and X-rays of 88–400 keV. However, the activity level

is too little to be concerned about radiation exposure from  $^{176}$ Lu, and it does not pose any problem in PET imaging because its photon energy is lower than 511 keV.

The overall characteristics of cerium-doped gadolinium oxyorthosilicate (GSO) detectors are quite good for application in PET technology. Even though it has lower light output and stopping power than the LSO detector, its better energy resolution has prompted some commercial manufacturers to use this detector in PET technology. Fabrication of GSO detectors requires great care, because the crystals are fragile. GSO detectors collect data faster than other materials and hence are often called "fast crystal." These detectors can be cut into smaller crystals resulting in improved spatial resolution of the system.

Barium fluoride (BaF<sub>2</sub>) has the shortest decay time of 0.6 ns and is primarily used in time-of-flight scanners that were rarely used clinically, because of various technical difficulties, but are now being brought into the market by some manufacturers.

A recently introduced detector, yttrium-activated lutetium oxyorthosilicate (LYSO), has the physical properties similar to LSO and has been used in PET scanners by a commercial vendor.

Cerium-doped yttrium oxyorthosilicate (YSO) is a new type of detector, but no commercial manufacturer has yet used it in PET technology.

Some promising detectors such as cerium-doped lutetium iodide and cerium-doped lanthanum bromide are in the development stage. Also, to increase the spatial resolution in tomographic imaging, two scintillation crystals with different decay constants are coupled in layers to form a single dual-layered detector. GSO and BGO detectors and NaI(Tl) and LSO detectors have been coupled in this manner for high-resolution scanners. The location of photon interaction is determined from the decay of the pulse, which eliminates the uncertainty in the depth of interaction thus improving the spatial resolution in the images. The dual detector, also called *phoswich*, can be used for either SPECT or PET scanning by switching between the two detectors.

Lithium-activated germanium and silicon, commonly known as semiconductors, have been used for photon detection. Photons interact with these materials ejecting an electron from the atomic orbital and creating a positively charged hole in the atom. The electron-hole pair moves as current under the application of a voltage. These are called photodiodes. PM tubes (see later) are not used and multiplication of electrons does not occur, so the signal is significantly weaker than the PM tube signal. Application of higher voltage increases the electron multiplication in the detector but does not improve the efficiency enough to justify their use in PET scanners. A separate category of semiconductor detectors like cadmium-zinc-tellurium (CZT) or cadmium-tellurium (CdTe) has relatively high atomic numbers (high stopping power) and excellent energy resolution ( $\sim$ 5%) and is used for photon detection. Recently a prototype PET scanner using CdTe detectors and a three-layer depth of interaction detection system have been developed for patient studies yielding high spatial resolution and low scatter noise. There is a great potential for these types of detectors in the future.

#### Photomultiplier Tube

As discussed briefly earlier, a PM tube is needed to convert the light photons produced in the detector as a result of  $\gamma$ -ray interaction to an electrical pulse. The PM tube is a vacuum glass tube containing a photocathode at one end, ten dynodes in the middle, and an anode at the other end, as shown in Fig. 2.1. The photocathode is usually an alloy of cesium and antimony that releases electrons after absorption of light photons. The PM tube is fixed onto the detector by optical grease or optical light pipes.

A high voltage of  $\sim$ 1,000 V is applied between the photocathode and the anode, with about 100-V increments between the dynodes. When light photons from the detector strike the photocathode of the PM tube, electrons are emitted, which are accelerated toward the next closest dynode by the voltage difference between the dynodes. Approximately 1–3 electrons are emitted per 7–10 light photons. Each of these electrons is again accelerated toward the next dynode and then more electrons are emitted. The process of multiplication continues until the last dynode is reached and a pulse of electrons is



FIGURE 2.1. A photomultiplier tube showing the photocathode at one end, several dynodes inside, and an anode at the other end.
produced, which is then attracted toward the anode. The pulse is then delivered to the preamplifier. Next, it is amplified by an amplifier to a detectable pulse, which is then analyzed for its size by the PHA, and finally delivered to a recorder or computer for storage or to a monitor for display. PM tubes are sturdy and expensive but provide fast and strong output pulse.

#### Pulse Height Analyzer

A PHA is a device that sorts out photons of different energies arising either from the individual photons of the same or different radionuclides, or from the scattered photons. Functionally, a PHA is a discriminator with a lower level and an upper level setting or with a baseline and a window above the baseline. In either setting, photons of selected energy only are accepted and others are rejected. This type of pulse sorting is essential in nuclear medicine imaging to count mainly unscattered photons that come out of the organ of interest for image formation. The narrower the window of the PHA, the more accurate is the energy discrimination of photons from the sample, but the detection efficiency is reduced. In the case of PET systems, the window of the PHA is centered around 511 keV, with a width of 350–650 keV.

#### Arrangement of Detectors

In the earlier designs of PET cameras, each detector (normally BGO) was glued to a single PM tube, and a large array of such detectors were arranged in multiple circular rings around the object of imaging. The axial field of view (FOV) is defined by the width of the array of the rings, and the number of detectors per ring varies with the manufacturers. The total number of detectors ranges in the thousands, depending on the manufacturer. The larger the number of detectors and hence the more PM tubes per ring, the better the spatial resolution of the system. Although such systems provide good resolution, the cost of using many PM tubes is high, and packaging of a large number of detectors with PM tubes becomes impractical.

In modern PET scanners, the *block detector* has been designed and used in which small detectors, created by partially cutting a large block of detector material, are utilized and the number of PM tubes is reduced. Round or square PM tubes of 1–5 cm dimension are commonly used in PET scanners. A schematic block detector is shown in Fig. 2.2. Typically, each block detector is about 3-cm thick and grooved into an array of  $6 \times 8$ ,  $7 \times 8$ , or  $8 \times 8$  elements by making partial cuts through the crystal with a saw. The cuts are made at varying depths, with the deepest cut at the edge of the block. The grooves between the elements are filled with an opaque reflective material that prevents optical spillover between elements. Such uneven cutting results in linear sharing of light among PM tubes so that light from photon interaction in the



FIGURE 2.2. A schematic block detector is segmented into  $8 \times 8$  elements, and four PM tubes are coupled to the block for pulse formation (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

corner element with deep cut will be detected by the PM tube located under that element, whereas the light from the middle interaction will be shared by all PM tubes. The width of the detector elements, among other factors, determines the spatial resolution of the imaging device and is normally 3-5 mm in modern PET scanners. The entire block detector is attached to several PM tubes (normally four PM tubes) in the same fashion as in scintillation cameras. BGO block detectors can use up to 16 detector elements per PM tube, whereas LSO block detectors use up to 144 detector elements because of higher intensity of scintillation emission. A typical commercial block detector is shown in Fig. 2.3. A PET scanner can contain many block detectors, the number of which varies with the manufacturer. These detectors are arranged in arrays in full rings or partial rings in different configurations discussed later. The number of rings varies from 18 to 32 depending on the manufacturer. The block detector design has the advantage of reduced dead time compared with those of the scintillation cameras because of the restricted light spread in the former.

A modification of the basic block detector has been made such that each PM tube straddles over four quadrants of four different blocks (Fig. 2.4). The technique of quadrant sharing permits the use of larger PM tubes and reduces the total number of PM tubes used in the PET system. This design improves the spatial resolution relative to the basic design, but has the disadvantage of increasing the dead time.

In PET scanners with block detectors, each detector pair is not connected by coincidence circuitry for practical difficulty, so the detectors are grouped together into banks or sets, which are then connected in coincidence opposite to each other. Essentially each detector in a set is connected by a coincidence circuit with a time window to a set of opposite detectors (both in plane and



FIGURE 2.3. A typical commercial block detector  $(8 \times 8)$  attached to four square PM tubes (*bottom*) and a packaged module (*top*), developed and manufactured by Siemens Medical Solutions USA. (Courtesy of CPS Innovations, Knoxville, TN, USA. currently Siemens Medical Solutions USA, Inc.).



FIGURE 2.4. Block detector illustrating the quadrant sharing of PM tubes. (a) PM tubes assigned in four quadrants separately. (b) Each PM tube shares four quadrants of four block detectors and improves the spatial resolution. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).



FIGURE 2.5. The transverse field of view determined by the acceptance angles of individual detectors in a PET scanner. Each detector is connected in coincidence with as many as half the total number of detectors in a ring and the data for each detector are acquired in a "fan beam" projection. All possible fan beam acquisitions are made for all detectors, which define the FOV as shown in the figure. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

axial). Typically, the time window is set at 6–20 ns depending on the type of detector. If there are N detectors in a ring, typically each detector can be connected in coincidence with N/2 detectors on the opposite side, and, therefore, N/2 "fan-beam" projections are available for each detector (Fig. 2.5). These fan-beam projections form for each detector an *angle of acceptance* in the transaxial plane, and these angles of acceptance for all detectors (up to N/2) are in multicoincidence with each detector, the larger will be the angle of acceptance, and hence the larger transaxial FOV for the PET system.

#### **PET Scanners**

Dedicated PET scanners are typically designed with detectors (block detectors) arranged in an array of full or partial rings with a diameter of 80–90 cm. The full ring geometry is realized in a circular or hexagonal form with either the use of block detectors or large area detectors with buit-in position-locating capability. Several earlier PET scanners used partial rings of opposite block or continuous detectors. The configurations of detectors in some PET systems are illustrated in Fig. 2.6. Since PET systems are axially fixed, whole-body scanners are equipped with a computer-controlled moving bed so that the patient can be positioned at different positions along the axial field for whole-body scanning. The whole-body scan length varies from 170 to 198 cm



FIGURE 2.6. Different configurations of PET scanners. (a) A circular full-ring scanner. (b) Hexagonal array of quadrant-sharing panel detectors. (c) Continuous detectors using curve plates of NaI(Tl). (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

depending on the manufacturer. The features of current PET scanners from three manufacturers are given in Table 2.2.

#### **Coincidence Scintillation Cameras**

Conventional scintillation cameras using NaI(Tl) detectors are available in dual-head and triple-head designs to perform planar and SPECT imaging. To utilize them as PET systems, the heads of these cameras are connected with a coincidence circuitry. The coincidence time window is typically set at  $\sim$ 12 ns for dual-head and  $\sim$ 10 ns for triple-head cameras. Data are acquired by rotating the heads without the collimator around the subject. These units are capable of switching between PET and SPECT modes, of course, using the collimator in the latter mode. These scanners are very attractive to the community hospitals because of the relatively low cost, while providing the scope for PET imaging.

A disadvantage of the coincidence scintillation cameras is that they have low sensitivity due to low detection efficiency of NaI(Tl) crystal for 511-keV photons, which results in a longer acquisition time. To improve the sensitivity, thicker detectors of sizes 1.6–2.5 cm have been used in some cameras, but even then, coincidence photopeak efficiency is only 3–4%. This increase in crystal thickness, however, compromises the spatial resolution of the system in SPECT mode. Fast electronics and pulse shaping are implemented in modern systems to improve the sensitivity. Also, there is a significant camera dead time and pulse pileups due to relatively increased single count rates in the absence of a collimator in PET mode. Low coincidence count rates due to low detection efficiency of NaI(Tl) detectors for 511-keV photons cause higher background noise that results in low contrast in the reconstructed image with these scanners, compared to dedicated PET scanners. The overall spatial resolution of the dual-head coincidence cameras is poorer than that of the PET scanners.

#### **PET/CT Scanners**

In the interpretation of nuclear medicine studies, physicians always prefer to have a comparison between high-resolution CT or MR images and lowresolution PET or SPECT images of a patient for precise localization of lesions. It is very useful to compare the images before and after therapy to assess the effectiveness of treatment. To this end, efforts are made to coregister these two sets of digital images. In coregistration, the matrix size, voxel intensity, and the rotation are adjusted to establish a one-to-one spatial correspondence between the two images. This process is called the alignment or coregistration of images. Several techniques are employed in alignment of images of different modalities, among which the following three are common: In the manual method, the contour of the two sets of images is traced and then the images are aligned; second, in the landmark technique, an external point marker that can be seen on both images is attached to the patient, or an internal marker such as a structure in an organ that is common to both images is chosen; third, in the fully automated method, surfaces or boundaries between organs are chosen by algorithms to define the images for alignment. This technique is useful for rigid body organs such as the brain, whereas it is likely to cause noises and hence errors in registration of the nonrigid, moving organs, such as the heart, abdomen, etc. Another important method of image alignment based on voxel intensities of the two images uses the difference in intensities or the standard deviations of the ratios of image intensities (voxelby-voxel basis) for proper alignment of the two images. After alignment, the source image or each discrete point in the source image is transformed to the coordinate system of the target image (e.g., CT images transformed to PET images). This is done on a voxel-by-voxel basis. In all cases, algorithms have been developed and employed to achieve coregistration of images of different modalities. Most software is vendor-neutral and supports fusion of any combination of functional and anatomical images of different modalities. Some of the common software are Siemens Medical Solutions' Syngo FusionD and TrueD, Philips Healthcare's Syntegra, GE Healthcare's Volemetrix, MIM Vista's MIM, Cedara's PET/CT Workstation, Thinking Systems' MDStation Thin-Client WebServer/Client, and Hermes Medical Solutions' Hermes Workstation.

The coregistered images are displayed side by side with a linked cursor indicating spatial correspondence or may be overlaid or fused using the gray scale or color display. The spatial correspondence by coregistration between the



FIGURE 2.7. A schematic illustration of a PET/CT system. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

images of two modalities obtained at separate imaging sessions suffers from positional variations of the patient scanned on different equipment and at different times. In addition, patient motion, including involuntary movement of the internal organs, adds to the uncertainty in the coregistration. Even with the most sophisticated algorithm, an error of 2–3 mm in alignment is not uncommon.

To circumvent the problems of positional variations in coregistration of images from different equipment, an integrated system of PET and CT units has been developed by several manufacturers. Similar systems of SPECT/CT and PET/MRI are also available commercially. In a PET/CT system (Fig. 2.7), both units are mounted on a common support with the CT unit in the front and the PET unit in the back next to the CT unit. Both units use the same gantry and a common imaging table. The centers of the scan fields of PET and CT scanners are separated by a fixed distance called the displacement distance. The axial travel range of the scanning table varies from 170 to 200 cm depending on the manufacturers. Because of the displacement between the centers of scan fields of the two systems, the actual scan field is limited by the maximum distance given by the travel range of the table minus the displacement distance.

The CT unit used in the PET/CT system comprises an X-ray producing unit that consists of a cathode filament that emits electrons when a high voltage (kV) is applied to it and a rotating tungsten anode. Electrons from the cathode are focused to impinge on the rotating anode whereby an intense beam of brehmsstralung and characteristic K X-rays is produced. In a CT scan, the unit transmits a focused beam of X-rays through a patient's body and the transmitted beam is detected by solid detectors composed of materials such as ceramics, gadolinium oxysulfide, gemstone, etc. These detectors emit visible light upon interaction with X-rays, which are processed by the photodiode to produce signal for detection. In some scanners, xenon gas detectors are used in which gas is ionized by X-rays producing current for measurement. The kilovolt (kV) in CT units varies from 100 to 140 kV, and the maximum X-ray energy ranges from 100 to 140 keV. Depending on the



FIGURE 2.8. (a) A large array of detectors in an arc form are rigidly connected to an X-ray tube. Both rotate around the object at the same speed with the tube transmitting the X-ray beam in a fan-beam projection defined by the arc and the detectors detect the attenuated beam on the opposite side of the object. This configuration is most commonly used. (b) Detectors are arranged in a fixed ring and the X-ray tube rotates inside the circular path of the ring. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

design and the manufacturer, a large number of detectors (thousand) are arranged in an arc form or a full ring around the patient. In the arc form, the X-ray tube and the detector arc are mechanically tied and rotate together in 180° opposition inside the gantry during the study (Fig. 2.8a). In full ring geometry, the detectors are arranged in a fixed 360° ring around the patient, while the X-ray tube only rotates (Fig. 2.8b). In either case, the X-ray tube projects the X-ray beam through the patient's body while rotating fast around the patient, and the detectors opposite to the X-ray tube detect the transmitted photons, which are stored as counts in the computer. The data are then processed to form a CT transmission image (slice). For scanning the entire body length, the scanning table with the patient has to be translated axially after each slice is acquired. The CT scanner can be single slice or multislice collecting data simultaneously for many slices (6, 16, 32, 64, or 128) with the different rotation speeds. In helical or spiral CT units, the patient table translates or moves while the X-ray tube rotates around the patient during the study. This results in a helical or spiral pattern of the motion of the X-ray tube around the patient, hence the name. The entire time for a conventional CT transmission scan is only a minute at most, and it is much shorter for the helical CT.

When the incident X-ray beam passes through the patient's body, it is attenuated by the tissue. The attenuation of the X-ray beam depends on the density of the body tissue of the patient, giving structural information of different organs. Conventional single-energy CT units provide images of individual organs with different intensities due to differences in attenuation of photons in tissues. These images are obscured by the shadow of adjacent organs or tissues. To have a clear image of an organ of interest, two separate images of the subject are obtained at two different X-ray energies, and shadow intensity is removed from the intended image by coregistration using software manipulation. A typical example is detection and display of blood vessels and bones in clear contrast to one another. To avoid the difficulty and the inconvenience of two separate CT studies, currently two X-ray tubes operating at separate energies (e.g., 80 and 140 keV) are installed in the same CT unit (e.g., Siemen's Somatom), which simultaneously revolve around the patient and collect transmission data. Alternatively, a single X-ray unit is installed (GE Healthcare's Lightspeed) that can be switched between energies and takes two energy images in a fraction of a second. Images at two energies are then processed by coregistration software to separate the tissues of different densities, and the tissue image with shadowing intensity can be removed resulting in clear images of the organ of interest. Dual energy CTs reduce the scan time and provide high contrast images and at the same time reduce radiation exposure if contrast agents are used.

An important advantage of a CT transmission scan in the PET/CT system is that the scan data can be used for attenuation correction of PET emission images, obviating the need for a separate lengthy transmission scan in the dedicated PET system. The use of CT scans for attenuation correction reduces the whole-body scan time significantly. CT attenuation correction and fusion of CT and PET images are discussed in detail in Chap. 3.

Prior to the introduction of PET/CT, multimodality images were fused by the algorithm technique that was limited mainly to the brain. In 1999, GE Healthcare introduced the first PET/CT, called the Hawkeye, using a dualhead NaI(Tl) camera and a low-energy CT scanner, followed later in 2001 by the Discovery LS (GE Healthcare). Since then, manufacturers such as Siemens, GE, and Philips have brought a variety of much improved PET/CT units into the market. The physical features of a few PET/CT scanners are listed in Table 2.3 and a typical PET/CT scanner is shown in Fig.2.9.

Because of the increased diagnostic accuracy offered by PET/CT, the worldwide market share of PET/CT is increasing exponentially, whereas that of the stand-alone PET scanners has dwindled to almost zero.

#### Small Animal PET Scanner

Drugs are commonly used in animal research prior to their clinical use in humans. The safety and effectiveness of a drug is initially established by studying its in vivo biodistribution and pharmacokinetics in animals. These animal studies using clinical PET systems are hindered by the relatively poor resolution of images offered by the scanner. For this reason, small animal PET scanners have been developed that permit in vivo studies of PET tracers, providing high resolution of the images. These scanners are small enough to be installed in a small room.

#### 34 2. PET Scanning Systems

$Manufacturers {\rightarrow}^a$	Phi	lips <sup>b</sup>	Siemens <sup>c</sup>		GE Healthcare <sup>c</sup>	
Models→ Features↓	GEMINI TF Big Bore	GEMINI TF 64 (PET/CT)	Biograph mCT	Biograph TruePoint	Discovery VCT	Discovery PET/CT 600
Gantry dimension $(\mathbf{H} \times \mathbf{W} \times \mathbf{D})$	$219 \times 239$	213 × 225	$204 \times 234$	$202 \times 239$	$192 \times 230$	$192 \times 226$
$(\Pi \times W \times D)$ Weight (Irg)	× 34 4 007	X 224	2 077	2 072	2 000	× 205
Vortical travel (cm)	4,007	4,201	52 06	52 101	55 5 102	4,910
Patient part (am)	47.1	55.5 70	33-90 70	70	55.5–105 70	37-105
Maximum nationt	207	105.5	70 227	204	226	226
weight (kg)	221	193.3	221	204	220	220
Patient scan range (cm)	190	190	190	190	160	170
Acquisition mode	3D,4D,TOF	3D,4D,TOF	3D	3D	2D,3D,4D	3D,4D
User interface	Brilliance workspace	Brilliance workspace	Syngo	Syngo	Windows	Windows
DICOM 3.0 PET/CT	Yes	Yes	Yes	Yes	Yes	Yes
CT-detector	Solid-state GOS	Solid-state GOS	Ultrafast ceramic	Ultrafast ceramic	V-Res	CT HiLight Matrix II
Number of elements in CT	19,584	43,008	47,104	26,880	58,368	21,888
Number of slices	16	64	40,64,128	6,16,40,64	64	16
CT scan field (cm)	70	70	70	70	70	70
CT kV range	90-140	90-140	80-140	80-140	80-140	80-140
CT mA range	20-500	20-500	20-800	28-665	10-800	10-400
CTDI (mGy/100 mAs)	10.9	10.17	9.3 (40,64)	15.4 (6,16)	8.5	10.6
B/16 cm phantom			8.5 (128)	4.5 (40,64)		

TABLE 2.3. Features of different PET/CT scanners

<sup>a</sup>Reprinted with permission, Copyright 2009, ECRI institute, http://www.ecri.org, 5200 Butler Pike, Plymouth Meeting, PA 19462, USA. 610-825-6000

<sup>b</sup>Data supplied by Philips Healthcare, USA

<sup>c</sup>Reprinted with permission, Copyright 2009, Imaging Technology News (http://www.itonline. net), Scranton Gillette Communications (http://www.scrantongillete.com) 3030 w. Salt Creek Lane, Suite 201, Arlington Heights, IL 60005-5025, USA. Some of Siemens data were provided by Annemarie Grammens, Siemens Medical Solutions, USA

The first small animal PET scanner (Model 713) introduced by Siemens consists of a single 64-cm diameter ring of 80 BGO block detectors collimated with 7 annular tungsten septa (Cutler et al, 1992). With the introduction of LSO detectors and fiberoptic readouts of individually cut crystals, small animal scanners with higher resolution have been developed. The microPET developed by the University of California, Los Angeles, consists of 30 LSO block detectors arranged in a continuous ring, and each block has an array of  $8 \times 8$  individual crystals of dimension  $2 \times 2 \times 10$  mm (Chatziioannou et al, 1999). There are 8 rings, each with 240 crystals, thus totaling 1,920 crystals in the tomograph. The gantry bore is 16 cm and the ring diameter is 17.2 cm with a transaxial FOV of 11.25 cm and axial FOV of 1.8 cm. Each of the 64 crystals



FIGURE 2.9. Gemini TF Big Bore PET/CT system. (Courtesy of Philips Healthcare, USA).

in each block is connected to one of the 64 individual channels of a multichannel PM tube by optical fibers. Most of the electronics and signal processing are identical to those of clinical PET scanners. The unit had an average intrinsic resolution of 1.58 mm and an average sensitivity of 3.92 cps/kBq.

Because of the importance of animal work in drug development that later translates into clinical use in humans, much improved small animal PET scanners have been developed by manufacturers such as Siemens Medical Solutions, GE Healthcare, and Bioscan, and several scanners are now commercially available. The features of small animal PET scanners of the three manufacturers are given in Table 2.4. A small animal PET scanner is shown in Fig. 2.10. With the advent of molecular imaging, much progress can be achieved in PET imaging from the use of these improved scanners.

#### 36 2. PET Scanning Systems

Manufacturer→	GE	Siemens	Bioscan
Model→	Triumph LabPET (Con-	Inveon	Nano PET/CT
Features↓	figurable to 4, 8, and		
	12 cm nominal axial		
	FOV)		
Scanner geometry	Ring	Ring	Ring
Detector	LYSO/LGSO	LSO	LYSO
Number of crystal rings	16, 32, 48 depending on configuration	80	12
Transaxial FOV (cm)	10	10	9.4
Axial FOV (cm)	3.7, 7.5, 11.2 depending on configuration	12.7	9.5
Ring diameter (cm)	16.2	16.1	15
Spatial resolution (cm)	<1.0	1.3	<1.2
Sensitivity at CFOV (%)	1.7, 2.5, 8.0 depending	6.72 (350–625 keV)	8.3
	on configuration		

TABLE 2.4. Features of commercially available small animal PET scanners from three vendors

*CFOV* Center of Field of ViewData are summarized from Visser EP et al (2009) J Nucl Med 50:139; Bao Q et al (2009) J Nucl Med 50:401; Wang et al (2006) J Nucl Med 47:1891; and http://www.bioscan.com

#### Mobile PET or PET/CT

For the convenience of hospitals and clinics that do not have a PET scanner or a dual-head coincidence camera, mobile PET scanners are available commercially to provide PET service to these facilities. PET scanners, preferably PET/CT scanners, along with the control console are installed in sturdy mobile vans. These mobile PET/CT vans move to different client's sites to provide PET imaging services. Because of the scanner's weight and heavy electrical requirement, a concrete pad with enhanced electrical connections must be built at the client site to support the weight of the mobile system. This ensures the correct leveled positioning of the van at the site. The power supply (typically 430 V, three phase at 60 Hz) is provided at the client's site. Also, a generator is installed in the van to run chillers and air conditioning during transportation to keep PET scanners at operating temperatures. Currently, only <sup>18</sup>F-FDG PET imaging is provided by all mobile PET services.

One must obtain a valid license from the State and/or the Nuclear Regulatory Commission (NRC) to operate a mobile PET or PET/CT system, providing services to different client sites. A requirement for the license is to have a letter of agreement between the licensee and the client signed by the management (chief executive officer or designee) detailing the responsibilities of each. Some states do not allow injection of the radiotracer in the coach, necessitating a separate injection room and a waiting room at the client's site. Many states may require a sink, changing area, specific security considerations, and fire protection in the mobile van. The van must meet overload Department of Transportation (DOT) regulations.



FIGURE 2.10. A small animal PET scanner, Inveon Dedicated PET. (Courtesy of Siemens Medical Solutions USA, Inc.).

All necessary accessories for PET studies, including a dose calibrator, <sup>18</sup>F-FDG storage, a wipe test counter, a survey meter, and so on, are kept in the van. The mobile PET van moves daily to different clients' sites according to the schedule made prior to the day of examination. The patient's PET study is performed and the data are processed in the van, while the interpretation can be made either at the van or at the home site of the mobile PET company. It requires a great deal of logistics in scheduling PET studies at different sites using a mobile PET scanner. The <sup>18</sup>F-FDG must be delivered early in the morning, and enough of it should be available to complete the day's schedule. The mobile PET company may have its own cyclotron and radiochemistry laboratory that supplies <sup>18</sup>F-FDG to the van, or it may be purchased from another cyclotron facility.

The timing of the studies must be well coordinated with each client to avoid any overlap of schedules with other clients. Overall, mobile PET provides easy access to PET examinations for many community hospitals that are unable to afford a PET scanner because of the cost. However, during inclement weather, the transportation of the van may be problematic.

## Questions

- 1. Describe the general principles of positron emission tomography.
- 2. Explain why an LSO detector is better than a BGO detector in PET scanning and NaI(Tl) is least preferred.
- 3. What are block detectors and why are they preferred to single detectors in a PET scanner?
- 4. Typical energy resolutions of BGO and LSO detectors in PET scanners are about (a) 10%; (b) 15%; (c) 24%; (d) 5%.
- 5. The common number of PM tubes per block detector in a PET scanner is (a) 2; (b) 4; (c) 6; (d) 8.
- 6. Positron scanners comprised of BGO or LSO detectors are arranged in full or partial rings, and each detector is connected to a number of opposite detectors in coincidence. If there are N detectors in the scanner, what is the maximum number of fan-beam projections available for coincidence counting?
- 7. The number of BGO or LSO detectors in common PET scanners is of the order of (a) tens of; (b) thousands of; (c) hundreds of; (d) only a few detectors.
- 8. The number of rings in commercial PET scanners varies from (a) 50 to 100; (b) 5 to 10; (c) 18 to 32; (d) 1 to 5.
- 9. Explain how SPECT scintillation cameras can be used in coincidence counting. Discuss the advantages and disadvantages of these cameras in coincidence counting.
- 10. Describe the technique of PET/CT imaging. Why is PET/CT better than only PET in detecting various tumors?
- 11. PET/CT imaging has the advantage over dedicated PET imaging because of:
  - (a) shorter scanning time True\_\_\_\_; False \_\_\_\_.
  - (b) higher sensitivity of PET scanner True\_\_\_\_; False \_\_\_\_.
  - (c) better localization of abnormalities True\_\_\_\_; False \_\_\_\_.

- 12. If the travel range of the scanning table is 180 cm, and the displacement distance between the centers of the scan fields of CT and PET scanners is 60 cm, what is the maximum body length that can be scanned in this PET/CT scanner?
- 13. The spatial resolution of small animal PET scanners is much better than that of the clinical scanners. Why?
- 14. What is the advantage of the dual-layered detectors in PET scanning?
- 15. The transverse FOV of PET is defined by (a) pulse width, (b) the detector material, (c) the angle of acceptance, (d) number of PM tubes.
- 16. What is the basis of dual energy CT scanners?
- 17. The good characteristics of PET detectors include (a) high energy resolution, (b) high light output, (c) high stopping power, and (d) short scintillation decay time.
- 18. Pulse height analyzer is used to (a) increase the count rate, (b) include the scattered radiation, (c) sort the photons of interest, and (d) shorten the scan time.

### References and Suggested Reading

- Blodgett TM, Meltzer CC, Townsend DW (2007). PET/CT: Form and function. Radiology 242:360
- Bushberg JT, Seibert JA, Leidholdt Sr EM, Boone JM (2002). The essential physics of medical imaging, 2nd ed. Lippincott, Williams and Wilkins, Philadelphia
- Chatziioannou AF, Cherry SR, Shao Y et al (1999). Performance evaluation of microPET: a high-resolution lutetium oxyorthosilicate PET scanner for animal imaging. J Nucl Med 40:1164
- Cherry SR, Dahlbom M (2004). PET; Physics, instrumentation, and scanners. In: Phelps ME (ed) PET; Molecular imaging and its biological applications. Springer, New York
- Cutler PD, Cherry SR, Hoffman EJ et al (1992). Design features and performances of a PET system for animal research. J Nucl Med 33:595
- Cherry SR, Sorensen JA, Phelps ME (2003). Physics in nuclear medicine, 3rd ed. W.B. Saunders, Philadelphia
- Larobina M, Brunetti A, Salvatore M (2006). Small animal PET: a review of commercially available imaging systems. Curr Med Imag Rev 2:187
- Melcher CL (2000). Scintillation crystals for PET. J Nucl Med 41:1051
- Patton JA (2002). Physics of PET. In: Delbeke D, Martin WH, Patton JA, Sandler MP (eds) Practical FDG imaging. Springer, New York
- Turkington TG (2001). Introduction to PET instrumentation. J Nucl Med Technol 29(1):89

# 3 Data Acquisition and Corrections

#### PET Data Acquisition

PET is based on the detection in coincidence of the two 511-keV annihilation photons that originate from  $\beta^+$  emitting sources (e.g., the patient). The two photons are detected within an electronic time window (e.g., 12 ns) set for the scanner and must be along the straight line connecting the centers of the two detectors called the line of response (LOR). Since the two photons are detected in coincidence along the straight line in the absence of an absorptive collimator, this technique is called electronic collimation. All coincident events are collectively called prompts, which include true, random, scattered, and multicoincidence events. Examples of these events are illustrated in Fig. 3.1. A true coincident event arises when two 511-keV photons from a single annihilation event are detected by a detector pair along the LOR (Fig. 3.1a). Random coincidences occur when two unrelated 511-keV photons from two separate annihilation events are detected by a detector pair within the same time window (Fig. 3.1b). These events raise the background causing loss of image contrast. Scatter coincidences occur due to Compton scattering of annihilation photons in the patient in the forward direction without much loss of energy (Hoffman and Phelps, 1986). One 511-keV photon and one scattered photon or both scattered photons arising from the same annihilation event may fall within the 511-keV energy window and be detected by a detector pair within the coincidence time window (Fig. 3.1c). Scatter coincidences raises the background of the image and degrades the image contrast. Multicoincidence occurs when more than two unrelated 511-keV photons are detected in coincidence in different detectors within the time window, but these events are discarded because of the difficulty in positioning them.

In a full ring system, the data are collected simultaneously by all detector pairs, whereas in partial ring systems, the detector assembly is rotated around the patient in angular increments to collect the data. In acquiring the coincidence events, three steps are followed:

41



FIGURE 3.1. (a) True coincidence events (b) Random coincidence events detected by two detectors connected in coincidence along the *dotted line*. The two 511-keV photons originated from different positron annihilations. (c) Scattered coincidence events. Two scattered photons with little loss of energy originating from two annihilation events may fall within PHA window and also within coincidence time window to be detected as a coincidence event by two detectors.

- 1. The location of the detector pair in the detector ring is determined for each coincident event.
- 2. The pulse height of the photon detected is checked if it is within the pulse energy window set for 511 keV.
- 3. Finally, the position of the LOR is determined in terms of polar coordinates to store the event in the computer memory.

As stated in Chap. 2, in a PET scanner, block detectors are cut into small detectors and coupled with four PM tubes, which are arranged in arrays of rings. Each detector is connected in coincidence to as many as N/2 detectors, where N is the number of small detectors in the ring. So which two detectors detected a coincidence event within the time window must be determined. Pulses produced in PM tubes are used to determine the locations of the two detectors (Fig. 3.2). As in scintillation cameras, the position of each detector is estimated by a weighted centroid algorithm. This algorithm estimates



FIGURE 3.2. A schematic block detector is segmented into  $8 \times 8$  elements, and four PM tubes are coupled to the block for pulse formation. The pulses from the four PM tubes (A, B, C, and D signals) determine the location of the element in which 511-keV  $\gamma$ -ray interaction occurs, and the sum of the four pulses determines if it falls within the energy window of 511 keV. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography ©2009. All Rights Reserved).

a weighted sum of individual PM tube pulses, which are then normalized with the total pulse obtained from all PM tubes. Similar to scintillation camera logistics, the X and Y positions of the detector element in the ring are obtained as follows:

$$X = \frac{(B+C) - (A+D)}{A+B+C+D},$$
(3.1)

$$Y = \frac{(C+D) - (A+B)}{A+B+C+D}.$$
 (3.2)

Here A, B, C, and D are the pulses from the four PM tubes as shown in Fig. 3.2.

The four pulses (A, B, C, D) from four PM tubes are then summed up to give a Z pulse, which is checked by the pulse height analyzer (PHA) if its pulse height is within the energy window set for the 511-keV photons. If it is outside the window, it is rejected; otherwise, it is accepted and processed further for storage.

The last step in data acquisition is the storage of the data in the computer. Unlike conventional planar imaging where individual events are stored in an (X, Y) matrix, the coincidence events in PET systems are stored in the form of a *sinogram*. Consider an annihilation event occurring at the \* position in Fig. 3.3a. The coincidence event is detected along the LOR indicated by



FIGURE 3.3. PET data acquisition in the form of a sinogram. Each LOR data (**a**) is plotted in  $(r, \phi)$  coordinates. Data for all *r* and  $\phi$  values are plotted to yield sinogram indicated by the *shaded area* (**b**). (Only a part is shown.) (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved)

the arrow between the two detectors. It is not known where along the line of travel of the two photons the event occurred, since photons are accepted within the set time window (say, 12 ns) and their exact times of arrival are not compared. The only information we have is the positions of the two detectors in the ring that registered the event, i.e., the location of the LOR is established by the (X, Y) positioning of the two detectors. Many coincidence events arise from different locations along the LOR and all are detected by the same detector pair and stored in the same pixel.

For data storage in sinograms, each LOR is defined by the distance (r) of the LOR from the center of the scan field (i.e., the center of the gantry) and the angle of orientation  $(\phi)$  of the LOR (i.e., the angle between r and the vertical axis of the field). If we plot the distance r on the x-axis and the angle  $\phi$  on the y-axis, then the coincidence event along the LOR  $(r, \phi)$  will be assigned at the cross-point of r and  $\phi$  values (Fig. 3.3b). In a given projection, adjacent detector pairs constitute parallel LORs (at different r values in Fig. 3.3a) at the same angle of orientation. The plot of these LORs will be seen as a horizontal row at angle  $\phi$ . When all projections around the field of view are obtained, the plot of the LORs at different projection angles and r values will result in the shaded area in Fig. 3.3b, which is called a sinogram. A sinogram is essentially a matrix of fan-beam projections defined by the angle of acceptance. A typical normal sinogram is shown in Fig. 3.4.

PET data are acquired directly into a sinogram in a matrix of appropriate size in the computer memory. The sinogram is basically a two-dimensional (2D) histogram of the LORs in the (distance, angle) coordinates in a given



FIGURE 3.4. A typical normal sinogram indicating all detectors are working properly.

plane. Thus, each LOR (and hence, detector pair) corresponds to a particular pixel (or element) in the sinogram, characterized by the coordinates r and  $\phi$ . For each coincidence event detection, the LOR is determined, the corresponding pixel in the sinogram is located, and a count is added to the pixel. In the final sinogram, the total counts in each pixel represent the number of coincidence events detected during the counting time by the two detectors along the LOR.

It is of note that comparing raw data acquired in PET with those in SPECT, each projection image in SPECT represents data acquired at that projection angle across all slices, whereas in PET, each sinogram represents the data acquired for a slice across all angles. A set of sinograms from a complete, multislice PET study can be deciphered in the computer to generate a series of projection views that are similar to SPECT raw data.

Data are acquired either in frame mode or list mode. Details of these acquisitions are given in books on physics in nuclear medicine, and the readers are referred to them. Briefly, in frame mode, digitized signals are collected and stored in X, Y positions in a matrix of given size and depth for a specified time or total number of counts. In list mode, digitized X- and Y- signals are coded with "time marks" as they are received in sequence and stored as individual events as they occur. After the acquisition is completed, data can be manipulated to form images in a variety of ways to meet a specific need. This process is time consuming despite the wide flexibility it provides. In PET studies, while the frame mode acquisition has been routinely used, with the introduction of faster computers, the list mode acquisition is now being used more commonly for the newer cameras.

The data acquisition can be applied to both static and dynamic imaging of an object using the frame mode of data collection. In static imaging, a frame is obtained consisting of a set of sinograms acquired over the length of the scan, whereas in dynamic imaging, the data are collected in multiple frames of sinograms, each of a predetermined duration. In dynamic imaging, a gated method can be employed as in the cardiac blood pool gated studies, and in these studies, list mode acquisition of data is helpful providing very high temporal resolution. After acquisition, list mode data can be binned into sinograms, and frame durations can be determined. Whereas the static scans are useful to estimate the gross tracer uptake, dynamic scans provide information as to how the tracer distribution varies with time at a given site.

How many counts need to be acquired per projection and what size matrix should be chosen for adequate quality of images vary with the different cameras depending on the scatter, random, and extent of smoothing needed. A three-dimensional (3D) scanner would require more counts per projection than a 2D scanner because of the more scatter events in the 3D scanner. Typically 250,000–500,000 counts are needed for optimal quality of images. For good quality images, the pixel size is recommended to be 2–3 mm. If the FOV is of the order of 300 mm acquired in a128 × 128 matrix, then pixel size would be ~2.3 mm indicating the right choice of the matrix for data acquisition.

Since PET systems are axially fixed, whole-body imaging is accomplished by moving a computer-controlled bed with the patient on it along the axial field and collecting data at adjacent bed positions. In whole-body imaging, the total scan time depends on the patient's body length and the effective axial FOV of the scanner per bed position. Since the sensitivity decreases toward the periphery of the FOV, the effective axial FOV is less than the actual FOV and it is necessary to overlap the bed positions in whole-body imaging. A typical overlap of 3–5 cm is common, and an even higher value is used in 3D acquisition, because of the sharper decrease in sensitivity toward the periphery of the FOV. The time for data acquisition at each bed position in whole-body imaging is 5–10 min.

#### Time of Flight Method

The time of flight (TOF) PET technique is based on the measurement of time difference in the arrival of the two 511-keV annihilation photons at the detectors, as illustrated in Fig. 3.5. Suppose two detectors are equidistant, x, from the center of FOV (CFOV) and a positron is annihilated in the patient at position \* at a distance  $\Delta x$  from the CFOV. One of the 511-keV photons will travel  $x + \Delta x$  and the other will travel  $x - \Delta x$ . Since the photons travel at speed of light (c), the difference in time ( $\Delta t$ ) of arrival of the two photons at the detectors is 2  $\Delta x/c$ . Note that the photons from the CFOV arrive at the



FIGURE 3.5. A schematic diagram illustrating the principle of time of flight (TOF) technique. The time difference  $(t_A-t_B)$  in the arrival of two photons is related to  $\Delta x$ . Using TOF information the annihilation point is determined within a spatial range of  $(c \cdot \Delta t)/2$ . (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved)

detectors simultaneously ( $\Delta x = 0$ ). The uncertainty in the annihilation position is usually much smaller than the diameter *D* of the patient (with good timing resolution). The signal-to-noise ratio (SNR) increases with improved timing resolution and is proportional to  $D/\Delta x$ , i.e.,  $2D/(c \cdot \Delta t)$ . For a 40-cm subject and with a timing resolution of 0.5 ns, the SNR (sensitivity) increases by a factor of 5.3. With fast electronics and scintillators, and also shorter time window, TOF PET scanners can measure the time difference  $\Delta t$  fairly accurately and provide high-resolution images.

Decades ago, the TOF PET scanners were introduced using fast detector like cesium fluoride (CsF) or barium fluoride (BaF<sub>2</sub>) to allow high count rates, but spatial resolution and sensitivity were poorer than those of conventional PET scanners with BGO, because of poor light production. With the advent of improved scintillators like LSO, LYSO, and LaBr<sub>3</sub>, along with more efficient and reliable PM tubes, TOF is reemerging as the accepted technique in commercial PET scanners. Philips Healthcare is marketing Big Bore Gemini TF PET scanners based on the TOF technique. Current TOF scanners offer better spatial resolution and sensitivity because of increased light production in the detector material and the shorter timing resolution. Moreover, this technique improves the image quality in heavy patients, compared to the conventional PET scanners that lead to a loss of counts as well as an increase in scattered counts.

# *Two-Dimensional vs. Three-Dimensional Data Acquisition*

Coincidence events detected by two detectors within the time window are termed "prompt" events. The prompts include true, random, and scatter coincidence events. In many PET systems, in an attempt to eliminate random and scatter photons discussed later, annular septa ( $\sim$ 1 mm thick and radial width



FIGURE 3.6. (a) 2D data acquisition with the septa placed between the rings so that true coincidence counts are obtained avoiding randoms and scatters. Detectors connected in the same ring give direct plane events. However, detectors are connected in adjacent rings and cross plane data are obtained as shown. (b) When septa are removed, the 3D data acquisition takes place, which include random and scatter events along with true events.

of 7–10 cm) made of tungsten or lead are inserted between rings (Fig. 3.6a). In some scanners, septa are retractable or fixed, while in others, they are not incorporated, depending on the manufacturers. These septa function like the parallel-hole collimators in scintillation camera imaging. Only direct coincidence events between the two paired detectors in a ring are recorded. Such counting is called the 2D mode of data acquisition. In this mode, most of the random and scattered photons from outside the ring are prevented by the septa to reach the detectors, leaving the true coincidences to be recorded (Fig. 3.6a). The use of septa reduces the fraction of scattered photons from 30 to 40% without septa to 10–15%.

Detector pairs connected in coincidence in the same ring give the *direct* plane event (Fig. 3.6a). To improve sensitivity in 2D acquisition, detector pairs in two adjacent rings are connected in coincidence circuit. Coincidence events from a detector pair in this arrangement are detected and averaged and positioned on the so-called *cross plane* that falls midway between two adjacent detector rings (Fig. 3.6a). In current PET scanners, small detectors are used for better resolution, but results in low sensitivity in the direct and cross planes. So additional cross planes are included from nearby rings that are connected in coincidence so that the overall sensitivity of the scanner is increased. The acceptable maximum number of rings that are connected in coincidence for cross planes is 5 or 6. Note that for an *n*-ring system, *n* direct planes and n-1 cross planes can be obtained in 2D acquisition. Thus, a total of 2n-1 sinograms are generated, each of which produces a transaxial image

slice. While the cross planes increase the sensitivity, they degrade the spatial resolution.

The overall sensitivity of PET scanners in 2D acquisition is 2–3% at best. To increase the sensitivity of a scanner, the 3D acquisition has been introduced in which the septa are retracted or they are not present in the scanner (Fig. 3.6b). This mode includes all coincidence events from all detector pairs, thus increasing the sensitivity by a factor of almost 4-8 over 2D acquisitions. If there are *n* rings in the PET scanner, all ring combinations are accepted and so  $n^2$  sinograms are obtained. However, scattered and random coincidences are increasingly added to the 3D data, thus degrading the spatial resolution as well as requiring more computer memory. As a trade-off, one can limit the angle of acceptance to cut off the random and scattered radiations at the cost of sensitivity. This can be achieved by connecting in coincidence each detector to a fewer number of opposite detectors than N/2 detectors. The sensitivity in 3D mode is highest at the axial center of the field of view and gradually falls off toward the periphery. Three-dimensional data require more storage as they are approximately 10<sup>3</sup> times more than 2D data and so result in timeconsuming computation. However, current fast computers have significantly overcome this problem.

#### Factors Affecting Acquired PET Data

The projection data acquired in the form of sinograms are affected by a number of factors, namely variations in detector efficiencies between detector pairs, random coincidences, scattered coincidences, photon attenuation, dead time, and radial elongation. Each of these factors contributes to the sinogram to a varying degree depending on the 2D or 3D acquisition and needs to be corrected for prior to image reconstruction. These factors and their correction methods are described below.

#### Normalization

Modern PET scanners can have 10,000–35,000 detectors arranged in blocks and coupled to several hundred PM tubes. Because of the variations in the gain of PM tubes, location of the detector in the block, and the physical variation of the detector, the detection efficiency of a detector pair varies from pair to pair, resulting in nonuniformity of the raw data. This effect in dedicated PET systems is similar to that encountered in conventional scintillation cameras used for SPECT and PET studies. The method of correction for this effect is termed the *normalization*. Normalization of the acquired data is accomplished by exposing uniformly all detector pairs to a 511-keV photon source (e.g., <sup>68</sup>Ge source), without a subject in the field of view. Data are collected for all detector pairs in both 2D and 3D modes, and normalization factors are calculated for each pair by dividing the average of counts of all detector pairs (LORs) by the individual detector pair count. Thus, the normalization factor  $F_i$  for each LOR is calculated as

$$F_i = \frac{A_{\text{mean}}}{A_i},\tag{3.3}$$

where  $A_{\text{mean}}$  is the average coincidence counts for all LORs in the plane and  $A_i$  is the counts in the *i*th LOR. The normalization factor is then applied to each detector pair data in the acquisition sinogram of the patient as follows:

$$C_{\text{norm},i} = C_i \times F_i, \tag{3.4}$$

where  $C_i$  is the measured counts and  $C_{\text{norm},i}$  is the normalized counts in the *i*th LOR in the patient scan. A problem with this method is the long hours (~6 h) of counting required for meaningful statistical accuracy of the counts, and hence overnight counting is carried out. These normalization factors are generated weekly or monthly. Most vendors offer software for routine determination of normalization factors for PET scanners. A problem with this method is that scatter and random coincidences require different normalizations from true coincidences, which is difficult to accomplish separately.

A component-based variance reduction method is employed to partially resolve these problems. Normalization factors are calculated as the product of intrinsic crystal efficiencies and geometric factors that account for the variation in crystal efficiency with the position of the crystal in the block and photon incidence angle. Intrinsic efficiencies of individual detectors are determined from the average sum of the coincidence efficiencies between a given detector and all opposite detectors connected in coincidence. The geometric factors are normally determined by the manufacturers using a very high activity source and they presumably remain constant. This reduces the computation from the number of LORs (millions) to the number of detectors (thousands). Even though normalization by the component-based method is less time consuming, residual artifacts in images reconstructed from normalized acquisitions of uniform phantoms have been reported.

#### Photon Attenuation

The 511-keV annihilation photons originating from different locations in the body are attenuated by the tissue, as they traverse different thicknesses to reach the detector pair in coincidence. If  $\mu$  is the linear attenuation coefficient of 511-keV photons in the tissue, and *a* and *b* are the tissue thicknesses traversed by the two 511-keV photons along the LOR (Fig. 3.7), then the probability *P* of a coincidence detection is given by

$$P = e^{-\mu a} \times e^{-\mu b} = e^{-\mu(a+b)} = e^{-\mu D},$$
(3.5)



FIGURE 3.7. Two 511-keV photons detected by two detectors after traversing two different tissue thicknesses, a and b. D is equal to the sum of a and b. Attenuation is independent of location of annihilation and depends on the total dimension of the body. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography ©2009. All Rights Reserved)



FIGURE 3.8. (a) Profile of raw acquired data showing depression in activity at the center. (b) The same profile with attenuation correction. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography  $^{\odot}2009$ . All Rights Reserved)

where D is the total thickness of the body. Equation (3.5) is applicable to organs or tissues of uniform density. All coincident events along the same LOR will have the attenuation effect given by Eq. (3.5). When photons travel through different organs or tissues with different  $\mu$  values, then Eq. (3.5) becomes

$$P = e^{-\sum_{i=0}^{n} \mu_i \mathbf{D}_i},$$
 (3.6)

where  $\mu_i$  and  $D_i$  are the linear attenuation coefficient and thickness of the *i*th organ or tissue, and *n* is the number of organs or tissues the photon travels through. Photon attenuation causes nonuniformities in the images (Fig. 3.8), because of the loss of relatively more coincidence events from the central tissues than the peripheral tissues of an organ and also because the two photons may transverse different organs along the LOR. Therefore, corrections must be made for this attenuation of photons in the body tissue.

Note that the probability P is the attenuation correction factor, which is independent of the location of positron annihilation and depends on the total thickness of the tissue. If an external radiation passes through the body,

the attenuation of the radiation will be determined by an effective attenuation coefficient  $\mu$  (tissues of different  $\mu_i$ ) and the thickness of the body, as expressed by Eq. (3.5). This introduces the transmission method of attenuation correction, by using an external source of radiation rather than using the patient as the emission source, and the method is described below.

#### Attenuation Correction Methods

**Theoretical Method:** A simple theoretical calculation based on Eq. (3.5), also called the Chang method, can be applied for attenuation correction based on the knowledge of  $\mu$  and the contour of an organ, such as the head, where uniform attenuation can be assumed. However, in organs in the thorax (e.g., heart) and the abdomen areas, attenuation is not uniform due to the prevalence of various tissue structures, and the theoretical method is difficult to apply and, therefore, a separate method such as the transmission method is employed.

**Transmission Method Using Radioactive Sources:** In the transmission method, typically a thin rod source containing a long-lived positron emitter (e.g., <sup>68</sup>Ge,  $t_{1/2} = 270$  days), and extending along the axis of the scanner, is attached to the PET scanner gantry. The <sup>68</sup>Ge source on the gantry is rotated by an electric motor around the scanner, exposing all detector pairs to radiation uniformly. In some systems, point sources of <sup>137</sup>Cs( $t_{1/2} = 30$  years) are used. Two scans are obtained: a blank scan without the patient in the scanner and a transmission scan with the patient positioned in the scanner. Correction factors are calculated for each detector pair (i.e., each LOR) as:

$$\frac{I_0}{I} = \mathrm{e}^{\Sigma \mu_i \mathrm{D}_i},\tag{3.7}$$

where  $I_0$  is the blank scan data and I is the measured transmission scan data. These factors are then applied to all individual LOR counts in the sinogram obtained in the subsequent patient's emission study. However, the blank transmission scan need not be taken for every patient, rather a scan taken at the beginning of the day is good for all patients for the day. Note that the patient's transmission scan must be taken at each bed position during whole-body imaging for attenuation correction.

Using the currently available rod sources, the above method requires the transmission scan to be taken before the emission scan and obviously requires a long time to acquire enough counts for good accuracy of the measured attenuation correction factors. An alternative to this approach is to collect the transmission scan postinjection immediately after the emission scan without moving the patient from the bed. This method obviates the need for patient motion

and misalignment. Although the residual activity is present from the radiopharmaceutical injection, its value along an LOR is small and the high flux of the transmission source in a small volume along the LOR is enough to mask its effect. However, the detectors must be sufficiently efficient to detect both transmission and emission activities. A further reduction of transmission scan time has been possible by introducing a technique called the segmentation procedure based on the knowledge of prior  $\mu$ -values of certain tissue types. The measured  $\mu$ -values from the transmission scans are modified to match the closest allowed known  $\mu$ -values. This method reduces the transmission scan time to several minutes.

*CT Transmission Method*: In PET/CT scanning, in addition to its use in fusion of PET and CT images, the CT transmission scan can be conveniently used to make attenuation correction of PET emission data. The CT scan takes a minute at the most, while the <sup>68</sup>Ge transmission scan takes as much as 20–40 min depending on the activity level of the <sup>68</sup>Ge source. Thus, it obviates the need for a separate lengthy <sup>68</sup>Ge transmission scan. Typically, a blank CT scan is obtained without the patient in the scanner, which is stored for subsequent use in the calculation of attenuation correction factors for patients' emission scans for the day. Next, the CT transmission scan of each patient is obtained and the map of the attenuation correction factors is generated from this scan and the blank scan using Eq. (3.7), which are then applied to correct each patient's scan.

The attenuation correction factor depends on the energy of the photons, and therefore, correction factors derived from  $\sim$ 70 ke V CT X-ray scans must be scaled to the 511-keV photons of the PET by applying a scaling factor defined by the ratio of the mass attenuation coefficient of the 511-keV photons to that of the 70-keV X-ray in a given tissue. Here a mean energy 70 keV of the X-ray beam is assumed as the energy of a monochromatic beam that would give the same  $\mu$  as the polychromatic beam averaged over all energies. This attenuation factor is assumed to be the same for all tissues that are considered to have the same mass attenuation coefficient except bone, which has a slightly higher mass attenuation coefficient. The attenuation correction factors are calculated for each pixel and applied to PET emission data. The CT transmission method provides essentially noiseless attenuation correction factors. Figure 3.9 illustrates the effect of attenuation correction using the CT transmission scan on transverse whole-body images at the liver level. Various factors affect the CT attenuation factors that are discussed later in the chapter.

#### Random Coincidences

As already mentioned, prompt coincidence counts include random or accidental coincidences that raise the background on the images. Random events



FIGURE 3.9. IIIustration of attenuation correction by using CT transmission data on transverse whole-body images at the liver level. (a) Attenuation corrected images; (b) Uncorrected images. Notice that the attenuation correction improves the images significantly showing better contrast and details.

occur when two unrelated 511-keV photons from two separate positron annihilation locations are detected by a detector pair within the width of the time window (Fig. 3.1b). They increase with increasing width of the energy window as well as the coincidence timing window and with increasing activity [varies as the square of activity, see Eq. (3.8) below]. Random events add to the background causing artifacts and loss of image contrast and are more problematic in low-efficiency detectors such as thin NaI(Tl) crystals and in 3D counting.

The rate of random coincident events is given by

$$R = 2\tau \cdot C_1 \cdot C_2, \tag{3.8}$$

where  $\tau$  is the time width of the pulses in nanoseconds for the system and  $C_1$  and  $C_2$  are the single count rates in counts/s on each of the two detectors on the LOR. The quantity  $2\tau$  is the coincidence timing window discussed in Chap. 2. Thus, one calculates *R* by measuring the single count rate on each detector for a given time window and then corrections are made by subtracting it from the prompts between a detector pair. Random events measured by this method are affected by systematic errors associated with electronics in PET scanners. Note that random coincidence events vary with the square of the administered activity, whereas the true coincidence events increase linearly with the administered activity.

Efforts have been made to minimize random events by using the faster electronics and shorter time window, e.g., BGO system (12 ns), GSO and NaI(Tl) systems (8 ns), and LSO system (6 ns). Still, further corrections are needed to improve the image contrast. Note that crystals with shorter scintillation decay time also reduce the random coincidences, e.g., random events are less in LSO (70 ns) than in BGO (300 ns).

A common method of correction for random events is to employ two coincidence circuits – one with the standard time window (e.g., 6 ns for LSO) and another with a delayed time window (say, 50–56 ns) of the same energy window. The counts in the standard time window include both the randoms plus trues, whereas the delayed time window contains only the randoms. For a given source, the random events in both time windows are the same within statistical variations. Delayed window counts are subtracted from the standard window counts to obtain the true coincidence counts, which are essentially free of any systematic errors associated with the PET scanner because they cancel by subtraction.

#### Scatter Coincidences

Annihilation radiations may undergo Compton scattering while passing through the body tissue, and because of the high energy (511 keV), most of these scattered radiations move in the forward direction without much loss of energy (Hoffman and Phelps, 1986). Such scattering may also occur in the crystal itself. Many of these scattered radiations may fall within the

energy window of PHA setting for 511-keV photons and may be detected by a detector pair within the coincidence time window (Fig. 3.1c). These scattered radiations increase the background to the image, thus degrading the image contrast. The scatter contribution increases with the density and depth of the body tissue, the density of the detector material, the activity in the patient, and the window width of PHA for the PET system. Since both scattered and true coincidence rates vary linearly with the administered activity, the scatter-to-true ratio does not change with the activity. Also, this ratio does not change with the width of the time window, because scatter events arise from the same annihilation event and the two similar photons arrive at the two detectors almost at the same time.

The pulse height window cuts off a large fraction of the scattered radiations, which is limited by the width of the window. In 2D acquisition, the use of septa in multiring PET systems removes additional scattered events, whereas in 3D acquisition, they become problematic because of the absence of septa. Typically, the scatter fraction ranges from 15% in 2D mode to more than 40% in 3D mode for modern PET scanners.

#### Correction for Scatter Coincidences

Correction for scattered events is essential, particularly for 3D acquisition of PET data, because of the loss of contrast and resolution in the image. A review by Zaidi and Koral (2004) provides an extensive account of scatter events in patient imaging and methods to correct them. Several methods have been applied for scatter correction, which are briefly described below.

Dual Energy Method: In this method, coincidence counts are acquired in 3-D mode in two separate energy windows - the photopeak window and a low energy window placed just below the photopeak window. An example of the energy selection is illustrated in Fig. 3.10 with 200–380 keV for the low energy window and 380–680 keV for the photopeak window. In the upper energy window, both scattered and unscattered photons are counted, whereas in the low energy window, mostly scattered photons and only a few unscattered photons are counted. Because there is a difference in counting efficiencies in the two energy windows, a scaling factor is applied to correct the counts. Two scaling factors are derived from measurements using a line source (1) in the air at the center of the scanner and (2) in a water-filled brain phantom positioned at the center of the scanner. The ratio of counts in air in the two windows is due to unscattered events, while the ratio in the water-filled phantom is due to scattered events (Fig. 3.10). These two ratios (i.e., scaling factors) are applied to scale the measured data in both windows, and subtraction of the two scaled energy window data results in a distribution of scatter in the upper energy window. The latter is smoothed and then subtracted from the measured upper energy window data to yield scatter-corrected sinogram



FIGURE 3.10. Setting of lower and upper energy windows in the energy spectra of a scanner for a line source in air (*open circle*) and in a water-filled cylinder (*filled circle*). The energy spectrum from water-filled phantom shows scattering of photons. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography ©2009. All Rights Reserved)

for reconstruction of PET mages. The scaling factors derived from measurements in air- and water-filled phantom remain constant for all patients, but in reality they vary with the source geometry (e.g., patients of different sizes) – a definite problem in whole-body imaging.

An extension of the dual energy method is the use of triple windows in which three windows are chosen with two overlapping windows of different width having the same upper energy level located below the lower level of the photopeak, which is centered on 511 keV. Data are obtained for the object and a calibration phantom. A calibration factor is calculated from the ratio of counts in the two lower scatter windows for both the calibration phantom and the object. The scatter contribution to the photopeak is then estimated from the calibration factor and the narrower energy window data. This method works well for a wide range of activity distribution and object sizes.

*Fitting to Scatter Outside the Object:* In this method, the scatter is estimated by fitting an analytic function (Gaussian or parabolic) to the activity outside the source and interpolating the function to the source. The interpolated scatter contributions are then subtracted from the measured source counts to obtain scatter-corrected data for reconstruction of PET images. This method is based on the assumption that (1) the events outside the source are only scatter events, (2) the scatter distribution is a low-frequency function across the FOV, and (3) they are independent of activity distribution in the source.

**Convolution Method:** A point source is used to measure the scatter function, which is then used to convolve with the source distribution to give an estimation of scatter data. An iterative method is used so that after each iteration, the scatter estimate is improved. The best estimates of scatter events are scaled and then subtracted from the measured image data. The measured scatter function takes into account its dependence on the location and size of the source, detection angle, etc. and thus improves the scatter estimation. This method is computationally efficient because of the availability of fast algorithms.

**Calculation/Simulation Method:** In this simulation technique, Monte Carlo calculation is employed to separate the scattered and unscattered events from the measured events. Initially filtered back projection is applied to the measured emission data to obtain the true reconstructed image of the source. This input image is considered as the 3D source activity distribution for photon tracking in the Monte Carlo simulation, in which the volume planes of the image are stacked and positioned appropriately in the simulated scanner geometry, assuming a common axis. The algorithm then tracks the interaction of each photon in the scattering medium (e.g., patient) and its detection in the block detectors in a simulated 3D PET acquisition. The distribution of total events and scattered events is calculated and the corresponding sinograms are generated. The scatter data are smoothed and then subtracted from the measured data to give the unscattered data. The unscattered data may contain some random events which need to be corrected separately. This method is the most accurate of all methods, but obviously it does not take into consideration the scatter from outside the source.

#### Dead Time

When a 511-keV photon interacts within the detector and is absorbed in the crystal, light photons are produced, which strike the photocathode of the PM tube. A pulse is generated at the end of the PM tube and amplified by an amplifier; the energy and the spatial position of the photon are determined and finally a count is recorded. When two such events are detected by two detectors in the time window, a coincidence event is recorded.

The total time required to complete the above steps is defined as the *dead* time  $(\tau)$  and is related to the signal integration time that depends on the electronics and the scintillation decay time. During this time the detection system is unable to process a second event, which will be lost. This loss (called the dead-time loss) is a serious problem at high count rates and varies with different PET systems. It is obvious that the dead-time loss can be reduced by using detectors with shorter scintillation decay time and faster electronics in the PET scanners.

In scintillation counting, two 511-keV photons may arrive at and be absorbed completely in the detector simultaneously and, therefore, a photopeak of 1.022 MeV will be produced, which will fall outside the energy window of 511-keV photopeak. If, however, two Compton scattered photons are summed up simultaneously in the detector and the resultant peak falls within the window, then the event will be counted but be mispositioned because of the two unrelated events. These events are called the *pulse pileups*, which can cause image distortion at high count rates.

Dead time correction is made by empirical measurement of observed count rates as a function of increasing concentrations of activity. From these data, the dead time loss is calculated and a correction is applied to the measured data to compensate for the dead-time loss. Other techniques, such as use of buffers, in which overlapping events are held off during the dead time, use of pulse pile-up rejection circuits, and use of high-speed electronics, have been applied to improve the dead time correction.

#### Radial Elongation

Radiation elongation, also called the parallax error or radial astigmatism, arises from the coincidence events that occur at off-center locations in the FOV. The off-centered 511-keV photons from the patient can strike tangentially at the backside of the detector pair and form a coincidence event (Fig. 3.11). As seen in the figure, the positioning of the detectors by X, Y analysis is defined by the dashed line some distance d away from the actual LOR (solid line), resulting in the blurring of the image due to unknown depth



FIGURE 3.11. An illustration of radial elongation. An off-center event (*solid line*) strikes the back of the detector pair tangentially. The *X*, *Y* positioning of the detectors (*dash line*) is a distance *d* away from the actual location of the positron annihilation, causing the blurring of the image. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup> 2009. All Rights Reserved)

of interaction in the detector material. At the center of the FOV, this effect is absent as the photons enter the detectors perpendicular to the face. This effect worsens with the LORs farther away from the center of the FOV and with thicker and wider detector. Also from Fig. 3.11, it can be seen that this effect can be improved by having a larger diameter of the detector ring. This parallax error can be corrected by measuring the light on the front and back of the detector and using the difference to estimate the depth of photon interaction in the detector.

#### PET/CT Data Acquisition

Because of the increased sensitivity, specificity, and accuracy in detecting various tumors, fusion imaging using the PET/CT modality has become the state-of-the-art technique in the imaging field. Because the patient remains in the same position on the bed, the alignment and fusion of the CT (anatomical) and PET (functional) images greatly improve the detection of lesions. For these reasons, PET/CT scanning is widely used in diagnostic oncologic applications. As discussed later, CT scans are also used for attenuation correction of PET emission data.

Data acquisition in PET/CT is performed in two steps: first, CT scan and next, PET scan. In a typical PET/CT protocol, a patient is injected with the PET tracer (normally, <sup>18</sup>F-FDG) and allowed to wait for 45-60 min. Waiting for a period shorter than this gives poor target-to-background ratios. After the waiting period, an initial scout scan (topogram) like a conventional X-ray is obtained of the patient during the continuous table motion toward the gantry to define the axial extent of the torso to be imaged. Next, the patient is moved to the CT field of view and a transmission scan is obtained, which takes only a short period of less than a minute. During the CT scan, the patient is asked to hold his breath or, if unable, to breathe in a shallow manner to minimize motion artifact. After the CT scan is completed, the bed with the patient on it is advanced inside the PET scanner and positioned so that the PET scan field matches the CT scan field. During the PET data acquisition, the CT scan data can be concurrently used to calculate the attenuation corrections (see later) and to reconstruct the CT images. After the completion of PET data acquisition, data are corrected for attenuation, and PET images are reconstructed as described in Chap. 4. The CT and PET images are then fused using appropriate algorithms for precise localization of abnormalities. The typical time for the entire protocol for PET scanners using BGO detectors is about 30 min. This is because CT-based attenuation factors can be generated in 30-40 s compared to 30 min for <sup>68</sup>Ge transmission scan. This can be further reduced by using faster crystals such as LSO and LYSO and also TOF technique. A typical study involving the fusion of transverse PET and CT images demonstrating non-small cell lung carcinoma is illustrated in Fig. 3.12.



FIGURE 3.12. A study showing the fusion of PET and CT images. Transverse (a) CT, (b) PET, and (c) PET/CT fused images showing non-small cell lung carcinoma in the right upper lobe. On PET/CT image, the tumor is accurately demonstrated, which is well differentiated from pulmonary atelectasis. (Reprinted with permission from: Antoch G et al (2003) Non-small cell lung cancer: dual modality PET/CT in preoperative staging. Radiology 229:526)
The PET/CT scanning is very useful in equivocal clinical situations, particularly in whole-body imaging for tumor detection. A very small tumor is well detected by PET but can be missed by CT. On the other hand, a large tumor with minimal functional deviations may be seen on a CT image, but may not be detected by PET. In both situations, PET/CT would localize the tumor accurately. Overall, accuracy of diagnosis is increased by 20–25% when PET/CT is used instead of either alone. It should be noted that at present, while PET/CT whole-body scanning has been highly successful in detecting various oncologic conditions, the application of PET/CT in cardiac imaging has faced challenges because of the motion of the heart. Sophisticated algorithms, however, have been designed to overcome this difficulty to an extent.

### Factors Affecting PET/CT Data

Although PET/CT modality is widely employed for diagnostic purpose, CT data acquired either for fusion of PET and CT images or for photon attenuation correction are affected by several factors that cause artifacts in PET/CT images. The factors include patient positioning, metal objects, CT contrast agents, truncation artifacts, and respiratory movement, which are discussed below.

**Positioning of Patient:** In patient positioning, questions arise if the patient should raise up or down the arms on the sides. For scanning the thoracic, abdominal, and pelvic areas, the arms are raised to eliminate hardening of the beam and scatter artifacts and also to avoid unnecessary exposure to radiation. But for head and neck scanning, the arms are kept down on the sides to avoid the shadow of the arms in the image of the area. Likewise, the knee should be supported by proper resting aids such as vacuum bags or foam pellets to avoid any artifact.

**Metal Objects:** Metal objects, such as dental fillings, jewelries, prosthesis, etc., cause higher attenuation of photons than tissues showing artifacts in the photopenic areas. This effect is prominent with low energy X-rays than with high energy 511-keV photons, because of the greater photoelectric absorption of the former in the high Z metals. Mismatch occurs between the CT scans containing such artifacts and the PET scan, and proper fusion cannot be made. If CT data are also used for attenuation correction, the attenuation factors calculated from these scans are overestimated leading to corresponding overestimation of activity in the region and thereby creating a false-positive finding on PET images (Fig. 3.13). Often, it is advisable to omit attenuation correction. Over the years, reconstruction algorithms have been developed and metal artifacts have been almost eliminated.



FIGURE 3.13. Illustration of overestimation of attenuation due to a pacemaker showing focal uptake in the chest area. (Reprinted with permission from Parker et al at Web site, http://www.jpnm.org)

*Contrast Agents*: In recent years, in addition to its use in fusion and attenuation correction, the CT unit in PET/CT systems has been used for diagnostic purposes, and for these CT scans, contrast agents are often recommended for better diagnostic accuracy. When intravenous or oral iodinated contrast materials are administered for diagnostic CT studies, they accumulate in body tissues or organs, which absorb photons more than in normal tissues or organs causing a greater attenuation in tissues than without the contrast agent and so artifacts are generated. However, such effects are minimal in PET images due to high energy of photons. If these CT scans with contrast agents are used for attenuation correction in PET/CT studies, attenuation correction factors will be overestimated causing an overestimation of activity in the region, thus producing false-positive PET scans (Fig. 3.14). These artifacts, however, depend on the quantity of contrast agent administered, its biodistribution and blood



FIGURE 3.14. Illustration of the effect of contrast agents on PET/CT scans. Attenuation correction factors are overestimated in tissues where contrast agent localizes and thus results in false-positive scan. (Reprinted with permission from Parker et al at Web site, http://www.jpnm.org)

clearance, and time between administration and CT scan. Practically, artifacts due to intravenous contrast agents are found to be insignificant perhaps due to its rapid dispersion in the blood. On the other hand, after administration the in vivo concentration of oral contrast agents increases due to water reabsorption causing artifacts. Modified energy scaling methods have been employed in some studies to separate the contrast-enhanced voxels from bone pixels, thus nearly eliminating such artifacts. Some investigators have advocated, and many have followed, to avoid altogether the use of contrast agents in low-dose CT for attenuation correction. Also the use of water-based negative contrast agents has been suggested, which would eliminate such artifacts entirely. It should be pointed out that CT has to be operated at high kV and mAs, where the radiation dose to the patient remains high compared to that in the low-dose CT scan for attenuation correction and localization.

**Truncation:** Another factor, called truncation factor, arises from the difference in transverse FOV of the CT and PET scanners. CT scans of the abdomen and thorax are acquired with arms raised above the head and neck outside the CT FOV. However, in PET scanning, such holding up of arms for 30–40 min is uncomfortable to patients and so scanning is performed with arms on the side. While the patient port in PET/CT scanners varies from 70 to 85 cm depending on the manufacturer, the transverse FOV of the CT scanner is ~50 cm and that of the PET scanner is ~60 cm. Because of the difference in FOV, in the PET/CT scanning with arms down, some angular CT projections may be truncated. For very large patients, other parts of the body also

maybe truncated. As a result, the attenuation correction factors are zero in the region between the edges of CT FOV and PET FOV meaning an underestimation of the real values. Also there is a streaking artifact (high activity seen as a ring) at the edge of CT image, which results in overestimation of attenuation factor in this region leading to potential misinterpretation of the PET scan.

A simple method of recovering the truncated data is to linearly extrapolate the truncated CT projections to the extent of PET FOV and then setting the values to zero at the edge of the PET FOV. The attenuation correction by this method is adequate to remove the truncation artifacts in PET/CT images (Fig. 3.15). Using the iterative method rather than the filtered back projection technique also has shown to help to eliminate these artifacts.



FIGURE 3.15. Effect of truncation on attenuation correction due to difference in patient port diameter between CT ( $\sim$ 50 cm) and PET (70–85 cm) scanners. CT attenuation factors are extrapolated to the extent of the PET FOV to correct for the truncated area. (Reprinted with permission from Parker et al at Web site, http://www.jpnm.org)

**Respiratory Movement:** In PET/CT studies, respiratory movement causes mismatch in fusion of CT and PET images in the abdomen or chest areas due to displacement of their positions on the two images. CT scans are normally acquired in short time (less than a minute) with breath-hold at full inspiration during which the diaphragm is displaced downward because of the expansion of the lungs and the diaphragm appears to be filled with air. On the other hand, PET scans are acquired over a long time (20-40 min) while the patient is freely breathing. This results in a PET image that represents an average of many breathing cycles and the diaphragm appears in the normal position. The CT attenuation in the diaphragm area is underestimated because air is considered in its place during CT scan, and so attenuation-corrected PET images will show cold spots in this region. The discrepancy in anatomical positions between CT and PET scans caused by respiratory motion results in artifacts in the fused PET/CT image (Fig. 3.16). Several protocols have been advocated to minimize this error, namely, (a) continuous shallow breathing for both CT and PET scans, (b) breath-hold CT with partial inspiration, (c) motion-averaged CT over many respiratory cycles, (d) respiratory-gated CT and PET, and so on. Of all these, shallow breathing for both CT and PET techniques is now widely used to minimize the artifacts. With the inclusion of multidetector CT in PET/CT scanners, respiratory motion artifacts have been greatly reduced, but the exact match of the CT and PET image still remains elusive.

In recent years, 4D imaging involving gating of the respiratory cycle, similar to the cardiac-gated technique, has been introduced and a vast improvement



CT coronal

PET coronal

Fused coronal

PET NAC coronal

FIGURE 3.16. Effect of respiratory movement on fused PET/CT image showing a cold spot due to low attenuation in the area of the displaced diaphragm during breath-hold CT scan. (Reprinted with permission from Parker et al at Web site, http://www.jpnm.org)

in the fusion of PET and CT images has been achieved. In this technique, CT data covering the whole lung axially are obtained in a "step-and-shoot" manner in a cine mode usually for each breathing cycle at each bed position. Similarly gated PET data are acquired in ten 0.5-s bins for about 10 min. A real-time position management equipment monitors the respiratory cycle and triggers the acquisition at the expiration phase. The time of the trigger and the acquired data are stored in the computer.

### Questions

- 1. Describe how a sinogram is generated in PET data acquisition.
- 2. Each pixel in a sinogram is represented by:
  - (a)  $r, \phi$  coordinates of the coincidence event
  - (b) X and Y coordinates of the coincidence event
  - (c) (X, Y, Z) coordinates of the coincidence event
- 3. The location of the LOR is defined by:
  - (a)  $r, \phi$  coordinates of the coincidence event
  - (b) X, Y positions of the detector pair
  - (c) X, Y, Z positions of the coincidence event
- 4. A sinogram is a (a) file containing individual annihilation events, (b) a matrix of parallel projection data, (c) a matrix of fan beam projection data, and (d) reconstructed image.
- 5. In whole-body PET imaging, scanning is performed at 5–7 bed positions to scan the intended axial length of the body. At each bed position, there is an overlap of 3–5 cm between scans of two bed positions. Why?
- 6. In whole-body PET imaging, the overlap of bed positions is larger in 3D acquisition than in 2D acquisition. True \_\_\_\_\_; False \_\_\_\_\_.
- 7. The 2D PET data acquisition is accomplished in a PET scanner by the use of (a) parallel-hole collimator, (b) lead shield, (c) tungsten septa, or (d) concrete.
- 8. Explain the direct plane events and cross plane events in 2D data acquisition. What is the total number of sinograms that can be generated in a scanner with *n* rings?
- 9. The sensitivity in 3D acquisition is 4–8 times more than that in 2D acquisition. What are the disadvantages with these high counts, and how can you overcome them?
- 10. Explain five important factors that affect fusion imaging by PET/CT. What methods are adopted to mitigate these effects?
- 11. Attenuation of 511-keV photons in body tissues primarily affects (a) uniformity of the image, (b) spatial resolution of the scanner, and (c) sensitivity of the scanner.
- 12. Attenuation of the two 511-keV photons arising from positron annihilation in an organ is independent of the location of the event but depends

on the total thickness of tissue the two photons traverse. True \_\_\_\_\_; False \_\_\_\_\_.

- 13. Describe a method of attenuation correction for PET acquisition data.
- 14. If one of the two 511-keV photons arising from annihilation in an organ traverses through a thickness of 2.2 cm of the organ and the other photon traverses 1.8 cm of the organ, what is the attenuation correction factor? (Linear attenuation coefficient of 511-keV photons in tissue is 0.5 cm<sup>-1</sup>.)
- 15. In PET/CT, attenuation correction factors are calculated based on the CT transmission scan that uses ~70 keV X-rays. What is done to correct for attenuation of 511-keV PET photons?
- 16. Attenuation correction in PET is independent of the depth of tissue the photon traverses. True\_\_\_\_; False \_\_\_\_\_.
- 17. FDG images without attenuation correction will show(a) increased activity at the center, (b) reduced uptake at the center,(c) uniform activity all over the image.
- 18. In the time-of-flight technique, calculate the increase in signal-to-noise ratio (sensitivity) for a subject of 50 cm diameter and a timing resolution of 0.6 ns.
- Contrast agents used in the CT part of PET/CT imaging cause overestimation of attenuation correction in PET images. True \_\_\_\_\_; False \_\_\_\_\_ Explain why.
- 20. Describe the method of normalization of the acquired PET data to correct for nonuniformity due to variations in the gain of PM tube, location of the detector in the block, and physical variation of the detectors.
- 21. Random events can be reduced A: by (a) narrowing or (b) increasing the coincidence time window; B: by (a) increasing or (b) decreasing the activity administered, C: by (a) widening or (b) narrowing the energy window, and D: by crystals with (a) shorter or (b) longer scintillation decay time.
- 22. Random events can be reduced by
  - (a) increasing the scan time. True\_\_\_\_; False \_\_\_\_\_
  - (b) using a denser crystal. True\_\_\_\_; False\_\_\_\_\_
- 23. Describe the methods of correction for random coincidences and scatter coincidences in the acquired data for PET images.
- 24. What are the contributing factors for the scatter coincidences in PET images?
- 25. Indicate how the true, random, and scatter coincidences vary with activity;
  - (a) linearly or (b) as square of the activity.
- 26. Explain the error caused by radial elongation and how it can be corrected.

### References and Suggested Reading

Bailey DL (2003). Data acquisition and performance characterization in PET. In: Valk PE, Bailey DL, Townsend DW, Maisey MN (eds) Positron emission tomography. Springer, New York

- Cherry SR, Dahlbom M (2004). PET; Physics, instrumentation, and scanners. In: Phelps ME (ed). PET; Molecular imaging and its biological applications. Springer, New York
- Cherry SR, Sorensen JA, Phelps ME (2003). Physics in nuclear medicine, 3rd ed. W.B. Saunders, Philadelphia, PA
- Fahey FH (2002). Data acquisition in PET imaging. J Nucl Med Technol 30:39
- Hoffman EJ, Phelps ME (1986). Positron emission tomography: principles and quantitation. In: Phelps ME, Mazziotta J, Schelbert H (eds) Positron emission tomography and autoradiography: principles and applications for the brain and heart. Raven Press, New York, p 237
- Karp JS, Surti S, Daube-Witherspoon et al (2008). Benefits of time-of-flight in PET: experimental and clinical results. J Nucl Med 49:462
- Kinahan PE, Hasegawa BH, Beyer T (2003). X-ray-based attenuation correction for positron emission tomography/computed tomography scanners. Semin Nucl Med 33:166
- Nehmeh SA, Erdi YE, Pan T et al (2004). Four-dimensional (4D) PET/CT imaging of the thorax. Med Phys 31:3179
- Sureshbabu W, Mawlawi O (2005). PET/CT imaging artifacts. J Nucl Med Technol 33:156
- Townsend DW (2008). Positron emission tomography/computed tomography. Semin Nucl Med 38:152
- Turkington TG (2001). Introduction to PET instrumentation. J Nucl Med Technol 29:1
- Zaidi H, Koral KF (2004). Scatter modeling and compensation in emission tomography. Eur J Nucl Med Mol Imaging 31:761

## 4 Image Reconstruction

Projection data acquired in two-dimensional (2D) mode or three-dimensional (3D) mode are stored in sinograms that consist of rows and columns representing angular and radial samplings, respectively. Acquired data in each row are compressed (summed) along the depth of the object and must be unfolded to provide information along this direction. Such unfolding is performed by reconstruction of images using acquired data. The 3D data are somewhat more complex than the 2D data and usually rebinned into 2D format for reconstruction. After correction for the factors discussed in Chap. 3, the data are used to reconstruct transaxial (transverse) images from which vertical long axis (coronal) and horizontal long axis (sagittal) images are formed. Reconstruction of images is made by two methods: filtered backprojection and iterative methods. Both methods are described below.

### Simple Backprojection

In 2D acquisition, activity in a given line of response (LOR) in a sinogram is the sum of all activities detected by a detector pair along the line through the depth of the object. The principle of backprojection is employed to reconstruct the images from these acquired LORs. A reconstruction matrix of a definite size (e.g.,  $128 \times 128$  pixels) is chosen. While the image matrix is in (x, y) coordinates, the sinogram data are in polar coordinates. An image in (x, y) position is related to polar coordinates  $(r, \phi)$  (Fig. 3.3b) by

$$r = x\sin\phi + y\cos\phi. \tag{4.1}$$

For each image pixel (x, y) at each projection angle  $\phi$ , r is calculated by Eq. (4.1). The measured counts in the projection sinogram corresponding to the calculated r are added to the (x, y) pixel in the reconstruction matrix. This is repeated for all projection angles. Thus, the backprojected image pixel



FIGURE 4.1. Principle of backprojection in image reconstruction. (a) An object with two hot spots (*solid spheres*) is viewed at three projection angles (at  $120^{\circ}$  angle) and the acquired data are backprojected for image reconstruction; (b) When many views are obtained, the reconstructed image represents the activity distribution with "hot" spots, but the activity is blurred around the spots; (c) Blurring effect described by 1/r function, where *r* is the distance away from the central point. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography ©2009. All Rights Reserved)

A(x, y) in the reconstruction matrix is given by

$$A(x,y) = \frac{1}{N} \sum_{N=1}^{N} p(r,\phi),$$
(4.2)

where  $p(r, \phi)$  is the count density in the sinogram element in the acquired matrix and N is the number of projection angles. When all pixels are computed, a reconstructed image results from this simple backprojection (Fig. 4.1).

In another approach of simple backprojection, in the reconstruction matrix of chosen size, the counts along an LOR in a sinogram detected by a detector pair are projected back along the line from which they originated. The process is repeated for all LORs, i.e., for all detector pairs in the PET scanner. Thus, the counts from each subsequent LOR are added to the counts of the preceding backprojected data, resulting in a backprojected image of the original object.

### Filtered Backprojection

The simple backprojection has the problem of "star pattern" artifacts (Fig. 4.1a) caused by "shining through" radiations from adjacent areas of

increased radioactivity resulting in the blurring of the object (Fig. 4.1b). Since the blurring effect decreases with distance (r) from the object of interest, it can be described by a 1/r function (Fig. 4.1c). It can be considered as a spillover of some counts from a pixel of interest to the neighboring pixels, and the spillover decreases from the nearest pixels to the farthest pixels of different frequencies. The blurring effect is minimized by applying a filter to the acquisition data, and filtered projection data are then backprojected to produce an image that is more representative of the original object. Such methods are called the filtered backprojection and are accomplished by the Fourier method described below.

### The Fourier Method

According to the Fourier method, the measured line integral  $p(r, \phi)$  in a sinogram is related to the count density distribution A(x, y) in the object obtained by the Fourier transformation. The projection data obtained in the spatial domain (Fig. 4.2a) can be expressed in terms of a Fourier series in the frequency domain as the sum of a series of sinusoidal waves of different amplitudes, spatial frequencies, and phase shifts running across the image (Fig. 4.2b). This is equivalent to sound waves that are composed of many sound frequencies. The data in each row of an acquisition matrix can be considered to be composed of sinusoidal waves of varying amplitudes and frequencies in the frequency domain. This conversion of data from spatial domain to frequency domain is called the *Fourier transformation* (Fig. 4.3). Similarly the reverse operation of converting the data from frequency domain to spatial domain is termed the inverse Fourier transformation.



FIGURE 4.2. Representation of data in the spatial and frequency domains. The activity distribution as a function of distance in an object (spatial domain) (**a**) can be expressed as the sum of the four sinusoidal functions (**b**).



FIGURE 4.3. The Fourier transform of this activity distribution is represented, in which the amplitude of each sine wave is plotted at the corresponding frequency of the sine wave.

In the Fourier method of backprojection, the projection data in each profile are subjected to the Fourier transformation from spatial domain to frequency domain, which is symbolically expressed as

$$F = (v_x v_y) = \mathcal{F} \cdot f(x, y), \tag{4.3}$$

where  $F(\nu_x, \nu_y)$  is the Fourier transform of f(x, y) and  $\mathcal{F}$  denotes the Fourier transformation. In essence, the Fourier transform  $F(\nu_x, \nu_y)$  of each projection in the sinogram of the 2D projection data is taken prior to back projection. Straight backprojection of these Fourier projections produces a blurred image because of the oversampling at the center and less sampling at the edge. To reduce blurring (i.e., to improve the signal-to-noise ratio), the Fourier projections must be "filtered" using appropriate filters.

A filter  $H(\nu)$ , in the frequency domain is applied to each projection, i.e.,

$$F'(v) = H(v) \cdot F(v), \tag{4.4}$$

where  $F'(\nu)$  is the filtered Fourier projection which is obtained as the product of  $H(\nu)$  and  $F(\nu)$ .

Finally, the inverse Fourier transformation is performed to obtain filtered projection data in the spatial domain, which are then backprojected in the same manner as in the simple backprojection. With the use of faster computers, the Fourier technique of filtered backprojection has gained wide acceptance in reconstruction of images in nuclear medicine.

Several factors affect the filtered backprojection. Adequate sampling of projections (both linear and angular projections related to r and  $\phi$  of the sinogram) is needed for accurate backprojection. Data noise, positron range, noncolinearity, scattering, and random events are not taken into consideration in the method. Also in this model, detectors are assumed to be point

sources, whereas in reality they have dimensions that cause nonuniform distribution of activity resulting in nonuniform projection.

### Types of Filters

A number of Fourier filters have been designed and used in the reconstruction of tomographic images in nuclear medicine. All of them are characterized by a maximum frequency, called the Nyquist frequency, which gives an upper limit to the number of frequencies necessary to describe the sine or cosine curves representing an image projection. Because the acquisition data are discrete, the maximum number of peaks possible in a projection would be in a situation in which peaks and valleys occur in every alternate pixel, i.e., one cycle per two pixels or 0.5 cycle/pixel, which is the Nyquist frequency. If the pixel size is known for a given matrix, then the Nyquist frequency can be determined. For example, if the pixel size in a  $64 \times 64$  matrix is 4.5 mm for a given detector, then the Nyquist frequency will be

Nyquist frequency = 0.5 cycle/pixel = 0.5 cycle/0.45 cm = 1.11 cycles/cm.

A common and well-known filter is the ramp filter (name derived from its shape in frequency domain) shown in Fig. 4.4 in the frequency domain. An undesirable characteristic of the ramp filter is that it amplifies the noise associated with high frequencies in the image even though it removes the blurring effect of simple backprojection. To eliminate the high-frequency noise, various filters have been designed by including a window in them. Such filters are basically the products of the ramp filter with a sharp cutoff at the Nyquist frequency (0.5 cycle/pixel) and a window with amplitude 1.0 at low frequencies but gradually decreasing at higher frequencies. A few of these windows (named after those who introduced them) are illustrated in Fig. 4.5, and the corresponding filters (more appropriately, filter–window combinations) are shown in Fig. 4.6.

The effect of a decreasing window at higher frequencies is to eliminate the noise associated with the images. The frequency above which the noise is eliminated is called the cutoff frequency ( $\nu_c$ ). As the cutoff frequency is increased, spatial resolution improves and more image detail can be seen up to a certain frequency. At a too high cutoff value, image detail may be lost due to inclusion of inherent noise. Thus, a filter with an optimum cutoff value should be chosen so that primarily noise is removed, while image detail is preserved. Filters are selected based on the amplitude and frequency of noise in the data. Normally, a filter with a lower cutoff value is chosen for noisier data as in the case of obese patients and in <sup>201</sup>Tl myocardial perfusion studies or other studies with poor count density.



FIGURE 4.4. The typical ramp filter in frequency domain.



FIGURE 4.5. Different windows that are used in combination with a ramp filter to suppress the higher frequency noise in backprojection method.

Hann, Hamming, Parzen, and Shepp-Logan filters are all "low-pass" filters, because they preserve low-frequency structures, while eliminating high-frequency noise. All of them are defined by a fixed formula with a userselected cutoff frequency ( $\nu_c$ ). It is clear from Fig. 4.6 that while the most smoothing is provided by the Parzen filter, the Shepp-Logan filter produces the least smoothing.

An important low-pass filter that is most commonly used in nuclear medicine is the Butterworth filter (Fig. 4.7). This filter has two parameters: the critical frequency ( $f_c$ ) and the order or power (n). The critical frequency is the frequency at which the filter attenuates the amplitude by 0.707, but not the frequency at which it is reduced to zero as with other filters. The parameter, order n, determines how rapidly the attenuation of amplitudes occurs with increasing frequencies. The higher the order, the sharper the fall. Lowering the critical frequency, while maintaining the order, results in more smoothing of the image.



FIGURE 4.6. Different filters (filter–window combinations) that are obtained by multiplying the respective windows by the ramp filter with cutoff at Nyquist frequency of 0.5 cycle/pixel.



FIGURE 4.7. Butterworth filters with different orders and cutoff frequencies.

Another class of filters, the Weiner and Metz filters, enhances a specific frequency response.

Many commercial software packages are available, offering a variety of choices for filters and cutoff values. The selection of a cutoff value is important so that noise is reduced, while image detail is preserved. Reducing a cutoff value will increase smoothing and degrade spatial resolution. No filter is perfect, and therefore, the design, acceptance, and implementation of a filter are normally done by trial and error with the ultimate result of clinical utility.

### Iterative Reconstruction

In iteration methods of image reconstruction, an initial estimate of image activity is stored in a matrix identical in size to the acquisition matrix. Usually all pixels in the estimate matrix are assigned an initial constant value. A set of simulated projections are unfolded from this estimate for comparison with the acquired projection. It is accomplished by a process called the *forward* projection, as opposed to the backprojection, in which the weighted sum of the activities in all pixels along an LOR is determined to give an estimated projection. After all projections are unfolded, each estimated projection is then compared with the corresponding measured projection. If there is a difference between the two, a weighted correction is applied to all pixels in each estimated projection. All corrected projections are backprojected to obtain an updated image, which is then entered into the algorithm as the estimated image for the next iteration. Iterations are continued until an acceptable agreement between the two sets of projections is achieved. The concept of iterative reconstruction techniques is illustrated in Fig. 4.8. Several algorithms have been developed for iterative methods. They differ primarily in the manner in which the projections are computed from the estimated image, the order in which the corrections are applied, and the type of error corrections to be applied to the estimated projections.

Mathematically, a simulated projection  $q_i$  from an estimated image matrix (Fig. 4.9) is given by

$$q_i = \sum_{j=1}^{N} a_{ij} C_j,$$
 (4.5)

where  $C_j$  is the counts (activity) in the *j*th pixel,  $a_{ij}$  is the probability that an emission from pixel *j* is recorded, and *N* is the number of pixels in the *i*th LOR. The weight,  $a_{ij}$ , is equal to the fraction of activity in the *j*th pixel out of



FIGURE 4.8. A conceptual step in iterative reconstruction methods. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).



FIGURE 4.9. A projection data  $q_i$  in a sinogram is estimated from all pixels along the LOR and compared with the measured projection data  $p_i$ . (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved).

the total activity along the *i*th LOR. The projection  $q_i$  is then compared with the measured projection  $p_i$ . If there is a difference,  $(p_i - q_i)$ , then a weighted correction is applied to all N pixels along the *i*th LOR according to Eq. (4.4).

$$\Delta C_{j} = \frac{a_{ij}(p_{i} - q_{i})}{\sum_{j=1}^{N} a_{ij}},$$
(4.6)

where  $\Delta C_j$  is the correction to the *j*th pixel. This comparison and correction is repeated for all projections. The corrected projections are then backprojected to generate an updated estimated image, which is reentered in the algorithm as the next image, and comparison and correction is repeated. The iteration continues until there is an acceptable convergence between the estimated and true images.

There are three ways of calculating and applying error corrections. In a point-by-point correction technique, the errors for all LORs passing through a single pixel are calculated and are used to correct that point before proceeding to the next point. In the projection-by-projection (LOR by LOR) correction technique, the error is computed and the image is updated for each LOR before proceeding to the next LOR. In the simultaneous iteration reconstruction technique, all errors for all comparison LORs are calculated at the same time and then the image is updated.

The most widely used iterative algorithms in PET are *maximum-likelihood* expectation maximization (MLEM) algorithm and ordered-subset expectation maximization (OSEM) algorithm. The main feature of the MLEM algorithm is to update the image during each iteration using Eqs. (4.3) and (4.4). In the method, estimation of an image, unfolding of projections, comparison of estimated and measured projections, updating of projections for the difference, and backprojection of corrected projections to form the estimated image are all applied. It requires many iterations (as many as several hundred) to achieve an acceptable agreement between the estimated image and

the measured image. With many iterations, the inherent noise due to low photon counting systems causes variance on the image and often some smoothing is applied to reduce overall noise levels. This method, however, demands a lengthy computation time.

To reduce the computation time, the OSEM algorithm has been introduced, which is a modification of MLEM, in that angular projections are grouped into subsets, and MLEM iteration is performed on each subset rather than each projection in it. Suppose there are 32 projections acquired at 32 equal angular intervals around the object and they are grouped into 8 subsets. Then each subset contains four projections:

Subset 1: projections 1, 9, 17, 25 Subset 2: projections 2, 10, 18, 26 ..... Subset 8: projections 8, 16, 24, 32

Standard MLEM is applied to each subset, using the rows of the estimated matrix corresponding to the LORs in the measured subset. The resulting reconstruction is then used as the starting value for the next subset. A single iteration is considered complete when all eight subsets in the above example are processed. Use of eight subsets in OSEM, as in this example, accelerates convergence by nearly a factor of 8 compared with that in standard MLEM, thus shortening the computation time. Additional iterations can be performed for better agreement by repeating the process on the same ordered subsets, always using the estimated reconstruction of the previous iteration as the starting estimated image for the next.

For noiseless projections, it has been shown that each OSEM estimate based on one subset of projections converges to a maximum likelihood solution as close as a full iteration of MLEM using all projections in the subset (Hudson and Larkin, 1994). It is this feature of OSEM that accelerates the computation process, and in general, the computation time is shortened with decreasing number of subsets (i.e., with more projections in each subset). However, there is a tendency of having more image variance with increasing number of subsets when compared to MLEM. So an optimum number of subsets need to be chosen.

The OSEM method can incorporate attenuation factors whereby the image quality is further improved. The method has been modified to include random, scatter, and attenuation corrections in the 3D reconstruction model yielding better images. The latest development of the method, "High-Definition (HD)" PET, includes the point spread function (PSF), which varies throughout the FOV, because of the radial elongation (photons striking the detector obliquely). By appropriately modeling the PSF with measured activity distribution across the FOV, uniform spatial resolution has been achieved and much improved images have been obtained. Despite many improvements in image quality by the OSEM method, the effect of obese patients on image quality is still a challenge to resolve. In general, iterative reconstruction methods do not produce artifacts observed with FBP methods and provide a better



FIGURE 4.10. Comparison of filtered backprojection (FBP) and iterative (OSEM) methods with attenuation correction. (a) Lungs, (b) Normal Liver, (c) Liver with tumor, (d) Breast. FBP images with attenuation corrections are noisier than OSEM images with attenuation correction. (Reprinted by permission of Society of Nuclear Medicine from: Riddell C et al (2001) Noise reduction in oncology FDG PET images by iterative reconstructions: a quantitative assessment. J Nucl Med 42:1316)

signal-to-noise ratio in regions of low tracer uptake (Fig. 4.10). Overall, the MLEM and OSEM iterative methods reduce noise providing high-quality images and are currently included in many PET and SPECT systems. Refer to the references (Hudson and Larkin, 1994; Shepp and Vardi, 1982) for a detailed description of the iterative methods.

Another algorithm, the row-action maximum-likelihood algorithm (RAMLA), has been proposed as a special case of OSEM requiring sequences of orthogonal projections, which leads to faster convergence than OSEM itself.

In the time of flight (TOF) technique, the sinogram is divided into time bins, where each time bin contains the counts registered with time difference  $\Delta t$ . The image estimation is made by simulating the time bins and then the iterative method is applied to match a sinogram simulated from a prototype image with the real sinogram. Reconstruction of TOF images by iterative methods provide better images than those without TOF information.

### **3D** Reconstruction

Reconstruction of images from 3D data is complicated by a very large volume of data, particularly in a multiring scanner. In a multiring scanner having N rings, a full 3D acquisition would generate N direct (perpendicular to the axis of the scanner) and N(N - 1) oblique sinograms ( $N^2$  total) in the absence of septa, compared to 2N - 1 as in the case of 2D acquisition. Processing and storage of such a large amount of data is challenging for routine clinical applications. Furthermore, in 3D acquisition, there is more activity measured at the center of the scanner axis than at the edge causing spatial variance that in turn leads to complication in the reconstruction of the images.

The filtered backprojection can be applied to 3D image reconstruction with some manipulations. The 3D data sinograms are considered to consist of a set of 2D parallel projections, and the FBP is applied to these projections by the Fourier method. The iteration methods also can be generally applied to the 3D data. However, the complexity, large volume, and incomplete sampling of the data due to the finite axial length of the scanner are some of the factors that limit the use of the FBP and iterative methods directly in 3D reconstruction. To circumvent these difficulties, a modified method of handling 3D data is commonly used, which is described below.

A common method of 3D reconstruction involves the rebinning of the 3D acquisition data into a set of 2D equivalent projections. Rebinning is achieved by assigning axially tilted LORs to transaxial planes intersecting them at their axial midpoints. This is equivalent to collecting data in a multiring scanner in 2D mode, and the technique is called the single-slice rebinning algorithm (SSRB). The method works well along the central axis of the scanner, but steadily becomes worse with increasing radial distance. This is true with smaller objects and as long as the axial acceptance angle is relatively narrow. Otherwise, views along the vertical and horizontal long axes become blurred. In another method, called the Fourier rebinning (FORE) algorithm, rebinning is performed by applying the 2D Fourier method to each oblique and transverse sinogram in the frequency domain. This method is more accurate than the SSRB method because of the more accurate estimate of the axial location of the source. After rebinning of 3D data into 2D data sets, the FBP or iterative method is applied. This method amplifies statistical noise slightly compared with SSRB, but results in significantly less distortions.

In a 2D ring scanner, complete uniform transverse projections are obtained regardless of the position of the source inside the scanner's FOV, whereas in a 3D cylindrical scanner, this situation would occur only in a spherical sphere. In a typical cylindrical scanner of finite length, the projections are truncated toward the outer axial extent of the scanner (Fig. 4.11) that had to be restored prior to reconstruction for better signal-to-noise ratios. A practical method of 3D PET image reconstruction called the three-dimensional reprojection (3DRP) algorithm is employed to correct for truncation of the projections at the outer extent of the scanner. In this method, the 3D data are deciphered into conventional 2D sinograms. An initial 3D volume estimate is made of the object image by applying the Fourier 2D filtered backprojection to only direct plane projections (which are not truncated) and then reconstructing the image. Then unmeasured oblique projections that are truncated are estimated by numerical forward projection or reprojection of the estimated image. In essence, the activity from the estimated image is numerically added to the missing LORs, which are then summed to give the missing sinogram (Fig. 4.11a). This method significantly improves the signal-to-noise ratio, but is very time consuming because of the complexity of computation and a large volume of data to handle.



FIGURE 4.11. (a) LORs that are not sampled beyond the scanner length in the 3D acquisition are shown by *dashed line*. (b) A 3D image is estimated by applying 2D filtered backprojection to the 3D data, and from the estimated image activity is added to the truncated LORs, which are then added to form the missing sinograms. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography  $^{\circ}2009$ . All Rights Reserved)

#### Partial Volume Effect

In PET imaging, the reconstructed images should depict the radiotracer distribution uniformly and accurately throughout the field of view (FOV). However, because of the limit of the spatial resolution of current PET scanners, "hot" spots (structures) relative to a "cold" background that are smaller than twice the resolution of the scanner show partial loss of intensity, and the activity around the structure appears to be smeared over a larger area than it occupies in the reconstructed image. While the total counts are preserved, the object appears to be larger and to have a lower activity concentration than it actually has. Similarly, a cold spot relative to a hot background would appear smaller with high activity concentration. Such underestimation and overestimation of activities around smaller structures in the reconstructed images is called the partial volume effect (Fig. 4.12), and this reduces the contrast between high and low uptake regions. However, this effect also contains the so-called spillover effect due to contamination of activity from the neighboring tissues to these hot or cold areas.

Corrections need to be applied for overestimation or underestimation of activities to these smaller structures in the reconstructed images. A correction factor, called the recovery coefficient (RC), is the ratio of the reconstructed count density to the true count density of the region of interest that is smaller than twice the spatial resolution of the system. The recovery coefficient is determined by measuring the count density of different objects containing the same activity but with sizes larger as well as smaller than the spatial resolution of the system. Normally, the recovery coefficients would be 1 for larger



FIGURE 4.12. An illustration of partial volume effect. (a) Cross section of a sphere phantom with six different spheres; (b) PET images of the spheres demonstrating partial volume effect. (Reproduced with permission from Rota Kops E, Krause BJ (2000) Partial volume effects/corrections. In: Wieler HJ, Coleman RE (eds) PET in Oncology. Springer, Darmstadt)



FIGURE 4.13. Recovery coefficients as a function of object size. (Reproduced with permission from Rota Kops E, Krause BJ (2000) Partial volume effects/corrections. In: Wieler HJ, Coleman RE (eds) PET in oncology. Springer, Darmstadt)

objects (Fig. 4.13). These RC values are then applied to the images of small structures for partial volume corrections. However, the sizes of the in vivo structures are not precisely known, and so the phantom RC data may not be accurate for these structures. Other methods using point-spread functions of the activity distribution around the object have been investigated with limited success.

### Questions

- 1. Discuss the methods and merits and disadvantages of filtered backprojection and iterative methods.
- 2. Why are filters used in reconstruction of PET images by backprojection?

- 3. What is the common initial step that is taken in the reconstruction of 3D data?
- 4. When do you apply various corrections (e.g., detection efficiency variations, noise components, random and scatter coincidences, attenuation) in the FBP and iterative methods of image reconstruction?
- 5. In a six-ring PET scanner, how many direct and oblique sinograms can be obtained in 3D acquisition?
- 6. What is the partial volume effect and how do you correct it?
- 7. A PET scanner has a FOV diameter of 20 cm. If a  $64 \times 64$  matrix is used for data acquisition, what is the pixel size?
- 8. OSEM method is slower in computation than MLEM method. True\_\_\_\_\_; False\_\_\_\_\_.
- 9. Both OSEM and MLEM methods reduce image noise compared to filtered back projection. True\_\_\_\_\_; False\_\_\_\_\_.
- 10. 3D reprojection method is commonly used in 3D reconstruction because of (a) less time consuming in computation, (b) correction for the loss of projections at the edge of the scan axis, and (c) improvement in noise reduction on images.

### References and Suggested Reading

- Bacharach SL (1995). Image analysis. In: Wagner HN Jr, Szabo Z, Buchanon JW (eds) Principles of nuclear medicine. W.B. Saunders, Philadelphia, PA, pp 393–404
- Cherry SR, Dahlbom M (2004). PET; Physics, instrumentation, and scanners. In: Phelps ME (ed) PET; Molecular imaging and its biological applications. Springer, New York
- Cherry SR, Sorensen JA, Phelps ME (2003). Physics in nuclear medicine, 3rd ed. W.B. Saunders, Philadelphia, PA
- Defrise M, Kinahan PE, Christian M (2003). Image reconstruction algorithms in PET. In: Valk PE, Bailey DL, Townsend DW, Maisey MN (eds) Positron emission tomography. Springer, New York
- Defrise M, Townsend DW, Clack R (1989). Three-dimension image reconstruction from complete projections. Phys Med Biol 34:573
- Dreyer KJ, Mehta A, Thrall JH (2002). PACS: A guide to the digital revolution. Springer, New York
- Hoffman EJ, Phelps ME (1986). Positron emission tomography; principles and quantitation. In: Phelps ME, Mazziotta J, Schelbert H (eds) Positron emission tomography and autoradiography: principles and application for the brain and heart. Raven Press, New York, p 237
- Hudson HM, Larkin RS (1994). Accelerated image reconstruction using ordered subsets of projection data. IEEE Trans Med Imaging 13:601
- Shepp LA, Vardi Y (1982). Maximum likelihood reconstruction for emission tomography. IEEE Trans Med Imaging MI-1:113

# 5 Storage, Display, and PACS

Completion of a nuclear medicine procedure involves many steps that are intertwined with one another. A referring physician orders a nuclear medicine study for a patient after clinical examination. The patient reports to the nuclear medicine department for the study according to the schedule. The study is performed according to the established protocol using specific equipment. The data are processed and used to construct images which are then stored for display on monitors as needed. The nuclear physician retrieves the images from storage and interprets them to diagnose the patient's diseases. The report on the diagnosis is dictated into a computer, which can be retrieved along with images by the referring physician for making a clinical decision for the patient. The entire sequence of operations in the procedure is depicted by the term *workflow* that represents each operation much like flow charts. Workflow software has been developed by various vendors to implement all sequential operations of a procedure in an integrated form. The advantage of workflow lies in the management of large imaging data in multiple formats along with the capability of interrelating among different operations. Below is given a description of storage and display of image data in nuclear medicine and the concept of workflow involving multiple operations to complete a study.

### Storage

Reconstructed digital PET images are stored in the computer in the format of a matrix. The images are characterized by two quantities: matrix size and pixel depth. In PET studies, the computer memory approximates the FOV as a square matrix of a definite size that can range from  $64 \times 64$  to  $512 \times 512$ with a total of 1,026 (1 K) to 262,144 (262 K) picture elements, called pixels, respectively. The matrix size depends on the type of study and is chosen by the operator. Since the FOV is approximated to the matrix size, the pixel size is calculated by dividing the length of FOV by the number of pixels across the matrix. For example, if an image of  $250 \times 250 \text{ mm}$  FOV is stored in a  $128 \times 128$  matrix, then the pixel size would be  $250/128 \approx 2$  mm. The spatial resolution of an image is improved by decreasing the pixel size, but is limited by the spatial resolution of the scanner. Pixel size smaller than one-third the spatial resolution of the PET system does not improve the image resolution any more. Thus, for a 6 mm spatial resolution, choosing pixel size smaller than 2 mm does not add to the improvement of the image resolution.

How many counts can be stored in a pixel depends on the depth of the pixel, which is represented by a byte or a word. Digital computers operate with *binary* numbers using only two digits, 0 and 1, as opposed to ten digits, 0–9, in the decimal system. The basic unit of the binary system is a *bit* (binary digit) that is either 0 or 1. In computer nomenclature, a byte of memory is equal to eight bits that can store up to  $2^{8}$ , i.e., 0–255 units of information. Similarly, a word of memory consists of 16 bits or two bytes and can store up to  $2^{16}$ , i.e., 0–65,535 units of information. The color levels or gray shades on the displayed images are affected by pixel depth. Currently 32-bit and 64-bit processors have been introduced, allowing storage capacity of  $2^{32}$  and  $2^{64}$  units of information in computers.

Digital images are commonly stored in the hard drive of the local computer for a short period of time for display and interpretation. Hard drives with storage capacity of more than 1 terabyte (Tb) are currently available. Also, Redundant Arrays of Inexpensive Disk (RAID) provide additional storage in the computer. After completion of the study, the images are archived in long-term storages, which are available in a variety of hardware accessories. Optical spinning media, magnetic tape, and magnetic spinning media are the common forms of external storage of image. Holographic storage has great potential to accommodate information density on the order of 800 Gb/in<sup>2</sup>, far exceeding the capacity of currently available media. For reasons of natural disasters, terrorism, viruses, etc., electronic data vaulting has become an emerging technique for off-site data storage, which provides a means for geographically distant storage and retrieval of data as needed.

Storage management software is available from vendors with a licensing fee and warranty for long-term storage, some with disaster recovery provision. All these software include the features of backup and replications. All vendors market both hardware and software as a package deal. IBM, Hewlett-Packard, Storage Technology Corporation, and Sony are among many vendors, who provide these storage packages. PET/CT vendors like GE Healthcare, Siemens Medical Solutions, and Philips Healthcare provide their own proprietary hardware plus software packages for data storage. Hardware in these packages includes optical spinning media, magnetic tape, or magnetic spinning media.

### Display

Images are displayed on video monitors after the conversion of digital images into analog images by digital-to-analog conversion (DAC) at the video interface between the computer and the monitor. Two common video monitors are cathode ray tubes (CRTs) or flat panel-type liquid crystal display (LCD) monitors. These monitors are characterized by parameters such as spatial resolution, contrast resolution, aspect ratio, luminance, persistence, refresh rate, and dynamic range. These properties are described in standard physics books on imaging, and are not discussed here. It should be noted that the spatial resolution and luminance of LCD monitors are far superior to those of CRTs. These monitors are set in what is called the *workstation*, where practitioners manipulate, view, and interpret images using the computer attached to the workstation.

Display can be in either grayscale (black and white) or color-scale format. Grading of scale in either case is dictated by the pixel values (number of counts in the pixel) in the digital image. The number of counts in a pixel defines the brightness level of the pixel. Thus, in a digital image, the grayscale can be applied to delineate areas of contrast, and when comparing separate images, the grayscale should be kept the same for all images.

Color display of digital images can be obtained by assigning color hues to different pixel values corresponding to counts stored in the individual pixels. In a common color scale, blue, green, yellow, and red colors from the visible spectrum are in order assigned to pixels with increasing counts: blue color to the pixels with the lowest counts and red color to the pixels with the highest counts. Edges of color bands are blended to produce a gradual change over the full range of the color scale. As with the grayscale, the color scale provides contrasts between areas of different pixel counts and thus a means to discriminate between normal and abnormal areas on the images. Conventionally, PET functional images are displayed in color, and CT anatomical images are shown in grayscale. On fusion of the two images, the combination of color and gray scales is quite effective in differentiating the abnormal areas.

Often a grayscale or color-scale bar is shown on the side of the image so that the interpreter can easily differentiate the contrast on the image. The regions of interest (ROIs) can be chosen from sequential images, and time-activity curves can be obtained by plotting counts in ROIs against the corresponding time. Images can be subtracted from one another or can be superimposed, as needed.

PET images can be displayed in transaxial, coronal (horizontal long axis) or sagittal (vertical long axis) views separately, or simultaneously on the same screen (Fig. 5.1). On a simultaneous display, a point within an image of the object is chosen using the cursor and three images that pass through that point are displayed. New sets of images are obtained by moving the cursor to a different point along the image. Such sequential screening of images is helpful in delineating the abnormal areas in patients on images.



FIGURE 5.1. Simultaneous display of PET images of the brain in transaxial, coronal (*horizontal long axis*), and sagittal (*vertical long axis*).

Angular projections around an object can be computed from the threedimensional (3D) tomographic data and then displayed in continuous rotation. This results in the presentation of the image data in a movie or cinematographic (or cine) mode whereby a rotating 3D image is seen on the screen. The relative location of a lesion in an organ with respect to other organs in the body can be easily identified in these movie presentations of PET images.

### Software and DICOM

Commercial vendors provide software for acquisition, processing, storage, and display of images specially designed for their scanners. Such software is either developed by the vendor or acquired from a third-party software developer. These types of software use a proprietary format for each vendor, and it is difficult to transfer, store, and display images on equipment from different vendors.

This problem can be partially solved by using equipment all from the same vendor in an institution. To overcome this difficulty, the American College of Radiology (ACR) and the National Electrical Manufacturers Association (NEMA) jointly sponsor a standard format for software called Digital Imaging and Communications in Medicine (DICOM) to facilitate the transmission and usage of medical images and related data among different imaging equipment. DICOM consists of a standard image format as well as a network communication protocol, and specifies standard formats for operations such as Patients, Studies, Storage, Query/Retrieve, Verification, Print, Study, etc.

Currently, all vendors provide software conforming to the DICOM standard, and agree to a commitment to that effect to all customers. Compliance with this standard establishes a common format for imaging systems connecting hardware and software components, and allows interoperability for transfer of images and associated information among multiple vendors' devices. The DICOM standard is particularly useful in the implementation of the Picture Archival and Communication System (PACS), which is discussed here.

### PACS

The PACS is a system for storage of images and transferring images between computers in different facilities through networks. This system consists of devices to produce and store digital images electronically, workstations to view and interpret images, and a network linking computers from different sites. Appropriate PACS software allows the interpreter to manipulate images as needed, at his own location, by retrieving images from other locations via PACS. The introduction of PACS has eliminated the use of X-ray films or Polaroid films for routine interpretation of images, making the imaging centers filmless.

A PACS connects different computers through a high-speed network to share information. This connection can be in a single department using a local area network (LAN), in a hospital using the intranet, or outside the hospital via the Internet. In radiology, it is often desirable to compare CT, MRI, and ultrasound images with those of nuclear medicine studies. A PACS is helpful to provide such comparative studies among different imaging modalities via Web protocols without physically moving to and from different locations of the department. Similar transfer of images can occur through a PACS to other parts of the hospital, to different parts of the country, or even to other countries.

In a radiology department, the Radiology Information System (RIS) is implemented to maintain all aspects of the workflow within the department, from scheduling to billing to reporting. Similarly, hospitals have the Hospital Information System (HIS) that maintains information on patients regarding their demographic data, clinical history, laboratory data, medication, and again, scheduling, tracking, billing, and reporting. A PACS can integrate both RIS and HIS for broader exchange of information among healthcare personnel that will save time and money in healthcare operations. In an integrated system, a referring physician can call in an image of a patient on his computer connected to the PACS, rather than waiting for the hard copy from the imaging department. He can then correlate the clinical findings with the images in the same sitting with considerable saving of time. A schematic integrated PACS is shown in Fig. 5.2.

A PACS is maintained by a server that provides storage, informatics, etc. for communication among members of the PACS, and also as many workstations as necessary to connect to the server. As already mentioned, at workstations one can retrieve reports and images of patients from the PACS and manipulate them to interpret as needed. A PACS is run by software designed for a particular operating system, such as Windows, Mac OS, Unix, or Linux, although most PACS workstations run on a PC platform. All PACS software can perform some standard functions, but ease of operation may vary. They differ at times in limitation of the number of the patient studies that can be displayed on a monitor screen. The software provides different protocols to access the PACS at the workstation. For example, a protocol may be based on a modality and body part combination, such as "CT abdomen/pelvis," or on a secondary descriptor such as "gallbladder stone



FIGURE 5.2. A schematic PACS integrating RIS and HIS. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art and Photography <sup>©</sup>2009. All Rights Reserved).

protocol," or on a subspecialty such as "nuclear medicine." A PACS software should be able to present and interact with all pertinent information for a given patient from different systems, such as the hospital system, the radiology system, and the dictation system.

PACS software must address four issues: confidentiality, integrity, reliability, and availability. From the legal point of view mandated by various federal and state regulations, these issues are paramount in the operation of a healthcare institution.

Confidentiality refers to how well private information is kept private, regardless of whether it is a patient, employee, or corporation. Information is available only to authorized persons, and none will be divulged to unauthorized individuals. This invokes the concept of security in the information system. In most cases, security is maintained in the system by introducing an appropriate "user's I.D. and password" format for each eligible user. Recent implementation of a federal law, the Hospital Insurance Portability and Accountability Act (HIPAA), has made it mandatory to insure stricter confidentiality measures in the healthcare system. A PACS should strictly meet this requirement.

Integrity refers to the correctness and completeness of patient information. An error in demographic data or patient medication regimen may result in a fatal condition, which can provoke a legal action. A PACS should provide maximum integrity to maintain a reliable information system.

Reliability refers to the stability of the PACS – meaning the downtime of the system should be nil. If a PACS falters in its operation and encounters frequent failures, it will seriously disrupt the healthcare operation, leading to adverse financial loss. The software should be well written and user-friendly to avoid unnecessary failures of the system.

Availability refers to the timely access to patient information, which can affect the quality of care. Patient data should be entered into the computer on time by the healthcare personnel, as delays can have adverse effects on patient care. Computers and networks must have no or minimal downtime to avoid delays in patient management. A PACS software should address this issue faithfully to maintain an efficient system.

PACS software is evolving over time to meet the challenging demands of healthcare professionals and usually is up for upgrade every 6–12 months. Since a variety of factors are involved in the implementation of PACS in a facility, a caveat is in order for purchasing a PACS from a vendor. One should make a thorough assessment of the software prior to purchase. Even though trade shows and demonstrations at professional meetings may offer a reasonable background on the system, one should not hesitate to ask for a visit to sites that have the actual systems that are up and running before making a decision to purchase.

More than a dozen of PACS software are available commercially in the market from different vendors. Each of these systems is sold as a package consisting of the software and a Web-based server. There are dozens of PACS

software companies, such as Siemens Healthcare, GE Healthcare, Philips Healthcare, Agfa, Fujifilm, Aspyra, Infinitt, Medweb, Sectra, and Voyager, to name a few, which market the PACS packages that are universally compatible with most imaging systems. Vendors often customize the software to meet the specific need of a customer. All vendors claim their software to be robust, reliable, and user-friendly, with an uptime of more than 99.9%. Even though many PACS versions are applicable to imaging equipment of different manufacturers, it is not uncommon to encounter a few glitches in implementing the PACS of one vendor into a system of a different vendor.

The use of PACS has become common in most hospitals although many independent free-standing operations are yet to integrate PACS in their operations. According to a study in 1999 by the Institute of Medicine (IOM), an estimated 98,000 Americans die each year due to medical errors. These deaths could be prevented by having PACS because of the quick and easy access by the healthcare providers to reliable and comprehensive patient information. The IOM is strongly recommending hospitals and physicians to adopt electronic record keeping, a measure that could save thousands of Americans. The US Congress is planning on legislation to implement mandatory electronic record keeping of patients' health information. This would need a more uniform standard for PACS software. To have such a standard, the medical community and perhaps the federal government should come up with a consensus policy similar to DICOM so that PACS can be instituted universally for all concerned.

### Teleradiology

A patient's diagnostic images obtained at one location can be transferred to different locations by PACS through computer networks. This system is termed *teleradiology* in parallel with telemedicine. Nowadays the practice of nuclear medicine has spread over different geographical regions, and nuclear physicians cover many hospitals and clinics, reading patient scans from distant locations. It is time consuming and impractical for these practitioners to commute to different distant hospitals to read scans. Teleradiology offers a great advantage to these practitioners, because they can read patients' reports and scans from different hospitals at their own locations using teleradiology. For example, on-call nuclear physicians can read scans at home using a computer connected to the teleradiology network through a cable modem, ISDN or DSL connection, or Wi-Fi (wireless) technology provided by the local telecommunications company. Teleradiology has advanced greatly, so much so that interstate teleradiology and worldwide intercountry teleradiology are quite common in modern medical practice.

Teleradiology communication is accomplished in several ways. The classical technique involves the use of two workstations directly connected to each other via TCP-IP protocol with built-in data security and teleconferencing capability. Mail servers in the internet can serve efficiently to communicate images via e-mails provided they are fast and dedicated to avoid transmission delays. Web-based servers offer a convenient way of submitting and receiving patient data over the internet. Different combinations of these methods are often made to customize individual preferences. For example, radiologists can use their own computers for acquisition and reporting, while transmitting images via an established gateway using available standard protocols such as DICOM, and HL7. The gateway performs all necessary steps such as data security, compression, etc. for passage through WAN and send the data to many locations or even to different countries.

By virtue of teleradiology, the radiology business groups in the USA are in the global practice of radiology by outsourcing, for example, qualified radiologists in India to interpret imaging scans performed in the USA. This provides a great deal of financial benefit because Indian radiologists are paid less than one-third the pay that their US counterparts get.

### Questions

- 1. LCD monitors are superior to CRT monitors for image display. Explain why.
- 2. What are the major media for the storage of image information in radiology?
- 3. What is the standard format used in software for transmission of images and related data among different imaging equipment?
- 4. PACS has become the most efficient means of exchanging patients' data among physicians and medical institutions. Specify some important features and advantages of PACS to justify such a unique status.
- 5. What are the important issues of PACS one should consider in purchasing a PACS software?
- 6. Most PACS software is PC-based. True \_\_\_\_; False \_\_\_\_\_;
- 7. How many ways teleradiology can be accomplished via internet?

### References and Suggested Reading

- Dreyer KJ, Mehta A, Thrall JH (2002). PACS: a guide to the digital revolution, Springer, New York
- Huang HK (2004). PACS and imaging informatics: basic principles and applications, Wiley, New Jersey
- Kohn LT, Corrigan JM, Donaldson MS (eds) (1999). To err is human: building a safer health system, National Academy Press, Washington

### 6 Performance Characteristics of PET Scanners

A major goal of the PET studies is to obtain a good quality and detailed image of an object by the PET scanner, and so it depends on how well the scanner performs in image formation. Several parameters associated with the scanner are critical to good quality image formation, which include spatial resolution, sensitivity, noise, scattered radiations, and contrast. These parameters are interdependent, and if one parameter is improved, one or more of the others are compromised. A description of these parameters is given below.

### Spatial Resolution

The *spatial resolution* of a PET scanner is a measure of the ability of the device to faithfully reproduce the image of an object, thus clearly depicting the variations in the distribution of radioactivity in the object. It is empirically defined as the minimum distance between two points in an image that can be detected by a scanner. A number of factors discussed below contribute to the spatial resolution of a PET scanner.

Detector size: One factor that greatly affects the spatial resolution is the intrinsic resolution of the scintillation detectors used in the PET scanner. For multidetector PET scanners, the intrinsic resolution  $(R_i)$  is related to the detector size d.  $R_i$  is normally given by d/2 on the scanner axis at midposition between the two detectors and by d at the face of either detector. Thus it is best at the center of the FOV and deteriorates toward the edge of the FOV. For a 6-mm detector, the  $R_i$  value is  $\sim 3 \text{ mm}$  at the center of the FOV and  $\sim 6 \text{ mm}$  toward the edge of the FOV. For continuous single detectors, however, the intrinsic resolution depends on the number of photons detected, not on the size of the detector, and is determined by the full width at half maximum of the photopeak.

*Positron range*: A positron with energy travels a distance in tissue, losing most of its energy by interaction with atomic electrons and then is annihilated after capturing an electron (Fig. 6.1). Thus, the site of  $\beta^+$  emission differs from the site of annihilation as shown in Fig. 6.1. The distance (range) traveled

97



FIGURE 6.1. Positrons travel a distance before annihilation in the absorber and the distance increases with positron energy. Since positrons with different energies travel in zigzag directions, the effective range is the shortest distance between the nucleus and the direction of 511 keV photons. This effective range degrades the spatial resolution of the PET scanner. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography ©2009. All Rights Reserved)

by the positron increases with its energy, but decreases with the tissue density. Since the positrons are deflected after interaction with electrons resulting in a zigzag trajectory, the positron range is essentially an effective range, which is given by the shortest (perpendicular) distance from the emitting nucleus to the positron annihilation line. Furthermore, positrons are emitted with a distribution of energy, which also affects the effective range. The effective positron ranges in water for <sup>18</sup>F ( $E_{\beta+,\max} = 0.64 \text{ MeV}$ ) and <sup>82</sup>Rb. ( $E_{\beta+,\max} = 3.35 \text{ MeV}$ ) are 2.2 and 15.5 mm, respectively (Table 1.2). Since coincidence detection is related to the location of annihilation and not to the location of  $\beta^+$  emission, an error ( $R_p$ ) occurs in the localization of spatial resolution. This contribution ( $R_p$ ) to the overall spatial resolution is determined from the full width at half maximum (FWHM) of the positron count distribution, which turns out to be 0.2 and 2.6 mm for <sup>18</sup>F and <sup>82</sup>Rb, respectively (Tarantola et al, 2003).

Noncolinearity: Another factor of concern is the noncolinearity that arises from the deviation of the two annihilation photons from the exact 180° position. That is, two 511 keV photons are not emitted at exactly 180° after the annihilation process (Fig. 6.2), because of some small residual momentum of the positron at the end of the positron range. The maximum deviation from the 180° direction is  $\pm 0.25^{\circ}$  (i.e.,  $0.5^{\circ}$  FWHM). Thus, the observed LOR between the two detectors does not intersect the point of annihilation, but is somewhat displaced from it, as illustrated in Fig. 6.2. This error ( $R_a$ ) degrades the spatial resolution of the scanner and deteriorates with the distance between the two detectors. If D is the distance in cm between the two detectors (i.e., detector ring diameter), then  $R_a$  can be calculated from the point-spread-function as follows:

$$R_{\rm a} = 0.0022D. \tag{6.1}$$



FIGURE 6.2. Noncolinearity of 511 keV annihilation photons. Because there is some residual momentum associated with the positron, the two annihilation photons are not emitted exactly at 180°, but at a slight deviation from 180°. Two detectors detect these photons in a straight line, which is slightly deviated from the original annihilation line. The maximum deviation is  $\pm 0.25^{\circ}$ . (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup> 2009. All Rights Reserved)

The contribution from noncolinearity worsens with larger diameter of the ring, and it amounts to 1.8–2 mm for currently available 80–90-cm PET scanners.

*Reconstruction method used*: Choice of filters with a selected cutoff frequency in the filtered backprojection reconstruction method may introduce additional degradation of the spatial resolution of the scanner. For example, a filter with a too high cutoff value introduces noise and thus degrades spatial resolution. An error ( $K_r$ ) due to the reconstruction technique is usually a factor of 1.2–1.5 depending on the method (Huesman, 1977).

Localization of detector: The use of block detectors instead of single detectors causes an error  $(R_{\ell})$  in the localization of the detector by X, Y analysis and it may amount to 2.2 mm for BGO detectors (Moses and Derenzo, 1993). However, it can be considerably minimized by using better light output scintillators, such as LSO.

Combining the above factors, the overall spatial resolution  $R_t$  of a PET scanner is given by

$$R_{\rm t} = K_{\rm r} \times \sqrt{R_{\rm i}^2 + R_{\rm p}^2 + R_{\rm a}^2 + R_{\ell}^2}.$$
 (6.2)

#### 100 6. Performance Characteristics of PET Scanners

$Manufacturers {\rightarrow}^a$	Philips <sup>b</sup>		Siemens <sup>c</sup>		GE Healthcare <sup>c</sup>	
Models→ Features↓	GEMINI TF Big Bore	GEMINI TF 64 (PET/CT)	Biograph mCT	Biograph TruePoint	Discovery VCT	Discovery PET/CT 600
Sensitivity –	7.2	7.2	9.5	7.6	9.1	9.1
3D (cps/kBq/cc)						
Transverse	4.7	4.7	4.4	4.2	5.0(2D)	5.1
Resol. at 1 cm					5.0(3D)	
(mm)						
Transverse	5.2	5.2	5.8	4.8	5.4(2D)	5.6
Resol. at 10 cm (mm)					5.4(3D)	
Axial Resol.	4.7	4.7	4.5		5.0(2D)	5.6
at 1 cm (mm)					5.0(3D)	
Axial Resol.	5.2	5.2	4.8	5.5	5.6(3D)	6.3
at 10 cm (mm)						
Peak noise	94	110	100	165	78	76
equivalent				170		
count rate				(TrueV)		
(kcps) (3D)						
Scatter	31	30	<36	<36	36	38
fraction (%)						

<sup>a</sup> Reprinted with permission, Copyright 2009, ECRI institute, http://www.ecri.org, 5200 Butler Pike, Plymouth Meeting, PA 19462. 610-825-6000

<sup>b</sup> Data supplied by Philips Healthcare, USA

<sup>c</sup> Reprinted with permission, Copyright 2009, Imaging Technology News (http://www.itonline. net), Scranton Gillette Communications (http://www.scrantongillete.com) 3030 w. Salt Creek Lane, Suite 201, Arlington Heights, IL 60005-5025. Some of Siemens data were provided by Annemarie Grammens, Siemens Medical Solutions, USA

In whole-body scanners, the detector elements are normally large and therefore,  $R_i(d \text{ or } d/2)$  is large so that the contribution of  $R_p$  is negligible for <sup>18</sup>F-FDG ( $E_{\beta+,\max} = 0.64 \text{ MeV}$ ) whole body imaging. For <sup>18</sup>F-FDG studies using a 90-cm diameter PET scanner with 6 mm detectors,  $R_a \sim 2 \text{ mm}$ , and assuming  $R_p = 0$ ,  $R_\ell = 2.2 \text{ mm}$  and  $K_r = 1.5$ ,  $R_t = 1.5 \times \sqrt{3^2 + (2.2)^2 + 2^2} =$ 6.3 mm at the center of FOV and  $R_t = 1.5 \times \sqrt{6^2 + (2.2)^2 + 2^2} = 10.0 \text{ mm}$ at the edge of FOV of the scanner. However, the contribution of  $R_p$  may be appreciable for high-energy positron emitters (e.g., <sup>82</sup>Rb;  $E_{\beta+,\max} =$ 3.35 MeV) and small animal PET scanners (e.g., microPET system) having smaller detectors.

The detailed method of measuring the spatial resolution of a PET scanner is given later in this chapter. The spatial resolutions of PET scanners from different manufacturers are given in Table 6.1.
### Sensitivity

The sensitivity of a PET scanner is defined as the number of counts per unit time detected by the device for each unit of activity present in a source. It is normally expressed in counts per second per microcurie (or megabecquerel) (cps/ $\mu$ Ci or cps/kBq). Sensitivity depends on the geometric efficiency, detection efficiency, PHA window settings, and the dead time of the system. The detection efficiency of a detector depends on the scintillation decay time, density, atomic number, and thickness of the detector material that have been discussed in Chap.2. Also, the effect of PHA window setting on detection efficiency has been discussed in Chap.2. The effect of the dead time on detection efficiency has been described in Chap.3. In the section below, only the effects of geometric efficiency and other related factors will be discussed.

The geometric efficiency of a PET scanner is defined by the solid angle projected by the source of activity at the detector. The geometric factor depends on the distance between the source and the detector, the diameter of the ring and the number of detectors in the ring. Increasing the distance between the detector and the source reduces the solid angle and thus decreases the geometric efficiency of the scanner and vice versa. Increasing the diameter of the ring decreases the solid angle subtended by the source at the detector, thus reducing the geometric efficiency and in turn the sensitivity. Also the sensitivity increases with increasing number of rings in the scanner.

Based on the above factors discussed, the sensitivity *S* of a single ring PET scanner can be expressed as (Budinger, 1998):

$$S = \frac{A \cdot \varepsilon^2 \cdot e^{-\mu t} \cdot 3.7 \times 10^4}{4\pi r^2} (\text{cps}/\mu\text{Ci}), \qquad (6.3)$$

where A = detector area seen by a point source to be imaged,  $\varepsilon =$  detector's efficiency,  $\mu$  is the linear attenuation coefficient of 511 keV photons in the detector material, t is the thickness of the detector, and r is the radius of the detector ring. The proportionality to  $\varepsilon^2$  arises from the two detectors with efficiency  $\varepsilon$ , i.e.,  $\varepsilon \times \varepsilon$ . So if the single detector efficiency is reduced by half, the coincidence detection efficiency is  $\varepsilon/2 \times \varepsilon/2 = \varepsilon^2/4$ .

Equation (6.3) is valid for a point source at the center of a single ring scanner. For an extended source at the center of such scanners, it has been shown that the geometric efficiency is approximated as w/2r, where w is the axial width of the detector element and r is the radius of the ring (Cherry et al, 2003). Thus the sensitivity of a scanner is highest at the center of the axial FOV and gradually decreases toward the periphery. In typical PET scanners, there are also multiple rings and each detector is connected in coincidence with as many as half the number of detectors on the opposite side in the same ring as well as with detectors in other rings. Thus the sensitivity of multiring scanners will increase with the number of rings.

Note that the sensitivity of a PET scanner increases as the square of the detector efficiency, which depends on the scintillation decay time and stopping power of the detector. This is why LSO, LYSO and GSO detectors are preferred to NaI(Tl) or BGO detectors (see Table 2.1). In 2D acquisitions, system sensitivity is compromised because of the use of septa between detector rings, whereas these septa are retracted or absent in 3D acquisition, and hence the sensitivity is increased by a factor of 4–8. However, in 3D mode, random and scatter coincidences increase significantly, the scatter fraction being 30–40% compared to 15–20% in 2D mode. The overall sensitivities of PET scanners for a small-volume source of activity are about 0.2–0.5% for 2D acquisition and about 2–10% for 3D acquisition, compared to 0.01–0.03% for SPECT studies (Cherry et al, 2003). The greater sensitivity of the PET scanner results from the absence of collimators in data acquisition.

Sensitivity is given by volume sensitivity expressed in units of  $kcps/\mu Ci/cc$  or cps/Bq/cc. It is determined by acquiring data in all projections for a given duration from a volume of activity (uniformly mixed) and dividing the total counts by the duration of counting and by the concentration of the activity in the source. Manufacturers normally use this unit as a specification for the PET scanners. The detailed method of determining volume sensitivity is described under acceptance tests in this chapter. The volume sensitivities of PET scanners from different manufacturers are given in Table 6.1.

#### Noise Equivalent Count Rate

Image noise is the random variation in pixel counts across the image and is given by  $(1/\sqrt{N}) \times 100$ , whose N is the counts in the pixel. It can be reduced by increasing the total counts in the image. More counts can be obtained by imaging for a longer period, injecting more radiopharmaceutical, or improving the detection efficiency of the scanner. All these factors are limited by various conditions, e.g., too much activity cannot be administered because of increased radiation dose to the patient, random coincidence counts, and dead time loss. Imaging for a longer period may be uncomfortable to the patient and improving the detection efficiency may be limited by the design of the imaging device.

The image noise is characterized by a parameter called the noise equivalent count rate (*NECR*) which is given by

$$NECR = \frac{T^2}{T + S + R},\tag{6.4}$$

where T, R, and S are the true, random, and scatter coincidence count rates, respectively. This value is obtained by using a 20-cm cylindrical phantom of uniform activity placed at the center of the FOV and measuring prompt coincidence counts. Scatter and random events are measured according to

methods described later in this chapter. The true events (T) are determined by subtracting scatter (S) and random (R) events from the prompt events. From the knowledge of T, R, and S, the NECR is calculated by Eq. (6.4). The NECR is proportional to the signal-to-noise (SNR) ratio in the final reconstructed images and, therefore, serves as a good parameter to compare the performances of different PET scanners. The 3D method has a higher NECR at low activity. However, the peak NECR in the 2D mode is higher than the peak NECR in the 3D mode at higher activity. Image noise can be minimized by maximizing NECR.

Another type of image noise arises from nonrandom or systematic addition of counts due to imaging devices or procedural artifacts. For example, bladder uptake of <sup>18</sup>F-FDG may obscure the lesions in the pelvic area. Various "streak" type artifacts introduced during reconstruction may be present as noise in the image.

### Scatter Fraction

The scatter fraction (SF) is another parameter that is often used to compare the performances of different PET scanners. It is given by

$$SF = \frac{C_{\rm s}}{C_{\rm p}},\tag{6.5}$$

where  $C_s$  and  $C_p$  are the scattered and prompt count rates. The lower the *SF* value, the better the performance of a scanner and better the quality of images. The method of determining *SF* is given later in this chapter. Comparative *SF* values for different PET scanners are given in Table 6.1.

# Contrast

Contrast of an image arises from the relative variations in count densities between adjacent areas in the image of an object. Contrast (C) gives a measure of the detectability of an abnormality relative to normal tissue and is expressed as

$$C = \frac{A - B}{A},\tag{6.6}$$

where A and B are the count densities recorded in the normal and abnormal tissues, respectively.

Several factors affect the contrast of an image, namely: count density, scattered radiations, type of film, size of the lesion, and patient motion. Each contributes to the contrast to a varying degree. These factors are briefly discussed here. Statistical variations of the count rates give rise to noise that increases with decreasing information density or count density (counts/cm<sup>2</sup>), and are given by  $(1/\sqrt{N}) \times 100$ , where N is the count density. For a given image, a minimum number of counts are needed for a reasonable image contrast. Even with adequate spatial resolution of the scanner, lack of sufficient counts may give rise to poor contrast due to increased noise, so much so that lesions may be missed. This count density in a given tissue depends on the administered dosage of the radiopharmaceutical, uptake by the tissue, length of scanning, and the detection efficiency of the scanner. The activity of a dosage, scanning for a longer period, and the efficiency of a scanner are optimally limited, as discussed above under *NECR*. The uptake of the tracer depends on the pathophysiology of the tissue in question. Optimum values for a procedure are obtained from the compromise of these factors.

Background in the image increases with scattered radiations and thus adds to degradation of the image contrast. Maximum scatter radiations arise from the patient. Narrow PHA window settings can reduce the scatter radiations, but at the same time the counting efficiency is reduced.

Image contrast to delineate a lesion depends on its size relative to system resolution and its surrounding background. Unless a minimum size of a lesion develops larger than system resolution, contrast may not be sufficient to appreciate the lesion, even at higher count density. The effect of lesion size depends on the background activity surrounding it and on whether it is a "cold" or "hot" lesion. A relatively small-size "hot" lesion is easily well contrasted against a lower background, whereas a small-size "cold" lesion may be missed against the surrounding tissue of increased activities.

Film contrast is a component of overall image contrast and depends on the type of film used. The density response characteristics of X-ray films are superior to those of Polaroid films and provide the greatest film contrast, thus adding to the overall contrast. Developing and processing of exposed films may add artifacts to the image and, therefore, should be carried out carefully.

Patient motion during imaging reduces the image contrast. This primarily results from the overlapping of normal and abnormal areas due to movement of the organ. It is partly alleviated by restraining the patient or by having him in a comfortable position. Artifacts due to heart motion can be reduced by using the gated technique. Similarly, breath holding may improve the thoracic images.

### Quality Control of PET Scanners

In the image formation of an object using PET scanners, several parameters related to the scanners play a very important role. To ensure high quality of images, several quality control tests must be performed routinely on the scanner. The frequency of these tests is either daily or weekly, or even at a longer interval depending on the type of parameter to be evaluated.

# Daily Quality Control Tests

*Sinogram (uniformity) check*: Sinograms are obtained daily using a long-lived <sup>68</sup>Ge or <sup>137</sup>Cs source mounted by brackets on the gantry and rotating it around the scan field without any object in the scanner. It can also be done by using a standard phantom containing a positron emitter at the center of the scanner. All detectors are uniformly exposed to radiations to produce homogeneous detector response and hence a uniform sinogram. A malfunctioning detector pair will appear as a streak in the sinogram.

Typically, the daily acquired blank sinogram is compared with a reference blank sinogram obtained during the last setup of the scanner. The difference between the two sinograms is characterized by the value of the so-called average variance, which is a sensitive indicator of various detector problems. It is expressed by the square sum of the differences of the relative crystal efficiencies between the two scans weighted by the inverse variances of the differences. The sum divided by the total number of crystals is the average variance. It is essentially a  $\chi^2$  value. If the average variance exceeds 2.5, recalibration of the PET scanner is recommended, whereas for values higher than 5.0, the manufacturer's service is warranted (Buchert et al, 1999). In Fig. 3.4, the average variance between the two scans is 1.1, indicating all detectors are working properly.

### Weekly Quality Control Tests

In the weekly protocol, system calibration and plane efficiency are performed by using a uniform standard phantom filled with radioactivity, and normalization is carried out by using a long-lived radionuclide rotating around the field of view or a standard phantom with radioactivity placed at the center of the scanner.

*System Calibration*: A system calibration scan is obtained by placing the standard phantom containing a positron emitter in a phantom holder at the center of the FOV for uniform attenuation and exposure. The reconstructed images are checked for any nonuniformity. A bad detector indicates a decreased activity in the image, and warrants the adjustment of PM tube voltage and the discriminator settings of PHA.

*Normalization*: As discussed in Chap. 3, normalization corrects for nonuniformities in images due to variations in the gain of PM tubes, location of the detector in the block and the physical variation of the detector. This test is carried out by using a rotating rod source of a long-lived radionuclide (normally <sup>68</sup>Ge) mounted on the gantry parallel to the axis of the scanner or using a standard phantom containing a positron-emitter at the center of the scanner. The activity used in the source is usually low to avoid dead time loss. Data are acquired in the absence of any object in the FOV. This exposes all detectors uniformly. The multiplication factor for each detector is calculated by dividing the average of counts of all detector pairs by each individual

detector pair count (i.e., along the LOR) (Eq. 3.3). These factors are saved and later applied to the corresponding detector pairs in the acquired emission data of the patient (Eq. 3.4). Normalization factors normally are determined weekly or monthly. To have better statistical accuracy in individual detector pair counts, several hours of counting is necessary depending on the type of scanner, and therefore, overnight acquisition of data is often made.

Dose calibration of PET scanner: Standard uptake values (SUV) and other parameters of PET images are often calculated that require the knowledge of absolute activity in regions of interest (ROI). The counts (corrected for randoms, dead time, scatter and attenuation) in individual pixels of the ROI are converted to absolute activity by using calibration factors. To calculate the calibration factor, *CF*, a cylindrical phantom (normally 20 cm long and 20 cm in diameter) containing a known amount of positron-emitter activity (e.g.,  ${}^{68}$ Ge or  ${}^{18}$ F) in a known volume is scanned, and an image is obtained. The calculated concentration of activity is given by

$$A_{\rm cal} = \frac{A}{V} \times N \times \exp[-0.693 t/t_{1/2}], \tag{6.7}$$

where A is the activity (Bq or  $\mu Ci$ ) in the phantom measured in a dose calibrator, V is the volume of the phantom (ml), N is the branching ratio of positron decay of the radionuclide, and t is the time delay from initial measurement to the start of the scan, and  $t_{1/2}$  is the half-life of the radionuclide used. Some investigators determine the activity by measuring an aliquot of the sample in a well counter whose counting efficiency is known.

Images are reconstructed using the scan data of the phantom after correction for scatter, randoms and attenuation. Using a large ROI on each of the central image slices, the mean ROI activity (*Bq/pixel or \muCi/pixel*) for each slice is calculated, from which an average measured activity *A*<sub>measured</sub> is calculated using the ROIs of all slices. The calibration factor *CF* is then given by

$$CF = \frac{A_{\text{measured}}}{A_{\text{cal}}}.$$
 (6.8)

CF is applied to the measured activity in the ROI of interest of the patient scan to calculate the absolute activity in the ROI that is used in the calculation of SUV. Note that if the radionuclide in the patient study is different from the calibration source radionuclide, the branching ratio Nof the radionuclide must be taken into calculation. This calibration of PET scanners should be performed at installation, after major service or at least annually.



FIGURE 6.3. NEMA phantoms for PET performance tests. (a) This NEMA body phantom is used for evaluation of the quality of reconstructed images and simulation of whole body imaging using camera-based coincidence imaging technique. (b) This phantom is used for measuring scatter fraction, dead time, and random counts in PET studies using the NEMA NU 2-2007 standard, (c) Close up end of the sensitivity phantom, (d) Set of six concentric aluminum tubes used in phantom (c) to measure the sensitivity of PET scanners. (Courtesy of Data Spectrum Corporation, Hillborough, NC)

### Acceptance Tests for PET Scanners

Acceptance tests are a battery of quality control tests performed to verify various parameters specified by the manufacturer for a PET scanner. These are essentially carried out soon after a PET scanner is installed in order to establish the compliance of specifications of the device. The most common and important specifications are transverse radial, transverse tangential, and axial resolutions; sensitivity; scatter fraction; and count rate performance. It is essential to have a standard for performing these tests so that a meaningful comparison of scanners from different manufacturers can be made.

In 1991, the Society of Nuclear Medicine (SNM) established a set of standards for these tests for PET scanners (Karp et al, 1991). Afterward, in 1994, the National Electrical Manufacturers Association (NEMA) published a document, NU 2-1994, recommending improved standards for performing these tests, using a  $20 \times 19$  cm phantom (NEMA, 1994) (Fig. 6.3a). This phantom is useful for earlier scanners, in which the axial FOV is less than 17 cm and data are acquired in 2D mode, because of the use of septa. Modern wholebody PET scanners have axial FOVs as large as 25 cm, and employ 3D data acquisition in the absence of septa. The coincidence gamma cameras have typical FOVs of 30–40 cm. Because of larger FOVs and high count rates in 3D mode, the NU 2-1994 phantom may not be accurately applied for some tests in some scanners, and a new NU 2-2001 standard has been published by NEMA in 2001 (NEMA, 2001) and corresponding new phantoms have been introduced. Currently most PET scanners use the LSO or LYSO detectors composed of natural lutetium (Lu) that has a 2.6% radioisotopic content of <sup>176</sup>Lu ( $t_{1/2} = 4.0 \times 10^{10}$  years). This isotope emits  $\beta^-$  particle and a cascade of high energy  $\gamma$  and X-rays. These intrinsic radiations cause errors in the performance parameters of a scanner such as the sensitivity, count losses, random events, etc. To correct for the contribution of this intrinsic activity, Watson et al (2004) have recommended modifications in the performance tests and accordingly, NEMA has introduced the NEMA NU 2-2007 (2007) standard for these tests of PET scanners with Lu-based detectors. Many features of this standard have been kept the same as those of the NU 2-2001 standard, with some modifications for the sensitivity, count losses, and random events. No publication using this model for validation of commercial PET scanners has been reported in the literature as of this writing. Daube-Witherspoon et al (2002) reported the methods of performing these tests based on the NEMA NU2-2001 standard. The following is a brief description of these tests based on this article and the article of Watson et al (2004), and NEMA NU2-2007 standard has been alluded to, wherever needed. Refer to these publications for further details.

# Spatial Resolution

The spatial resolution of a PET scanner is determined by the FWHM of pointspread-functions (PSF) obtained from measurement of activity distribution from a point source. The spatial resolution can be transverse radial, transverse tangential, and axial, and these values are given in Table 6.1 for scanners from different manufacturers.

The spatial resolution is measured by using six point sources of <sup>18</sup>F activity contained in glass capillary in a small volume of less than 1 cc (Daube-Witherspoon et al, 2002). For axial resolutions, two positions – at the center of the axial FOV and at one-fourth of axial FOV – are chosen (Fig. 6.4). At each axial position, three point sources are placed at x = 0, y = 1 cm (to avoid too many sampling of LORs), x = 10 cm, y = 0, and x = 0, y = 10 cm. Data are collected for all six positions and from reconstructed image data, PSFs are obtained in X, Y, and Z directions for each point source at each axial position. The FWHMs are determined from the width at 50% of the peak of each PSF, totaling 18 in number. Related FWHMs are combined and then averaged for the two axial positions to give the transverse radial, transverse tangential and axial resolutions. Transverse resolution worsens as the source is moved away from the center of the FOV (Fig. 6.5), i.e., the resolution is best at the center and deteriorates toward the periphery of the scanner.

# Scatter Fraction

Scattered radiations add noise to the reconstructed image, and the contribution varies with different PET scanners. Normally the test is performed with a



FIGURE 6.4. Arrangement of six-point sources in the measurement of spatial resolution. Three sources are positioned at the center of the axial FOV and three sources are positioned at one-fourth of the axial FOB away from the center. At each position, sources are placed on the positions indicated in a transverse plane perpendicular to the scanner axis. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup> 2009. All Rights Reserved)

very high activity source counted over a period of time, from which high activity data are used for determination of random events and count losses (see later) and low activity data for scatter fraction. A narrow line source made of 70-cm-long plastic tubing and filled with high activity of <sup>18</sup>F is inserted into a 70 × 20 cm cylindrical polyethylene phantom through an axial hole made at a radial distance of 4.5 cm and parallel to the central axis of the phantom (Fig. 6.3b). The phantom is placed at the center both axially and radially on the scan table such that the source is closest to the patient table, since the line source and the bed position affect the measured results.

Data acquisition is recommended in two ways based on whether random events are estimated separately for scanners with Lu-based detectors or they are assumed negligible as in scanners with non-Lu detectors. If the random events are to be estimated independently for Lu-based scanners, then data are acquired over time using two windows – a peak window and a delayed window until both dead time count losses and random events are reduced to less than 1% of the true rates. For PET scanners with non-Lu detectors, data acquisition is continued with only a peak window until the random-to-true ratio is less than 1% (NEMA, 2007). The data are used to form both random and prompt sinograms, which are basically 2D representation of projection rays versus angle. Oblique projections are assigned to the slice where they cross the scanner axis using single slice rebinning. The sinogram profile of an extended diameter of 24 cm (4 cm larger than the phantom) is generated, because the FOV varies with different scanners. Each projection in the sinogram is shifted so that the peak of the projection is aligned with the center



FIGURE 6.5. Point spread functions (PSF) at 0 and 10 cm from the FOV. The transverse resolution (FWHM) is best at the center and worsens radially across the FOV. (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup> 2009. All Rights Reserved)

of the sinogram (line source image). This produces a sum projection with a counts density distribution around the maximum counts (peak) at the center of the sinogram (NEMA, 2001, 2007). It is arbitrarily assumed that all true events including some scatter lie within a 4-cm-wide strip centered in each sinogram of the line source and that there are no true events but scatter events beyond  $\pm 2$  cm from the center of the sinogram. Thus the total count  $C_{\rm T}$  is the area under the peak in prompt sinogram that includes true events plus scatter and random events. In the case of PET scanners with non-Lu detectors,  $C_{\rm T}$  will contain only the true plus scatter events.

For Lu-based PET scanners, random counts are estimated from the delayed window sinograms for all projections in a slice to give  $C_R$  for the slice, which is then applied to calculate true and scatter events. For non-Lu scanners, random events are negligible and not measured separately.

Scattered events under the peak are estimated by taking the average of the pixel counts at  $\pm 2 \text{ cm}$  positions from the center, multiplying the average by the number of pixels (obtained by interpolation) along the 4-cm strip and finally adding the product to the counts in pixels outside the strip. This gives total scatter events ( $C_S$ ) for the slice. Using the values of  $C_T$ ,  $C_R$ , and  $C_S$ , the true count for a slice is calculated as

$$C_{\rm true} = C_{\rm T} - C_{\rm R} - C_{\rm S} \tag{6.9}$$

and for PET scanners with non-LSO detectors, the true count is

$$C_{\rm true} = C_{\rm T} - C_{\rm S}. \tag{6.10}$$

The scatter fraction  $SF_i$  for the slice is given by Eq. (5.5) as

$$SF_i = C_S / (C_{True} + C_S).$$
(6.11)

The system scatter fraction SF is calculated from the weighted average of the  $SF_i$  values of all slices. These values are given in Table 6.1 for several PET scanners.

Note that counting rates for each component are calculated by dividing the respective counts by time of acquisition to give total count rate  $R_{\rm T}$ , true count rate  $R_{\rm True}$ , random count rate  $R_{\rm R}$ , and scatter count rate  $R_{\rm S}$ .

### Sensitivity

Sensitivity is a measure of counting efficiency of a PET scanner and is expressed in count rate (normally, cps) per unit activity concentration (normally, MBq or  $\mu$ Ci per cc).

According to NEMA NU 2-2001 and NEMA NU 2-2007 standards, a 70-cm-long plastic tube filled with a known amount  $(A_{cal})$  of a radionuclide is used (Fig. 6.3c, d) (Daube-Witherspoon et al, 2002). The level of activity is kept low so as to have random rate less than 5% of the true counts and count loss less than 1%. The source is encased in metal sleeves of various thicknesses and suspended at the center of the transverse FOV in parallel to the axis of the scanner in such a way that the supporting unit stays outside the FOV.

Successive data are collected in sinograms using five metal sleeves. Duration of acquisition and total counts in the slice are recorded for each sleeve, from which the count rate is calculated. Count rates are corrected for decay to the time of calibration of radioactivity and then summed for all slices to give the total count rate for each sleeve. Next, the natural logarithm of the measured total count rate ( $R_T$ ) is plotted as function of sleeve thicknesses. After fitting of the data by linear regression, the extrapolated count rate ( $R_0$ ) with no metal sleeve (no attenuation) is obtained. For non-Lu scanners, the random rate ( $R_R = C_R/T_{acquisition}$ ) is negligible. Scatter count rate determined by the method described previously is subtracted from  $R_0$  to give the true count rate ( $R_{true}$ ) for the system. Thus,

$$R_{\rm true} = R_0 - R_{\rm S}.$$
 (6.12)

For Lu-based scanners, there is an intrinsic activity as well as possible intrinsic random events due to  $^{176}$ Lu, which need to be subtracted from the total count rate. These can be measured with the plastic tubing in place in the scanner but without any activity in it. Both prompt and delayed acquisitions are made of the tubing as described in section on Scatter Fraction, from which intrinsic prompt rate and intrinsic random rate are calculated. The true intrinsic count rate  $R_{int}$  is obtained by subtracting the random rate from the prompt rate in all sinograms. Thus, for Lu-based scanners, true count rate  $R_{true}$  is given as

$$R_{\rm true} = R_0 - R_{\rm S} - R_{\rm R} - R_{\rm int}.$$
 (6.13)

The system sensitivity is calculated as

$$S = R_{\rm true}/A_{\rm cal},\tag{6.14}$$

where  $A_{cal}$  is the calibrated activity added to the tubing. The sensitivity is given in either  $cps/\mu Ci/cc$  or cps/kBq/cc. The measurement of sensitivity is repeated with the source placed radially at 10 cm from the center of the transverse FOV. The system sensitivity of commercial PET scanners is given for both 0 and 10 cm positions and the values for some scanners at the center of FOV are given in Table 6.1.

#### Count Rate Losses and Random Coincidences

To characterize the count rate behavior of a PET scanner at high activity, random events, *NECR*, and dead time loss are determined as a function of activity. The activity source is the same as described above under Scatter Fraction in this chapter. A high activity source of <sup>18</sup>F is used to acquire the sinogram and data are collected until the activity level is low enough to consider random events and dead time count losses to be negligible. The total counts are obtained from each high activity sinogram, which comprise true, random, and scatter events. The total count rate  $R_{\rm T}$  is obtained by dividing the total counts by the duration of acquisition. As in scatter fraction experiment, the low activity data are used to calculate the scatter fraction  $SF_i$  and the true count rate  $R_{\rm true}$  for each slice Eqs. (6.9–6.11). The random count rate  $R_{\rm R}$  at high activity acquisition for each slice is then calculated by (Daube-Witherspoon et al 2002),

$$R_{\rm R} = R_{\rm T} - [R_{\rm true}/(1 - SF_i)].$$
(6.15)

The system random count rate is calculated by summing  $R_{\rm R}$  values for all slices.

The NECR for each slice is computed by Eq. (6.4) as

$$(\text{NECR}) = (R_{\text{true}})^2 / R_{\text{T}}.$$
 (6.16)

The system *NECR* is computed as the sum of *NECR*s for all slices. These values for some PET scanners are shown in Table 6.1.

The percent dead time count loss (% DT) as function of activity is calculated by

$$\% DT = (1 - R_{\text{true}} / R_{\text{extrap}}) \times 100,$$
 (6.17)

where  $R_{\text{extrap}}$  is the count rate extrapolated from the low activity data to the activity at the time when the total count rate  $R_{\text{T}}$  is measured.

### Quality Control of CT Scanners

Like PET scanners, CT scanners need daily QC testing to check if they are performing within acceptable limits of operational parameters. Most of the daily tests are automatic and less rigorous. These tests include tube voltage, mA setting and detector response, which are available as system-ready messages. Operator-based daily QC tests include the evaluation of image uniformity, accuracy of CT numbers of water (given in Hounsfield unit HU), tube voltage, and image noise measured at commonly used voltages. The uniformity is assessed by observing the display of a CT image of a phantom. Water CT numbers and standard deviations are measured by using a water phantom in the scan plane and should be within  $0 \pm 5$  HU. All these measurements are mostly menu-driven initiated by the manufacturers' software, and the final result is often given in the form of PASS/FAIL display. Other parameters such as slice thickness, spatial resolution, contrast resolution, linearity, and laser alignment are assessed monthly or quarterly as recommended by the manufacturers.

An important parameter, CT dose index (*CTDI*, defined as the cumulative dose along the patient's axis for a single tomographic image), should be evaluated at least semiannually at different values of kVp and mA. It is measured by using an ionization chamber or a thermoluminescent dosimeters placed in a tissue-equivalent acrylic phantom simulating head or body. ACR (2007) recommends maximum doses (*CTDI*) of 6 rad (60 mGy) for brain, 3.5 rad (35 mGy) for adult abdomen and 2.5 rad (25 mGy) for pediatric (5-year-old) abdomen. The details of these measurements are available in standard CT physics books.

# Questions

- 1. The typical transaxial resolution at 1 cm of a PET scanner ranges between (a) 14 and 16 mm (b) 3 and 4 cm (c) 4 and 7 mm.
- 2. What are the common factors that affect the spatial resolution of a PET scanner? Out of these, which one is most predominant?
- 3. The transverse resolution is worse at the center of the FOV than away from the center. True \_\_\_\_\_; False \_\_\_\_\_.
- 4. The axial resolution of a scanner is its ability to differentiate two points on an image along the axis of the scanner. True \_\_\_\_\_; False \_\_\_\_\_.
- 5. If the detector size is 8 mm, what is the expected approximate spatial resolution for <sup>18</sup>F-FDG PET images at the center of the FOV?
- 6. The maximum positron energy for <sup>18</sup>F is 0.64 MeV and for <sup>82</sup>Rb is 3.35 MeV. Which radiopharmaceutical would provide better spatial resolution?
- 7. Noncolinearity is a factor that affects the spatial resolution of a PET scanner. How is it affected by the diameter of the detector ring? For a 90-cm diameter detector ring, what is the value of the noncolinearity component in the overall spatial resolution?
- 8. Describe the method of measuring transverse radial, transverse tangential, and axial spatial resolutions of a PET scanner.
- 9. Define the sensitivity of a PET scanner and discuss the important parameters that affect the sensitivity.
- 10. Scanner 1 has twice the ring diameter of scanner 2. The ratio of sensitivities of scanner 1 to scanner 2 is:
  - (a) 0.75
  - (b) 0.67
  - (c) 0.25
- 11. The sensitivity in 3D acquisition is four to eight times higher than in 2D acquisition. Why?
- 12. The overall sensitivities of PET scanners in 2D mode are:
  - (a) 1–2%
  - (b) 3–5%
  - (c) 0.2–0.5%
  - and in 3D mode:
  - (a) 2–10%
  - (b) 0.5–1%
  - (c) 15–20%
- 13. Scanner 1 has the detectors of size 3 mm, and scanner 2 has the detectors of size 6 mm. Assuming that all detectors are squares and all other parameters are the same, the sensitivity of scanner 1 is: (a) half; (b) one-tenth; or (c) one-fourth of scanner 2.
- 14. Describe the methods of daily and weekly quality control tests for PET and CT scanners.

- 15. Explain why and how normalization of PET acquisition data is carried out.
- 16. What are acceptance tests? Describe the methods of determining sensitivity and scatter fraction for a PET scanner.
- 17. The noise equivalent count rate (*NECR*) is proportional to the signal-tonoise in the reconstructed image. True \_\_\_\_\_; False \_\_\_\_\_.
- The sensitivity of a scanner increases with (a) the size of the detector in the ring True \_\_\_\_\_; False \_\_\_\_\_; (b) with the diameter of the detector ring True \_\_\_\_\_; False \_\_\_\_\_.
- 19. Scanner 1 has the individual detector size of 36 mm<sup>2</sup> and scanner 2 has the detector size of 60 mm<sup>2</sup>. Scanner 1 has (a) 30%; (b) 60%; (c) 1.7 times the sensitivity of scanner 2.
- 20. Define contrast of an image. Elucidate the different factors that affect the contrast.
- 21. Increasing administered activity increases the spatial resolution: True \_\_\_\_\_; False \_\_\_\_\_.
- 22. Increasing administered activity increases the contrast resolution: True \_\_\_\_\_; False \_\_\_\_\_.
- The daily QC check of CT scanner includes (a) laser alignment; (b) CT number of water; (c) tomographic uniformity; (d) tomographic image noise.

# References and Suggested Reading

ACR (2007). CT Accreditation Program Requirements

- Brix G, Zaers J, Adam LE et al (1997). Performance evaluation of a whole-body PET scanner using the NEMA protocol. J Nucl Med 38:1614
- Buchert R, Bohuslavizki UH, Mester J et al (1999). Quality assurance in PET: evaluation of the clinical relevance of detector defects. J Nucl Med 40:1657
- Budinger TF (1998). PET instrumentation: what are the limits? Semin Nucl Med 28:247
- Cherry SR, Sorensen JA, Phelps ME (2003). Physics in Nuclear Medicine. 3rd ed. Saunders, Philadelphia
- Daube-Witherspoon ME, Karp JS, Casey ME et al (2002). PET performance measurement using the NEMA NU 2-2001 standard. J Nucl Med 43:1398
- Huesman RH (1977). The effects of a finite number of projection angles and finite lateral sampling of projections on the propagation of statistical errors in transverse section reconstruction. Phys Med Biol 22:511
- Karp JS, Daube-Witherspoon ME, Hoffman EJ et al (1991). Performance standards in positron emission tomography. J Nucl Med 32:2342
- Kearfott K (1989). Sinograms and diagnostic tools for the quality assurance of a positron emission tomograph. J Nucl Med Technol 17:83
- Keim P (1994). An overview of PET quality assurance procedures: part 1. J Nucl Med Technol 22:27
- Moses WW, Derenzo SE (1993). Empirical observation of performance degradation in positron emission tomographs utilizing block detectors. J Nucl Med 34:101P

- National Electrical Manufacturers Association (1994). NEMA Standards Publications NU 2-1994. Performance measurements of positron emission tomographs, National Electrical Manufacturers Association, Washington DC
- National Electrical Manufacturers Association (2001). NEMA Standard Publication NU 2-2001. Performance measurements of positron emission tomographs, National Electrical Manufacturers Association, Rosslyn, VA
- National Electrical Manufacturers Association (2007). NEMA Standard Publication NU 2-2007. Performance measurements of positron emission tomographs, National Electrical Manufacturers Association, Rosslyn, VA
- Tarantola G, Zito F, Gerundini P (2003). PET instrumentation and reconstruction algorithms in whole-body applications. J Nucl Med 44:756
- Watson CC, Casey ME, Eriksonn L et al (2004). NEMA NU2 performance tests for scanners with intrinsic activity. J Nucl Med 45:822
- Zanzonico P (2008). Routine quality control of clinical nuclear medicine instrumentation: a brief review. J Nucl Med 49:1114

# 7 Cyclotron and Production of PET Radionuclides

More than 3,000 nuclides are known, of which approximately 270 are stable and the remainder are radioactive. The majority of radionuclides are artificially produced in the cyclotron and reactor. In PET technology, only positron-emitting radionuclides are required, and only a few positron emitters of all radionuclides have been suitably utilized in the clinical studies. These radionuclides include <sup>11</sup>C, <sup>13</sup>N, <sup>18</sup>F, <sup>15</sup>O, etc., and are produced in the cyclotron. The operation of a cyclotron and the production of useful positron emitters are described below.

# Cyclotron Operation

In a cyclotron (Fig. 7.1), charged particles (S) are accelerated in circular paths within the two D-shaped hollow metallic electrodes called the *dees* (A and B) under vacuum by means of an electromagnetic field. Charged particles can be either positive ions (e.g., proton, deuteron,  $\alpha$  particle) or negative ions (e.g., negatively charged hydrogen atom, H<sup>-</sup>. The following is a description of a cyclotron to accelerate H<sup>-</sup> particles (negative ion cyclotrons).

The ions are obtained from an ion source (S) positioned at the center of the cyclotron. The ion source is a small chamber located between two negative high-voltage (V) (1-3kV) tantalum cathodes. The hydrogen gas flows (4–10 mL/min) into the chamber. Electrons emitted from the cathodes and constrained by the magnetic field of the main magnet interact with the hydrogen atoms to form a plasma in the chamber that consists of three entities: protons, negatively charged hydrogen atoms H<sup>-</sup>, and neutral hydrogen atoms. In some cyclotrons, the gas is ionized by applying 20 kV DC, producing proton and H<sup>-</sup>. Protons or negative hydrogen ions (H<sup>-</sup>) are pulled out of the ion source chamber through a narrow slit by the electrostatic force depending on the polarity of the dees.

The two dees (A and B) are half-pie-shaped, troughlike, hollow copper structures connected to an alternating high-voltage (30 kV) oscillator operating at radiofrequencies of 20–30 MHz and are positioned between the two



FIGURE 7.1. A schematic illustration of a cyclotron: V alternating voltage, S ion source, A and B dees under vacuum, D carbon foil stripper, W window.

poles of an electromagnet. In some cyclotrons, there are four dees, which look like a quarter of a pie. The inside of the dees is kept at extremely high vacuum  $(10^{-6} \text{ mtorr for positive ions and } 10^{-7} \text{ mtorr for negative ions})$ . Since H<sup>-</sup> can lose its electrons on interaction with any molecule inside the dee, such high vacuum is essential in negative ion cyclotrons, which is tenfold higher than in positive ion cyclotrons. Charged ions are attracted toward a dee with an opposite charge during the cycle of oscillating radiofrequency voltage waveforms and pass into the hollow dee. While in the dee, ions do not experience any electrical field, but are subjected to a magnetic field provided by a large electromagnet (up to 2 tesla). Under the magnetic field, the path of the ions bends such that as the ions reach the edge of the dee, the polarity of the dee is changed. At this moment, the ions are repelled by the dee and also attracted toward the opposite dee, thus gaining more kinetic energy to accelerate. The radiofrequency is so synchronized that every time the ions cross the dee intersection, the polarity of the dee is changed and the ions gain energy and travel in a larger trajectory in the dee. For a particular cyclotron, the energy of the ions depends on the radius of the cyclotron, magnetic field and charge and mass of the ion. Thus, the kinetic energy (K.E.) of the ion is given by

$$K.E. = \frac{(qMr)^2}{2m},\tag{7.1}$$

where q is the charge of the particle, M is the magnetic field in gauss, r is the radius of the cyclotron, and m is the mass of the particle.

Since negative  $H^-$  ions do not interact with the nuclei of the target and positive ions do, a 2- to 5-µm-thick and <4 cm in diameter carbon foil (D) is inserted vertically inside the cyclotron just ahead of the target position to strip two electrons to produce positive ions (i.e., protons), which then can cause

nuclear reactions in target nuclei. The carbon foils are loaded in a carousel, and multiple such carousels (e.g., 2-6) are placed in appropriate locations near the exit inside the cyclotron. The carousels are spinned under computer control providing multiple beam lines as needed. The negative ion cyclotron offers the scope of dual bombardments where two targets can be irradiated simultaneously. A carousel containing the carbon stripping foil is inserted in the path of the beam in such a way that only a part of the beam passes through it producing a positive ion beam that is steered out to the beam line leading to a target for radionuclide production. The remainder of the beam is intercepted by a carbon foil in another carousel further down the orbit to produce a second positive ion beam aimed at another target. Two separate targets can be used for the production of two different radionuclides (e.g., <sup>18</sup>F and <sup>13</sup>N) or two same targets may be used to produce a larger quantity of the same radionuclide. The kinetic energy of the accelerated particles can vary from a few MeV to several hundred electron volts, depending on the size and design of the cyclotron. For a given cyclotron, the external beam energy remains constant, whereas the internal beam energy varies radially inside the cyclotron. Various particles, namely,  $\alpha$  particle, proton, deuteron, <sup>3</sup>He, and a few heavy ions can be accelerated depending on the design of the cyclotron. The operation of cyclotrons is mostly automatic with minimal manual input and is controlled by the computer.

There are several features that make the negative ion cyclotron operationally more advantageous than the positive ion cyclotron. Beam extraction in a positive ion cyclotron is accomplished by steering the beam along a relatively long channel under the application of an electrostatic force with an extraction efficiency of  $\sim$ 80%. The remaining 20% of the positron beam is lost inside the cyclotron inducing radioactivity in the housing. This obviously warrants more shielding around the cyclotron unit. In contrast, beam extraction in a negative ion cyclotron by carbon foil stripping is a simple method. Because of the short path of extraction and an extraction efficiency of almost 100%, cyclotron housing is not activated by positive ions and shielding requirement is less than in positive ion cyclotrons. In a negative ion cyclotron, the particle beam can be split into several beam lines providing the scope of irradiating several targets simultaneously. On the other hand, a positive ion cyclotron is limited to only a single beam line because of the large size of the electrostatic deflector. However, since H<sup>-</sup> can lose the electrons by an encounter with any molecule producing positive ions, the vacuum inside the negative ion cyclotron needs to be extremely high compared to the positive ion cyclotron.

A point of consideration for the positive ion cyclotron is that the internal beam of positrons of variable energy can be utilized for radionuclide production by placing a probe with the target at different radial positions. The negative ion cyclotron does not have this provision.

# Medical Cyclotron

Medical cyclotrons are compact cyclotrons that are primarily used to produce short-lived, positron-emitting radionuclides used for PET imaging. Most of the clinically useful positron emitters are formed by nuclear reactions with low-energy particles and hence the compact cyclotrons. These are commercially available and can be installed in a relatively small space. Moreover, in medical cyclotrons, negative hydrogen ions (H<sup>-</sup>) are commonly accelerated, because unlike in positive ion cyclotrons, the housing of the cyclotron does not become radioactive in negative ion cyclotrons. Also, the beam can be split by two carbon-stripping foils so that two targets can be irradiated simultaneously. Whereas the particle energy may be in the range of a billion electron volts in high-energy cyclotrons, the typical energy of the protons or H<sup>-</sup> particles in medical cyclotrons ranges between 10 and 30 MeV. In some medical cyclotrons, both deuterons and H<sup>-</sup> particles can be accelerated interchangeably by switching the ion sources between deuterium and hydrogen. Shielding is a major concern for cyclotron installation. Whereas, in highenergy cyclotrons, shielding is achieved mostly by thick concrete walls and with large separation between the walls and the cyclotron, medical cyclotrons are mostly self-shielded with lead blocks because of their compact nature. The shielding commonly consists of four lead block quadrants supported on casters that wheel in and out for closing and opening of the quadrants for easy access to the cyclotron for maintenance. The operation of a medical cyclotron is a turnkey type and computer controlled, and a technologist with optimal training can operate it without difficulty. A typical medical cyclotron is shown in Fig. 7.2. The cyclotrons from different manufacturers are listed in Table 7.1.

# Nuclear Reaction

When targets of stable elements are irradiated by placing them in the external beam or in the internal beam of accelerated particles at a given radius inside a cyclotron, the particles interact with the target nuclei and nuclear reactions take place. Depending on the kinetic energy, the incident particle may be completely absorbed, depositing all its energy, or may leave the nucleus after interaction with one or more nucleons, leaving part of its energy. Nuclear reactions involving very high-energy particles are called spallations, in which many nucleons are ejected from the nucleus by the direct interaction of the incident particle. In either case, an excited nucleus is formed, and the excitation energy is disposed of by the emission of protons and neutrons, provided it is energetically allowed. Particle emission is followed by a cascade of  $\gamma$ -ray emissions when the former is no longer energetically possible. Depending on the energy deposited, several nucleons may be emitted resulting in the



FIGURE 7.2. A commercial cyclotron, ECLIPSE HD, developed and manufactured by Siemens Medical Solutions USA. (Courtesy of Siemens Medical Solutions USA, Inc.). The features of this cyclotron are given in Table 7.1.

Company	Model	Beam type	Proton particle energy (MeV)	Proton beam current $(\mu A)$	No. of target positions	Simultaneous irradiation of targets
IBA	Cyclone 10/5	$H^-/d^-$	10/5	60/35	8	2
	Cyclone 18/9	$H^{-}/d^{-}$	18/9	80/35	8	2
Siemens	Eclipse	Н-	11	50	8	2
GE	PETtrace	$H^-/d^-$	16.5	75	8	2
	Minitrace		9.6	60	8	2
Advanced	TR 30	$H^-/d^-$	15-30	1,000	8	2
Cyclotror	n TR-24	$H^{-1}$	15-24	300	16	2
Systems	TR 14–19	$H^-/d^-$	14–19	300	16	2
Best	BCSI 14p	Н-	14	100	4	2
Cyclotror	1					
System,						
Inc.						
Sumitomo	HM-12	$H^-/d^-$	12	90	4	2

TABLE 7.1. Features of medical cyclotrons from different manufacturers

production of different radionuclides. The larger the energy deposited, the more particles are emitted, and a variety of radionuclides are produced. A simple nuclear reaction induced by a proton p on a target  ${}^{A}_{Z}X$  can be given by

$$^{A}_{Z}X(p,n)^{A}_{Z+1}Y,$$

where *n* is the neutron emitted and  ${}^{A}_{Z+1}Y$  is the radionuclide formed.

The target material for irradiation must be pure and preferably monoisotopic or at least enriched isotopically to avoid the production of extraneous radionuclides. Radionuclides are separated from the target material by appropriate chemical methods such as solvent extraction, precipitation, chromatography, ion exchange, and distillation. Cyclotron-produced radionuclides are typically neutron deficient and, therefore, decay by  $\beta^+$  emission or electron capture. Also, the radionuclides, which are different from the target nuclides, do not contain any stable (or "cold") atoms and are called *carrierfree*. Another term for these preparations is no-carrier-added (NCA), because no cold atoms have been intentionally added to the preparations.

### Target and Its Processing

Excessive heat is generated in the target during irradiation with charged particles at a beam current of  $50-1,000 \,\mu A$ , and the temperature can rise, exceeding  $1,000^{\circ}$ C. This is because only 0.1% of the incident particles reacts with the nucleus and the rest interact with the atomic electrons producing intense heat. If proper precautions for heat dissipation are not taken, the target may be burned or melted. The most common method is to cool the probe to which the target is attached by using circulating water, helium gas, or other coolants. Also, the targets are designed in the form of a foil to maximize heat dissipation.

The common form of the target is the metallic foil, but metals melt at high temperature caused by high beam intensity of the particles. Other forms are oxides, carbonates, nitrates, etc., contained in the aluminum tubes, which are flattened after loading to maximize heat loss. The choice of aluminum is owing to its high melting point.

Liquid targets are used in the production of many PET radionuclides, particularly <sup>18</sup>F and <sup>13</sup>N. Fluorine-18 is produced by using a liquid target of <sup>18</sup>O-enriched water and so is <sup>13</sup>N by using 5 nM ethanol in water. The target volume is small in the range of 3–15 ml under high pressure. Since <sup>18</sup>O-water is expensive, it is customary to recover it for subsequent irradiation and the method of recovery is described in the later section.

Gas targets are used for some PET radionuclides such as  ${}^{11}C$  and  ${}^{15}O$ . A mixture of  ${}^{14}N_2$  gas and (1%)  ${}^{16}O_2$  gas is used to produce  ${}^{11}C$ , and a mixture

of enriched  ${}^{15}N_2$  gas and 2.5%  ${}^{16}O_2$  is used for the production of  ${}^{15}O$ . The gas targets are maintained at high pressure.

### Equation for Production of Radionuclides

The amount of activity produced by irradiation of a target material with a charged particle beam can be quantitated by

$$A = In\sigma(1 - e^{-\lambda t}), \tag{7.2}$$

where A, the activity in disintegration per second of the radionuclide produced; I, intensity of irradiating particles (number of particles/cm<sup>2</sup> s); n, number of target atoms;  $\sigma$ , formation cross section (probability) of the radionuclide (cm<sup>2</sup>); it is given in units of "barn," which is equal to  $10^{-24}$  cm<sup>2</sup>;  $\lambda$ , decay constant of the radionuclide given by  $0.693/t_{1/2}$  (s<sup>-1</sup>); and t, time of irradiation in seconds.

Equation (7.2) indicates that the quantity of radionuclides increases with time of irradiation, intensity, and energy of the particles (related to  $\sigma$ ) of the incident particle, and the amount of target material. The term  $(1-e^{-\lambda t})$  is called the saturation factor, which approaches to unity when t is five to six half-lives of the radionuclide in question. At that time, the yield of the radionuclide is maximum, and its rates of production and decay become equal, indicating that there is no gain in activity by further irradiation. For irradiation for five to six half-lives of the daughter, Eq. (6.2) then becomes

$$A = In\sigma. \tag{7.3}$$

A graphic representation of Eqs. (7.2) and (7.3) is shown in Fig. 7.3.

The values of I are measured by various techniques, the description of which is beyond the scope of this book, but they are available from the cyclotron operators. The values of  $\sigma$  also have been determined for various nuclear reactions and are available in literature. The number of atoms N of the target is given by

$$N = \frac{W \times K}{A_{\rm w}} \times 6.02 \times 10^{23},\tag{7.4}$$

where W is the weight of the target,  $A_w$  and K are the atomic weight and natural abundance of the target element, and  $6.02 \times 10^{23}$  is the Avogadro's number.

Note that 1 ampere (A) is equal to 1 Coulomb (C)/s, and 1 C equals to  $6.25 \times 10^{18}$  protons, so in a cyclotron where protons or H<sup>-</sup> are accelerated, the beam intensity is conventionally expressed in  $\mu A/cm^2$ -h. The yield of the radionuclide is then expressed in MBq or mCi per  $\mu Ah$ .



FIGURE 7.3. Production of radionuclides in a cyclotron. The amount of activity produced reaches a maximum (saturation) in five to six half-lives of the radionuclide.

#### Problem 7.1

Calculate the activity of <sup>18</sup>F produced when 1 g of 70% enriched H<sub>2</sub><sup>18</sup>O is irradiated for 1 h with a proton beam of 30  $\mu$ A/cm<sup>2</sup> in a cyclotron. The half-life of <sup>18</sup>F is 110 min and the cross section for the <sup>18</sup>O (p, n) <sup>18</sup>F reaction is 300 millibarn (1 barn = 10<sup>-24</sup> cm<sup>2</sup>).

Answer:

Since 1 A is equal to 1 C/s and 1 C equals  $6.25\times10^{18}$  protons, the number of protons in 30  $\mu A/cm^2$  is

$$I = 30 \times 10^{-6} \times 6.25 \times 10^{18} = 1.875 \times 10^{14} \text{ protons/(cm}^2 \cdot \text{s})$$
  
$$\sigma = 0.3 \times 10^{-24} \text{ cm}^2$$

Effective molecular weight of enriched water is  $0.3 \times 18 + 0.7 \times 20 = 19.4$ .

$$N = \frac{0.7 \times 1}{19.4} \times 6.02 \times 10^{23} = 2.17 \times 10^{22} \text{ atoms}^{18}\text{O}$$
$$\lambda = \frac{0.693}{110 \times 60} = 1.05 \times 10^{-4} \text{ s}^{-1}$$
$$t = 1 \times 60 \times 60 = 3.600 \text{ s}$$

Using Eq. (7.1)  

$$D (dps) = 1.875 \times 10^{14} \times 2.17 \times 10^{22} \times 0.3 \times 10^{-24} \times [1 - \exp(-1.05 \times 10^{-4} \times 3,600)]$$

$$= 1.22 \times 10^{12} \times 0.3148$$

$$= 3.84 \times 10^{11} dps(384 GBq)$$

$$A = \frac{3.84 \times 10^{11}}{3.7 \times 10^{10}}$$

$$= 10.4 Ci$$

### Specific Activity

Specific activity of a sample is defined as the radioactivity per unit mass of a radionuclide or a labeled compound. If a 50-mg sample contains 100 mCi (370 MBq), then the specific activity of the sample is given as 100/50 = 2 mCi/mg or 74 MBq/mg. One should not confuse the specific activity with the concentration, which is given in mCi/ml or MBq/ml. The specific activity is at times expressed in units of mCi/mole (MBq/mole) or mCi/µmole (MBq/µmole).

The specific activity of a carrier-free radionuclide can be calculated by

Specific activity (mCi/mg) = 
$$\frac{3.13 \times 10^9}{A \times t_{1/2}}$$
, (7.5)

where A is the mass number of the radionuclide;  $t_{1/2}$  is the half-life in hours of the radionuclide.

The specific activity is an important parameter to consider in radiolabeling and in vivo biodistribution of tracers. Cold molecules in low-specific-activity radiopharmaceuticals compete with radioactive molecules and lower the uptake of the tracer in tissues. Similarly, low-specific-activity radionuclides yield poor radiolabeling.

### Production of Positron-Emitting Radionuclides

Since only a limited number of short-lived radionuclides are useful for PET imaging, production of those in routine clinical use and a few with potential for future clinical use are described here. A few essential long-lived positron emitters are also included. The different characteristics of these radionuclides are summarized in Table 7.2.

Nuclide	Physical half-life $(t_1, c_2)$	Mode of decay (%)	$\gamma$ -ray energy (keV)	Abundance (%)	Common production method
<sup>11</sup> C	20.4 min	$\beta^{+}(100)$	511	200	$^{10}B(d n)^{11}C$
6 <sup>C</sup>	20.4 11111	β (100)	511	200	$^{14}N(p,\alpha)^{11}C$
$^{13}_{7}N$	10 min	$\beta^{+}(100)$	511	200	${}^{12}C(d, n){}^{13}N$
,					${}^{16}{\rm O}({\rm p}, \ \alpha){}^{13}{\rm N}$
15 -		- 1 - 4			$^{13}C(p, n)^{13}N$
<sup>15</sup> <sub>8</sub> O	2 min	$\beta^{+}(100)$	511	200	$^{14}N(d, n)^{15}O$
18 <sub>E</sub>	110 min	$\beta^{+}(07)$	511	10/	$^{13}N(p, n)^{13}O(p, n)^{18}F$
9 <sup>1</sup>		p(97)	511	194	O(p, n)
$^{02}_{30}$ Zn	9.3 h	$\beta^+(8)$	41	25	$^{03}Cu(p, 2n)^{02}Zn$
62 C	0.7 min	EC(92)	550 511	56 104	627 n 62Cy concretor
29 <sup>Cu</sup>	9.7 11111	FC(3)	511	194	Zii- Cu generator
<sup>68</sup> Ga	68 min	$\beta^{+}(89)$	511	178	<sup>68</sup> Ge- <sup>68</sup> Ga generator
31		EC(11)			${}^{68}$ Zn(p, n) ${}^{68}$ Ga
<sup>68</sup> <sub>32</sub> Ge	270.8d	EC(100)	-	-	${}^{66}Zn(\alpha, 2n){}^{68}Ge$
<sup>94m</sup> <sub>42</sub> Tc	52 min	$\beta^{+}(70)$	511	140	$^{94}Mo(p, n)^{94m}Tc$
40		EC(30)	871	94	
			1,521	4.5	
			1,868	5.7	
$^{124}_{53}I$	4.2 d	$\beta^{+}(23)$	511	46	$^{124}$ Te(p, n) $^{124}$ I
		EC(77)	603	61	
			1,691	10.4	snallation
$^{82}_{37}$ Rb	75 s	$\beta^{+}(95)$	511	190	$^{98}\text{Mo} \xrightarrow{\text{spanation 82}} \text{Sr}$
		EC(5)	777	13.4	↓ 25.6d
					<sup>82</sup> Rb

#### 126 7. Cyclotron and Production of PET Radionuclides

TABLE 7.2 Production and characteristics of common positron emitters

# Fluorine-18

Fluorine-18 ( $t_{1/2} = 110 \text{ min}$ ) is commonly produced by the <sup>18</sup>O(p, n)<sup>18</sup>F reaction on a H<sub>2</sub><sup>18</sup>O target using 11–18MeV protons in medical cyclotrons. <sup>18</sup>O-O<sub>2</sub> gas target also has been used as the target for <sup>18</sup>F production, but has not received wide acceptance because of the low yield. H<sub>2</sub><sup>18</sup>O (85–99% enriched) is isotopically enriched target material in liquid form and is available from commercial vendors (e.g., Isotec, Inc., Miamisburg, OH, USA). A metal target holder (e.g., silver, titanium, nickel, copper, and stainless steel) with cavities of 0.1–4 cc volume is used to contain H<sub>2</sub><sup>18</sup>O. Target design varies widely with the type and energy of the cyclotron. After irradiation, the target mixture is loaded on a column of carbonate ion exchange resin, and H<sub>2</sub><sup>18</sup>O is forced out of the column by neon gas and reused as the target. <sup>18</sup>F<sup>-</sup> ion is recovered by eluting the column with potassium carbonate solution. Greater than curie (GBq) amount of <sup>18</sup>F-fluoride is easily produced in an 11-MeV cyclotron after bombardment for an hour. The NCA specific activity of <sup>18</sup>F-fluoride is in the order of about 1 × 10<sup>4</sup> Ci/mmol

 $(3.7 \times 10^5 \text{ GBq/mmol})$ . <sup>18</sup>F-fluoride has been used for labeling deoxyglucose to produce <sup>18</sup>F-fluorodeoxyglucose (<sup>18</sup>F-FDG), and other <sup>18</sup>F-labeled radiopharmaceuticals for PET imaging (discussed later).

Some compounds such as L-dopa need the precursor fluorine-18 gas  $[^{18}F]F_2$  instead of  $F^-$  ion for electrophilic labeling. It is produced by the  $^{18}O(p, n)^{18}F$  reaction on an  $^{18}O$  gas target contained in aluminum tubing. After irradiation, the  $^{18}O$  gas target is recovered cryogenically in a stainless steel cylinder cooled in liquid nitrogen and  $^{18}F$  gas remains adsorbed on the target wall. The latter is then recovered by flashing with 1% nonradioactive fluorine gas mixed with krypton or neon with a recovery efficiency of about 50%.

#### Carbon-11

Carbon-11 has a half-life of 20.5 min and can be produced by <sup>10</sup>B(d, n) <sup>11</sup>C, <sup>11</sup>B(p, n) <sup>11</sup>C, and <sup>14</sup>N(p,  $\alpha$ )<sup>11</sup>C reactions in the cyclotron. In the first two reactions, B<sub>2</sub>O<sub>3</sub> is the target and nitrogen gas in the third. Both <sup>11</sup>CO and <sup>11</sup>CO<sub>2</sub> are produced in boron targets by using 10–12 MeV protons, which are then flushed out by neutral gases. Either <sup>11</sup>CO is oxidized to have all the gas in <sup>11</sup>CO<sub>2</sub> form, or <sup>11</sup>CO<sub>2</sub> is reduced to have all the gas in <sup>11</sup>CO and <sup>11</sup>CO<sub>2</sub> are commonly used as precursors in the preparation of various clinically useful compounds, such as <sup>11</sup>C-palmitate for myocardial metabolic imaging by PET.

The most common method of <sup>11</sup>C production is the <sup>14</sup>N(p,  $\alpha$ ) <sup>11</sup>C reaction with 10–12 MeV protons. When the pure <sup>14</sup>N target is mixed with traces of oxygen, both <sup>11</sup>CO and <sup>11</sup>CO<sub>2</sub> are produced. <sup>11</sup>CO<sub>2</sub> is recovered by initially trapping <sup>11</sup>CO<sub>2</sub> in a liquid nitrogen trap and later removing it by flushing with helium or heating the trap. The yield can be in curie (GBq) range with 99.9% purity.

The <sup>14</sup>N(p,  $\alpha$ )<sup>11</sup>C reaction is carried out by bombardment of a mixture of N<sub>2</sub> and H<sub>2</sub> to give <sup>11</sup>C, which reacts with N<sub>2</sub> to produce <sup>11</sup>CN, followed by hydrolysis of <sup>11</sup>CN to give <sup>11</sup>CH<sub>4</sub> (95–100% radiochemical yield). Carbon-11-methane is often allowed to react with NH<sub>3</sub> over platinum at 1,000°C to give a 95% overall yield of H<sup>11</sup>CN. Various biological molecules such as aliphatic amines, amino nitriles, and hydantoins have been labeled with <sup>11</sup>C using H<sup>11</sup>CN or <sup>11</sup>CH<sub>4</sub> as a precursor. A frequently employed precursor for <sup>11</sup>C labeling is <sup>11</sup>C-methyl iodide, which is prepared by either converting <sup>11</sup>C-CO<sub>2</sub> to <sup>11</sup>C-methoxide followed by reaction with hydroiodic acid, or by a gas phase reaction where <sup>11</sup>C-CH<sub>4</sub> is reacted with iodine.

### Nitrogen-13

Nitrogen-13 has a half-life of 10 min and is commonly used as NH<sub>3</sub>. It is produced by the <sup>12</sup>C(d, n)<sup>13</sup>N reaction by bombarding Al<sub>4</sub>C<sub>3</sub> or methane with 6–7 MeV deuterons, or by the <sup>16</sup>O(p,  $\alpha$ )<sup>13</sup>N or <sup>13</sup>C(p, n)<sup>13</sup>N reaction.

However, the <sup>16</sup>O(p,  $\alpha$ )<sup>13</sup>N reaction is the most common method of <sup>13</sup>N production, and a target of pure water contained in a titanium holder is used for irradiation with 11–12 MeV protons. The major chemical species are nitrates, nitrites, ammonia, and hydroxylamine, of which the nitrate has the highest yield and is separated by the ion exchange method. The nitrates and nitrites are reduced to give <sup>13</sup>NH<sub>3</sub> which is swept by helium into saline. <sup>13</sup>NH<sub>3</sub> in the form of NH<sub>4</sub><sup>+</sup> ion is primarily used for myocardial perfusion imaging by PET. <sup>13</sup>NH<sub>3</sub> is also used to label glutamine and asparagine for assessment of viability of tissues.

# Oxygen-15

Oxygen-15 has a half-life of 2 min and is produced by the <sup>14</sup>N(d, n)<sup>15</sup>O reaction by 8–10 MeV deuteron irradiation of gaseous nitrogen or by the <sup>15</sup>N(p, n)<sup>15</sup>O reaction by 10–12 MeV proton bombardment of enriched <sup>15</sup>N gas target contained in an aluminum alloy container. Pure <sup>15</sup>O gas is used for bolus and steady-state metabolic studies. <sup>15</sup>O<sub>2</sub> is passed over activated charcoal heated at 1,000°C to convert it to C<sup>15</sup>O and C<sup>15</sup>O<sub>2</sub>, which are then used for labeling hemoglobins in clinical investigations of pulmonary and cardiac malfunctions. Oxygen-15-labeled water is obtained by heating a mixture of <sup>15</sup>O and hydrogen gas and is useful for cerebral and myocardial perfusion studies.

# Iodine-124

Iodine-124 has a half-life of 4.2 days and is produced by the <sup>124</sup>Te(d, 2n) <sup>124</sup>I or <sup>124</sup>Te (p, n) <sup>124</sup>I reaction using 10–18 MeV protons and a 96% enriched <sup>124</sup>Te target in the form of oxide. While it has the advantage of having a long half-life to produce suitable iodinated PET tracers, its low positron abundance (only 23%) and complex decay scheme involving high-energy photons cause difficulty in PET imaging.

# Strontium-82

Rubidium-82 ( $t_{1/2} = 75$  s) is available from the <sup>82</sup>Sr-<sup>82</sup>Rb generator (supplied by Bracco Diagnostics, Inc.). <sup>82</sup>Sr ( $t_{1/2} = 25.6$  days) is produced by the <sup>85</sup>Rb (p, 4n) <sup>82</sup>Sr reaction using the high-energy proton beam on a <sup>85</sup>Rb target or by the spallation reaction of <sup>99</sup>Mo target with very high-energy protons, the latter being the preferred reaction. The <sup>82</sup>Sr radionuclide is separated from the target by the ion-exchange method. The purified <sup>82</sup>Sr in amounts of 90–150 mCi (3.33–5.55 GBq) is loaded on a stannic oxide column in the generator. <sup>82</sup>Rb generator by using an infusion pump (see Chap. 11.). The major impurities in the <sup>82</sup>Sr sample are <sup>85</sup>Sr ( $t_{1/2} = 65d$ ) and <sup>83</sup>Sr ( $t_{1/2} = 32$  h). While <sup>85</sup>Sr contamination can be as much as five times the <sup>82</sup>Sr activity in the

range of 400–700 mCi (14.8–25.9 GBq) when produced using the <sup>98</sup>Mo target, it is significantly less when the <sup>85</sup>Rb target is used. However, <sup>83</sup>Sr decays to a negligible quantity by the time <sup>82</sup>Sr is loaded on the generator column.

# Technetium-94m

Technetium-94m ( $t_{1/2} = 52 \text{ min}$ ) is produced by the <sup>94</sup>Mo(p, n)<sup>94m</sup>Tc reaction using an enriched <sup>94</sup>Mo target and 11–12 MeV protons. <sup>94m</sup>Tc is separated from <sup>94</sup>Mo by steam distillation. It is an attractive positron emitter since it can be substituted for <sup>99m</sup>Tc in many SPECT radiopharmaceuticals for use in PET imaging.

# Germanium-68

Germanium-68 ( $t_{1/2} = 270.8$  days) is mainly used as a sealed source for transmission scan and quality control studies in PET imaging. It is produced by the  ${}^{66}$ Zn( $\alpha$ , 2n) ${}^{68}$ Ge reaction, or the 40-MeV proton bombardment of a gallium target, or the spallation reactions in a molybdenum target with high-energy protons. It decays by electron capture and remains in equilibrium with  ${}^{68}$ Ga ( $t_{1/2} = 68 \text{ min}$ ). It is also used in the  ${}^{68}$ Ge- ${}^{68}$ Ga generator to provide easy supply of  ${}^{68}$ Ga.

# Copper-62

Copper-62 ( $t_{1/2} = 9.7 \text{ min}$ ) is available from the  ${}^{62}\text{Zn}{}^{-62}\text{Cu}$  generator supplied by Proportional Technologies, Inc. Zinc-62 ( $t_{1/2} = 9.3 \text{ h}$ ) is produced by the  ${}^{63}\text{Cu}$  (p, 2n)  ${}^{62}\text{Zn}$  reaction by irradiation with 25–30 MeV protons using a 99% pure copper-63 foil target (Green et al, 1990). The typical yield is about 4.5 mCi per *mA*-*h* at EOB.  ${}^{62}\text{Zn}$  is taken up in 2N HCl and loaded on a Dowex 1 × 8 anion exchange column to afford the  ${}^{62}\text{Zn}{}^{-62}\text{Cu}$  generator.  ${}^{62}\text{Cu}$  is eluted with 2N HCl for use in the synthesis of  ${}^{62}\text{Cu}$ -PTSM, which is useful for measurement of perfusion in heart, kidney, and brain.

# Questions

- 1. Describe the principles of the operation of a cyclotron.
- 2. What is the major advantage of a negative ion cyclotron over a positive ion cyclotron?
- 3. Why is the higher vacuum required in a negative ion cyclotron than in a positive ion cyclotron?
- Describe the production of the following radionuclides in a cyclotron. (a) <sup>13</sup>N, (b) <sup>11</sup>C, (c) <sup>18</sup>F, and (d) <sup>15</sup>O.

- 5. Radionuclides produced in a cyclotron are typically carrier-free or NCA. True \_\_\_\_\_; False \_\_\_\_\_.
- 6. Calculate the activity of <sup>18</sup>F when 700 mg of 85% enriched H<sub>2</sub><sup>18</sup>O is irradiated for 1 h with a proton beam of  $20 \,\mu A/\text{cm}^2$  in a cyclotron. The half-life of <sup>18</sup>F is 110 min and the cross section for the <sup>18</sup>O(p, n)<sup>18</sup>F reaction is 200 millibarn (1 barn =  $10^{-24}$  cm<sup>2</sup>).
- 7. In producing a radionuclide with  $t_{1/2} = 3$  h in a cyclotron, what is the duration of irradiation after which there is no more gain in additional activity?
- 8. What are the chemical forms of <sup>18</sup>F that are obtained at the end of bombardment to be used for further chemical synthesis?
- 9. The specific activity of a radioactive sample decreases with the increasing cold atoms. True \_\_\_\_\_; False \_\_\_\_\_.
- 10. Calculate the specific activity of a carrier-free  ${}^{18}$ F sample.
- Negative ion cyclotrons are more advantageous than positive ion cyclotrons, because the negative ion beam is easily extracted. True \_\_\_\_\_; False \_\_\_\_\_.

# References and Suggested Reading

- Friedlander G, Kennedy JW, Miller JM (1981). Nuclear and radiochemistry, 3rd ed. Wiley, New York
- Green MA, Mathias CJ, Welch MJ et al (1990). Copper-62 labeled pyruvaldehide Bis(N<sup>4</sup>-methylthiosemicarbazonato) Copper (II): Synthesis and evaluation as a positron emission tomography tracer for cerebral and myocardial perfusion. J Nucl Med 31:1989
- McCarthy TJ, Welch MJ (1998). The state of positron emitting radionuclide production in 1997. Semin Nucl Med XXVII:235
- Saha GB (2004). Fundamentals of nuclear pharmacy, 5th ed. Springer, New York
- Saha GB, MacIntyre WJ, Go RT (1992). Cyclotrons and positron emission tomography for clinical imaging. Semin Nucl Med 22:150
- Silvester DJ, Waters SL (1979). Radionuclide production. In: Sodd VJ, Allen DR, Hoogland DR, Ice RD (eds) Radiopharmaceuticals II. Society of Nuclear Medicine, New York, p 727
- Stöcklin G, Pike VW (1993). Radiopharmaceuticals for positron emission tomography, Kluwer, Dordrecht

# 8 Synthesis of PET Radiopharmaceuticals

PET radiopharmaceuticals are uniquely different from SPECT radiopharmaceuticals in that the former have radionuclides that are positron emitters and the majority of them have short physical half-lives. The most common PET radionuclides are  ${}^{11}C, {}^{15}O, {}^{13}N, {}^{18}F$ , and  ${}^{82}Rb$ , which are short-lived (see Table 7.2) and put limitations on the synthesis time for PET radiopharmaceuticals and their clinical use. The attractive advantage of PET radiopharmaceuticals, however, is that the ligands used in radiopharmaceuticals are common analogs of biological molecules and, therefore, often depict a true representation of biological processes after in vivo administration. For example,  ${}^{18}F$ -fluorodeoxyglucose (FDG) is an analog of glucose used for cellular metabolism and  $H_2^{15}O$  for cerebral perfusion.

Many radiopharmaceuticals have been used for PET imaging; however, only a few are routinely utilized for clinical purposes. Almost all of them are labeled with one of the four common positron emitters:  ${}^{11}C$ ,  ${}^{13}N$ ,  ${}^{15}O$ , and  ${}^{18}F$ . Of the four,  ${}^{18}F$  is preferred most, since it has a relatively longer half-life ( $t_{1/2} = 110 \text{ min}$ ) that allows its supply to remote places. In all cases, a suitable synthesis method is adopted to provide a stable product with good labeling yield, high specific activity, high purity and, most importantly, high in vivo tissue selectivity. The following is a description of the syntheses of the common clinically used PET radiopharmaceuticals and a few with potential for future use.

### PET Radiopharmaceuticals

### <sup>18</sup>F-Sodium Fluoride

Fluorine-18 ( $t_{1/2} = 110 \text{ min}$ ) is produced by irradiation of <sup>18</sup>O-water with 10–18 MeV protons in a cyclotron and recovered as <sup>18</sup>F-sodium fluoride by passing the irradiated water target mixture through a carbonate type anion exchange resin column. The water passes through, whereas <sup>18</sup>F<sup>-</sup> is retained

on the column, which is recovered by elution with potassium carbonate solution. Its pH should be between 4.5 and 8.0. While <sup>18</sup>F-sodium fluoride is most commonly used for the synthesis of FDG, it is also used for other <sup>18</sup>F-labeled PET radiopharmaceuticals. The US FDA has approved it for bone scintigraphy, since it localizes in bone by exchanging with  $PO_4^-$  ion in the hydroxyapatite crystal.

# <sup>18</sup>*F*-*Fluorodeoxyglucose*

<sup>18</sup>F-2-fluoro-2-deoxyglucose (2-FDG) is normally produced in places where a cyclotron is locally available. Its molecular formula is  $C_8H_{11}$ <sup>18</sup>FO<sub>5</sub> with molecular weight of 181.3 daltons. <sup>18</sup>F-2-FDG can be produced by electrophilic substitution with <sup>18</sup>F-fluorine gas or nucleophilic displacement with <sup>18</sup>F-fluoride ions. The radiochemical yield is low with the electrophilic substitution, so the nucleophilic displacement reaction has become the method of choice for <sup>18</sup>F-FDG synthesis. Deoxyglucose is labeled with <sup>18</sup>F by nucleophilic displacement reaction of an acetylated sugar derivative followed by hydrolysis (Hamacher et al, 1986). In nucleophilic substitution, a fluoride ion reacts to fluorinate the sugar derivative. A solution of 1,3,4,6-tetra-*O*acetyl-2-*O*-trifluoromethane-sulfonyl-β-D-mannopyranose in anhydrous acetonitrile is added to a dry residue of <sup>18</sup>F-fluoride containing aminopolyether (Kryptofix 2.2.2) and potassium carbonate (Fig. 8.1). Kryptofix 2.2.2 is used as a catalyst to enhance the reactivity of the fluoride ions. The mixture is heated



FIGURE 8.1. Schematic synthesis of <sup>18</sup>F-2-Fluoro-2-deoxyglucose (FDG). (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography <sup>©</sup>2009. All Rights Reserved)

under reflux for about 5 min. The solution is then passed through a C-18 Sep-Pak column, and acetylated carbohydrates are eluted with tetrahydrofuran (THF), which are then hydrolyzed by refluxing in hydrochloric acid at 130°C for 15 min. <sup>18</sup>F-2-fluoro-2-deoxyglucose (2-FDG) is obtained by passing the hydrolysate through a C-18 Sep-Pak column. The yield can be as high as 60%, and the preparation time is approximately 50 min. The final solution is filtered through a 0.22- $\mu$ m filter and diluted with saline, as needed. It should have a pH of 7.0.

Since Kryptofix 2.2.2 is toxic causing apnea and convulsions, modifications have been made to substitute it with tetrabutylammonium hydroxide or bicarbonate, which have been adopted by many commercial vendors. Also, in some other methods, the C-18 Sep-Pak column separation has been eliminated so as to carry out the acidic hydrolysis in the same vessel. In methods where Kryptofix 2.2.2 is still used, several Sep-Pak columns are used to separate Kryptofix 2.2.2 and reduce it to practically a negligible quantity.

<sup>18</sup>F-2-FDG is used primarily for the study of metabolism in the brain and heart and for the detection of epilepsy and various tumors. In metabolism, <sup>18</sup>F-2-FDG is phosphorylated by hexokinase to 2-FDG-6-phosphate which is not metabolized further. It should be noted that 3-fluoro-deoxyglucose (3-FDG) is not phosphorylated and hence is not trapped and essentially eliminated rapidly from the cell. This is why 3-FDG is not used for metabolic studies.

# 6-<sup>18</sup>*F*-*L*-*F*luorodopa

Like <sup>18</sup>F-2-FDG, 6-<sup>18</sup>F-L-fluorodopa is also produced in places where a cyclotron is available locally. There are several methods of synthesizing 6-<sup>18</sup>F-fluoro-3,4-dihydroxyphenylalanine (6-<sup>18</sup>F-L-fluorodopa), of which the method of fluorodemetallation using electrophilic fluorinating agents is most widely used. Electrophilic reactions involve the reaction of fluorine in the form of F<sup>+</sup> with other molecules. Only the L-isomer of dopa is important, because the enzymes that convert dopa to dopamine, which is targeted by the radiopharmaceutical, are selective for this isomer. Initially, a suitably protected organomercury precursor (N-[trifluoroacetyl]-3,4-dimethoxy-6-trifluoroacetoxymercuriophenylalanine ethyl ester) of dopa is prepared. [<sup>18</sup>F]-labeled acetylhypofluorite prepared in the gas phase is then allowed to react with the mercury precursor in chloroform or acetonitrile at room temperature. Other precursors using metals such as tin, silicon, selenium and germanium have been reported. Acid hydrolysis with 47% HBr provides a relatively high yield (10–12%) of 6-<sup>18</sup>F-L-fluorodopa (Luxen et al. 1987) compared with other available methods. Substitution at position 6 is most desirable, because this does not alter the behavior of dopa, whereas substitutions at 2 and 5 do. It is sterilized by filtering through a 0.22-µm membrane filter and is supplied at pH between 4.0 and 5.0. Normally EDTA and ascorbic



a. 6-18F-L-FLUORODOPA







c. <sup>11</sup>C-METHYLSPIPERONE





d. <sup>11</sup>C-L-METHIONINE



e. <sup>11</sup>C-RACLOPRIDE

f. <sup>18</sup>F-FLUOROMISONIDAZOLE

FIGURE 8.2. Molecular structures of (a)  $6^{-18}$ F-L-fluorodopa, (b)  $^{11}$ C-flumazenil, (c)  $^{11}$ C-methylspiperone, (d)  $^{11}$ C-L-methionine, (e)  $^{11}$ C-raclopride, (f)  $^{18}$ F-fluoromisonidazole (Reprinted with the permission of The Cleveland Clinic Center for Medical Art & Photography<sup>©</sup> 2009. All Rights Reserved)

acid are added to the final preparation for stability. The molecular structure of 6-<sup>18</sup>F-L-fluorodopa is shown in Fig. 8.2a.

# <sup>18</sup>*F*-*Fluorothymidine* (*FLT*)

<sup>18</sup>F-FLT is prepared by nucleophilic reaction between <sup>18</sup>F-sodium fluoride and a precursor, 2, 3'-anhydro-5'-O-benzoyl-2'-deoxythymidine, which is prepared by standard organic synthesis (Machula et al, 2000). <sup>18</sup>F-sodium fluoride is added to a mixture of Kryptofix 2.2.2 and potassium carbonate in acetonitrile, and the mixture is dried to a residue by heating at 120°C for 5 min. The precursor in dimethyl sulfoxide (DMSO) is added to the dried residue and heated at 160°C for 10 min. Hydrolysis of the 5'-0-protecting group is performed with sodium hydroxide. <sup>18</sup>F-FLT is isolated by passing through alumina Sep-Pak and further purified by using high-performance liquid chromatography (HPLC). The overall yield is about 45% and the radiochemical purity is more than 95%. The synthesis time is about 60 min.

Since thymidine is incorporated into DNA and provides a measure of cell proliferation, <sup>18</sup>F-FLT is commonly used for in vivo diagnosis and characterization of tumors in humans.

# <sup>18</sup>*F*-*BMS*-747158-02

This is an <sup>18</sup>F-labeled pyridaben derivative that binds to mitochondrial complex I of the electron transport chain with high affinity. It is prepared by mixing dry <sup>18</sup>F-containing Kryptofix 2.2.2 with BMS-747155-01 in dry acetonitrile and heating at 90°C for 10 min (Huisman et al, 2008). The product is then purified further by HPLC to give an overall radiochemical yield of 50–60% and radiochemical purity of 99%.

<sup>18</sup>F-BMS-747158-02 is being evaluated for clinical use in humans for the measurement of myocardial perfusion by PET.

# <sup>18</sup>*F*-*O*-(2-*F*luoroethyl)-*L*-*Tyrosine* (*FET*)

The synthesis of <sup>18</sup>F-FET is carried out in two steps (Wester et al, 1999): First, ethylene glycol-1,2-ditosylate in acetonitrile is reacted with dry <sup>18</sup>F-containing Kryptofix 2.2.2 and potassium bicarbonate at 90°C for 10 min. The product is purified by absorbing it on a polystyrene cartridge and then eluting with dimethylsulfoxide. Second, the eluate is mixed with dipotassium sodium salt of L-tyrosine and heated at 90°C for 10 min. The mixture is purified by HPLC and cation exchange to afford <sup>18</sup>F-FET. The radiochemical yield is about 40–45% with purity between 97 and 99%.

<sup>18</sup>F-FET is used as a PET tracer for the detection of a variety of tumors.

# <sup>18</sup>*F*-*Fluoromisonidazole (FMISO)*

<sup>18</sup>F-FMISO is synthesized in one-step reaction between the protected precursor, 1-(2'-nitro-1'-imidazolyl)-2-*O*-tetrahydropyranyl-3-*O*-toluenesulfonyl-propanediol (NITTP) and <sup>18</sup>F-containing Kryptofix 2.2.2 in acetonitrile solution (Kamarainen et al, 2004). The labeled product is hydrolyzed with acid to give <sup>18</sup>F-FMISO, which is further purified by column chromatography using a Sep-Pak cartridge. From an automated synthesis, the radiochemical yield is 34% at EOB after a synthesis time of 50 min. HPLC shows a radiochemical purity of 97%. The molecular structure of <sup>18</sup>F-FMISO is shown in Fig.8.2f.

<sup>18</sup>F-FMISO is a specific tracer for detection of hypoxic tissues by PET.

# <sup>18</sup>*F*-1-(5-fluoro-5-deoxy- $\alpha$ -arabinofuranosyl)-2-nitroimidazole (FAZA)

<sup>18</sup>F-FAZA is synthesized by nucleophilic substitution reaction between the precursor 1-(2,3-di-*O*-acetyl-5-*O*-tosyl-α-D-arabinofuranosyl)-2-nitroimidazole in DMSO solution and <sup>18</sup>F-fluoride containing mixture of Kryptofix 2.2.2 and potassium carbonate at 100°C for 5 min (Reischl et al, 2005). The product is hydrolyzed with NaOH solution at 20°C for 2 min, and the solution is neutralized with NaH<sub>2</sub>PO<sub>4</sub>. It is further purified by HPLC and sterilized by 0.22-µm filtration. The radiochemical yield is about 61%.

<sup>18</sup>F-FAZA is used for the detection of tissue hypoxia by PET.

# <sup>15</sup>*O*-Water

<sup>15</sup>O-oxygen ( $t_{1/2} = 2 \text{ min}$ ) is produced in the cyclotron by the <sup>15</sup>N(p, n)<sup>15</sup>O reaction, or the <sup>14</sup>N(d, n)<sup>15</sup>O reaction, and the irradiated gas is transferred to a [<sup>15</sup>O] water generator in which <sup>15</sup>O is mixed with hydrogen and passed over a palladium/charcoal catalyst at 170°C (Meyer et al, 1986; Welch and Kilbourn, 1985). The H<sub>2</sub><sup>15</sup>O vapor is trapped in saline, and the saline solution is filtered through a 0.22-µm membrane filter. The sample is then passed through a radiation detector for radioassay and ultimately injected online into a patient in a very short time.

 $H_2^{15}O$  is commonly used for myocardial and cerebral perfusion studies.

# n-<sup>15</sup>O-Butanol

 $n^{-15}$ O-butanol is prepared by the reaction of  ${}^{15}$ O-oxygen, produced by the  ${}^{15}$ N(p, n) ${}^{15}$ O reaction, with tri-*n*-butyl borane loaded onto an alumina Sep-Pak cartridge (Kabalka et al, 1985). Carrier oxygen at a concentration of about 0.5% is added to the  ${}^{15}$ N target in order to recover  ${}^{15}$ O. After the reaction,  $n^{-15}$ O-butanol is eluted from the cartridge with water. It is further purified by passing through C-18 Sep-Pak and eluting with ethanol–water.

 $n^{-15}$ O-butanol is used for blood flow measurement in the brain and other organs. It is a better perfusion agent than <sup>15</sup>O-water, because its partition coefficient is nearly 1.0 compared to 0.9 for water.

# <sup>13</sup>N-Ammonia

Nitrogen-13-labeled ammonia ( $t_{1/2} = 10 \text{ min}$ ) is produced by reduction of <sup>13</sup>N-labeled nitrates and nitrites that are produced by proton irradiation of water in a cyclotron. The reduction is carried out with titanium chloride in alkaline medium. <sup>13</sup>N-NH<sub>3</sub> is then distilled and finally trapped in acidic saline solution. Wester et al (1991) has used a pressurized target of aqueous ethanol, in which ethanol acts as a hydroxyl free radical scavenger to improve the
yield of <sup>13</sup>N-NH<sub>3</sub>. The mixture is passed through an anion-exchange resin to remove all anion impurities. It is filtered through a 0.22- $\mu$ m membrane filter and its pH should be between 4.5 and 7.5. The US FDA has approved it for measurement of myocardial and cerebral perfusion.

## <sup>11</sup>C-Sodium Acetate

<sup>11</sup>C-sodium acetate is produced by the reaction of the Grignard reagent, methylmagnesium bromide in diethyl ether, with cyclotron-produced <sup>11</sup>Ccarbon dioxide at  $-15^{\circ}$ C (Oberdorfer et al, 1996). After reaction, the product is allowed to react with O-phthaloyl dichloride to produce <sup>11</sup>C-acetyl chloride, which is then hydrolyzed to <sup>11</sup>C-acetate with saline. The solution is filtered through a 0.22-µm membrane filter. <sup>11</sup>C-acetate has been found to be stable at pH between 4.5 and 8.5 for up to 2 h at room temperature. The overall yield is about 10–50%. It is used for the measurement of oxygen consumption (oxidative metabolism) in the heart, since acetyl CoA synthetase converts <sup>11</sup>C-acetate to acetyl coenzyme A after myocardial uptake, which is metabolized to <sup>11</sup>C-CO<sub>2</sub> in the tricarboxylic acid cycle.

## <sup>11</sup>C-Flumazenil

<sup>11</sup>C-flumazenil is commonly labeled at the *N*-methyl position by *N*methylation with <sup>11</sup>C-iodomethane, which is prepared from <sup>11</sup>C-CO<sub>2</sub>, and using the freshly prepared Grignard reagent, methylmagnesium bromide (Maziere et al, 1984). The specific activity is very important for this product and therefore is purified by HPLC to give an optimum value between 0.5 and 2 Ci/µmol (18.5–74GBq/µmol). It remains stable for up to 3 h at room temperature at pH 7.0. The molecular structure of <sup>11</sup>C-fumazenil is shown in Fig. 8.2b.

Since it is a benzodiazepine receptor ligand, <sup>11</sup>C-flumazenil is primarily used for the neuroreceptor characterization in humans.

## <sup>11</sup>*C*-*Methylspiperone*

<sup>11</sup>C-methylspiperone (MSP) is prepared by *N*-methylation of commercially available spiperone with <sup>11</sup>C-methyl iodide in the presence of Grignard reagent, methylmagnesium bromide, using different solvents and bases (Mazière et al, 1992). Since spiperones are sensitive to bases and to radiolysis at high level of activity, the yield of <sup>11</sup>C-MSP has been variable for different investigators. Cold spiperone present in the preparation reduces its specific activity and should be controlled. Specific activity should be around 10–50 GBq/mol (270–1,350 mCi/mol). High specific activity <sup>11</sup>C-MSP undergoes autodecomposition in saline due to radiation, and a hydroxyl radical

scavenger (e.g., ethanol) is added to prevent it. The final preparation is filtered through a 0.22- $\mu$ m membrane filter and its pH is adjusted to 7  $\pm$  1 with a suitable buffer. The molecular structure of <sup>11</sup>C-methylspiperone is shown in Fig. 7.2c.

<sup>11</sup>C-methylspiperone is primarily used to determine the dopamine-2 receptor density in patients with neurological disorders, because of its high affinity for D-2 receptors in the brain.

## <sup>11</sup>C-L-Methionine

<sup>11</sup>C-L-methionine has <sup>11</sup>C at its methyl position and has two forms: L- $[1 - {}^{11}C]$  methionine and L-[S-methyl-<sup>11</sup>C] methionine. The former is obtained by the reaction between <sup>11</sup>C-CO<sub>2</sub> precursor and carbanion produced by a strong base added to the respective isonitrile, followed by hydrolysis with an acid. The latter is obtained by alkylation of the sulfide anion of L-homocysteine with <sup>11</sup>C-iodomethane. The product is purified by HPLC yielding a purity of >98% and further filtered through a 0.22-µm membrane filter. The pH should be between 6.0 and 8.0 and it is stable for 2 h at room temperature. The molecular structure of <sup>11</sup>C-L-methionine is shown in Fig. 8.2d.

This compound is used for the detection of different types of malignancies, reflecting the amino acid utilization (transport, protein synthesis, transmethylation, etc.).

## <sup>11</sup>C-Raclopride

Raclopride is labeled with <sup>11</sup>C either by *N*-ethylation with [1-<sup>11</sup>C] iodoethane or by *O*-methylation with [<sup>11</sup>C] iodomethane, although the latter is more suitable for routine synthesis. Both <sup>11</sup>C-labeled iodoethane and iodomethane are prepared from <sup>11</sup>C-CO<sub>2</sub>. The product is purified by HPLC giving a purity of greater than 98%. The specific activity should be in the range of 0.5–2 Ci/µmol (18.5–74 GBq/µmol). The product at pH between 4.5 and 8.5 remains stable for more than 1 h at room temperature. The molecular structure of <sup>11</sup>C-raclopride is shown in Fig.8.2e.

<sup>11</sup>C-raclopride is primarily used to detect various neurological and psychiatric disorders, such as Parkinson's disease, schizophrenia, etc.

## <sup>11</sup>C-Choline

<sup>11</sup>C-choline is prepared by the reaction between the precursor <sup>11</sup>C-methyl iodide and dimethylaminoethanol at 130°C for 5 min (Hara et al, 1999). The reaction mixture is evaporated to remove the precursors leaving behind the residue of <sup>11</sup>C-choline, which is dissolved in water and further purified by the cation exchange method. The final product is available as <sup>11</sup>C-choline chloride with a radiochemical yield of ~43% at the end of synthesis.

<sup>11</sup>C-choline is a highly specific PET tracer used for the detection of various tumors.

## <sup>62</sup>Cu-Pyruvaldehyde-bis(N<sup>4</sup>- methylthiosemicarbazonato) Copper(II) (PTSM)

 $^{62}$ Cu-PTSM is prepared by mixing H<sub>2</sub>(PTSM) in ethanol and  $^{62}$ Cu acetate solution at room temperature for 2–3 min (Green et al, 1990). The mixture is passed through C<sub>18</sub> Sep-Pak column, and finally  $^{62}$ Cu-PTSM is eluted from the column with ethanol followed by filtration through a 0.2-µm filter. The radiochemical yield is nearly 50% (without decay correction).

<sup>62</sup>Cu-PTSM is used for measurement of myocardial perfusion by PET.

## <sup>82</sup>Rb-Rubidium Chloride

<sup>82</sup>Rb-rubidium chloride is available from the <sup>82</sup>Sr–<sup>82</sup>Rb generator, which is manufactured and supplied monthly by Bracco Diagnostics. The activity in the column is typically 90–150 mCi (3.33–5.55 GBq) <sup>82</sup>Sr at calibration time. <sup>82</sup>Rb is eluted with saline and must be checked for <sup>82</sup>Sr and <sup>85</sup>Sr breakthrough daily before the start of its use for patient studies. The allowable limit for <sup>82</sup>Sr is 0.02 μCi/mCi or 0.02 kBq/MBq of <sup>82</sup>Rb and the limit for <sup>85</sup>Sr is 0.2 μCi/mCi or 0.2 kBq/MBq of <sup>82</sup>Rb. Since <sup>82</sup>Rb has a short half-life of 75 s, it is administered to the patient by an infusion pump (see Chap. 12). The administered activity is the integrated activity infused at a certain flow rate for a period of time set by the operator, which is provided on the printout by a printer.

<sup>82</sup>Rb is approved by the FDA for myocardial perfusion imaging to delineate ischemia from infarction.

#### Automated Synthesis Devices

Conventional manual methods of synthesis of radiopharmaceuticals using a high level of radioactivity are likely to subject the persons involved in the synthesis to high radiation exposure. This is particularly true with short-lived positron emitters such as <sup>11</sup>C, <sup>13</sup>N, <sup>15</sup>O, and <sup>18</sup>F, because the quantity of these radionuclides handled in the synthesis is very high. To minimize the level of exposure, automated modules have been devised for the synthesis of PET radiopharmaceuticals.

The automated synthesis device, often called the *black box*, is a unit controlled by microprocessors and software programs to carry out the sequential physical and chemical steps to accomplish the entire synthesis of a radiolabeled product. The unit consists of templates or vials prefilled with required chemicals attached to the apparatus via tubings that are connected to solenoid



FIGURE 8.3. A schematic block diagram showing different components in the <sup>18</sup>F-FDG synthesis box. (Reproduced with kind permission of Kluwer Academic Publishers from Crouzel C et al (1993) Radiochemistry automation PET. In: Stöcklin G, Pike VW (eds) Radiopharmaceuticals for positron emission tomography, Kluwer Academic, Dordrecht, The Netherlands, p 64. Fig. 9)

valves to switch on and off as needed. Most black boxes are small enough to be placed in a space of  $20 \times 20 \times 20$  in. and are capable of self-cleaning. In some units, disposable cassettes (cartridges) are employed so that new cassettes can be used for each new synthesis, thus minimizing the radiation exposure. Various parameters for synthesis such as time, pressure, volume, and other requisites are all controlled by a remote computer. The unit has a graphic display showing the status of the on-going process. After the synthesis, a report with the date, start and end time of the radiosynthesis, and the calculated yield is printed out. Technologists can operate these units very easily. Automated synthesis modules for <sup>18</sup>F-FDG, <sup>13</sup>N-NH<sub>3</sub>, <sup>11</sup>C-CH<sub>3</sub>I, <sup>11</sup>C-HCN, <sup>11</sup>C-acetate, and a few other PET tracers are commercially available. Versatile automated modules are commercially available to use for the synthesis of a variety of PET tracers. This is accomplished by simple exchange or modification of various segments inside the unit to suit the specific product synthesis. A schematic diagram of a black box for <sup>18</sup>F-FDG synthesis is shown in Fig. 8.3. An automated synthesis module for <sup>18</sup>F-compounds marketed by Bioscan is shown in Fig. 8.4. Other vendors include GE Healthcare (Tracerlab), Siemens Medical Systems, and Eckert & Ziegler.



FIGURE 8.4. An automated F-18-Plus nucleophilic fluorination system. (Courtesy of Bioscan, Inc., Washington, DC)

## Compounding of PET Radiopharmaceuticals for Human Use

Although the above section describes methods of various PET radiopharmaceuticals, their commercial manufacturing, marketing, and distribution are governed by the US Food and Drug Administration (FDA) under FDA Modernization Act (FDAMA) passed by US Congress in 1997. However, compounding and dispensing of drugs for human use based on physician's order falls under the regulations of medical and pharmacy practices in individual states in the USA. A noncommercially available drug, if ordered in a prescription by a physician, can be compounded by a pharmacist or some qualified individuals authorized and supervised by the physician using US pharmacopeia (USP) guidelines under the regulations of practice of medicine and pharmacy. Because PET radiopharmaceuticals are short-lived and produced daily in the cyclotron on the order of a prescription by a physician, their production for human use is considered compounding and falls under the USP guidelines. The physicians and pharmacists who compound (or oversee the compounding of) PET radiopharmaceuticals must be responsible for the strength, quality, and integrity of the product for compounding and dispensing.

Like any drug, PET radiopharmaceuticals have to undergo a variety of procedural steps and quality control tests prior to human administration. Strict guidelines for compounding of these drugs have been set by US Pharmacopeia in USP General Chapter <823> "Radiopharmaceuticals for Positron Emission Tomography – Compounding." Although USP Chapter <797> "Sterile Compounding of Pharmaceuticals" entails requirements for sterile compounding of all drugs, USP Chapter <823> supersedes USP Chapter <797> for PET radiopharmaceuticals after compounding, further handling, manipulation, and use of these products fall under the guidelines of USP Chapter <797>.

USP Chapter <797> classifies compounded sterile preparations (CSP) or pharmaceuticals into low-risk, medium-risk, and high-risk level categories based on the potential chemical, microbial, and endotoxin contamination. Radiopharmaceuticals including PET radiopharmaceuticals belong to the low-risk level group.

USP Chapter < 823 > describes at length the guidelines for compounding of PET radiopharmaceuticals. For the sake of brevity, only a brief outline will be presented here.

## Components, Materials, and Supplies

Under this category, specifications of components, materials, and supplies used for compounding of PET tracers must be established in writing for the following:

- (a) Identity, purity, and quality of components (chemicals, targets, gases, etc.), containers and closures, analytical supplies, (chromatography columns, etc.), sterility and pyrogen testing agents must be established.
- (b) Storage conditions (heat, light, humidity, etc.) in a controlled area for the above materials must be known or established.
- (c) Records of lot number, quantity, manufacturer, date of receipt, and expiration date of all the above materials must be kept.
- (d) Verification of each lot of the above material complying with the required specifications must be made.

## Compounding Procedure Verification

- (a) Acceptance limits for the identity, purity, and quality of each compounded radiopharmaceutical must be set in writing.
- (b) A written procedure for compounding of each PET radiopharmaceutical including sterilization by filtration (0.22  $\mu$ m for parenteral administration and 0.45  $\mu$ m for inhalation). These procedures need to be routinely updated, reviewed, and verified at least once a year.

- (c) The use of computer and related automated equipment must undergo strict controls as to their accuracy, operation, and upgrade instituted by authorized personnel only.
- (d) A verification method must be established to verify that all the above steps have met the set acceptance criteria. Prior to human use of a new or modified PET tracer, three consecutive batches of the product must be compounded and verified for the acceptance limit.
- (e) Expiration date and storage conditions must be established and recorded.

## Dispensing of PET Radiopharmaceuticals

The following general rules are recommended for dispensing PET radiopharmaceuticals:

- (a) All compounding and dispensing must be done in sterile clean area using aseptic technique.
- (b) Label all components for identity and traceability.
- (c) The label of PET radiopharmaceutical container must contain: the name of the radiopharmaceutical, a lot or batch number, a radioactive symbol, total activity and concentration at calibration time, and time and date of expiration.
- (d) Records of all the above information and the percent yield of the final product must be maintained in writing for each batch of the PET tracer.
- (e) The qualified individual compounding a batch must initial the record attesting to the accurate current compounding procedure used.
- (f) The overall responsible individual must sign and date the record attesting to compliance to the verified compounding procedure.

## Aseptic Technique

- (a) Equipment and components used in compounding PET radiopharmaceuticals must be clean and sterile supported by a verification method.
- (b) Work must be done in clean areas, e.g., a Class 100 aseptic hood like laminar flow hood.
- (c) Clean garb and sterile gloves must be worn during compounding.
- (d) Vial septum should be sterilized by swabbing with 70% alcohol before inserting the content into or withdrawing it from the vial.

## Quality Control of PET Radiopharmaceuticals

The quality control tests have been categorized for PET radiopharmaceuticals into two groups: those with nuclides with  $t_{1/2} > 20 \text{ min}$  and those with nuclides with  $t_{1/2} < 20 \text{ min}$ . In the case of the former, each production on a given day is considered a batch; while in the latter group, a batch is defined as all related subbatches of PET radiopharmaceuticals compounded on a given day. The first subbatch (for  $t_{1/2} < 20 \text{ min}$ ) is designated as the *initial quality control subbatch* for the day, which is used for all quality control tests for all subsequent subbatches.

- (a) The following tests must be carried out for all PET radiopharmaceuticals prior to release for human use:
  - Visual inspection.
  - pH.
  - Radionuclidic purity.
  - Radiochemical purity.
  - Specific activity.
  - Limits for residual solvents or toxic chemicals.
  - A bubble test to check the integrity for the membrane filter immediately after filtration but prior to release of the product. (This is done by applying air pressure through the filter until the validated bubble point is reached. Filter integrity is indicated by the absence of a steady stream of bubbles.)
  - A 20-min endotoxin test on each batch  $(t_{1/2} > 20 \text{ min})$  or quality control subbatch  $(t_{1/2} < 20 \text{ min})$ .
  - Sterility tests on each individual batch  $(t_{1/2} > 20 \text{ min})$  or quality control subbatch  $(t_{1/2} < 20 \text{ min})$  initiated within 24 h of sterility filtration.
- (b) Written procedures for each quality control test must be established.
- (c) Verification testing of all equipment (e.g., dose calibrator) and procedures must be carried out to comply with the acceptance limit. The results must be recorded, signed, and dated by the individual carrying out the test.

## Methods of Quality Control

In the above section, requirements for compounding of PET radiopharmaceuticals have been presented. In this section, the methods of quality control tests for these products are briefly described below. Since PET radiopharmaceuticals are short-lived, some lengthy tests cannot be performed prior to release for human use and so they are performed within a short time after the release.

The quality control tests can be divided into two categories: physicochemical tests and biological tests. Refer to Saha (2004) for detailed description of these methods. These tests are briefly outlined below.

*Physicochemical Tests*: Physicochemical tests include the tests for the physical and chemical parameters of a PET radiopharmaceutical, namely physical appearance, isotonicity, pH, radionuclidic purity, chemical purity, and radiochemical purity.

*Physical appearance.* Physical appearance relates to the color, clarity, or turbidity of a PET radiopharmaceutical and should be checked by visual inspection of the sample.

pH. The pH of a PET radiopharmaceutical for human administration should be ideally 7.4, but both slightly acidic and basic pH values are tolerated due to the buffer capacity of the blood. The pH can be adjusted by adding appropriate buffer to the solution.

*Isotonicity*. Isotonicity is the ionic strength of a solution, which is mainly adjusted by adding appropriate electrolytes. Normally PET radiopharmaceuticals have appropriate isotonicity for human administration.

*Radionuclidic purity*. The radionuclidic purity of a radiopharmaceutical is the fraction of total activity in the form of the desired radionuclide in the sample. These impurities primarily arise from the radionuclides produced by various nuclear reactions in a target as well as the impurities in the target material. Using a multichannel spectrometer, one can determine the level of impurities in a sample of a positron-emitting radionuclide produced by a specific nuclear reaction in a cyclotron. Using highly pure target material and appropriate chemical separation techniques, the radionuclidic impurity can be minimized to an acceptable level. Short-lived radionuclides can be allowed to decay to have a pure long-lived radionuclide in question. Even though the impurities in the routine preparations of PET radionuclides do not vary significantly from batch to batch, periodic checkup is recommended to validate the integrity of the method of production. The radionuclidic impurities must be established in <sup>11</sup>C, <sup>13</sup>N, <sup>15</sup>O, and <sup>18</sup>F radionuclides, prior to their use in the synthesis of radiolabeled compounds.

*Chemical purity*. Chemical purity is the fraction of a radiopharmaceutical in the form of the desired chemical molecule whether all of it is radiolabeled or not. The presence of extraneous stable atoms may cause adverse reactions and is not desirable in a PET radiopharmaceutical. These impurities arise from the incomplete synthesis, addition of extraneous ingredients during the synthesis, and so on. Chemical methods such as the spectrophotometric method, ion exchange, solvent extractions, chromatography, etc. are applied to measure the level of these chemical impurities. Again, these tests can be performed a priori in many dry runs and thus the level of chemical impurities can be established, prior to human administration.

*Radiochemical purity.* The radiochemical purity of a radiopharmaceutical is defined as the fraction of the total activity in the desired chemical form in the sample. These impurities arise from incomplete labeling, breakdown of the labeled products over time due to instability, and introduction of extraneous labeled ingredients during synthesis. These impurities cause altered in vivo biodistribution after administration, resulting in an unnecessary radiation dose to the patient. For these reasons, the United States Pharmacopea (USP) and the United States Food and Drug Administration have set limits on the impurities in various radiopharmaceuticals, and these limits must not be exceeded in clinical operations. Since most PET radiopharmaceuticals are produced on site daily, the radiochemical purity must be checked for each batch. For very short-lived radionuclides, however, the methodology must be validated beforehand by carrying out many dry runs so that the radiochemical purity of the product remains within the limit set for human administration.

Various analytical methods are employed to establish the radiochemical purity of PET radiopharmaceuticals. The most common method is HPLC, which gives separation of components with high resolution. The general principle of HPLC involves forcing a sample at high pressure through a column of special packing material by an electric pump, whereby various components pass out of the column at different rates depending on their molecular weights. The fractions are collected at different times. The different components can then be identified and quantitated either by counting the radioactivity in each fraction with a counter or by measuring their absorbance with an ultraviolet (UV) monitor.

Another common method of determining the radiochemical purity is the thin layer chromatography (TLC). In this method, a drop of the radiopharmaceutical sample is spotted on a solid-phase paper strip (e.g., silica gel, Whatman) and then the paper is placed vertically in a small vial containing a small amount of an appropriate solvent, taking care that the spotted area remains above the solvent. The solvent flows along the paper strip, and different components of the sample will flow at different rates along the strip depending on their solubility in the solvent. The ratio of the distance traveled by a component to the distance traveled by the solvent front is called the  $R_{\rm f}$ value. When the solvent front reaches the top of the strip, the strip is removed and scanned for the distribution of components along the strip. Alternatively, the strip is cut into several segments (e.g., ten segments), and the activity in each segment is measured by a counter. From the counts of the segments, the radiochemical purity can be calculated.

*Biological Tests*: Biological tests include sterility testing, pyrogen testing, and toxicity testing.

Sterility. Sterility indicates the absence of any viable bacteria or microorganisms in a radiopharmaceutical preparation. All radiopharmaceuticals must be sterile prior to administration to humans, and it is normally accomplished by filtering the product through a 0.22- $\mu$ m membrane filter or heating the sample to 120°C for 20 min at a pressure of 18 pounds per square inch. PET radiopharmaceuticals are normally sterilized by filtration because of their short half-life.

Sterility tests are normally performed by incubating the sample with fluid thioglycollate medium at  $30-35^{\circ}$ C for 14 days or with soybean–casein digest medium at  $20-25^{\circ}$ C for 14 days. The sample volume should be as large as that for human dosage. If bacterial growth is observed in either test, the preparation is considered asterile. For PET radiopharmaceuticals, these tests must be started within 24 h after the release of the product.

*Pyrogenicity.* Pyrogens are bacterial endotoxins consisting of polysaccharides or proteins produced by the metabolism of microorganisms and upon

administration they cause undue symptoms such as fever, flushing, chill, sweating, malaise, etc. These symptoms typically set in 30 min to 2 h after administration and are rarely fatal. There are no specific methods of making a preparation pyrogen-free, and the only way to avoid pyrogens is to strictly follow the method of preparation employing meticulous aseptic technique so that microbes are not introduced into the sample.

Tests for pyrogens include a rabbit test, in which rabbits are administered with the radiopharmaceutical and their rectal temperatures are monitored. From the rise in temperature in the rabbits, pyrogenicity of a sample is determined. However, a simpler and quicker method is the so-called limsulus amebocyte lysate (LAL) test, also called the bacterial endotoxin test (BET). In this test, the lysate of amebocytes from the blood of the horseshoe crab (*Limulus polyphemus*) is mixed with the sample and incubated at 37°C. An opaque gel is formed within 15–60min depending on the concentration of pyrogens.

*Toxicity*. The toxicity of a radiopharmaceutical causes alteration in the histology or physiologic functions of an organ or even death of a species after in vivo administration. It is commonly characterized by  $LD_{50/60}$ , which is defined as the quantity of a sample that kills 50% of the species within 60 days after administration. It must be established at least in two species before human administration, and the dosage to the humans is decided by a large safety factor. Toxicity arises from the pharmaceutical part and most PET radiopharmaceuticals are not toxic for human administration.

# USP Specifications for Routine PET Radiopharmaceuticals

## <sup>18</sup>*F*-*Fluorodeoxyglucose*

Appearance:	Clear
pH:	4.5–7.5
Specific activity:	Not less than 1 Ci(37 GBq)/µmol
Radionuclidic purity:	Not less than 99.5% should correspond to 511 keV, 1.022 MeV, or Compton scatter peaks of $^{18}{\rm F}$
Chemical purity:	Major impurities are Kryptofix 2.2.2 and 2-chloro-2-deoxy-D-glucose, which are determined by TLC. Kryptofix 2.2.2 should not exceed 50 $\mu$ g/ml of the sample volume and 2-chloro-2-deoxy-D-glucose should not exceed 1 mg per total volume of the batch produced
Radiochemical purity:	It is determined by TLC using activated silica gel as the solid phase and a mixture of acetonitrile and water (95:5) as the solvent. The $R_{\rm f}$ value of <sup>18</sup> F-FDG is 0.4. The radiochemical purity should be more than 90%

## 6-<sup>18</sup>*F*-*L*-*Fluorodopa*

Appearance:	Clear
pH:	6–7
Specific activity:	Not less than 100 mCi (3.7 GBq)/mmol
Radionuclidic purity:	Not less than 99.5% correspond to 511 keV, 1.022 MeV, or Compton scatter peaks of $^{18}\rm{F},$ with no individual impurity present more than 0.1%
Chemical purity:	Since the most common method of production utilizes organomer- cury precursor, mercury is the major toxic impurity. It is deter- mined by atomic absorption spectrometry and its USP limit is $0.5 \mu\text{g/ml}$ of L-dopa solution
Radiochemical purity:	It is determined by the HPLC method or ion pair chromatography. The USP limit is 95% of the total radioactivity in the form of $6^{-18}$ F-L-fluorodopa

## <sup>13</sup>N-Ammonia

Appearance:	Clear
pH:	4.5–7.5
Specific activity:	No carrier added
Radionuclidic purity:	Not less than $99.5\%$ should correspond to $511  keV$ , $1.022  MeV$ ,
	and Compton scatter of <sup>13</sup> N
Chemical purity:	Aluminum and titanium are the common impurities, determined
	by colorimetric methods. The USP limit of $Al^{3+}$ is 10 µg/ml of the
	solution
Radiochemical purity:	It is determined by the HPLC method. The radiochemical yield
	should be greater than 95%

## Questions

- 1. Describe in detail the method of <sup>18</sup>F-FDG synthesis.
- 2. Describe the method of synthesis of (a) 6-<sup>18</sup>F-L-Fluorodopa; (b) <sup>18</sup>F-fluorothymidine; (c) <sup>11</sup>C-L-methionine.
- 3. What is the difference between the nucleophilic and electrophilic reaction?
- 4. What are the clinical uses of <sup>18</sup>F-FDG, <sup>18</sup>F-FLT, 6-<sup>18</sup>F-L-Fluorodopa, <sup>15</sup>O-Water, <sup>13</sup>N-Ammonia, <sup>11</sup>C-Sodium acetate, and <sup>11</sup>C-Methylspiperone.
- 5. Describe the operational principles of an automated synthesis box.
- 6. Define (a) radionuclide purity, (b) radiochemical purity, (c) chemical purity of a radiopharmaceutical.

- 7. Describe the method of determining the radiochemical purity of a <sup>18</sup>F-FDG sample.
- 8. Describe the methods of sterilizing radioactive samples.
- 9. Describe the methods of sterility tests and pyrogen tests.
- 10. A sterile sample is always pyrogen-free. True \_\_\_\_\_; False \_\_\_\_\_.
- 11. PET radiopharmaceuticals fall under USP guidelines (a)  $\langle 823 \rangle$  or  $\langle 797 \rangle$ .
- 12. A LAL test is required prior to release of PET radiopharmaceuticals for human use. True \_\_\_\_; False \_\_\_\_.
- 13. Sterility test of PET radiopharmaceuticals must begin (a) prior to release;(b) within 24 h of release; (c) anytime after release; (d) is not required.

## References and Suggested Reading

- Green MA, Mathias CJ, Welch MJ et al (1990). Copper-62-labeled pyruvaldehyde bis (N<sup>4</sup>-methylthiosemicarbazanato) copper (II): synthesis and evaluation as a positron emission tomography tracer for cerebral and myocardial perfusion. J Nucl Med 31:1989
- Hamacher K, Coenen HH, Stöcklin G (1986). Efficient stereospecific synthesis of NCA 2-[<sup>18</sup>F]-fluoro-2-deoxy-D-glucose using aminopolyether supported nucle-ophilic substitution. J Nucl Med 27:235
- Hara T, Yuasa M (1999). Automated synthesis of [<sup>11</sup>C] Choline, a positron-emitting tracer for tumor imaging. Appl Radiat Isot 50:531
- Huisman MC, Higuchi T, Reder S et al (2008). Initial characterization of an <sup>18</sup>F-labled myocardial perfusion tracer. J Nucl Med 49:630
- Kabalka GW, Lambrecht RM, Fowler JS et al (1985). Synthesis of <sup>15</sup>O-labelled butanol via organoborane chemistry. Appl Radiat Isot 36:853
- Kamarainen EL, Kyllonen T, Nihtila O et al (2004). Preparation of fluorine-18 labeled fluoromisonidazole using two different synthesis methods. J Labeled Comp Radiopharm 47:37
- Luxen A, Guillaume M, Melega WP et al (1992). Production of 6-[<sup>18</sup>F]fluoro-L-dopa and its metabolism in vivo a critical review. Nucl Med Biol 19:149
- Machula HJ, Blocher A, Kuntzch M et al (2000). Simplified labeling approach for synthesizing 3'-deoxy-3'-[<sup>18</sup>F]fluoro-thymidine [<sup>18</sup>F]FLT. J Radioanal Nucl Chem 243:843
- Maziere M, Hantraye P, Prenant C et al (1984). Synthesis of ethyl-8-fluoro-5,6dihydro-5-[<sup>11</sup>C]-methyl-6-oxo-4H-imidazo[1,5][1,4] benzodiazepine-3-carboxylate (R<sub>0</sub>-151788-<sup>11</sup>C): a specific radioligand for the in vivo study of central benzodiazepine receptors by positron emission tomography. Int J Appl Radiat Isot 35:973
- Mazière B, Coenen HH, Haldin C et al (1992). PET radioligands for dopamine receptors and re-uptake sites: chemistry and biochemistry. Nucl Med Biol 19:497
- Meyer GJ, Ostercholz A, Handeshagen H (1986). <sup>15</sup>O-water constant infusion system for clinical routine application. J Label Comp Radiopharm 23:1209
- Oberdorfer F, Theobold A, Prenant C (1996). Simple production of [1-carbon-11] acetate. J Nucl Med 37:341

- Reischl G, Ehrlichmann W, Bieg C et al (2005). Preparation of the hypoxia imaging PET tracer [<sup>18</sup>F] FAZA: reaction parameters and automation. Appl Radiat Isot 62:897
- Saha GB (2004). Fundamentals of nuclear pharmacy, 5th ed. Springer, New York
- Stöcklin G, Pike VW (eds) (1993). Radiopharmaceuticals for positron emission tomography, Kluwer Academic, Dordrecht
- U.S. Pharmacopeia 32 & National Formulary 27 (2009). United States Pharmaceutical Convention, Rockville, MD
- Welch MJ, Kilbourn MR (1985). A remote system for the routine production of oxygen-15 radiopharmaceuticals. J Label Comp Radiopharm 22:1193
- Wester HJ, Herz M, Weber W et al (1999). Synthesis and radiopharmacology of O-2-[<sup>18</sup>F] fluoroethyl-L-tyrosine for tumor imaging. J Nucl Med 40:205
- Wieland D, Bida G, Padgett H et al (1991). In-target production of [<sup>13</sup>N]ammonia via proton irradiation of dilute aqueous ethanol and acetic acid mixtures. Appl Radiat Isot 42:1095

## 9 Regulations Governing PET Radiopharmaceuticals

The use of PET radiopharmaceuticals is regulated for both pharmaceutical quality as well as radiation exposure. In the USA, the pharmaceutical quality (e.g., stability, biological safety, efficacy, etc.) of PET radiopharmaceuticals is regulated by the United States Food and Drug Administration (FDA), whereas the radiation aspects are regulated by the Nuclear Regulatory Commission (NRC). The following is a brief description of different regulations that affect the use of PET radiopharmaceuticals. Only the important points of the regulations are presented.

#### Food and Drug Administration

Since 1975, the clinical use of all radiopharmaceuticals has been regulated by the US FDA. For investigational purposes, a Notice of Claimed Investigational Exemption for a New Drug (IND) is submitted by a sponsor (an individual or a commercial manufacturer) to the FDA for approval of the protocol to use a specific radiopharmaceutical in humans. There are three phases in the IND clinical investigation of a radiopharmaceutical. In Phase I, only pharmacologic and biodistribution data of the radiopharmaceutical are obtained in a limited number of humans and no therapeutic and diagnostic evaluation can be made. In Phase II, clinical effectiveness of the radiopharmaceutical is evaluated for a specific disease only in a few patients. In Phase III, a large number of patients are included in the clinical trial to establish the safety and clinical effectiveness of the radiopharmaceutical for a specific disease.

After a radiopharmaceutical is proven by clinical trials to be safe and efficacious for a specific clinical indication, a New Drug Application (NDA) is submitted with all clinical data by a commercial vendor to the FDA for approval to market it. If the FDA is convinced of the safety and effectiveness of the radiopharmaceutical for a clinical indication, the FDA then approves the product for marketing. It takes a long time (at times, a couple of years) from IND to NDA for approval of a particular radiopharmaceutical for clinical use in humans.

PET radiopharmaceuticals are uniquely different from conventional radiopharmaceuticals because they are short lived and most are produced on site at the cyclotron facility. In most cases, synthesis of these tracers by radiolabeling with positron emitters is accomplished by online automated methods for the sake of brevity. Several lengthy quality-control tests are often performed on an "after-the-fact" basis. The production methods and their technical details may vary from facility to facility. For these reasons, the FDA treats PET radiopharmaceuticals somewhat differently and attempts to standardize the techniques employed in all facilities. In the mid-1990s, the FDA published the regulations and guidelines for the manufacture of PET radiopharmaceuticals in the Federal Register. These regulations provided guidance for submission of NDAs and abbreviated NDAs (ANDAs) to the FDA for PET radiopharmaceuticals, and the guidelines gave details of the current good manufacturing practice (CGMP) to follow in the manufacture of PET radiopharmaceuticals.

However, the above regulations and guidelines were considered to be costly and burdensome by the nuclear medicine community, particularly the commercial vendors. Also, other radiopharmaceuticals as well as conventional drugs were subjected to strict scrutiny by the FDA, resulting in a very long waiting time for marketing approval. Following strong lobbying by the nuclear medicine community, drug manufacturers, and other stakeholders, the US Congress enacted the FDA Modernization Act (FDAMA) (Public Law 105–115) in 1997 to overhaul several aspects of the drug manufacturing industry, which took effect on November 21, 1997. Under the Act, the existing regulations regarding PET radiopharmaceuticals were retracted and new provisions were introduced.

In the FDAMA, PET radiopharmaceuticals are categorized as positronemitting drugs compounded by, or on the order of, a licensed practitioner following the state's regulations and meeting the specifications of the official monographs of the USP. The FDAMA directed the FDA to develop approval procedures and guidance for the manufacture of PET radiopharmaceuticals within a time frame of 4 years. In this 4-year time line, all PET tracer-producing facilities in USA were to be registered as drug manufacturers. In the first 2 years, the FDA was to consult with patient advocacy groups, professional associations, manufacturers, physicians, and scientists who prepare or use PET drugs, in developing approval procedures and CGMP for PET radiopharmaceuticals. The remaining 2 years were allowed for all PET radiopharmaceutical manufacturing facilities to comply with the new PET drug CGMP and register as manufacturers. During these 4 years, the FDAMA prohibited the FDA to require the submission of NDAs or ANDAs for PET radiopharmaceuticals produced according to the USP specifications. However, voluntary submissions of NDAs or ANDAs were not prohibited.

Based on the literature survey of PET data, the FDA concluded that certain PET radiopharmaceuticals, when produced under specific conditions, are safe and effective for certain clinical indications. The three PET radiopharmaceuticals <sup>18</sup>F-sodium fluoride for bone imaging, <sup>18</sup>F-FDG for use in oncology and for assessment of myocardial viability, and <sup>13</sup>N-NH<sub>3</sub> for evaluation of myocardial blood flow were approved by the FDA in 2000. <sup>82</sup>Rb-rubidium chloride was approved by the FDA for evaluation of myocardial perfusion in 1989.

The FDA also published in the Federal Register a draft guidance for industry entitled, "PET Drug Applications – Content and Format for NDAs and ANDAs" (March 10, 2000; 65 Fed.Reg. 13010). It is intended to assist manufacturers of certain PET radiopharmaceuticals in submitting NDAs or ANDAs. Comments were solicited until a final rule is adopted. The guidance details the criteria for when to apply for an NDA or an ANDA and what to include in the application.

As mandated by the FDAMA, since 1999, the FDA issued a couple of draft regulations and guidances for CGMP for PET drugs, each successive one being revised with responses to comments from the public and stakeholders. The final draft guidance for PET CGMP was issued in 2005 [PET Drug Products-Current good manufacturing practice (CGMP). September, 2005] and the final guidance (PET Drugs – Current good manufacturing practice (CGMP), December, 2009) has been issued.

Whereas readers are referred to these specific documents for details available on the Web site http://www.fda.gov/cder/fdama, some of the specifics are briefly mentioned here. The essence of this guidance emphasizes the importance of the overall quality assurance in manufacturing a PET radiopharmaceutical. All equipment and measurements used in the manufacture must be validated. The areas and hoods in which PET radiopharmaceuticals are manufactured must be run in a sterile condition. The personnel responsible for the manufacture must be well trained in the methodology, and an appropriate number of personnel are required in a production laboratory. Each step of the production must be verified and records must be maintained. The sterility and pyrogen testing of the finished product must be performed by appropriate methods. If a PET radiopharmaceutical is to be commercially distributed, appropriate containers and techniques must be adopted for safe shipments.

## Exploratory IND

A traditional Phase I IND requires a very comprehensive and detailed application for any human research protocol for evaluation of a drug. In 2006, the FDA has instituted a new approach, called the "Exploratory IND," to ease the application process as well as expedite the research progress. An exploratory IND is a clinical trial that is conducted early in Phase I, involves a limited exposure, and has no therapeutic or diagnostic intent (e.g., microdose study). It usually involves the use of a very limited dose of the drug in research subjects for a limited time (e.g., 7 days). Through exploratory IND, an investigator can assess (a) the mechanism of action, (b) pharmacokinetics, (c) the therapeutic potential of a drug from a group of candidates, and (d) explore the biodistribution using a variety of imaging techniques.

An exploratory IND containing the following information must be submitted to the FDA:

- (a) A clinical development plan: It entails the rationale for the drug in question, a single-dose or multiple-dose study, and pharmacologic and/or pharmacodynamic end points.
- (b) Chemistry, manufacturing, and control: It includes a summary report for each drug on the following: physicochemical and biological properties of the drug; dosages to be administered, route of administration, grade and quality of all ingredients in the manufacture of the drug, name and address of the manufacturer, if different from the sponsor; method of manufacture of the drug; composition of the drug; tests performed to ensure the identity, strength and quality, purity and potency of the drug; stability of the drug; and results of sterility and pyrogen tests.
- (c) Pharmacology and toxicology information regarding the drug: This information can be obtained from animal studies using increasing doses of the drug, but the needed information may be less than that required in a traditional IND.
- (d) Previous human experience with the investigational product, if any.

It should be noted that an exploratory IND is meant for quick assessment of pharmacokinetics, pharmacological effects, and mechanism of action of a drug for its potential clinical use. For pharmacokinetics study, microdoses of the product are used not to induce any pharmacological effect. A microdose is defined as less than 1/100th of the dose calculated to yield a pharmacological effect of a test product with a maximum dose of  $\leq 100 \,\mu g$ . Microdose studies performed in animals for pharmacokinetics are acceptable to the FDA for extrapolation to human studies. For pharmacological studies, toxicity of the test product is established in animals by repeated administration of the product over a 7-day period and observing the pathological changes in tissues. The study can be extended to a 2-week repeat study. The aim of the experiment is to establish the starting dose and the maximum dose of the test product for safety and efficacy in the clinical trial. The dose and the dosing regimen determined in the animal experiments for pharmacokinetics and pharmacologic effects are extrapolated to the human clinical trial to establish the mechanism of action for a given target. The study must be withdrawn after the completion of the proposed protocol. Readers are referred to "Guidance for Industry, Investigators and Reviewers Exploratory IND Studies" at http://www.fda.gov/cder/guidance for further information.

## Radioactive Drug Research Committee

In order to expedite research investigations of new radiopharmaceuticals, in 1975 the FDA allowed institutions to form the so-called *Radioactive Drug* Research Committee (RDRC) (21CFR 361.1), which functions like a mini-FDA. The committee is composed of at least five members - a nuclear physician, a radiochemist or radiopharmacist competent to formulate radioactive drugs, a person with experience in radiation safety and dosimetry, and at least two more individuals of other disciplines. Additional members of diverse disciplines are recommended in the committee. The RDRC is normally formed under a medical institution having sufficient experts, but a joint RDRC also can be established with more than one institution to achieve a high level of diversity and experience. The proposed committee membership with a designated chairman is submitted to the FDA, and upon satisfactory review it is approved by the FDA. The committee is primarily charged with the approving and monitoring of protocols involving the research use of radiopharmaceuticals to study the kinetics, distribution, localization, biochemistry, physiology, etc. in humans, but not for immediate therapeutic or diagnostic purpose nor to determine the safety and effectiveness of the drug as in a clinical trial.

The radiation dose to the critical organs (effective dose, dose to the lens and blood forming organ) cannot exceed 3 rem (0.03 Sv) from a single dosage and a sum of greater than 5 rem (0.05 Sv) per year during the entire study. Only 30 patients over the age of 18 can be studied per protocol, and a special summary report must be submitted to the FDA, if the number exceeds 30 and the age is greater than 18. The pregnant women are not allowed to participate in the study under RDRC.

An investigator formally submits a research protocol to the RDRC with detailed description of the study, but prior to submission, the protocol must be approved by the Institutional Review Board. The RDRC meets at least quarterly if active research is pursued, with at least 50% membership present. Members with conflict of interest in a protocol must excuse themselves from voting on the protocol. Based on the critical review of the protocol, the study may be or may not be approved by the RDRC. If approved, the study will be regularly monitored on the progress. Any adverse effects encountered during the study must be immediately reported to the FDA. The Chairman of the RDRC is the primary contact person with FDA and must submit an annual report on all projects. Also any change in the membership must be reported to and approved by the FDA.

#### Difference Between RDRC and Exploratory IND

The following major differences between the two processes are noted:

1. The study under the RDRC is a basic research protocol investigating the pharmacokinetics, pharmacology, biodistribution, etc. of a radioactive

drug in patients, whereas an exploratory IND is a clinical protocol to study the safety and efficacy of a drug using small dosages with maximally tolerable pharmacologic effect.

- 2. While an exploratory IND protocol is approved and monitored directly by the FDA, the RDRC studies are approved and monitored by the committee itself and the FDA monitors it only indirectly.
- 3. The number of subjects is normally limited to 30 in the RDRC, whereas there is no limit on the number of patients in exploratory IND, although it should be small.
- 4. In the RDRC, if subjects of age less than 18 or more than 30 subjects are used, a special summary report must be submitted to the FDA. Also women of childbearing age must declare in writing the absence of pregnancy to participate in the RDRC study. Under exploratory IND, no such restriction exists expect that each case is individually evaluated.
- 5. The RDRC limits the radiation doses to subjects, whereas in an exploratory IND there is no such limit.

## Radiation Regulations for PET Radiopharmaceuticals

Until 2005, the NRC regulated only byproduct materials that were produced in reactors, whereas all natural and accelerator-produced radionuclides were regulated by the state agencies such as the Health Department, Environmental Protection Department, etc. But the US Congress passed a law in 2005 to include all naturally occurring and accelerator-produced radionuclides as byproduct material and authorized the NRC to regulate them. Now all radionuclides, irrespective of the source of production, are regulated by the NRC. At the time of this writing, 37 of the 50 states in the USA have entered into agreement with the NRC to have the authority to regulate all byproduct materials. These states are called Agreement states and implement the NRC regulations for the use of byproduct material including PET radiopharmaceuticals. Regulations vary among 50 states, but the basic principles of regulations are the same in all states. However, state regulations can be stricter but not less strict than NRC regulations. In nonagreement states, the NRC is responsible for regulations of PET radiopharmaceuticals. Given below are the highlights of some important and pertinent regulations concerning the clinical and research use of PET radiopharmaceuticals.

## License or Registration

*Facilities* The PET center and/or the cyclotron facility must be registered or licensed by the state for the manufacture of PET radiopharmaceuticals. However, the use of PET radiopharmaceuticals is regulated by the NRC or Agreement States. The license for medical use of radiopharmaceuticals is

called the radioactive material (RAM) license, which a licensee obtains after applying to the NRC or the Agreement State. The RAM license specifies the type, chemical form, and the possession limit of the radionuclides to be used, depending on the scope of the operation at the applicant's facility. While a PET center may be approved for a few hundred millicuries of <sup>18</sup>F-FDG in its RAM license, the cyclotron facilities may be approved in the license for curie amounts for commercial distribution. Note that the <sup>82</sup>Sr-<sup>82</sup>Rb generator typically is supplied in a strength of 80–150 mCi (2.96–5.55 GBq) of <sup>82</sup>Sr, but it also contains <sup>85</sup>Sr which may be as much as five times the amount of <sup>82</sup>Sr. Although <sup>85</sup>Sr is not used clinically, but is contained in the generator, a licensee has to include in the RAM license the maximum possible amount of <sup>85</sup>Sr as the possession limit in addition to those of <sup>82</sup>Sr and <sup>82</sup>Rb. These licenses are issued for a certain number of years (e.g., 1 year, 3 years, etc.) and renewed after the period, if needed. The licensee agrees in the license application to strictly follow all the terms and regulations implemented by the NRC or Agreement State.

A cyclotron is required to be registered with the state since it produces radionuclides. A dedicated PET scanner may or may not be required to be registered in a state depending on the state's statutes on this matter. Many states require a certificate of need (CON) prior to the purchase of a PET scanner, a mobile PET, or a PET/CT scanner. A PET/CT scanner is required to be registered with the state because of the CT unit, since all states require registration of radiation-generating machines.

*Physicians* Physicians are required to be licensed by the NRC or the Agreement State as authorized users for the medical use of byproduct materials in humans. Accredited board certifications or minimum hours of training and experience are required to qualify as authorized users. As required by the NRC, 700 h of training and experience, which include 80 h of classroom and laboratory training in radiation science and 620 h of work experience in radionuclide handling, are needed to qualify as an authorized user for imaging and localization studies using PET radiopharmaceuticals (10CFR35.290). In addition to these requirements, a preceptor's certification as to the competence of the individual is required. The specialty boards that meet the requirements of the above hours of training and work experience are considered for the authorization for PET studies.

For interpretation of PET or PET/CT studies, the JCAHO requires that every hospital must have a definite policy in place to offer privileges to staff members to practice their discipline, but does not spell out any specific qualifications for any particular privilege. So all privileges that include interpretation of diagnostic images are hospital specific and normally are granted based on the standards of competency set forth by respective professional organizations. The Society of Nuclear Medicine, the American College of Nuclear Physicians, and the American College of Radiology set these standards for various diagnostic imaging modalities. For body PET interpretation, physicians should meet the following requirements: certification by the American Board of Nuclear Medicine (ABNM) or American Board of radiology (ABR); interpretation of 150 PET and/or PET/CT examinations under the direct supervision of an ABNM- or ABR-certified physician who has interpreted 500 PET and/or PET/CT examinations; 8 h of continuing medical education (CME) in PET and/or PET/CT studies for physicians with ABNM certification or ABR certification with nuclear radiology subspecialty; or 35 h of CME for other ABR-certified physicians. The continuation of privilege requires interpretation and reporting of 100 PET and/or PET/CT studies per year.

For interpretation of CT part in PET/CT studies, ABR-certified diagnostic radiologists are privileged by virtue of their training, whereas the ABNM-certified physicians should have training in CT that include 100 h of continuing education incorporating the physics of diagnostic radiology and interpretation of 500 CT examinations including a distribution of the neck, chest, abdomen, and pelvis, under the supervision of a qualified radiologist. The continuation of privilege requires interpretation and reporting of 100 PET/CT studies per year.

*Technologists* To work in nuclear medicine in USA, a nuclear medicine technologist is required to be certified by the Nuclear Medicine Technology Certification Board (NMTCB) or the American Registry of Radiologic Technologists (ARRT) with specialty in nuclear medicine technology. Many states require healthcare technologists to be licensed to practice their profession in the state. At present, 26 states in the country require licensing for nuclear medicine technologists; 38 states require licensure for radiographers; and 33 states require licensure for radiation therapists. Congress is considering the passage of the Consumer Assurance of Radiologic Excellence (CARE) bill to establish educational and credentialing standards for personnel who perform medical imaging and radiation therapy procedures. The nuclear medicine technology licensure is given based on the NMTCB certification and work experience. The duration of the license varies among the states, but they are renewable on the accrual of required continuing medical education (CME) credits.

Current nuclear medicine technologists can work as PET technologists; however, many consider PET technology to be a unique modality and hence see a need for a separate certification for the PET technologists. The NMTCB introduced a PET specialty examination starting in 2004 for nuclear medicine technologists and also now offers it to registered radiographers and radiation therapy technologists.

For taking the exam, the candidates must have active certification in NMTCB, ARRT(N), and Canadian Association of Medical Radiation Technologists [CAMRT(RTNM)] and 700 h of clinical experience as a certified/registered nuclear medicine technologist working on a dedicated PET scanner or a PET/CT scanner.

CAMRT(RT), CAMRT(RTT), ARRT(R), or ARRT(T) certificants are eligible to sit for the PET examination if they meet all the three of the following requirements:

- 1. Active CAMRT(RTR), CAMRT(RTT), ARRT(R), or ARRT(T) certification.
- 2. Seven hundred hours of documented clinical experience performing all aspects of PET imaging including radiopharmaceutical handling, injection, and imaging under supervision of a nuclear medicine physician or a radiologist and direct supervision of a certified NMTCB, ARRT(N), or CAMRT(RTNM) technologist.
- 3. Satisfactory completion of a minimum of 15 contact hours of coursework each in radiopharmacy, nuclear medicine instrumentation, and radiation safety (for a total of 45 h).

The PET/CT units involve the use of two modalities - PET using radionuclides and CT using X-ray radiations – thus complicating the issue of personnel as to who will operate them for a given patient study. Ideally, technologists credentialed in both CT and nuclear medicine technology should operate PET/CT units. However, regulations vary from state to state regarding the operation of PET/CT. Some states require dual certification of the technologists in nuclear medicine and radiography or require two technologists - one certified in nuclear medicine and the other in radiography. However, CT in PET/CT scanners is mainly used for fusion of CT and PET images and attenuation correction for PET images and is considered less complex than in diagnostic tests. Cross training programs are offered by different groups in the USA, which include several descriptive modules of course materials on CT technology. Nuclear medicine technologists take these courses online or by correspondence and then pass a test. These cross-trained technologists then take limited CT clinical training at the employment site or elsewhere to be qualified to perform the CT part in PET/CT studies for the purpose of fusion of images and attenuation correction only. Often, PET/CT facilities use the CT for diagnostic purpose as an additional service involving administration of contrast agents as needed. Cross-trained nuclear medicine technologists cannot perform these CTs, and registered radiographers with CT experience are required to perform them. With a shortage of trained technologists, staffing in PET/CT for CT operation often becomes difficult.

Based on these circumstances, the Society of Nuclear Medicine Technologists Section (SNMTS) and the American Society of Radiologic Technologists (ASRT) jointly issued two consensus statements that were published in *Journal of Nuclear Medicine Technology*, 2002;30:201. The first statement says in part, "Any registered radiographer with the credential RT (R), registered radiation therapist with the credential RT (T), or registered nuclear medicine technologist with the credential RT (N) or CNMT may operate PET/CT equipment after obtaining appropriate additional education or training and demonstrating competency..." A task force has been appointed by the ASRT

and SNMTS to outline and recommend a formal course of study for PET/CT technologists. The second consensus statement says in part, "States that license radiographers, nuclear medicine technologists, or radiation therapists are encouraged to amend their regulations to permit any of these individuals to perform PET/CT examinations after they have received appropriate additional education or training and demonstrate competency. States that do not currently license radiographers, nuclear medicine technologists, or radiation therapists are encouraged to adopt laws that regulate education and credentialing of these individuals..." In 2008, the ASRT published a consensus statement on the practice of CT based on a conference held in 2007 attended by all stakeholders (ASRT, 2008). It calls for increased continuing education in CT and also for a basic CT certification examination. One of the many recommendations pertinent to the PET/CT technologists calls for a solely separate CT examination for fusion imaging. It encourages flexibility in state regulations for CT operation. Following these recommendations, the ARRT now offers a postprimary certification in CT to nuclear medicine technologists certified by the ARRT or NMTCB. Following these consensus statements, the ARRT offers CT certification for PET/CT operation to nuclear medicine technologists certified by the ARRT or NMTCB.

As it stands now, in states requiring dual certification, two technologists – one certified for the CT part and the other for the PET part – must be employed to perform the PET/CT procedure, unless the technologist is certified in both modalities. In other states, a registered nuclear medicine technologist should be able to perform both PET and CT as long as the technologist is competent in both modalities.

#### Accreditation of PET Center

US Congress has passed a law requiring all nuclear medicine facilities to be accredited by an accreditation agency to qualify for reimbursement for clinical procedures. The Centers for Medicare and Medicaid Services (CMS) and private healthcare insurers such as Blue Cross/Blue Shield, Oxford Health, and United Healthcare in many states are requiring many nuclear medicine facilities to be accredited for reimbursement for patient studies. The American College of Radiology (ACR) and The Intersocietal Commission for the Accreditation of Nuclear Medicine Laboratories (ICANL) are two organizations that have set criteria for such accreditation of nuclear medicine laboratories. Both programs stress on the continuous quality improvement of nuclear medicine laboratories through a peer review and education process. The facilities that are interested in accreditation must apply to these organizations by submitting appropriate applications and fees, which typically run into several thousands of dollars. The entire nuclear medicine department or a section of it, such as general nuclear medicine, nuclear cardiology, and PET center separately, can apply for accreditation, if so desired. The stand-alone or hospital-based PET centers need to be accredited to be eligible for reimbursement for patient studies.

Although both programs are similar in principle, the concept and focus of review process are somewhat different. The IACNL emphasizes on the types of examination involving a particular organ, critically reviewing the procedural, technical, and interpretative quality of patient studies. It requires submission of at least two representative case studies per organ type (e.g., central nervous, genitourinary, respiratory, pulmonary, cardiac and gastrointestinal, tumor, therapy, etc.), and most studies should be interpreted as abnormal by as many physicians as possible. Three PET studies need to be submitted under the ICANL requirement.

In contrast, ACR emphasizes the quality control, calibration of the equipment, and technology used in the procedures, and accordingly has developed three modules – module 1 for oncology, module 2 for brain, and module 3 for heart. A PET center must apply for all modules that are performed at the facility. For accreditation, the facility is required to submit information on the quality control and quality assurance program, data collection, reporting, radiopharmaceuticals procedures, and laboratory safety, along with clinical and approved phantom images. So, all equipment in a PET center is required to be calibrated and tested for accurate functionality for accreditation by ACR.

For accreditation, the ICANL requires physicians to be board-certified in Nuclear Medicine or in Radiology with special competency in nuclear medicine, whereas special competency in nuclear medicine is not required by ACR. While both standards mandates the quality control tests to be performed daily, weekly, monthly, or annually, ACR requires the presence of a medical physicist in the facility for monitoring the tests but the ICANL only recommends for such an individual. Technologists are required to be certified by ARRT (N) or NMTCB. Continuing education of specified hours is required for each professional category for continuation of accreditation. For detailed information, refer to http://www.acr.org and http://www.icanl.org.

#### **Regulations for Radiation Protection**

Because radiation causes damage in living systems, international and national organizations have been established to set guidelines for safe handling of radiations. The International Committee on Radiological Protection (ICRP) and the National Council on Radiation Protection and Measurement (NCRP) are two such organizations. They are composed of experts in the subject of radiation and set guidelines for working with radiation and limits of radiation exposure and dose to the radiation workers as well as the general public. The NRC or the state agencies adopt these recommendations and implement them into radiation protection programs in USA.

#### **Definitions**

Roentgen (R) is a measure of external exposure to radiations and is defined by the amount of  $\gamma$ - or X-ray radiation that produces  $2.58 \times 10^{-4}$  Coulomb(C) of charge per kilogram of air. This unit applies only to air, and  $\gamma$ - and X-ray radiations of energy less than 3 MeV.

*Rad* is a universal unit and is defined as

$$1 \text{ rad} = 100 \text{ ergs/gm} \text{ absorber} = 10^{-2} \text{ J/kg} \text{ absorber}.$$

In System Internationale (SI) units, it is termed gray (Gy) and given by

$$1 \operatorname{gray}(\operatorname{Gy}) = 100 \operatorname{rad} = 1 \operatorname{J/kg} \operatorname{absorber}.$$

*Rem* is the unit of dose equivalent and accounts for the differences in effectiveness of different radiations in causing biological damage. It is denoted by H and has the unit of rem. Thus.

$$H_{\rm r}\,({\rm rem})={\rm rad}\times W_{\rm r},$$

where  $W_r$  is the radiation weighting factor for radiation type r.  $W_r$  is related to linear energy transfer of the radiation and reflects the effectiveness of the radiation to cause biological damage.

In SI units, the dose equivalent  $H_r$  is given by *sievert* (Sv).

$$1 \operatorname{sievert}(Sv) = 100 \operatorname{rem}.$$

The values of radiation weighting factors  $W_r$  for different radiations are given in Table 9.1.

*Committed dose equivalent*  $(H_{T.50})$  is the dose equivalent to organs or tissues of reference (T) that will be received from an intake of radioactive material by an individual during the 50-year period following the intake.

Deep-dose equivalent  $(H_d)$ , which applies to the external whole-body exposure, is the dose equivalent at a tissue depth of  $1 \text{ cm} (1,000 \text{ mg/cm}^2)$ .

Shallow-dose equivalent  $(H_S)$ , which applies to the external exposure of the skin or an extremity, is the dose equivalent at a tissue depth of 0.007 cm  $(7 \text{ mg/cm}^2)$  averaged over an area of  $1 \text{ cm}^2$ .

Effective dose equivalent  $(H_{\rm E})$  is the sum of the products of the tissue weighting factors  $(W_T)$  applicable to each of the body organs or tissues that are irradiated and the committed dose equivalent to the corresponding organ

TABLE 9.1. Italiation weighting fac		
tors $(W_r)$ of different radiations		
Type of radiation	$W_{\rm r}$	
X-rays, $\gamma$ rays, $\beta$ particles	1.0	
Neutrons and protons	10.0	
$\alpha$ particles	20.0	
Heavy ions	20.0	

TABLE 0.1 Radiation weighting fac-

Tissue	$W_{ m T}^{ m a}$
Gonads	0.25
Breast	0.15
Red bone marrow	0.12
Lungs	0.12
Thyroid	0.03
Bone surfaces	0.03
Remainder	0.30
Total body	1.00
<sup>a</sup> From 10CFR20	

TABLE 9.2. Tissue weighting factors,  $W_{\rm T}$ , of different tissues

<sup>a</sup> From 10CFR20

or tissue  $(H_E = \Sigma W_T \times H_{T,r})$ .  $W_T$  accounts for the tissue sensitivity to radiation and their values are given in Table 9.2. Note that this is due to committed dose equivalent from internal uptake of radiation. This quantity is termed simply effective dose.

*Total effective dose equivalent* (TEDE) is the sum of the deep-dose equivalent (for external exposure) and the committed effective dose equivalent (for internal exposure).

*Radiation area* is an area in which an individual could receive from a radiation source a dose equivalent in excess of 5 mrem (0.05 mSv) in 1 h at 30 cm from the source.

*High radiation area* is an area in which an individual could receive from a radiation source a dose equivalent in excess of 100 mrem (1 mSv) in 1 h at 30 cm from the source.

*Very high radiation area* is an area in which an individual could receive from radiation sources an absorbed dose in excess of 500 rad (5Gy) in 1 h at 1 m from the source.

*Restricted area* is an area of limited access that the licensee establishes for the purpose of protecting individuals against undue risks from exposure to radiation and radioactive materials.

Unrestricted area is an area in which an individual could receive from an external source a maximum dose of 2 mrem  $(20 \,\mu Sv)/h$ , and access to the area is neither limited nor controlled by the licensee.

*Controlled area* is an area outside of the restricted area but inside the site boundary, access to which is limited by the licensee for any reason.

#### Caution Signs and Labels

Specific signs, symbols, and labels are used to warn people of possible danger from the presence of radiations in an area. These signs use magenta, purple, and black colors on a yellow background. Some typical signs are shown in Fig. 9.1.



FIGURE 9.1. Radiation caution signs and labels.

*Caution: Radiation Area*: This sign must be posted in radiation areas. *Caution: High Radiation Area or Danger: High Radiation Area*: This sign must be posted in high radiation areas.

*Caution: Radioactive Material or Danger: Radioactive Material:* This sign is posted in areas or rooms in which ten times the quantity or more of any licensed material specified in Appendix C of 10CFR20 are used or stored. All containers with quantities of licensed materials exceeding those specified in Appendix C of 10CFR20 should be labeled with this sign. These labels must be removed or defaced prior to disposal of the container in the unrestricted areas.

## Radiation Safety Officer

Large institutions employ radiation safety officers (RSOs) to implement and monitor various regulations for the use of radioactive materials. Smaller facilities such as clinics and stand-alone units often appoint authorized users as RSOs and hire an outside firm, which advises and monitors the radiation safety program at the facility. In these facilities, a radiation safety committee (RSC) is not needed. The duties of an RSO include investigations of accidents, spills, losses, thefts, misadministrations, unauthorized receipts, uses, and transfers of radioactive materials and instituting corrective actions. In larger institutions, in addition to the RSO, an RSC is required, which is composed of individuals experienced in radiation safety and oversees the overall radiation protection program at the institution. The RSO works with the recommendations of the RSC in setting the policies and procedures for the purchase, receipt, storage, transfer, and disposal of the radioactive materials. The RSO conducts periodic checks of calibration of survey instruments, dose calibrators, and surveys of radiation areas and keeps records of all activities related to the use of radiation at the facility.

#### Occupational Dose Limits

The annual occupational dose limit to an adult radiation worker is the more limiting of (1) total effective dose of 5 rem (0.05 Sv) or (2) the sum of deepdose equivalent and the committed dose equivalent to any individual organ or tissue, other than the lens of the eye, being equal to 50 rem (0.5 Sv).

The limit on the annual occupational dose to the lens of the eye is 15 rem (0.15 Sv).

The limit on the annual occupational dose to the skin and other extremities is the shallow-dose equivalent of 50 rem (0.5 Sv).

The annual occupational effective dose limit for the minor (<18 years working with radiation) is 0.5 rem (5 mSv). The occupational dose limit to the embryo/fetus during the entire gestation period of a declared pregnant radiation worker is 0.5 rem (5 mSv) with a monthly limit of 0.05 rem (0.5 mSv).

The effective dose to an individual member of the public is limited to 0.1 rem (1 mSv) per year.

#### Personnel Monitoring

Personnel monitoring is required when an occupational worker is likely to receive an excess of 10% of the annual dose limit from radiation sources and for individuals entering high or very high radiation areas. Monitoring is accomplished by using film badges or thermoluminiscent dosimeters (TLD).

The film badge is the most common method of personnel monitoring because of its cost effectiveness. It gives reasonably accurate readings of exposure from  $\beta$ -,  $\gamma$ - and X-ray radiations. The film badge consists of radiation-sensitive film held in a holder. Filters of different materials (aluminum, copper and cadmium) are attached to the holder in front of the film to differentiate the exposures from radiations of different energies and types. The density of the film changes with exposure to radiation and is measured after development by a densitometer. The measured density is proportional to the exposure from the radiation. The film badges are changed monthly and therefore give integrated radiation dose to the worker for every month.

The TLD consists of inorganic crystals of lithium fluoride (LiF) or manganese-activated calcium fluoride (CaF<sub>2</sub> : Mn) held in holders and is commonly used for finger exposures. TLDs exposed to radiations emit light when heated at  $300-400^{\circ}$ C and the amount of light emitted is proportional to

radiation energy absorbed, thus giving the exposure value. The TLD readings are reasonably accurate.

#### Receiving and Monitoring of Radioactive Packages

All packages carrying radioactive material are required to be monitored for possible radioactive contamination. The regulations described in 10CFR20 of the NRC are the plausible guide for monitoring the received radioactive packages and states normally follow this guide. Monitoring should be done within 3 h of delivery if the package is delivered in normal working hours or no later than 3 h from the beginning of the next working day if it is received after working hours.

Two types of monitoring are performed: survey for external exposure and wipe test for removable contamination on the surface of the package due to possible leakage of the radioactive material. The external survey is conducted by using a Geiger-Müller (GM) survey meter at the surface and at 1 m from the package. The wipe test for removable contamination is carried out by swabbing three 100-cm<sup>2</sup> areas on the package surface using absorbent paper and counting the swabs in a NaI(Tl) well counter. The NRC limits of these measurements are:

Test	Limits
Survey at the surface	$\leq 200  \mathrm{mR/h}$
Survey at 1 m	$\leq 10  \mathrm{mR/h}$
Wipe test	$\leq 6,600  \mathrm{dpm}/300  \mathrm{cm}^2$

If any of the readings exceeds the limit, the carrier and the RSO should be notified for further corrective action. All the data of monitoring are recorded in a logbook (Fig. 9.2).

## ALARA Program

Although regulations allow an annual maximum permissible dose to radiation workers, one should make considerable efforts to adopt strict protective measures in working with radiations so as to reduce the radiation dose *as low as reasonably achievable* (ALARA). Under this concept, techniques, equipment, and procedures are critically evaluated and adopted to minimize the radiation dose to the worker. The NRC has set two goals for a radiation worker to achieve: 10% of the occupational dose per quarter (Action level I) and 30% of the occupational dose per quarter (Action level II). If these limits are exceeded, corrective action must be taken or higher limits must be justified for a particular situation. The principles of radiation protection described later should be followed strictly to achieve ALARA compliance.





FIGURE 9.2. A sample log sheet for record keeping of unit dosages of <sup>18</sup>F-FDG.

#### Radioactive Waste Disposal

Radioactive waste generated in PET facilities contains mostly short-lived radionuclides and is disposed of by the most common method of decay-instorage. The solid waste is packaged in a yellow bag properly labeled with the date, radionuclide, and level of activity (in mR) and stored for decay. When the activity level in the bag is equal to or less than the background, the vellow bag is repackaged into a black plastic bag, which is then discarded in the regular trash. Obviously, waste from <sup>11</sup>C, <sup>13</sup>N, and <sup>15</sup>O does not need to be stored for decay-in-storage because of the short half-lives and needs only to be discarded at the beginning of the next day at the latest. <sup>18</sup>F-FDG waste may need to be stored for decay depending on the level of activity and the time of the day when it is stored. For <sup>82</sup>Rb, whose half-life is only 75 s, its disposal is not a concern. However, <sup>82</sup>Sr ( $t_{1/2} = 25.6$  days) and <sup>85</sup>Sr ( $t_{1/2} = 65$  days) breakthrough in the <sup>82</sup>Rb eluate obtained for daily calibration of the <sup>82</sup>Sr-<sup>82</sup>Rb generator for radiochemical yield must be monitored carefully and discarded according to the method recommended by the RSO at the PET facility.

#### Surveys for Radiation Exposure and Contamination

Working areas, benches, equipment, etc. may be contaminated unknowingly and should be surveyed frequently to avoid unnecessary radiation exposure. Surveys for ambient radiation exposure must be performed in all work areas at the end of the day using a Geiger-Müller (GM) counter. For each area, a trigger level is established from the average of several survey readings taken over a period of time. Daily survey reading should not exceed the trigger level, but if it exceeds, the source of excess radiation is identified and corrective action should be taken.

Wipe tests should be carried out to identify any removable contamination. These tests are done by swabbing the area with absorbent paper and counting the swab in a NaI(Tl) counter. For PET radiopharmaceuticals, these readings should be less than  $20,000 \text{ dpm}/100 \text{ cm}^2$  in the radiation areas at the PET facilities and  $2,000 \text{ dpm}/100 \text{ cm}^2$  in the unrestricted areas. If the readings exceed the limits, the area or the spot must be decontaminated. These tests should be done once a week.

## Syringe and Vial Shields

Since PET radionuclides produce high-energy 511-keV annihilation radiations, vials and syringes containing them should be handled using appropriate lead shields. A variety of syringe shields and vial shields for PET radiopharmaceuticals are available from commercial vendors. A typical PET syringe shield and a syringe holder are shown in Figs. 9.3 and 9.4. Both the syringe or syringe shield and the vial shield should be labeled conspicuously, indicating the name of the radiopharmaceutical, quantity of the activity, and the date and time of calibration.

## Use of Dose Calibrator

An accurate dose calibrator is needed to assay the dosage of a PET radiopharmaceutical for administration to humans. The dose calibrator must be calibrated for constancy, accuracy, linearity, and geometry. The readers are referred to Saha (2004) for the details of calibration of the dose calibrator.



FIGURE 9.3. Lead syringe shield. (Photos, courtesy of Biodex Medical Systems, Inc., NY)

FIGURE 9.4. A PET syringe holder. (Photo courtesy of Biodex Medical Systems, Inc., NY)



The activity of a dosage contained in a syringe is measured by placing the syringe in a plastic insert which is placed inside the dose calibrator. The activity is displayed in Ci, mCi, or  $\mu$ Ci units or GBq, MBq, or kBq units. Unit dosages (e.g., <sup>18</sup>F-FDG) supplied by the manufacturers are not required to be assayed again at the receiving facility. However, it is a good practice to assay it anyway.

## Radioactive Spill

It is likely in a PET facility that a radioactive spill may occur and appropriate action must be taken. A radioactive spill may be major or minor depending on the nature and extent of contamination involved in the spill. In the case of a major spill where the spread of contamination is large or personnel are contaminated, the incident must be reported immediately to the RSO. In all spills, the principle is to contain the radioactivity, and access to the area should be restricted. Cleaning the contaminated area by wiping with absorbent paper and using decontaminating liquid (Radiacwash) is all that is needed in most cases. Surveys and wipe tests must be conducted to assess the level of decontamination. In case of nonremovable contamination, a thin foil-type lead shield may be used to cover the area until the activity decays below the trigger level.

## Record Keeping

Records must be maintained for the receipt, storage, dispensing, and disposal of all radioactive materials in a PET facility. All patient dosages administered to patients must be logged in a record book with the patient's name, ID number (e.g., clinic number), date and time, and quantity of the activity administered (Fig. 9.2). Also, all the survey data must be recorded.

Nowadays commercial software is available for record keeping of all data including those of radiation safety and patient studies. The programs can also be customized to meet specific needs.

## **Principles of Radiation Protection**

The cardinal principles of radiation protection from external radiation sources are governed by four factors: time, distance, shielding, and activity.

#### Time

The radiation dose to an individual from an external source is proportional to the time the person is exposed to the source. The longer the exposure, the higher the radiation dose. It is advisable to spend no more time than necessary near radiation sources.

#### Distance

The radiation exposure varies inversely with the square of the distance from the source. Each radionuclide has an exposure rate constant,  $\Gamma$ , which is given in units of R-cm<sup>2</sup>/mCi-h at 1 cm or in SI units,  $\mu$ Gy-m<sup>2</sup>/GBq-h at 1 m, and these values for <sup>11</sup>C, <sup>13</sup>N, <sup>15</sup>O, <sup>18</sup>F, and <sup>82</sup>Rb are given in Table 9.3. The exposure X per hour at distance d(cm) from an *n* mCi source is given by

$$X = \frac{n\Gamma}{d^2},$$

where  $\Gamma$  is the exposure rate constant of the radionuclide. Working at maximum possible distance from radiation is prudent in reducing radiation exposure.

radi	onuclides		
Rac	lionuclide	$\Gamma$ (R-cm <sup>2</sup> /mCi-h at 1 cm)	$\Gamma (\mu Gy-m^2/GBq-h at 1 m)$
<sup>11</sup> C		7.18	193.7
$^{13}N$		7.18	193.7
<sup>15</sup> O		7.18	193.7
<sup>18</sup> F		6.96	187.9
<sup>82</sup> R	b	6.10	164.9

TABLE 9.3. Exposure rate constants of common positron-emitting

#### Problem 9.1

Calculate the cumulative exposure a radiation worker receives from a 15 mCi (555 MBq) <sup>18</sup>F-FDG source while standing for 2 h at a distance of 2 m ( $\Gamma$  for <sup>18</sup>F-FDG is 6.96 R-cm<sup>2</sup>/mCi-h at 1 cm).

#### Answer:

Since  $t_{1/2}$  of <sup>18</sup>F is 1.83 h and the worker stands for 2 h, the activity of <sup>18</sup>F-FDG decays considerably and hence the cumulative activity for 2 h is calculated as follows:  $\lambda$  for <sup>18</sup>F is 0.693/1.83 = 0.3787 h<sup>-1</sup>

The cumulative activity 
$$A_t = A_0 \frac{1 - e^{-\lambda t}}{\lambda} = \frac{15 \times (1 - e^{-0.3783 \times 2})}{0.3787}$$
  
= 21.04 mCi-h.

Using Eq. (9.1), the cumulative exposure X at 2 m

$$X = \frac{21.04 \times 6.96}{(200)^2} = 0.00366 \,\mathrm{R} = 3.66 \,\mathrm{mR}.$$

## Shielding

Radiations passing through absorbers lose energy by interaction with absorber material. This loss of energy is very effective in high Z materials such as lead, tungsten, etc. Therefore, these high Z materials are conveniently used as shielding materials for radiations, and lead is the shielding material of choice in most cases because it is the least expensive. Bricks, syringe shields, L-blocks (Fig. 9.5), and syringe containers made of lead are common examples of shielding. Handling radioactivity behind the lead shield, using syringe shields, and carrying dosages in lead containers, etc. are typical examples of radiation protection by shielding. The concept of half-value layer (HVL) of absorbing materials for different radiations has been discussed in Chap. 1 and should be kept in mind in handling radioactivity. In PET facilities, 511-keV photons from positron emitters are highly penetrating and, therefore, larger amounts of shielding material are needed in all aspects of radiation protection.

#### Problem 9.2

If the HVL of lead for 511-keV photons of  ${}^{18}$ F is 0.55 cm, calculate the thickness of the lead shield required to reduce the exposure by 90% from a 20 mCi  ${}^{18}$ F-FDG dosage in a vial.

Answer: According to Eq. (1.19), linear attenuation coefficient,

$$\mu = \frac{0.693}{\text{HVL}}$$

$$= \frac{0.693}{0.55}$$
$$= 1.26 \,\mathrm{cm}^{-1}$$

Because the initial beam is reduced by 90%, the transmitted beam is 10%.

$$0.1 = 1 \times e^{-1.26 \times x}$$
  
 $\ln(0.1) = -1.26 \times x$   
 $2.303 = 1.26 \times x$   
 $x = 1.82$  cm.

Thus, 1.82 cm of lead will be needed to reduce the exposure from a 20 mCi dosage by 90%.

Note that the 20-mCi dosage does not come into calculation because 90% reduction remains the same regardless of the quantity of dosage. However, the absolute exposure value in Roentgen will depend on the dosage. The exposure X beyond the 1.82-cm lead shield is calculated using Eq. (9.1):

$$X = \frac{0.1 \times 20 \times 6.96}{(1.82)^2} = 4.2 \,\mathrm{R/h}.$$



FIGURE 9.5. Lead barrier shield (L-block), behind which all formulation and handling of radioactive materials are carried out (Photo courtesy of Biodex Medical Systems Inc., NY).
#### Activity

Understandably, the lesser amount of radioactivity will result in less radiation exposure and dose. One should use only a necessary amount of radioactivity.

#### Do's and Don'ts in Radiation Protection Practice

*Do* wear laboratory coats and gloves when working with radioactive materials.

Do work in a ventilated fumehood while working with volatile material.

Do handle radioactivity behind a lead barrier shield, such as L-block.

Do cover the trays and workbench with absorbent paper.

Do store and transport radioactive material in lead containers.

*Do* wear a film badge while working in the radiation laboratory.

Do identify all radionuclides and dates of assay on the containers.

Do survey work areas for contamination as frequently as possible.

Do clean up spills promptly and survey the area after cleaning.

Do not eat, drink, or smoke in the radiation laboratory.

Do not pipette any radioactive material by mouth.

Do monitor hands and feet after the day's work.

*Do* notify the RSO in the case of a major spill or other emergencies related to radiation.

#### Department of Transportation

The Department of Transportation (DOT) regulates the transportation of radioactive materials and sets the regulations and guidelines for packaging, types of packaging material, limits of radioactivity in a package, and exposure limits for packages. All these regulations are contained in Title 49 of Code of Federal Regulations (49CFR).

The packages for radioactive shipping must pass certain tests, such as the drop test, corner drop test, compression test, and 30-min water spray test. A special shipping container made of lead that can ship 3 unit dosages of PET radiopharmaceuticals (e.g., <sup>18</sup>F-FDG) is shown in Fig. 9.6.

Radioactive packages must be properly labeled before transportation. There are three types of labels (Fig. 9.7) based on the *transportation index*, TI, which is defined as the exposure reading in mR/h at 1 m from the surface of the package. The maximum permissible TI is 10. The criteria for the three shipping labels are given in Table 9.4. The label "RADIOACTIVE" containing the value of TI must be placed on the outside of the package. For liquids, the label "THIS SIDE UP" must be pasted on the package. The label also must identify the contents and amounts of the radionuclides in becquerels. A shipping document containing all the above information must be placed inside the package.

#### 174 9. Regulations Governing PET Radiopharmaceuticals



FIGURE 9.6. Special shipping containers made of lead that can ship 3 unit dosages (Photo courtesy of Biodex Medical Systems, Inc., NY).



FIGURE 9.7. Three types of US DOT labels required for transportation of radioactive materials.

According to 49CFR173.421, certain transportation requirements are exempted for radionuclides, if only a limited quantity is shipped. These limits for <sup>11</sup>C, <sup>13</sup>N, and <sup>18</sup>F are 1.4 mCi (or 50 MBq) and those for <sup>82</sup>Sr and <sup>85</sup>Sr (for <sup>82</sup>Sr-<sup>82</sup>Rb generator) are 0.54 mCi (or 20 MBq) and 5.4 mCi (or 200 MBq), respectively. The surface exposure readings should not exceed 0.5 mR/h at all points of the package surface and the wipe test measurements should be

Type of label	Exposure (mR/h)	
	At surface	At 1 m
White-I	<0.5	_
Yellow-II	$>0.5 \le 50$	<1
Yellow-III	>50	>1

 TABLE 9.4.
 Labeling categories for packages

 containing radioactive materials
 \$\$

Note: No package shall exceed 200 mR/h at the surface of the package or 10 mR/h at 1 m. Transport index is the reading in mR/h at 1 m from the package surface and must not exceed 10

below 6,600 dpm/300 cm<sup>2</sup>. A notice or label, "Radioactive – Limited Quantity" must be enclosed inside or pasted outside or forwarded to the shipper along with the package. This notice must include the name of the shipper and the consignee, and the statement, "This package conforms to the conditions and limitations specified in 49CFR173.421 for radioactive material, excepted package-limited quantity of material, UN2910" in or on the package.

Employees who ship hazardous material, including radioactive material, must have hazmat training to be able to recognize and identify hazardous material, to conduct their specific functions, and to enforce safety procedures to protect the public. The training is given to a new employee within 90 days of employment and then repeated every 3 years. The training is provided by the employer or by other public or private sources, and a record of training must be maintained.

#### Distribution of <sup>18</sup>F-FDG

The need for <sup>18</sup>F-FDG is increasing tremendously as the demand for PET procedures for various clinical indications, particularly oncologic indications, increases nationwide. Although the number of cyclotron facilities is increasing in the USA, many hospitals have PET scanners but no cyclotron facility. These hospitals need <sup>18</sup>F-FDG to be supplied on a routine basis by a distant cyclotron facility.

The distribution of <sup>18</sup>F-FDG is quite challenging, because of the short halflife (110 min) and the distance to cover for delivery. For controlled, reliable, and economical delivery, ground shipping or air transport may be employed depending on the distance between the cyclotron facility and the PET imaging site. A maximum distance of about 200 miles may be appropriate for ground transportation, but air transport must be employed for longer distances. Air transport is risky, because of flight delay or inclement weather, and is 3–4 times costlier than ground transport. A dedicated charter aircraft is needed for reliable and timely delivery of <sup>18</sup>F-FDG. On the other hand, ground transportation is slower than air transport, but is more reliable. It is not as affected by inclement weather. Air transport requires delivery of <sup>18</sup>F-FDG by ground transportation from the cyclotron facility to the airport and from the airport to the client. This might negate the advantage of faster delivery by air transport.

Scheduling of delivery by ground or air transportation is the key to a successful and economically viable distribution of <sup>18</sup>F-FDG. All the orders of FDG dosages are received a day before, and deliveries to different client sites by a courier are scheduled with minimal routing. Deliveries to widely separated sites that cannot be served by one courier are made by separate couriers. Production schedule of <sup>18</sup>F-FDG batches must be synchronized with the different deliveries by separate couriers.

The shipping of <sup>18</sup>F-FDG must meet all regulations of DOT mentioned above, including approved shipping containers (DOT 7A containers, Fig. 9.6) and DOT training for all FDG shippers. The interstate commercial distribution of <sup>18</sup>F-FDG requires that the vendor must obtain a license from the state to operate as a distributor.

Because of increased demand for PET procedures using <sup>18</sup>F-FDG, several commercial vendors have set up cyclotron facilities at many locations around the country and distribute <sup>18</sup>F-FDG to distant customers. PETNET, a division of Siemens Medical Solutions, has more than four dozen distribution centers, covering more than 50% of FDG dosages in the USA. Cardinal Health and IBA have the major share of the remaining FDG sales. Many smaller suppliers as well as many academic sites are coming into the market.

#### Questions

- 1. If a radiopharmaceutical is not approved by the FDA for clinical use, but the clinician wants to use it for investigation, what is needed from the FDA for such a situation?
- 2. What different aspects of PET radiopharmaceuticals are controlled by the FDA?
- 3. The NRC controls the radiation aspect of PET radiopharmaceuticals. True \_\_\_\_\_; False \_\_\_\_\_.
- 4. The registration with the state is required for the following equipment:
  - (a) Cyclotron: yes, no, depends on state
  - (b) PET/CT: yes, no, depends on state
  - (c) PET scanner: yes, no, depends on state
- 5. Review thoroughly the regulations pertaining to the practice of nuclear medicine technologists in performing PET/CT imaging.
- 6. Define roentgen, rad, rem, and effective dose.
- 7. Define restricted area, radiation area, high radiation area, and very high radiation area.
- 8. In a room in a nuclear medicine department, one could receive 0.15 rem (1.5 mSv) in an hour at 30 cm from the radioactive sources. What type of sign is needed on the door of the room?

- 9. What are the responsibilities of a radiation safety officer?
- 10. The occupational dose limits for radiation workers are: effective dose \_\_\_\_\_; dose to the lens of the eye \_\_\_\_\_; and dose to extremities
- The annual radiation dose limit to: (a) the declared pregnant woman during the gestation period is \_\_\_\_\_; (b) to the minor \_\_\_\_; and (c) to the individual member of the public \_\_\_\_\_.
- 12. What is the common method of personnel monitoring?
- 13. What are the regulatory requirements for receiving and monitoring the radioactive packages?
- 14. Describe the principles of ALARA program.
- 15. What is the most common method of radioactive waste disposal of <sup>18</sup>F-FDG in a PET facility?
- 16. What are the limits for the GM survey and wipe test in the laboratory where PET radiopharmaceuticals are prepared and dispensed?
- 17. When is the personnel monitoring required of a person in a radiation laboratory?
- 18. Discuss the cardinal principles in radiation protection.
- 19. Calculate the cumulative exposure a technologist receives from a 10 mCi (370 MBq) 6-<sup>18</sup>F-L-fluorodopa while standing for 2 h at a distance of 1 m from the source ( $\Gamma$  for <sup>18</sup>F is 6.96 R-cm<sup>2</sup>/mCi-h at 1 cm).
- 20. Calculate the amount of lead necessary to reduce the exposure rate from a 200 mCi <sup>18</sup>F-FDG source to less than 15 mR/h at 30 cm from the source ( $\Gamma$  for <sup>18</sup>F = 6.96 R-cm<sup>2</sup>/mCi-h at 1 cm; HVL of lead for <sup>18</sup>F is 0.39 cm).
- 21. If 1% of the primary beam exits through a patient, calculate the exposure (%) at the midline of the patient.
- 22. Define transport index TI. What is the maximum TI allowed by DOT for transportation of radiopharmaceuticals?
- 23. Elucidate the criteria for shipping "limited quantity" of radioactive material.
- 24. A technologist who packages and ships radioactive material must have hazmat training. True \_\_\_\_\_; False \_\_\_\_\_.
- 25. Does a vendor need a license from the state for interstate distribution of <sup>18</sup>F-FDG?
- 26. What are the requirements for nuclear medicine technologists to do the CT in PET/CT studies for fusion and attenuation correction?
- 27. Why is accreditation of a PET facility needed?
- 28. What are the differences between the RDRC and the exploratory IND?

#### References and Suggested Reading

American Society of Radiologic Technologists (2008). Computed tomography in the 21st century – Changing practice for medical imaging and radiation therapy professionals, Albuquerque, NM

- Consensus Conference (2002). Fusion imaging: a new type of technologist for a new type of technology. J Nucl Med Technol 30:201
- Federal Registrar (2000). 65:13010
- International Commission on Radiological Protection (1997). General principles for the radiation protection of workers. ICRP 75. Elsevier, New York
- National Council on Radiation Protection and Measurement (1993). Limitation of exposure to ionizing, radiation (NCRP 116). NCRP Publications, Bethesda, MD
- National Council on Radiation Protection and Measurements (1989). Radiation protection and allied health personnel (NCRP 105). NCRP Publications, Bethesda, MD
- Nuclear Regulatory Commission (1995). Standards for protection against radiation. 10CFR part 20. Washington, DC
- Nuclear Regulatory Commission (2007). Medical uses of byproduct material. 10CFR part 35. Washington, DC
- Saha GB (2004). Fundamentals of nuclear pharmacy, 5th ed. Springer, New York
- SNM Practice Standard Committee (2006). Conjoint statement of the SNM and the American College of Nuclear Physicians and delineation of privileges for CT performed in conjunction with body PET or SPECT, Reston, Virginia
- SNM Practice Standard Committee (2006). Conjoint statement of the SNM and the American College of Nuclear Physicians on credentialing and delineation of privileges of body PET, Reston, Virginia
- US Food and Drug Administration (1997). Food and Drug Administration Modernization act of 1997, Rockville, MD
- US Food and Drug Administration (2005). PET drug products Current Good Manufacturing Practice (CGMP), Rockville, MD
- US Food and Drug Administration (2006). Guidance for industry, investigators, and reviewers. Exploratory IND Studies
- US Food and Drug Administration (2009). PET DRUGS Current Good Manufacturing Practice (CGMP). December, Rockville, MD

## 10 Reimbursement for PET Procedures

#### Background

Healthcare providers (physicians, hospitals, clinics, etc.) operate and are sustained by the reimbursement or payment for care they provide to patients. In the United States, revenue for healthcare services comes from a variety of sources including the patient, insurance companies (i.e., Blue-Cross/BlueShield, Cigna, Aetna), and the Centers for Medicare and Medicaid Services (CMS), formerly the Health Care Financing Administration (HCFA). The CMS provides healthcare insurance for Medicare and Medicaid beneficiaries. When interfacing with an insurance company or the CMS, there are three fundamental reimbursement concepts that must be considered to assure appropriate revenue for services provided. These include the concepts of coverage, coding, and payment.

#### Coverage

Coverage can be defined as the range or extent of healthcare that an insurer will pay for based on the terms of the insurance plan. The CMS under Medicare Act has developed two pathways to secure coverage policies or guidelines for reimbursement for clinical procedures or drugs: national coverage determination (NCD) and local coverage determination (LCD). A NCD is a determination by the CMS if a procedure or service is reasonable and necessary for reimbursement and is initiated either by the request of an outside party or by the CMS. Several factors are considered when developing a NCD for reimbursement for a service: (1) it meets a defined benefit category; (2) it is reasonable and necessary for the care of a patient; and (3) it is approved by the FDA for safety and effectiveness. (Some exceptions are made for products that are in clinical trials.) In addition, Medicare may request an evaluation of the health outcome of a particular procedure prior to making a national coverage decision. The CMS employs contractors, the Office of Health Technology Assessment (OHTA) in the Department of Human and Health Services, or literature reviews for the assessment of health outcome of different procedures. It is important to note that a NCD does not specify the code or the amount of payment. The LCDs are similar to NCDs but are established by the CMS contractors at local levels and applies to reasonable and necessary procedures or services for reimbursement. They can be superseded by NCDs and also do not specify the code or the amount of payment. The majority of LCDs are made by two categories of CMS contractors: the "fiscal intermediaries" who process claims from facilities/hospitals, and the "carriers" who process claims from physicians or freestanding imaging facilities.

NCDs have been developed and are currently in place for most clinical PET procedures. Private payers generally follow similar policies and procedures when establishing their coverage guidelines.

#### Coding

#### CPT, HCPCS, and APC Codes

Simply defined, coding systems are used by providers and health plans to document the delivery of healthcare services for reimbursement purposes as well as to track services provided. Two major types of codes are important to consider for all clinical procedures: Current Procedural Terminology (CPT) codes introduced by the American Medical Association (AMA); and Healthcare Common Procedure Coding System (HCPCS) codes developed by a committee composed of private insurers and CMS representatives. The CMS requires the use of CPT codes for reimbursement except in a few cases where HCPCS codes are required. It is important to note that the applicable code for a service or a drug may vary based on the site of service (hospital inpatient, hospital outpatient, freestanding imaging facility) and payer type (Medicare versus non-Medicare). While HCPCS codes represent specific disease indications, CPT codes primarily describe the procedures for different clinical indications. CPT codes can be used for indications that are not covered by Medicare. Ambulatory Payment Classifications or APCs are the CMS method of paying for outpatient services in the Medicare program, which is discussed later in this section.

The current CPT codes (2009 CPT codes, AMA) used for all approved PET studies of different clinical indications are summarized in Table 10.1. Initially, reimbursement by the CMS for these indications was limited to their diagnosis, staging, restaging, recurrence, and monitoring of therapy. Recently, this grouping of assessment has been replaced by two categories of assessment – *initial treatment strategy* (replacing former diagnosis and initial staging) and *subsequent treatment strategy* (replacing former treatment monitoring, restaging and detection of suspected recurrence). All cancer PET studies listed in Table 10.1 are reimbursed for both initial and subsequent treatment strategies. There are a number of other cancer indications,

CPT/HCPCS codes	Description
CPT 78811	Tumor imaging, positron emission tomography (PET); limited area (e.g., chest, head/neck)
CPT 78812	Tumor imaging, positron emission tomography (PET); skull base to mid thigh
CPT 78813	Tumor imaging, positron emission tomography (PET); whole body
CPT 78814	Tumor imaging, positron emission tomography (PET) with concurrently acquired computed tomography (CT) for attenuation correction and anatomical localization; limited area (e.g., chest, head/neck)
CPT 78815	Tumor imaging, positron emission tomography (PET) with concurrently acquired computed tomography (CT) for attenuation correction and anatomical localization; skull base to mid thigh
CPT 78816	Tumor imaging, positron emission tomography (PET) with concurrently acquired computed tomography (CT) for attenuation correction and anatomical localization; whole body
CPT 78459	Myocardial imaging, positron emission tomography (PET); metabolic evaluation
CPT 78491	Myocardial imaging, positron emission tomography (PET), perfusion; Single study at rest or stress
CPT 78492	Myocardial imaging, positron emission tomography (PET), perfusion; Multiple studies at rest and/or stress
CPT 78608	Brain imaging, positron emission tomography (PET); metabolic evaluation
CPT 78609	Brain imaging, positron emission tomography (PET); perfusion evaluation
HCPCS G0219	PET imaging whole body; melanoma for noncovered indications
HCPCS G0235	PET imaging, any site not otherwise specified (not covered by Medicare)
HCPCS A9526	Nitrogen N-13 ammonia, diagnostic, per study dose, up to 40 mCi
HCPCS A9552	Fluorodeoxyglucose F-18 FDG, diagnostic, per study dose, up to 45 mCi
HCPCS A9555	Rubidium RB-82, diagnostic, per study dose, up to 60 mCi

TABLE 10.1. CPT and HCPCS codes related to PET and PET/CT procedures

For diagnostic CT when performed in conjunction with PET/CT, it should be billed separately with Modifier  $59\,$ 

which are reimbursed for the initial treatment but must go through NOPR (described below) for subsequent treatment strategy. Some examples of this group of cancer indications are stomach, small intestine, pancreas, kidney, bladder, primary brain, and so on.

### Diagnosis Codes

In addition to CPT or HCPCS codes, the CMS also requires specific codes for diagnosis of diseases for inpatient, outpatient, and physician office utilization for efficient claims processing and appropriate reimbursement. These codes, called the diagnosis (Dx) codes, are listed in International Classification of Diseases, Ninth Revision, Clinical Modification (ICD-9-CM) for diagnosis for inpatient hospital procedure coding. ICD is designed by World Health Organization (WHO) to promote international comparability in the collection, processing, classification, and presentation of mortality statistics.

Major clinical condition	ICD-9-CM code	Specific diagnosis or staging of disease
Cardiac perfusion with	411	Ischemic heart disease
<sup>82</sup> Rb-RbCl	412	Old myocardial infarction
	413	Angina pectoris
	428	Heart failure
Cardiac metabolic by <sup>18</sup> F-FDG PET	414	Acute, chronic ischemia atherosclerosis
Cardiac metabolic by <sup>18</sup> F-FDG following inconclusive SPECT	794	Unspecified abnormal function study of cardiovascular system
Esophageal cancer	150	Malignant neoplasm of esophagus
Breast cancer (female)	174	Malignant breast cancer
Seizure	345	Epilepsy
Lung (solitary nodule)	235.7	Trachea, bronchus, and lung cancer
	239.1	Neoplasm of unspecified nature; respira- tory system
Lung (NSLC)	162	Trachea, bronchus, and lung cancer
	196.1	Intrathoracic lymph node cancer
Colorectal cancer, diagnosis	153	Colon cancer
	154	Cancer of rectum, rectosigmoid junction and anus
Melanomas	172	Malignant melanoma
Lymphomas	200	Lymphoma & reticulosarcoma
	201	Hodgkin's
	202	Other lymphomas
Head and neck	140-149	Lip, oral cavity, and pharynx cancer
	160	Nasal cavities, middle ear, sinus cancer
	161	Larynx cancer
All above organs except heart/brain	235	Neoplasm of unspecified nature
All above organs except heart and brain	V10	Personal history of neoplasm

TABLE 10.2. Examples of current diagnosis (ICD-9-CM) codes for PET studies

The diagnosis codes are listed in broad categories, i.e., each of these codes has subcategories for specific diagnosis. These values are obtained from ftp://ftp.cdc.gov/pub/Health\_ Statistics/NCHS/publications/ICD-9/2009

However, in the United States, the CMS uses these codes for classification of surgical, diagnostic, and therapeutic procedures. Along with CPT/HCPCS codes, Dx (ICD-9-CM) codes must be provided on the claim form for reimbursement. These codes are annually reviewed and updated. A few current representative Dx (ICD-9-CM) codes for the diagnosis of diseases by PET studies are given in Table 10.2.

#### Payment

As with coding, payment for healthcare services also varies based on the site of service (hospital inpatient versus outpatient, physician office setting, or freestanding imaging facility), and payer type. Note that the CMS pays only for medically necessary procedures, requires precertification for many specific procedures, and does not pay for PET studies for screening purposes.

#### Hospital Inpatient Services: Medicare

Faced with the need to try to contain rising hospital inpatient costs, the CMS introduced a prospective payment system known as Diagnosis Related Groups (DRG) in the early 1980s. Under the DRG program, a lump sum payment is made for all services for hospital inpatient stay based on the patient's course of hospitalization and discharge diagnosis. This payment is the same for all patients with a specific disease regardless of the length of the hospital stay.

#### Hospital Outpatient Services: Medicare

The CMS then focused their attention on hospital outpatient cost issues and implemented the Hospital Outpatient Prospective Payment System (HOPPS) on August 1, 2000, based on Ambulatory Payment Classification (APC) Groups. APCs are groupings of procedures that are clinically comparable and similar in terms of resource utilization and cost. APCs are similar to the hospital inpatient DRGs in that a fixed rate is paid for a grouping of procedures based on the reported hospital outpatient costs. APCs apply to hospital-based outpatient services only; professional fees are paid separately. Under HOPPS, all outpatient services are grouped into APCs based on the CPT or HCPCS codes. The CMS annually evaluates reported cost figures and revises and updates the APCs to establish a payment schedule for the year. Payment is also adjusted for regional variations. The rate published annually by the CMS is the national rate, which must be multiplied by a locality-specific factor to take into account the geographical variations in the cost of services provided.

#### Payment for PET Radiopharmaceuticals

For PET procedures performed in the hospital outpatient department, an additional payment is made for the cost of <sup>18</sup>F-FDG, <sup>82</sup>Rb-RbCl, and <sup>13</sup>N-NH<sub>3</sub>, provided the proper code and the dosage quantity are submitted. In the case of freestanding facilities and private medical practices, radiopharmaceuticals are reimbursed at 95% of the average wholesale price or are carrier-priced and may be paid separately or globally.

#### Physician's Payment by Medicare

While payment for hospital services (room, drugs, surgery, operating room, imaging, nursing etc.) is paid under DRG or APC depending on if the patient is inpatient or outpatient, professional fees for the physicians providing services for these patients are paid separately. Imaging studies such as PET, CT, and MRI have two components – technical and professional, and each component is paid separately by the CMS. However, in the case of freestanding facilities such as imaging center or private medical practice, the technical and professional fees are not separated, and a global reimbursement is made for the entire service.

Since 1992, physicians are reimbursed for their services according to a standardized fee schedule established by the CMS based on a system called the resource-based relative value system (RBRVS). The cost of a service consists of three components: physician's work (time, skill, and intensity), practice expense (rent, employee wages, etc.) and professional liability or malpractice insurance (insurance premiums). According to RBRVS, each of these components is assigned a relative value unit (RVU) based on the nature of service and a geographic practice cost index (GPCI) to adjust for the variation in cost in different geographical regions. The total RVU for a service is calculated as the sum of the products of each component RVU and component GPCI, and the payment is calculated by multiplying the total RVU by a conversion factor CF (a dollar value determined by the CMS). So the RVU for a service is:

 $\begin{aligned} \text{Total } \text{RVU} &= (\text{work } \text{RVU} \times \text{work } \text{GPCI}) + (\text{expense } \text{RVU} \\ &\times \text{expense } \text{GPCI}) + (\text{malpractice } \text{RVU} \times \text{malpractice } \text{GPCI}) \end{aligned}$ 

Payment for the service then is calculated as

 $Payment = Total RVU \times CF$ 

Every 5 years, the RBRVS fee schedule is reviewed by the CMS, whereas the physician's work RVU and CF are updated every year.

#### Freestanding Facilities: Medicare

In the freestanding facilities such as imaging centers and physician's private practices, the physician's professional service is considered a part of the entire procedure and is included in the global payment for the service.

#### Nonmedicare Payers: All Settings

Private insurance companies have a variety of payment arrangements with providers, and primarily follow the guidelines of the CMS.

#### Billing

There are two ways of billing: component billing and global billing. In component billing, there are two components for a given PET procedure: professional and technical components, which are billed separately. The professional component is billed for the physician interpretation services, and the technical component for facility services such as equipment, personnel time, and supplies. The global billing is made for both the technical and professional services together, usually applicable to freestanding facilities and private medical practices.

Claims for reimbursements must be submitted to the CMS using CPT codes for PET procedures along with Dx (ICD-9-CM) codes for all approved clinical indications. For billing purposes, several CPT codes have been assigned for all PET procedures with a few exceptions, which require HCPCS codes for billing. CPT codes can be used for "denial" of reimbursement for noncovered procedures. Private payers may be billed using CPT codes, while some private payers may require the use of the CMS HCPCS codes.

#### **Billing Process**

This section describes how a billing for a given study is processed from the beginning to the end. Prior to any study performed on a patient, the demographic data of the patient including the insurance information are entered into the computer by the admitting personnel or receptionist. This becomes a part of the overall medical record of the patient and should be available in the RIS and HIS via PACS. A diagnostic or therapeutic service is performed on a patient and the corresponding CPT or HCPCS codes are entered into the computer. These codes for most studies are usually formatted into bar codes on a template. The technologist performing the examination enters its code into the computer by swiping its bar code on the template using a penlight or a bar code reader. The physician then interprets the study and the report is stored. For each study, the Dx (ICD-9-CM) code is either entered by the technologist or by the physician during dictation, depending on the way it is set up at each facility.

Next, the data for each patient are forwarded electronically to the billing department, which then assembles the data into the proper format of a claim form, normally using a computer billing software. In some complicated studies, manual billing may be done and their paper records are saved. The computer-generated bill is then sent to the insurance company or Medicare who, after proper verification of whether it meets its criteria, accepts or rejects the claim for payment. In most cases, the amount for each examination is paid by the rate set by the insurance company or Medicare, not what is billed. There are several scenarios for Medicare payment. For hospital inpatients, Medicare pays the entire amount at the DRG rate. For hospital outpatient services, Medicare sets up a payment rate for a service, which is divided into two payments – one by Medicare and the other by the patient. The ratio between Medicare and patient payments varies with different services, but tends to be around 80:20, i.e., Medicare pays 80% of an eligible charge and the patient pays 20%. If the healthcare provider is in an "assignment" contract with Medicare, the patient cannot be charged more than 20% per contract agreement.

The payment by the private insurers varies depending on the contract between the insurer and the patient. These payments may be based on the usual and customary rates (UCR) set for a region, or by company-set RVUtype values, or according to the cost of the services provided. It is essential to work with the private insurers in the region to establish a reasonable payment rate for PET studies.

Rejection of a claim often arises from improper coding, incomplete billing information, and errors in demographic data of the patient entered initially. At times, insurance companies may not even notify denials, and so a follow-up by the billing personnel is required. Even if a payment is made, it may be an incorrect amount. The resolution of nonpayment or incorrect payment may take months, if it is accomplished at all, which is quite aggravating. Electronic billing through portals such as WebMD has eliminated many of these errors and substantially improved billing and collection.

It is essential that properly trained and knowledgeable personnel staff the billing department to avoid rejection and incorrect payment by the CMS. The reimbursement rate for PET studies is at the high end, and many PET centers are paying special attention to the billing process and employ a skilled billing individual as a special point man to concentrate on PET reimbursement. The point man interacts with the payers to clarify the criteria of these studies and explain to them the appropriateness of each PET study.

Healthcare financing is changing and evolving with time, with a continuous decline in reimbursement, while the cost of healthcare itself is growing. It is absolutely critical to attempt to maximize collection of reimbursement for each study, and this can be achieved only through understanding of codes for each study, providing proper codes and other information in the claim form, and appropriate follow-up in the case of rejection or incorrect payment.

#### Chronology of Reimbursement for PET Procedures

For many years, PET procedures were considered by the CMS as experimental and research-based and so were not reimbursed, although some private insurers did pay for the PET studies for very specific cases. Based on the approval of <sup>82</sup>Rb-RbCl by the FDA in 1989 for myocardial perfusion studies, and after a thorough review of scientific literature on the outcome of the PET study, the CMS first approved reimbursement for PET myocardial perfusion scans using <sup>82</sup>Rb-RbCl for both rest and pharmacological stress studies for patients suspected of having coronary artery disease. Similarly, based on the FDA approval and after considerable review of the literature, the CMS approved reimbursement starting in 1998 for two oncologic indications: staging of non-small-cell lung carcinoma (NSCLC) for metastasis; and characterization of solitary pulmonary nodules (SPN) for evidence of primary tumor supported by the computed tomography (CT). In 1999, with further evidence of efficacy of <sup>18</sup>F-FDG in oncologic indications, the CMS included coverage for the PET study of three more cancers: (1) localization of recurrent colorectal tumors indicated by rising levels of carcinoembryogenic antigen (CEA) (not covered for staging); (2) staging of lymphoma confirmed by pathology and as an alternative to a gallium scan; (3) evaluation of recurrent melanoma, prior to surgery, as an alternative to a gallium scan.

In 2001, the CMS made a dramatic change in its approach to coverage for PET procedures, and announced a NCD on PET procedures, based on a request by UCLA and Duke University for broad reimbursement coverage. This coverage request contained the summary and analysis of the literature of <sup>18</sup>F-FDG PET studies on cancer, cardiovascular disease, epilepsy, and Alzheimer's disease. In this broad coverage, reimbursement for diagnosis, staging, therapy assessment, and for recurrence of lung, colorectal, melanoma, lymphoma, head and neck, and esophageal cancers, was approved. Also included in this coverage was reimbursement for diagnosis for refractory seizure and myocardial viability using <sup>18</sup>F-FDG PET following inconclusive SPECT. Later, limited coverage for breast cancer, restaging of recurrent or residual thyroid cancer of follicular cell origin by <sup>18</sup>F-FDG PET and perfusion study of the heart using <sup>13</sup>N-NH<sub>3</sub> PET were added for CMS reimbursement.

The CMS limited the above coverage only to PET procedures that were performed using dedicated PET scanners and excluded those performed with hybrid cameras (dual-head coincidence cameras). For Medicare coverage, the dedicated PET scanners must use BGO, NaI(Tl), or other detectors of equal or superior performance characteristics and may be full-ring or partial-ring types. Under pressure by the medical community and having realized that efficacy and outcome of a procedure depends on, among other factors, the type and quality of equipment, the CMS addressed the issues of equipment used in PET procedures. Following a thorough literature survey, the CMS finally approved coverage for coincidence gamma camera-based PET procedures for some specific indications. The gamma cameras must have detectors, at least 5/8 in. thick, with digital electronics, and random and scatter corrections must be made for reconstruction, which must be performed by the iterative method. Note that the CMS and private insurers do not distinguish between PET and PET/CT procedures and reimbursement is identical, i.e., there is no additional reimbursement for the CT part of PET/CT procedures unless a CT study is specifically performed for the diagnosis of a particular indication without the PET examination and a claim for reimbursement is separately filed.

#### National Oncologic PET Registry

Medicare coverage for reimbursement is currently limited to a certain types of cancers. To extend the coverage for the noncovered indications, the CMS proposed a mechanism, referred to as *coverage with evidence development* (CED) that requires collection of PET data demonstrating the patient's health outcome. Under the CED initiative, the National Oncologic PET Registry (NOPR) was sponsored by the Society of Molecular Imaging and managed by the American College of Radiology (ACR) through the American College of Radiology Imaging Network (ACRIN). In this registry process, the CMS assesses the efficacy of the FDG procedures for specific indications to qualify for reimbursement. Facility registration began in November, 2005 and the patient registration in May 2006. Any PET facility that is approved for billing the CMS is eligible to participate in the NOPR, and Medicare patients who are referred for PET studies for cancer indications that are not currently reimbursed under Medicare can participate in the registry.

The NOPR calls for registration of facilities, patients, referring physicians for FDG PET studies with the NOPR. It requires an initial facility registration fee of \$50 and an escrow fee for each patient having the FDG PET study. Each eligible patient must be registered with the NOPR providing the pre-PET clinical and demographic data via a Web form filled out by the referring physician. The NOPR then assigns a registration number for the patient and enters pre-PET information into the NOPR database prior to the day of scan. The patient must consent to the inclusion of the study data in the future NOPR research.

After the completion of the PET study, the data are sent to the NOPR, which then sends out the post-PET form for the study to be filled out by the referring physician. The referring physician must return the form within 30 days. When the database for the patient is complete and the PET facility is notified by the NOPR about the completion, the PET facility then bills the CMS for reimbursement for technical and professional components separately or globally depending on the setup of the facility. Billing is made using appropriate CPT codes with a special modifier assigned for NOPR studies. Detailed information about the NOPR is available at http://www.cancerPETregistry.org.

**Disclaimer**: The codes provided in Tables 10.1 and 10.2 are valid at the time of this writing, but may change over time following rule changes by the CMS and other regulatory agencies.

#### Questions

- 1. Which federal agency is responsible for Medicare payment for health-care services?
- 2. Describe briefly how a Medicare payment for a particular clinical study is decided by the Centers for Medicare and Medicaid Services.

- 3. What are the different types of codes that need to be provided in a claim for reimbursement?
- 4. What is a relative value unit (RVU)?
- 5. Elucidate different steps taken in generating a bill for reimbursement for a study performed on a patient.
- 6. Name the PET radiopharmaceuticals for which reimbursements have been approved for specific clinical indications.
- 7. What is the minimum thickness of NaI(Tl) crystal needed in dual-head coincidence cameras for a clinical PET procedure to be eligible for reimbursement by Medicare?
- 8. Describe the NOPR process for a PET procedure. What is the purpose of NOPR?
- 9. Reimbursement for a PET procedure is the same in New York, NY and Duluth, MN. True\_\_\_\_\_; False\_\_\_\_\_.
- 10. DRG is a reimbursement system for \_\_\_\_\_ and APC is a reimbursement code for \_\_\_\_\_.

#### References and Suggested Reading

- AMA (2009). CPT codes, professional edition. The American Medical Association, Chicaco, IL
- Human Drugs: Positron Emission Tomography Drug Products: Safety and Effectiveness. (2000). Food and Drug Administration notices. Federal Register, March 10, 65:12999
- Keppler JS (2001). Federal regulations and reimbursement for PET. J Nucl Med Technol 29:173
- Medicare: Hospital Outpatient Services: Prospective Payment System (2001). Centers for Medicare and Medicaid Services proposed rules. Fed Regist 66:44671
- Medicare Hospital Outpatient Services: Prospective Payment System. (2002). Health care financial rules. Fed Regist 65:18433
- Medicare National Coverage Determinations Manual. (2009). pub 100–03 http://www.cms.hhs.gov/manuals/iom
- NOPR at http://www.cancerpetregistry.org
- Positron Emission Tomography (PET) Scans, Medicare Coverage Issues Manual, Section50–36, Transmittal R147 (2002). http://www.cms.gov//transmitals/ downloads/R147cim.pdf
- Society of Nuclear Medicine Physician Coding & Reimbursement Committee (2005). Educational Material on coding PET/CT with Integrated PET systems. (updated, 2006)

## 11 Design and Cost of PET Center

PET/CT has become one of the most common and useful modalities for detection and monitoring of treatment of human diseases because of its high diagnostic efficacy and accuracy. PET centers are growing in large number throughout the world as hospitals and outpatient imaging centers are utilizing PET/CT increasingly for patient care. A PET center is a designated area to accommodate one or more PET and/or PET/CT scanners. Smaller facilities normally possess only a single unit of PET/CT and procure their PET radiopharmaceuticals from commercial vendors having a cyclotron facility. These facilities are not likely to be considered as PET centers. Larger and academic institutes have PET centers that are large enough in area to accommodate several PET/CT scanners, one or more cyclotrons and a radiochemistry laboratory. These centers produce PET radiopharmaceuticals in their own cyclotron and use them for both patient care and research. The following is a brief description of the design of a PET center based on the clinical operation of one PET/CT scanner, a radiochemistry laboratory and a cyclotron.

The design of a PET center hinges on a number of factors: site, floor loading, size of the rooms available, traffic pattern inside the building, heating and cooling, electrical and water supply, and importantly, shielding in the facility to comply with the NRC or state regulations. These factors vary from facility to facility and from equipment to equipment from various vendors. The discussion here pertains to a generic PET center with minimal requirements for these entities, and a schematic layout of a PET center is illustrated in Fig. 11.1.

#### Site Planning

To build a modern PET center, it is essential to have a good site planning for a smooth and efficient installation of different units, such as the scanner and the cyclotron. An architectural blueprint must be drawn before construction begins. It is difficult and costly to make revisions after the completion of the project. Since a PET center involves the use of radiation, it must comply



FIGURE 11.1. A schematic layout of a PET center with a cyclotron. Note that the cyclotron and PET scanner rooms are on one side and the office area is on the opposite side of the center.

with all regulations of the NRC or the state regarding the exposure to the worker and the public. Logically, it is preferred to have the center far away from heavy traffic areas in the building to minimize exposure to nonradiation workers.

It is more challenging to set up a PET center in an existing facility (such as in a nuclear medicine department) than in a totally new secluded area. Redesigning the rooms, tearing down the walls, rerouting the electrical supply, water pipes, etc. are common difficulties that are faced in modifying the existing facility to set up a PET center. Often, certain requirements may be compromised to go along with the available features at the facility. On the other hand, it is preferred and much easier to build a PET center from scratch without any compromise in requirements.

Due to the heavy weight of the shielding and magnet, the cyclotron needs to be installed on the ground floor or in the basement, and soil and underground condition must be assessed. If the water level is too shallow, or the sewer is running under, these areas should be avoided or must be supported by additional support materials. Because of relatively lighter weight, the PET scanner, however, can be installed on any strong reinforced cement floor. In seismic areas, various units need to be properly anchored in compliance with local applicable seismic codes.

#### Passage

Passage is an important factor to receive and bring the PET and cyclotron units inside the PET center. The hallway must be wide enough and unhindered for easy delivery of these units to the installation site. Similarly, the door to the PET or cyclotron room also should be wide enough for easy access of the delivery crates. Normally a passage of  $8 \times 8$  feet in width and height should be optimal for the purpose. At times, in existing facilities where the current passage cannot be used, a new passage may have to be opened to allow for the delivery, thus adding to the cost.

#### PET Center

The PET center should be divided into three adjacent sections: one for the PET scanner facility; one for the cyclotron facility; and the third for the office area. The size of the first two sections depends on the dimensions of each vendor's equipment, and the third section depends on the size and scope of the operation in a given facility.

#### Scanner Section

The scanner section should have six rooms: a scan room, a control room, an electronics room, a patient preparation room, an injection room, and a patient uptake room. The scanner room size depends on the dimension of the PET/CT scanner, but the variations in dimensions of scanners from different vendors are not significant. A room of at least  $25 \times 20$  feet can be optimally used to install a PET/CT scanner from any vendor, along with storage for all supplies.

Adjacent to the scan room are the electronics room for all electrical units, connecting wires, etc., and the control room where the console for the operation of the scanner is installed. There should be a glass viewing window possibly of lead, between the scanning room and the control room for the operator to observe the patient during the study. Alternatively, a video camera in the scanner room and the monitor in the control room can be installed. The dimension of the electronics room should be approximately  $10 \times 8$  feet and that of the control room should be about  $10 \times 10$  feet. However, these dimensions can vary, if needed. All these rooms are interconnected for easy access to each room. Because the electronics modules and scanners generate

heat during operation, cooling is essential for the equipment and a good cooling and ventilation system must be installed. There should be a sink in the scanner room.

The patient preparation room should be preferably next to the above three rooms, but may be in an area not too distant from the scanner. Such a room should have a dimension of  $6 \times 6$  feet. This room is primarily used for the patient to change for preparation for the study. This room may also be used as the injection room for administration of PET radiopharmaceuticals such as <sup>18</sup>F-FDG, if a separate injection room is not affordable.

An injection room of  $6 \times 6$  feet should be equipped with a comfortable chair with armrest for the patient to sit on and a sink. All appropriate supplies should be stored in the room. A lead-shielded sharps container for syringe disposal and lead-shielded storage bin for other waste disposal are kept in the room.

Patients injected with <sup>18</sup>F-FDG are required to wait for 45–60 min before PET scanning and need to stay in a separate uptake room not to cause radiation exposure to the worker or the public. The PET room, the preparation room (if it is used as an injection room), and the uptake room should be well-shielded to comply with the limits on radiation exposure to workers and the public. This will be discussed later in the chapter.

#### **Cyclotron Section**

The cyclotron facility should be situated at the farthest location from the inside traffic in the PET center, since its operation is not directly related to the patient and the level of radiation exposure is relatively high in this area. It should consist of minimum four rooms: cyclotron room, control room, cooling room, and radiochemistry laboratory. The size of these rooms depends on the size of equipment and space available at the facility, and they should be adjacent to each other.

The size and structural features of a medical cyclotron vary from vendor to vendor and so require rooms of various dimensions. A room of  $25 \times 25$  feet should be adequate for most compact medical cyclotrons and should be equipped with a floor drain. The power supply unit may be installed in the cyclotron room or in a separate room.

Contaminated air from the cyclotron is exhausted to the outside atmosphere after passing through a HEPA filter and carbon filters. A stack monitor consisting of a gamma detector is installed to constantly monitor the level of radioactivity exhausted to meet the regulatory limits.

The weight of the magnet of a medial cyclotron runs around 22,000 lbs. Some cyclotrons are self-shielded with lead blocks weighing more than 35,000 lbs. Such heavy weight needs special consideration of the condition of the soil and the floor on which the cyclotron is to be installed. Entrance to the cyclotron room should be monitored by an electronic alarm to prevent accidental entrance to the room during the operation of the cyclotron. The control room houses a workstation, a printer and other auxiliary terminals to operate the cyclotron. A room with the size of  $10 \times 10$  feet should be adequate and should have easy access to the cyclotron room, but entrance must be monitored by an alarm.

The cooling system is required because of the heat generated by the electromagnet of the cyclotron and power supply unit associated with it. It consists of chillers with heat exchanger/deionizer water system that recirculates cooled water between the cyclotron and the power supply. The temperature of the system is maintained at around 7–15°C, depending on the type of cyclotron from a vendor. Chillers are installed in a room adjacent to the cyclotron and power supply rooms, although they are sometimes installed on the roof of the cyclotron building. The room size for chillers should be of the size  $10 \times 10$  feet and a floor drain is required in the room.

The radiochemistry room should be adjacent to the cyclotron for convenience of transfer of irradiated targets for processing and subsequent synthesis of PET radiopharmaceuticals. This room should be equipped with conventional labware along with a hot cell, a minicell, a synthesis box, a fume hood (preferably sterile), a sink, and steel workbench all around. The optimal size of the room should be  $20 \times 20$  feet, and a floor drain must be installed in the room. Shielding of this room is essential because a high level of radioactivity is handled inside. To this end, the walls of this room should be thick concrete (on the order of 40 cm). The room should be well-ventilated at a negative pressure and maintained at a comfortable temperature using appropriate heating and air conditioning. A section or a separate room within the radiochemistry room is designated for quality control and dispensing of PET radiopharmaceuticals and should have a laminar flowhood.

#### Office Area

The office area in a PET center should have various administrative offices, a waiting room, a reading room, a storage room for supplies, a toilet, a file storage room, etc. The administrative offices include physicians' offices, receptionist's office, and secretary's office. Depending on the scope of the operation, the office area varies in size. In a smaller operation, all activities mentioned above are carried out in one or two rooms, while in a larger operation, several rooms are utilized for various activities for efficient operation of the PET center, as shown in Fig. 11.1. The receptionist area should be in the front section of the center to receive the patients on arrival at the center. The entire area should be designed with the idea in mind that the area is an unrestricted area and so there is minimal radiation exposure not to exceed the regulatory limits from the adjacent PET scanner and the cyclotron rooms. An area between 400 and 600 square feet is an optimal estimate for the office suite in a relatively large PET center.

#### Caveat

A great deal of detail is involved in the planning and construction of a PET center with a cyclotron. To insure a successful project, it is essential to have one person charged with the responsibility of managing the entire project. This person should have a strong background and experience in medical facility construction, and should be involved from the beginning to the end of the project. If such a person is not available locally, an outside planner or construction manager is recommended. This person should be the contact and liaison between the vendor and the PET center management.

As with any construction project, a construction permit must be obtained from the local authority. All local construction codes must be adhered to regarding the electricity and water supply and fire safety. A health physicist or a medical physicist should be consulted to address the issues of shielding and personnel traffic in restricted areas. A radioactive material license from the appropriate authority must be in possession for the use of PET radiopharmaceuticals, before the PET center goes into operation. Authorized physicians must be included on the license.

#### Shielding

A major concern in the setting up of a PET center is the shielding requirement for the walls, floors, and ceilings of the PET room, the uptake room for injected patients, the cyclotron room, and the radiochemistry room, because of the high energy 511 keV photons from positron emitters handled in these areas. As mentioned, the cyclotron should be in an area away from the inside traffic and typically is installed on the lowest floor because of the heavy weight. Also, most compact cyclotrons are self-shielded with lead blocks. Even then, the cyclotron is housed in a room with thick concrete walls to reduce the radiation exposure outside the room. An unshielded cyclotron requires a very thick concrete vault with a lengthy maze for neutron exposure reduction. The radiochemistry room is also made of thick concrete walls and normally situated away from the inside traffic. Moreover, several enclosures made of lead bricks thick enough to considerably reduce radiation exposure are utilized in the laboratory for handling the radioactivity in the synthesis of PET radiopharmaceuticals.

The shielding requirement for the PET room is somewhat different because most facilities having a PET scanner is located in an area surrounded by areas often frequented by nonoccupational individuals. To meet the regulatory exposure limit for these individuals, sufficient shielding in the walls and the ceiling should be provided in the PET scanner room, the injection room, and the patient uptake room. It is often required to calculate how much shielding is needed for a new PET room, or how much shielding should be added to the wall in an existing room that is to be converted to a PET scanner room. The occupational workers work mostly inside the PET suite and satisfy their radiation exposure limit of 5 rem (0.05 Sv) per year by adopting ALARA principles and all radiation protection principles within the working area. A major consideration for shielding arises for the walls, ceiling, and floor that separate the scanner room and patient uptake room from unrestricted areas. The radiation exposure limit for nonoccupational individuals is 100 mrem (1 mSv) per year. Appropriate shielding should be estimated and provided for these areas to meet the regulatory limit. Several factors must be taken into consideration in estimating these shielding requirements, and these are discussed below.

- (a) Source of radiation. The source of radiation exposure is primarily the patient injected with a PET radiopharmaceutical. The patient may be on the PET scanning table or in the uptake room after injection. The PET radiopharmaceutical dosages are contained in lead-shielded containers and are not likely to contribute to the exposure. Since a patient is considered an extended source of radiation, annihilation radiation is attenuated by the body and so the dose rate is significantly reduced. Based on literature data, the AAPM Task Group (2006) has recommended a patient dose rate of  $0.092 \,\mu Sv \cdot m^2 / MBq \cdot h (0.34 \,mrad \cdot m^2 / mCi \cdot h)$  immediately after administration of <sup>18</sup>F-FDG. This corresponds to an effective attenuation factor of 0.36 and a transmission factor f of 0.64, which should be included in the calculation of shielding for 511 keV photons.
- (b) *Amount of activity*. The amount of activity administered to the patient determines the radiation exposure. Since the administered activity varies from patient to patient, an average value may be assumed in the estimation of shielding.
- (c) Decay of activity. The activity in a patient decays over time and so radiation exposure also decreases with time from a given patient. So, how long a patient stays in the PET center determines the exposure. The exposure can be calculated from the cumulative activity integrated over time the patient stays in the uptake room and the PET scanner room. Thus, the cumulative activity  $A_c$  is given by

$$A_{\rm c} = A_0 \frac{1 - e^{-\lambda t}}{\lambda},\tag{11.1}$$

where  $A_0$  is the initial administered activity,  $\lambda$  is the decay constant of the radionuclide in question and *t* is the time the patient with activity stays at the facility. This time includes the time from injection to the end of scanning, i.e., the waiting time after injection (e.g., <sup>18</sup>F-FDG injection) plus the scanning time.

(d) Number of patients per day. Radiation exposure occurs when a patient is injected with radioactivity and scanned, i.e., for the duration the patient stays at the facility after injection of radiopharamaceutical. There is no exposure in the absence of a patient injected with radiopharmaceutical. Therefore, the number of patients studied per day is an important factor in calculating the shielding.

(e) Distance. The radiation exposure decreases inversely with the square of the distance between the source and the walls, floor or ceiling. The exposure X at a distance d from a point source of A mCi (MBq) activity is given by

$$X = \frac{A\Gamma}{d^2},\tag{11.2}$$

where  $\Gamma$  is the exposure rate constant of the radionuclide which is discussed at length in Chap.9. The larger room cuts down the radiation exposure due to longer separation between the source and the outside of the wall.

(f) Shielding. Radiations are attenuated by absorbing material, and the attenuation depends on the atomic number and density of the material. Heavier metals such as lead, tungsten, etc. are effective shielding material to reduce radiation exposure. Construction materials such as plaster, gyp-sum boards, steel, and concrete have lower attenuation coefficients and thus have lesser shielding effect. The linear attenuation coefficients ( $\mu$ ) of some of the shielding materials are given in Table 11.1. Using these  $\mu$  values, one can calculate the thickness of shielding required for an initial exposure  $I_0$ , to reduce to  $I_x$  by the following formula:

$$I_x = I_0 e^{-\mu x}, (11.3)$$

where  $I_x$  is the exposure beyond a thickness x of the shielding material with linear attenuation coefficient  $\mu$ .

Equation (11.3) is valid for a narrow-beam geometry from a point source, and scattered radiations in the absorbing material are excluded. That is, each photon is either completely absorbed or transmitted. In reality, Compton scattering of 511 keV photons occurs within the shielding material, and some

Material	Atomic no $(Z)$	Density $\rho(g/cc)$	Attenuation
			coefficient
			$\mu(\mathrm{cm}^{-1})^{\mathrm{a},\mathrm{b}}$
Concrete	-	2.2	0.080
Iron	26	7.9	0.433
Tungsten	74	19.3	2.165
Lead	82	11.4	1.260

THE THE TROPERED OF GREETER OTHER HIGHER INCOMENTATION
--

<sup>a</sup>Adapted from Towson JEC (2003). Radiation dosimetry and protection in PET. In: Valk PE, Bailey DL, Townsend DW, Maisey MN (eds) Positron emission tomography, Springer, New York

<sup>b</sup>Based on broad beam geometry

of the photons which were heading away from the location point of exposure may be scattered back toward it, thus adding to the exposure. This broadbeam geometry gives rise to what is called a *build-up factor*, B, which is given by:

 $B = \frac{\text{Intensity of primary plus scattered radiations}}{\text{Intensity of primary radiations only}}.$ 

The value of *B* is always greater than 1 and depends on the thickness of the shielding material. It initially increases with the thickness of the shielding material and then reaches a plateau after a certain thickness. Also, the value of *B* is higher in low atomic number material than in high atomic number material, due to relatively more Compton scattering in the former. Thus, the build-up factor in gypsum board is higher than in lead. In lead, it can be assumed to be 1. In this case, the human body can be modeled to be segmented into different sections and iterative methods can be applied to estimate the shielding requirement. A phantom called *bottle manikin absorption* (BOMAB) is available, simulating various regions of human anatomy (arms, thigh, abdomen, chest, head) and can be used to estimate shielding need (ANSI, 1999).

(g) *Occupancy factor*. The occupancy of an area refers to the amount (fraction) of time the area is occupied by an individual per week. The suggested occupancy factors *T* are given in Table 11.2.

Combining all the above factors, one can formulate an equation for radiation exposure as follows:

$$X = \frac{A_0 \Gamma f B N (1 - e^{-\lambda t}) e^{-\mu x} T}{d^2 \lambda},$$
(11.4)

where

X = exposure (rem or Sv per week) at distance *d* from the patient and beyond the thickness *x* of shielding material

TABLE 11.2. Duggeste	a occupancy factors r	
Occupancy level	Type of area	Т
Full	Work areas, laboratories, nursing stations, living quarters, offices, Children's play area	1
Partial	Corridors, restrooms, unattended parking lots	1/4
Occasional	Waiting rooms, toilets, stairways, elevators, closets	1/16
*Values suggested in N	CRP 49	

TABLE 11.2. Suggested occupancy factors  $T^*$ 

- $A_0$  = activity in mCi (MBq) administered per patient
- $\Gamma = exposure rate constant (R-cm^2/mCi-h at 1 cm or <math display="inline">\mu Gy\text{-}m^2/GBq\text{-}h$  at 1 m)
- f = transmission factor that accounts for exposure coming from the patient
- B = build-up factor due to broad beam geometry
- N = number of patients per week
- $\lambda = \text{decay constant } (h^{-1}) \text{ of the radionuclide}$
- t =time (h) the patient spends in the PET facility after receiving tracer injection;
- $\mu$  = linear attenuation coefficient (cm<sup>-1</sup>) of photons in shielding material
- T =occupancy factor for the area in question
- d = distance from the patient in meter or centimeter
- x = thickness (cm) of shielding material.

CT causes radiation exposure to a varying degree due to scattered X-ray radiations from the patient during the study depending on the KV and mAs applied. The shielding required for 511 keV photons should be sufficient for the low energy (70–140 keV) X-rays, even though the X-ray beam intensity is extremely high compared to the intensity of 511 keV photons. Normally, one-eighth inch of lead is sufficient for both 511 keV and X-rays.

We will now illustrate an example of estimation of shielding requirements for a simple specific case in a PET center.

#### Case Study

A drywall separates the PET room and a common waiting room and stands at 2 m away from the center of the PET scanner. The facility performs six <sup>18</sup>F-FDG PET studies per day using 15 mCi (555 MBq) dosage per patient. How much shielding of lead will be needed on the wall to meet the regulatory radiation exposure limit? ( $t_{1/2}$  of <sup>18</sup>F = 1.833 h;  $\Gamma$  for <sup>18</sup>F = 6.96 R-cm<sup>2</sup>/mCi-h at 1 cm;  $\mu$  for <sup>18</sup>F in lead = 1.26 cm<sup>-1</sup>).

The common waiting area is considered a public area, and the exposure limit is 100 mrem/year or 100 mrem/50 weeks = 2 mrem/week.

Number of patients/week	$= 6 \times 5 \text{ days/week} = 30$
Activity/patient, A <sub>0</sub>	$= 10 \mathrm{mCi}$
Distance, d	$= 2 \mathrm{m} \mathrm{or} 200 \mathrm{cm}$
Time patient stayed after injection,	
t (assumed)	$= 40 \min(wait) + 20 \min(scan)$
	$= 60 \min$
	=1 h
Occupancy factor $T$ for waiting room	= 1/16
<i>B</i> for lead	=1
f for patient attenuation	= 0.64

Radiation exposure limit/week= 2 mrem/week= 0.002 rem/weekExposure rate constant  $\Gamma$  of  ${}^{18}\text{F} = 6.96 \text{ R-cm}^2/\text{mCi-h}$  at 1 cm $\mu$  for  ${}^{18}\text{F}$  in lead $= 1.26 \text{ cm}^{-1}$ Decay constant  $\lambda$  for  ${}^{18}\text{F}$  $= \frac{0.693}{1.833} = 0.378 \text{ h}^{-1}$ x (thickness of shielding)= ?

Thus,

$$0.002 \,(\text{rem/week}) = \frac{15 \times 6.96 \times 0.64 \times 30 \times 1 \times (1 - e^{-0.378 \times 1}) \times e^{-1.26x}}{200^2 \times 0.378 \times 16}$$
$$= \frac{4009 \times 0.3147 \times e^{-1.26x}}{241920}$$
$$e^{-1.26x} = 0.3835$$

Taking logarithm,

$$-1.26x = -0.9584$$
  
 $x = 0.76 \text{ cm}$   
 $\sim 0.30 \text{ in.}$ 

Thus, assuming the drywall provides no shielding, approximately 0.3 in. of lead shielding would be needed to add to the wall in order to reduce radiation exposure in the waiting area below the regulatory limit of 100 mrem/year to the public.

#### Cost of PET/CT and Cyclotron Operation

During the last decade, the growth of PET/CT has been phenomenal all over the world, especially in USA. Many community hospitals and academic institutions in USA now have one or more PET/CT scanners, because PET/CT studies for many oncologic indications are reimbursed by the CMS. In the past, the supply of <sup>18</sup>F-FDG was limited to only a few academic centers that owned a cyclotron, and PET studies were available only at these facilities. Nowadays, commercial nuclear pharmacies produce <sup>18</sup>F-FDG for daily distribution to many facilities, small or large, for clinical PET/CT studies thus obviating the need for a cyclotron in a facility. These facilities benefits from this arrangement without having to possess a cyclotron that is expensive to purchase as well as to operate. However, academic and research institutions that are interested in research using PET radiopharmaceuticals in addition to clinical <sup>18</sup>F-FDG are more likely to have a full-pledged PET center with a cyclotron and a radiochemistry laboratory. While the cost of operation and maintenance of a PET/CT scanner is moderate, that of a cyclotron is very high including personnel. The following is a brief summary of expenses for different items pertinent to a PET/CT scanner and a cyclotron.

The price of a PET/CT scanner ranges between \$1.7 million and \$2.5 million, depending on the choice of various features. At present, a 10-18 MeV medical cyclotron costs around \$1-1.5 million dollars. The operational and maintenance cost of a cyclotron is high because of power consumption and shielding requirement. While PET/CT can be run by regular nuclear medicine technologists sharing their daily responsibilities with other nuclear medicine studies, dedicated individuals trained in cyclotron operation are needed for a cyclotron. One or more radiochemists, radiopharmacists and technicians are required depending on the extent and scope of the operation, to synthesize the PET tracer of interest, to do its quality control and dispensing it for patients. While a radiochemist is responsible for synthesis aspect and routine operation of the cyclotron, a radiopharmacist is required to validate and dispense the patient dosages. These individuals earn a high-end salary of more than \$100,000, with the exception of technicians who earn slightly less. The cost of licensing, service contract, and insurance of a cyclotron is quite high ranging in several hundred thousand dollars. An additional item of cost in the cyclotron operation is the target material that can be quite expensive depending on the enrichment and availability.

If an institution having a cyclotron operates a business venture to distribute <sup>18</sup>F-FDG to other facilities for PET/CT studies, it must have a distribution license from the state, which will add to the cost for licensing. In addition, delivery of dosages calls for drivers or courier services prompting further expense. Considering the expenses, facilities that have no research plan or business of distribution are better off without a cyclotron avoiding the cost of cyclotron operation, while fulfilling the clinical demand by purchasing unit dosages of <sup>18</sup>F-FDG from commercial vendors at a substantial financial benefit.

#### Questions

- 1. What are the different factors one should consider in designing a PET center without any cyclotron?
- 2. In designing a cyclotron facility, the major concern is shielding. Elaborate on different factors that must be taken into consideration in the estimation of shielding around the facility.
- 3. In a PET center, a clinical laboratory is situated on the other side of a plaster wall of the PET room. Calculate the amount of lead shielding required to be added to meet the regulatory limit, given the following information: number of FDG studies per week = 25; <sup>18</sup>F-FDG dosage per patient = 10 mCi; linear attenuation coefficient of 511 keV photons in lead =  $1.26 \text{ cm}^{-1}$ ;  $\Gamma$  for <sup>18</sup>F = 6.96R-cm<sup>2</sup>/mCi-h at 1 cm; distance between

the scanner and the wall is 250 cm; patient stays in the department for a total of 1 h after injection.

4. What is a stack monitor? Where is it used?

#### References and Suggested Reading

- American National Standards Institute/Health Physics Society (1999). Specifications for the bottle manikin absorption phantom. Health Physics Society, McLean, VA; ANSI/HPS N13, p 35
- Courtney JC, Mendez P, Hidalgo-Salvatierra O, Bujenovic S (2001). Photon shielding for a positron emission tomography suite. Health Phys 81:S24
- Kearfott KJ, Carey JE, Clemenshaw MN, Faulkner DB (1992). Radiation protection design for a clinical positron emission tomography imaging suite. Health Phys 63:581
- Madsen MT, Anderson JA, Halama JR et al (2006). AAPM Task Group 108: PET and PET/CT shielding requirements. Med Phys 33:4
- Mathe B (2003). Shielding design for a PET imaging suite: a case study. Health Phys 84:S83

## 12 Procedures for PET Studies

In this chapter, different protocols for common PET procedures are described to provide a general understanding of how a PET study is performed. Only four procedures are included, namely whole-body PET imaging with <sup>18</sup>F-FDG, PET/CT whole-body imaging with <sup>18</sup>F-FDG, myocardial perfusion imaging with <sup>82</sup>Rb-RbCl, and myocardial metabolic imaging with <sup>18</sup>F-FDG. The procedures described here are generic in that there are variations in the detail of each procedure from institution to institution. Different institutions employ different techniques in immobilizing the patient on the table. Use of CT contrast agents in PET/CT is still a debatable issue, and some investigators use them, while others do not. While glucose loading is essential for myocardial <sup>18</sup>F-FDG studies in patients with low fasting glucose levels, there are varied opinions as to the lowest limit of glucose level at which glucose loading should be provided and what amount of glucose should be given orally. In lymphoma and colorectal studies, it is desirable to have a Foley catheter secured to the patient to eliminate extraneous activity in the bladder, but perhaps it is not universally employed by all.

In view of the above discussion, it is understandable that the procedures described below are a few among many with variations in detail, but the basics of PET or PET/CT imaging remain the same.

#### Whole-Body PET Imaging with <sup>18</sup>F-FDG

#### Physician's Directive

- 1. A nuclear medicine physician fills out a scheduled patient's history form indicating where the scan begins and ends on the body.
- 2. If the patient weighs over 250 lbs, the physician authorizes a dosage of <sup>18</sup>F-FDG higher than the normal dosage.

#### **Patient Preparation**

- 3. The patient is instructed to fast 6 h prior to scan.
- 4. Insert an IV catheter into the patient's arm for administration of <sup>18</sup>F-FDG.
- 5. For melanoma patients, injection must not be made in the affected extremity. Injection should be made away from the affected area.
- 6. A Foley catheter is required for patients with colorectal carcinoma and lymphoma, for voiding urine.
- 7. Remove all metallic items such as belts, dentures, jewelry, bracelets, hearing aids, bra, etc. from the patient.
- 8. The patient wears a snapless gown.

#### Dosage Administration

- 9. Inject <sup>18</sup>F-FDG (10–15 mCi or 370–555 MBq in a shielded syringe) into the patient through the IV catheter. Flush with 20 ml saline.
- 10. The patient waits for 40–60 min with instructions to remain calm and quietly seated during this waiting period.

#### Scan

- 11. Enter patient's name, birthdate, weight, and ID number into the computer.
- 12. Obtain a blank transmission scan without the patient in the scanner for attenuation correction using the rotating <sup>68</sup>Ge source before the first patient is done. This blank scan is used for subsequent patients for the day.
- 13. After the waiting period, the patient lies supine on the scan table with the head toward the PET scanner, and with arms up or down depending on the area to be scanned.
- 14. Position the patient inside the scanner to the upper limit of the scan as designated by the physician. This position is marked by the computer control on the console.
- 15. The patient is then moved to the lower limit of the scan and the position is marked by the computer control on the console.
- 16. The computer determines the length of the scan field from the positions marked in Steps 14 and 15. From the manufacturer's whole-body scanner chart, determine the number of bed positions needed for the length of the scan field.
- 17. Enter into the computer all pertinent information, e.g., dosage of <sup>18</sup>F-FDG, injection time, and number of bed positions.
- 18. Position the patient to the upper limit of scan in the scanner.
- 19. Collect a patient's transmission scan with the <sup>68</sup>Ge source.
- 20. Start the patient's emission scan collecting data for a preset count or time.

- 21. Move the table to the next bed position and repeat steps 19 and 20. Note: Steps 19–21 are automatically done by the computer control.
- 22. The scanner stops when the lower limit of the scan is completed (that is, scanning at all bed positions is completed).
- 23. The patient is released after the complete acquisition of the data.

#### Reconstruction and Storage

- 24. Attenuation correction factors are calculated from the blank transmission scan (Step 12) and patient transmission scan (Step 19). Reconstruct images using the corrected data with appropriate reconstruction algorithms (FBP or iterative method), provided by the manufacturer.
- 25. Images are sent to the workstation for display and interpretation.
- 26. Images are stored and archived for future use or for use in PACS, if available.

#### Whole-Body PET/CT Imaging with <sup>18</sup>F-FDG

#### Physician Directive

- 1. The nuclear physician evaluates the history of the patient and sets the scan limits of the body.
- 2. The physician authorizes a higher dosage of <sup>18</sup>F-FDG, if needed based on the patient's weight.

#### Patient Preparation

- 3. The patient is asked to fast for 6 h prior to scan.
- 4. Remove metallic items from the patient, including dentures, pants with zipper, bra, belts, bracelets, etc.
- 5. The patient wears a snapless gown.
- 6. Insert an IV catheter in the patient's arm for administration of <sup>18</sup>F-FDG.

#### Dosage Administration

- 7. If the patient is diabetic, check the blood glucose level. If the level is <200 mg/dL, inject <sup>18</sup>F-FDG into the patient a dosage of 0.22 mCi/kg (8.1 MBq/kg). If the level is >200 g, consult the physician. The cutoff value for glucose level varies with the institution. Measure the residual in the syringe to determine the administered activity.
- 8. The patient waits for 45–60 min after FDG administration and is instructed to remain quiet with minimal movement until the completion of the PET/CT scan.
- 9. The patient is asked to void prior to scanning.

#### Scan

- 10. Enter the patient's information into the computer, such as name, clinic or hospital number, birthdate, and weight as well as the dosage of <sup>18</sup>F-FDG.
- 11. Collect a blank CT transmission scan at the beginning of the day. It is used for subsequent patients for the day.
- 12. The patient lies supine on the scan table with the head toward the gantry and is positioned by laser light. The patient's arms are positioned up (suspected thorax) or down (suspected head and neck) depending on the area to be scanned. Comfortable supports are provided for the head and neck, the arms, and the knees.
- 13. The table advances by computer control toward the gantry (first CT). Acquire a topogram to define axial range of the body for scanning. The patient is asked not to move, close eyes and breathe normally during this phase. When the area to be scanned is covered by the topogram, scanning is stopped.
- 14. Position the patient in the CT scan field and procure a spiral CT transmission scan that takes less than 1 min.
- 15. After the completion of the CT scan, the table is automatically advanced into the PET scanner with the patient in the scan field. The number of bed positions is automatically calculated from the axial range defined by the topogram in Step 13. Data are acquired for a set time for each bed position.
- 16. After the completion of the PET data acquisition for the last bed position, the patient is released.

#### Reconstruction and Storage

- 17. Because CT images are collected in a short time, they are ready for calculation of attenuation correction factors before the first PET emission scan is obtained. The attenuation correction factors are calculated from the blank scan (Step 11) and patient's tansmission scan (Step 14) by the appropriate algorithm.
- 18. Attenuation correction factors are applied to acquired PET data (Step 15). PET images are then reconstructed from corrected data using either the FBP or the iterative method depending on the vendor's software.
- 19. The appropriate software fuses the CT and PET images of each slice.
- 20. The CT, PET, and fused PET/CT images are then sent to the workstation for display and interpretation.
- 21. Images are stored and archived for future use or for use in PACS, if available.

# Myocardial Metabolic PET or PET/CT Imaging with <sup>18</sup>F-FDG

#### Patient Preparation

- 1. The patient is instructed to fast for 6–12 h prior to scan.
- 2. Place an IV catheter in the arm of the patient for FDG administration.
- 3. Blood glucose level of the patient is checked. A variety of situations can arise as to glucose loading to titrate blood glucose level and several protocols have been developed. For details, refer to the American Society of Nuclear Cardiology Practice Guidelines: Imaging guidelines for Nuclear Cardiology Procedures: PET myocardial Perfusion and Metabolism Clinical Imaging (ASNC, 2003). One of the protocols is adopted as follows:
  - (a) If fasting glucose level is <110 mg/dL and no diabetes, give the patient 25–100 g of glucose orally and monitor the blood glucose. If at 45–60 min after administration, the glucose level is

130–140 mg/dL, give 1 U regular insulin IV 140–160 mg/dL, give 2 U regular insulin IV 160–180 mg/dL, give 3 U regular insulin IV 180–200 mg/dL, give 5 U regular insulin IV >200 mg/dL, notify physician.

- (b) If fasting glucose level is  $>\sim 110-130 \text{ mg/dL}$  or the patient is diabetic, then follow the schedule in (a).
- After blood glucose monitoring, administer 5–15 mCi (185–555 MBq)
   <sup>18</sup>F-FDG to the patient.
- 5. The patient is asked to wait for 45–60 min.
- 6. For a PET only study, obtain a blank transmission scan with a <sup>68</sup>Ge source before the first patient is done. This scan is used for all subsequent patients for the day. For a PET/CT scan, obtain a blank CT scan and store it for patient studies.

#### Scan

- 7. The patient lies supine on the scan table with arms up away from the field of the heart. Position the patient in the scanner with the heart in the axial field of view.
- 8. In PET/CT studies, obtain a topogram (scout scan) with CT to assess the positioning of the patient.
- 9. Procure a transmission (for attenuation correction) scan of the patient using the rotating <sup>68</sup>Ge source for the PET only study or with the patient in the CT field of view and applying CT for the PET/CT study.
- 10. Next, collect PET emission scan data for a preset time or count in a sinogram matrix of a chosen size. It should take about 10–30 min.

#### Reconstruction and Storage

- 11. Calculate attenuation correction factors from the blank transmission scan (Step 6) and patient's transmission scan (Step 9), and apply them to the acquired emission data Reconstruct images using the attenuation corrected emission data by the FBP or iterative method (e.g., OSEM) provided by the manufacturer. The pixel size in reconstructed images should be 2–4 mm.
- 12. The gating technique may be applied, if desired.
- 13. Images are then sent to the workstation for viewing and interpretation.
- 14. Next, images are stored for future use or for use in PACS, if desired.

## Myocardial Perfusion PET or PET/CT Imaging with <sup>82</sup>Rb-RbCl

#### **Patient Preparation**

- 1. The patient removes all clothing above the waist and wears a slip-on gown.
- 2. Twelve-lead EKG connections are then applied to the patient for monitoring vital signs during stressing.
- 3. The patient lies supine on the scan table with arms stretched out beyond the scanner gantry. The head and neck and the arms are kept comfortable and immobile with supports.
- 4. Insert an IV catheter into the arm for <sup>82</sup>Rb and pharmacologic agent (dipyridamole, lexiscan, or adenosine) infusion. The IV line is kept patent with saline. Patient's information is entered into the computer.

#### Dosage Administration and Scan

- 5. For a PET only study, collect a blank transmission scan at the beginning of the day by the <sup>68</sup>Ge source before the first patient is positioned in the PET scanner. This blank scan is used for all subsequent patients for the day. For a PET/CT study, collect a blank CT scan and store for future patients.
- 6. Position the patient so that the heart is within the scan field.
- 7. Connect the <sup>82</sup>Rb generator tubing from the infusion pump (see Addendum) to the patient's catheter. A low dosage of 10–20 mCi (370–740 MBq) <sup>82</sup>Rb is administered by the infusion pump and a topogram (scout scan) is obtained to ensure the position of the heart is in the correct scan field. In the case of PET/CT study, a topogram is obtained with CT for positioning check.
- 8. Take a patient's transmission scan with the rotating <sup>68</sup>Ge source or with a spiral CT scan.
- Administer <sup>82</sup>Rb by the infusion pump (see Addendum) for a cumulative activity of 40–60 mCi (1.48–2.22 GBq) for 2D acquisition or 20–40 mCi (0.74–1.48 GBq) for 3D acquisition. Infusion should be completed in a period of maximum 30 s.
- Start rest emission scan 70–90s after the <sup>82</sup>Rb infusion for normal left ventricular function and about 110–130s for poor ventricular function. Gated acquisition also can be performed, if desired.
- 11. Infuse the pharmacologic agent (dipyridamole at 0.57 mg/kg over 4 min, adenosine at 140 μg/kg/min for 6 min, or lexiscan at 0.4 mg/5 mL by rapid injection) using a pump, after the rest scan.
- 12. Administer <sup>82</sup>Rb by the infusion pump at the peak stress of the same cumulative activity as for the rest scan in Step 9.
- 13. Start stress emission scan at the peak stress collecting data for a preset count or time.
- 14. The patient is released after the completion of the PET scan.

## Reconstruction and Storage

- 15. Attenuation correction factors are calculated for each pixel from the transmission scan (Step 8) and the blank scan (Step 5) and applied to the PET emission data. Reconstruct images using the corrected data by the FBP or iterative method based on the algorithm provided by the manufacturer. The reconstruction should use a Butterworth or low-pass filter and a pixel size of 2–3 mm.
- 16. Images are sent to the workstation for display and interpretation.
- 17. Images are stored and archived for future use or for use in PACS, if desired.

## Addendum

## <sup>82</sup>Rb Infusion Pump

Rubidium-82 ( $t_{1/2} = 75$  s) is available from the <sup>82</sup>Sr-<sup>82</sup>Rb generator (supplied by Bracco Diagnostics, Inc.). Because of its short half-life, an automated infusion pump is employed for its delivery from the generator to the patient. The infusion pump is a device manufactured by RbM Services and distributed by Bracco Diagnostics Inc. that delivers <sup>82</sup>Rb by pumping 0.9% NaCl (normal saline) through the generator. A schematic diagram of the infusion pump is shown in Fig. 12.1. The lead-shielded generator is mounted on a mobile cart. A large-volume plastic syringe is connected through a three-way stopcock to a saline bottle or bag to supply saline to the generator for <sup>82</sup>Rb elution. The syringe is filled with saline and then pushes it through the generator to elute <sup>82</sup>Rb under the action of an electronically controlled pump. An outlet tubing from the generator carries the <sup>82</sup>Rb activity in saline under the action of



FIGURE 12.1. A schematic illustration of the <sup>82</sup>Rb infusion pump. The details of the operation of the pump are given in the text.

the pump to either a waste bottle or the patient. A divergence valve placed along the outlet tubing switches the line between the patient and the waste bottle. The initial low-level activity is discarded into the waste bottle, and later the uniform activity is directed to the patient. In the midway of the tubing before the divergence valve, a positron detector made of plastic scintillator coupled with a photomultiplier tube is installed to measure the activity passing through the tubing.

The infusion pump is operated electronically and equipped with several controls on a console that select the total volume (ml), total dosage (mCi), dosage rate (mCi/s), and flow rate (ml/min). A printer is included in the device to print out all parameters related to the infusion of the <sup>82</sup>Rb activity. Before the infusion pump is used for a given day, the pump device needs to be calibrated. There is a control knob on the console that sets a specified calibration factor for the generator. Calibration is performed at the beginning of the day prior to patient study using the calibration factor given for the generator. After flushing the low activity volume, the <sup>82</sup>Rb activity is collected in a vial for a certain time and measured in a dose calibrator immediately after the infusion is over. The measured activity is corrected for decay to the end of infusion and compared with the activity printed out by the printer. The discrepancy, beyond the specifications of the manufacturer, is corrected by adjusting the calibration factor and repeating the calibration. In this calibration experiment, the amounts of <sup>82</sup>Sr ( $t_{1/2} = 25.6$  days) and <sup>85</sup>Sr  $(t_{1/2} = 65 \text{ days})$  breakthrough are also determined by allowing the <sup>82</sup>Rb activity in the vial to decay completely and then measuring the activity of these two radionuclides, which must be within the limit set by the manufacturer.

For a patient study, the patient gets an IV catheter that is connected to the patient line of the infusion pump. The desired total volume, total activity to be administered and the flow rate are all set on the console by the operator prior to the start of infusion. First, the low activity volume of saline as detected by the detector is flushed out to the waste bottle by applying the purge button. After purging, when the preset dose rate threshold is achieved as detected by the detector, the activity is directed to the patient line, and the set amount of the cumulated activity is administered. The pump stops after the infusion of the desired amount of activity, and all relevant parameters are printed out by the printer.

The waste bottle should be emptied every morning prior to or at the end of system usage. The <sup>82</sup>Rb generator is supplied once a month, which is installed in the infusion cart replacing the old generator. Each new generator is supplied with a new tubing set (called the administration set), which replaces the old set. The old generator is returned to the supplier, Bracco Diagnostics, Inc.

## References and Suggested Reading

Am Soc Nucl Card (ASNC) (2003) Imaging guidelines for nuclear cardiology procedures: PET myocardial perfusion and metabolism clinical imaging.

# Appendix A Abbreviations Used in the Text

ALARA	As low as reasonably achievable
ANDA	Abbreviated new drug application
APC	Ambulatory payment classification
BGO	Bismuth germanate
CMS	Centers for Medicare and Medicaid Services
CPT	Current Procedural Terminology
DICOM	Digital Imaging and Communications in Medicine
DOT	Department of Transportation
DRG	Diagnosis Related Group
EC	Electron capture
FBP	Filtered backprojection
FDA	Food and Drug Administration
FDG	Fluorodeoxyglucose
FOV	Field of view
GSO	Gadolinium oxyorthosilicate
HCPCS	Healthcare Common Procedure Coding System
HIPAA	Hospital Insurance Portability and Accountability Act
HIS	Hospital Information System
HOPPS	Hospital Outpatient Prospective Payment System
HVL	Half-value layer
ICD-9-CM	International Classification of Disease, Ninth Revision,
	Clinical Modification
ICRP	International Committee on Radiological Protection
IND	Notice of Claimed Investigational Exemption for a New
	Drug
IRB	Institutional Review Board
IT	Isomeric transition
kV	Kilovolt
LAN	Local area network
LCD	Liquid crystal display

LOR	Line of response
LSO	Lutetium oxyorthosilicate
LYSO	Lutetium yttrium oxyorthosilicate
MIRD	Medical internal radiation dose
MLEM	Maximum-likelihood expectation maximization
NCA	No carrier added
NCD	National coverage determination
NCRP	National Council on Radiation Protection and Measurement
NDA	New Drug Application
NECR	Noise equivalent count rate
NEMA	National Electrical Manufacturers Association
NRC	Nuclear Regulatory Commission
OSEM	Ordered subset expectation maximization
PACS	Picture Archival and Communication System
PET	Positron emission tomography
PM	Photomultiplier (tube)
PHA	Pulse height analyzer
QF	Quality factor
RBE	Relative biologic effectiveness
RDRC	Radioactive Drug Research Committee
RIS	Radiology Information System
RSC	Radiation Safety Committee
RSO	Radiation Safety Officer
RVU	Relative value unit
SF	Scatter fraction
SPECT	Single photon emission computed tomography
SUV	Standard uptake value
TEDE	Total effective dose equivalent
TLC	Thin layer chromatography
TLD	Thermoluminescent dosimeter
TOF	Time of flight
LICD	

USP US Pharmacopeia

## Appendix B Terms Used in the Text

- *Absorption.* A process by which the total energy of a radiation is removed by a medium through which it passes.
- Annihilation radiation. Gamma radiations of 511 keV energy emitted at 180° after a  $\beta^+$  particle is annihilated by combining with an electron in matter.
- Atomic mass unit (amu). By definition, one-twelfth of the mass of  ${}^{12}$ C, equal to  $1.66 \times 10^{-24}$  g or 931 MeV.
- Atomic number (Z). The number of protons in the nucleus of an atom.
- *Attenuation.* A process by which the intensity of radiation is reduced by absorption and/or scattering during its passage through matter.
- *Auger electron*. An electron ejected from the outer electron shell by an X-ray by transferring all its energy.
- Average life ( $\tau$ ). See Mean life.
- Avogadro's number. The number of molecules in 1 g-mol of a substance, or the number of atoms in 1 g atom of an element. It is equal to  $6.02 \times 10^{23}$ .
- *Becquerel* (Bq). A unit of radioactivity. One becquerel is equal to 1 disintegration per second.
- *Binding energy*. The energy to bind two entities together. In a nucleus, it is the energy needed to separate a nucleon from other nucleons in the nucleus. In a chemical bond, it is the energy necessary to separate two binding partners by an infinite distance.
- *Biological half-life*  $(T_b)$ . The time by which one-half of an administered dosage of a substance is eliminated by biological processes such as urinary and fecal excretion.
- *Bremsstrahlung.* Gamma-ray photons produced by deceleration of charged particles near the nucleus of an atom.
- *Carrier*. A stable element that is added in detectable quantities to a radionuclide of the same element, usually to facilitate chemical processing of the radionuclide.
- *Carrier-free*. A term used to indicate the absence of any stable isotopic atom in a radionuclide sample.
- *Chelating agent.* A compound that binds to a metal ion by more than one coordinate covalent bond.

- *Committed dose equivalent*  $(H_{T,50})$ . The dose equivalent to organs or tissues of reference (T) that will be received from an intake of radioactive material by an individual during the 50-year period following intake.
- Conversion electron  $(e^{-})$ . See internal conversion.
- Cross section ( $\sigma$ ). The probability of occurrence of a nuclear reaction or the formation of a radionuclide in a nuclear reaction. It is expressed in a unit termed barn; 1 barn =  $10^{-24}$  cm<sup>2</sup>.
- *Curie* (Ci). A unit of activity. A curie is defined as  $3.7 \times 10^{10}$  disintegrations per second.
- *Cyclotron.* A machine to accelerate charged particles in circular paths by means of an electromagnetic field. The accelerated particles such as  $\alpha$  particles, protons, deuterons, and heavy ions possess high energies and can cause nuclear reactions in target atoms by irradiation.
- *Decay constant* ( $\lambda$ ). The fraction of atoms of a radioactive element decaying per unit time. It is expressed as  $\lambda = 0.693/t_{1/2}$  where  $t_{1/2}$  is the half-life of the radionuclide.
- *Deep-dose equivalent*  $(H_d)$ . Dose equivalent at a tissue depth of 1 cm  $(1,000 \text{ mg/cm}^2)$  due to external whole body exposure.
- *Dosage.* A general term for the amount of a radiopharmaceutical administered in microcuries or millicuries, or becquerels.
- Dose. The energy of radiation absorbed by any matter.
- *Dosimeter.* An instrument to measure the cumulative dose of radiation received during a period of radiation exposure.
- Dosimetry. The calculation or measurement of radiation absorbed doses.
- *Effective dose*  $(H_E)$ . An estimated whole-body dose weighted for radiosensitivity of each organ. It is calculated by summing the product of dose equivalent  $(H_r)$  and tissue radiosensitivity  $(W_T)$  of each organ,  $\sum_{T_r} H_{T,r} \cdot W_T$ .
- *Effective half-life*  $(T_e)$ . Time required for an initial administered dose to be reduced to one half due to both physical decay and biological elimination of a radionuclide. It is given by  $T_e = (T_p \times T_b)/(T_p + T_b)$ , where  $T_e$  is the effective half-life, and  $T_p$  and  $T_b$  are the physical and biological half-lives, respectively.
- *Electron* ( $e^{-}$ ). A negatively charged particle circulating around the atomic nucleus. It has a charge of  $4.8 \times 10^{-10}$  electrostatic units and a mass of  $9.1 \times 10^{-28}$  g, equivalent to 0.511 MeV, or equal to 1/1,836 of the mass of a proton.
- *Electron capture* (EC). A mode of decay of a proton-rich radionuclide in which an orbital electron is captured by the nucleus, accompanied by emission of a neutrino and characteristic X-rays.
- *Electron volt* (eV). The kinetic energy gained by an electron when accelerated through a potential difference of 1 V.
- *Erg.* The unit of energy or work done by a force of 1 dyne through a distance of 1 cm.

- Fission (f). A nuclear process by which a heavy nucleus divides into two nearly equal smaller nuclei, along with the emission of two to three neutrons.
- *Generator, radionuclide.* A device in which a short-lived daughter nuclide is separated chemically from a long-lived parent nuclide adsorbed on an adsorbent material. For example, <sup>99m</sup>Tc is separated from <sup>99</sup>Mo from the <sup>99</sup>Mo–<sup>99m</sup>Tc generator with saline.
- Gray(Gy). The unit of radiation dose in SI units. One gray is equal to 100 rad.
- *Half-life*  $(t_{1/2})$ . A unique characteristic of a radionuclide, defined by the time during which an initial activity of a radionuclide is reduced to one half. It is related to the decay constant  $\lambda$  by  $t_{1/2} = 0.693/\lambda$ .
- *Half-value layer (HVL).* The thickness of an absorbing material required to reduce the intensity or exposure of a radiation beam to one-half of the initial value when placed in the path of the beam.
- *Internal conversion.* An alternative mode to  $\gamma$ -ray decay in which nuclear excitation energy is transferred to an orbital electron which is then ejected from the orbit.
- *Ion.* An atom or group of atoms with a positive charge (cation) or a negative charge (anion).
- *Ionization chamber.* A gas-filled instrument used to measure radioactivity or exposure in terms of ion pairs produced in gas by radiations.
- *Isobars.* Nuclides having the same mass number, that is, the same total number of neutrons and protons. Examples are  ${}_{26}^{57}$ Fe and  ${}_{27}^{57}$ Co.
- *Isomeric transition (IT).* Decay of the excited state of a nuclide to another lower excited state or the ground state.
- *Isomers*. Nuclides having the same atomic and mass numbers but differing in energy and spin of the nuclei. For example, <sup>99</sup>Tc and <sup>99 m</sup>Tc are isomers.
- *Isotones.* Nuclides have the same number of neutrons in the nucleus. For example,  ${}^{131}_{53}$ I and  ${}^{132}_{54}$ Xe are isotones.
- *Isotopes.* Nuclides having the same atomic number, that is, the same number of protons in the nucleus. Examples are  ${}^{14}_{6}$ C and  ${}^{12}_{6}$ C.
- *K capture*. A mode of radioactive decay in which an electron from the K shell is captured by the nucleus.
- $LD_{50/60}$ . A dosage of a substance that, when administered or applied to a group of any living species, kills 50% of the group in 60 days.
- *Linear attenuation coefficient* ( $\mu$ ). The fraction of radiation energy absorbed and scattered per unit thickness of absorber.
- *Linear energy transfer (LET).* Energy deposited by radiation per unit length of the matter through which the radiation passes. Its usual unit is keV/mm.
- Mass number (A). The total number of protons and neutrons in a nucleus of a nuclide.
- *Mean life*( $\tau$ ). The period of time a radionuclide exists on the average before disintegration. It is related to the half-life and decay constant by  $\tau = 1/\lambda = 1.44t_{1/2}$ .

- *Metastable state* (m). An excited state of a nuclide that decays to another excited state or the ground state with a measurable half-life.
- *Neutrino* (v). A particle of no charge and mass emitted with variable energy during  $\beta^+$  and electron capture decays of radionuclides.
- *No carrier added (NCA).* A term used to characterize the state of a radioactive material to which no stable isotope of the compound has been added purposely.
- Nucleon. A common term for neutrons or protons in the nucleus of a nuclide.
- *pH*. The unit of hydrogen ion concentration. It is given by the negative common logarithm of the hydrogen ion concentration in a solution:  $pH = -\log_{10}[H^+]$ .
- *Phantom.* A volume of material artificially made to simulate the property of an organ or part of the body when exposed to radiation.

*Physical half-life*  $(T_p)$ . See half-life.

- *Quality factor (QF).* A factor dependent on linear energy transfer that is multiplied by absorbed doses to calculate the dose equivalents in rem. It is used in radiation protection in order to take into account the relative radiation damage caused by different radiations. It is 1 for X-,  $\gamma$ -, and  $\beta$ -rays, 10 for neutrons and protons, and 20 for  $\alpha$  particles.
- *Rad.* The unit of radiation absorbed dose. One rad is equal to 100 ergs of radiation energy deposited per gram of any matter, or  $10^{-2}$  J/kg of any medium.
- *Radiation weighting factor*  $(W_r)$ . See quality factor.
- *Radiochemical purity*. The fraction of the total radioactivity in the desired chemical form. If <sup>99m</sup>Tc-MAA is 90% pure, then 90% of the radioactivity is in the <sup>99m</sup>Tc-MAA form.
- *Radionuclidic purity*. The fraction of the total radioactivity in the form of the stated radionuclide. Any extraneous radioactivity such as <sup>99</sup>Mo in <sup>99m</sup>Tc-radiopharmaceuticals is an impurity.
- *Radiopharmaceutical.* A radioactive drug that can be administered safely to humans for diagnostic and therapeutic purposes.
- *Rem.* A dose equivalent defined by the absorbed dose (rad) times the relative biological effectiveness or quality factor or radiation weighting factor of the radiation in question.
- *Roentgen.* The quantity of X-rays or  $\gamma$  radiations that produces one electrostatic unit of positive or negative charge in 1 cm<sup>3</sup> of air at 0°C and 760 mmHg pressure (STP). It is equal to  $2.58 \times 10^{-4} \text{ C/kg}$  air.
- *Sensitivity.* The number of counts per unit time detected by a scanner for each unit of activity present in a source. It is given by counts per second per microcurie (cps/µCi) or (cps/kBq).
- Shallow-dose equivalent  $(H_s)$ . Dose equivalent at a tissue depth of 0.007 cm  $(7 \text{ mg/cm}^2)$  averaged over an area of 1 cm<sup>2</sup> due to external exposure to the skin.
- Sievert (Sv). The international unit of dose equivalent and equal to 100 rem.

- *Spatial resolution.* A measure of the ability of a scanner to faithfully reproduce the image of an object.
- *Tissue weighting factor*  $(W_T)$ . A factor related to the radiosensitivity of different tissues in living systems.
- *Tracer.* A radionuclide or a compound labeled with a radionuclide that may be used to follow its distribution or course through a chemical, physical, or metabolic process.

# Appendix C Units and Constants

### Energy

1 electron volt (eV)	$= 1.602 \times 10^{-12} \mathrm{erg}$
1 kiloelectron volt (keV)	$= 1.602 \times 10^{-9} \mathrm{erg}$
1 million electron volts (MeV)	$= 1.602 \times 10^{-6} \mathrm{erg}$
1 joule (J)	$= 107 \mathrm{ergs}$
1 watt (W)	= 107  ergs/s
	= 1  J/s
1 rad	$= 1 \times 10^{-2} \mathrm{J/kg}$
	= 100  ergs/g
1 gray (Gy)	= 100  rad
	= 1  J/kg
1 sievert (Sv)	$= 100 \mathrm{rem}$
	= 1  J/kg
1 horsepower (HP)	$=746\mathrm{W}$
1 calorie (cal)	= 4.184  J

### Charge

$= 6.25 \times 10^{18}$ charges
$= 4.8 \times 10^{-10}$ electrostatic unit
$= 1.6 \times 10^{-19} \mathrm{C}$
= 1  C/s

Mass and energy

1 atomic mass unit (amu)	$= 1.66  imes 10^{-24}  \mathrm{g}$
	$= 1/12$ the atomic weight of $^{12}$ C
	$= 931 \mathrm{MeV}$
1 electron rest mass	$= 0.511 \mathrm{MeV}$

$= 938.78 \mathrm{MeV}$
$= 939.07 \mathrm{MeV}$
$= 453.6  \mathrm{g}$
$= 28.3  \mathrm{g}$

## Length

$= 10^{-8}  {\rm cm}$
$= 10^{-6} \mathrm{m}$
$= 10^4 \text{\AA}$
$= 10^{-9} \mathrm{m}$
$= 10^{-13} \mathrm{cm}$
$= 2.54 \mathrm{cm}$
= 1.6  km

### Activity

1 curie (Ci)	$= 3.7 \times 10^{10}$ disintegrations per second		
	(dps)		
	$= 2.22 \times 10^{12}$ disintegrations per minute		
	(dpm)		
1 millicurie (mCi)	$= 3.7 \times 10^7 \mathrm{dps}$		
	$= 2.22  imes 10^9 \mathrm{dpm}$		
1 microcurie (uCi)	$= 3.7 \times 10^4 \mathrm{dps}$		
	$=2.22 imes10^{6}\mathrm{dpm}$		
1 becquerel (Bq)	$= 1 \mathrm{dps}$		
	$= 2.703 \times 10^{-11} \mathrm{Ci}$		
1 kilobecquerel (kBq)	$= 10^3 \mathrm{dps}$		
	$= 2.703 \times 10^{-8} \mathrm{Ci}$		
1 megabecquerel (MBq)	$= 10^{6}  dps$		
	$= 2.703 \times 10^{-5} \mathrm{Ci}$		
1 gigabecquerel (GBq)	$= 10^9 \mathrm{dps}$		
	$= 2.703 \times 10^{-2} \mathrm{Ci}$		
1 terabecquerel (TBq)	$= 10^{12} \mathrm{dps}$		
	= 27.03 Ci		

### Constants

$= 6.02 \times 10^{23}$ atoms/g-atom
$= 6.02 \times 10^{23}$ molecules/g-mol
= 3.1416
= 2.7183

## Appendix D Estimated Absorbed Doses from Intravenous Administration of <sup>18</sup>F-FDG and <sup>82</sup>Rb-RbCl

The dose estimate D in each organ is made by using the following internal dosimetry equation:

$$D = \tilde{A} \times S,$$

where  $\tilde{A}$  is the cumulated activity and *S* is the mean absorbed dose per cumulated activity.  $\tilde{A}$  is calculated from the initial administered activity and the biodistribution and residence time of the tracer in each organ. *S* is calculated from the knowledge of physical characteristics of the radiation in question, the mass of the organ and the absorption fraction of the radiation in the target organ. The values of *S* are available in literature for most common radiopharmaceuticals including <sup>18</sup>F-FDG. The experimental data for biodistribution and residence time are available in literature and used to calculate  $\tilde{A}$ . The following two tables give the absorbed doses per administered activity based on these calculations for <sup>18</sup>F-FDG and <sup>82</sup>Rb-RbCl, respectively.

Target organ	mGy/MBq	rad/mCi
Brain	$0.046 \pm 0.012$	$0.17\pm0.044$
Heart wall	$0.068 \pm 0.036$	$0.25\pm0.13$
Kidneys	$0.021 \pm 0.0059$	$0.078\pm0.022$
Liver	$0.024 \pm 0.0085$	$0.088 \pm 0.031$
Lungs	$0.015 \pm 0.0084$	$0.056\pm0.031$
Pancreas	$0.014 \pm 0.0016$	$0.052 \pm 0.0060$
Red marrow	$0.011 \pm 0.0017$	$0.040 \pm 0.0062$
Spleen	$0.015 \pm 0.0021$	$0.056 \pm 0.0078$
Urinary bladder wall <sup>b</sup>	$0.073 \pm 0.042$	$0.27\pm0.16$
Ovaries <sup>c</sup>	$0.011 \pm 0.0015$	$0.041 \pm 0.0055$
Testes <sup>c</sup>	$0.011 \pm 0.0016$	$0.041 \pm 0.0057$
Whole body <sup>d</sup>	$0.012 \pm 0.00077$	$0.043 \pm 0.0023$
Effective dose <sup>d,e</sup>	0.0190	0.070

Absorbed dose per unit administered activity of <sup>18</sup> F-FDG<sup>a</sup>

<sup>a</sup>Reproduced with permission from Hays MT, Watson EE, Thomas ER, et al (2002). MIRD dose estimate report no. 19: radiation absorbed dose estimates from <sup>18</sup>F-FDG. J Nucl Med 43:210.

<sup>b</sup>Dose to urinary bladder wall is based on 120-min void intervals, starting 120 min after dosing, using traditional static MIRD model.

<sup>c</sup>Doses to ovaries and testes include doses from residence times in urinary bladder and remainder of body as calculated from data in: Hays MT, Segall GM (1999) A mathematical model for the distribution of fluorodeoxyglucose in humans. J Nucl Med 40:1358.

<sup>d</sup>The calculation of whole-body dose is based on total energy deposited in the body divided by its total mass, whereas the total effective dose reported by ICRP is calculated by applying risk-based weighting factors to individual organ doses to estimate a uniform whole-body dose that in theory gives the same risk as the nonuniform pattern that actually occurred. The two values are based on different concepts and not comparable.

<sup>e</sup>From ICRP Publication No. 80. Pergamon Press, New York, 1999.

Adult absorbed radiation doses <sup>a</sup>			
Organ	mGy/2220 MBq	rads/60 mCi	
Adrenals	2.15	0.22	
Stomach	1.91	0.19	
Small intestine	3.11	0.32	
Upper large intestine	1.91	0.19	
Lower large intestine	1.91	0.19	
Heart wall	4.22	0.42	
Kidneys	19.1	1.92	
Liver	1.91	0.19	
Lungs	3.77	0.38	
Ovaries	0.84	0.084	
Pancreas	1.38	0.14	
Red marrow	0.84	0.084	
Testes	0.67	0.066	
Total body	0.95	0.096	
Effective dose <sup>b</sup>	7.5	0.755	

#### Absorbed dose due to <sup>82</sup>Rb-RbCl

<sup>a</sup>Obtained from package insert.

<sup>b</sup>Obtained from ICRP Publication No. 80. Pergamon Press, New York, 1999.

## Appendix E Evaluation of Tumor Uptake of <sup>18</sup>F-FDG by PET

PET imaging is widely used for the detection of a variety of tumors such as breast, colorectal, esophageal, head and neck, lung, thyroid, melanoma, lymphoma, and other cancers, because of its high sensitivity, specificity, and accuracy. In the interpretation of tumor FDG-PET images, it is desirable to compare the relative tumor FDG uptake with the adjacent normal tissue uptake. Such a comparison offers information on the degree of tumor progression and provides clues to appropriate management of the tumor. In radiation therapy or chemotherapy of tumors, comparative evaluation of tumor FDG-PET images before and after therapy is even more useful to assess the effect of therapy on tumor. In all cases, the reconstructed images are used to determine the tumor uptake of FDG relative to the normal tissue uptake.

There are several methods, visual, quantitative, and semiquantitative, to determine the tumor uptake of FDG. Visual assessment is commonly used in tumor diagnosis and staging, and is based on differences in contrast between tumor and adjacent tissue. This is a simplified method requiring only a single static image at a set time after injection and can be equally applied to assess the therapeutic response of the tumor. In the visual technique, it is important to adjust the image intensities of the tumor and adjacent tissues to the same gray or color scale.

While visual assessment of tumor is widely accepted in many nuclear medicine facilities, the quantitative or even semiquantitative method improves the detection and comparative assessment significantly and therefore is highly desirable. Quantitative methods, also called the kinetic methods, include two methods: compartmental analysis and Potlak analysis. Compartmental analysis is based on the fitting of the time-activity curve to a two-compartmental model, using measured arterial activity (input function) and nonlinear regression. The time course of activity in tissue is followed by serial imaging and arterial blood sampling. The metabolic rate of glucose given by this method is expressed in mol/min/ml. Potlak analysis provides similar information requiring a fewer data and only the integral of the blood activity for input function. Both methods are too complex and demanding of resources, and therefore are less favorable for routine clinical application. The details of these methods are beyond the scope of this book and the readers are referred to standard texts on kinetic modeling.

In semiquantitative methods, static images are utilized as in visual assessment to determine the tissue activity and compare the relative tumor uptake. One method uses an index, the tumor-to-normal tissue activity ratio (T/N), using data from the normal and tumor regions on the reconstructed images. The ratios are independent of the administered dosage, patient's weight or blood glucose level. The T/N ratio assessment is somewhat similar to visual assessment. The choice of an appropriate normal reference site, particularly in the abdomen and pelvic area, is critical in this analysis.

The most versatile semiquantitative technique is the *standard uptake value* (SUV) method that is widely used in nuclear medicine and molecular imaging. This value is also less commonly referred to as the differential uptake ratio (DUR). It is defined by the tissue concentration of activity as determined from the region of interest (ROI) on the PET image, divided by the injected dosage of the tracer, and multiplied by a calibration factor, which is basically the body weight, body surface or body lean mass. Thus,

$$SUV = (C_{ROI}/A) \times WT, \tag{E.1}$$

where  $C_{\rm ROI}$  is the decay-corrected radiotracer concentration in  $\mu Ci/g(Bq/g)$ of tissue in ROI, A is the injected radiotracer dosage in  $\mu$ Ci(Bq), and WT is the body weight of the patient. In SUV calculation, an ROI is chosen by the reader on the reconstructed image that is displayed on the computer monitor. The computer then calculates the average count density or maximum count density in the ROI, correct it for the decay for the uptake period and counting efficiency, estimates the area of ROI from the knowledge of pixel size and the number of pixels in ROI, and finally converts the corrected count density to activity per gram of tissue (assuming tissue density is equal to 1 g/cc). From the knowledge of the body weight of the patient, and the injected dosage in  $\mu$ Ci(Bq), the SUV is calculated for the ROI using Eq. (E.1). The FDG SUV values are unitless numbers, and for some normal tissues are: <1 for soft tissues; 1.5–2.0 for blood pool 1 h after injection;  $\sim$ 2.5 for liver and  $\sim$ 3.5 for renal cortex. The SUV values for various neoplastic tissues range from 2 to as high as 25, depending on the avidity of the different cancer cells for FDG. Note that if all of the tracer were uniformly distributed throughout the body, the SUV in each region would be 1. It implies that the SUV serves as a normalized T/N ratio index.

It is important to note that the SUV values are affected by several factors. The time period between tracer injection and scanning (i.e., the uptake period) is perhaps the largest single source of error in determining the SUV. Time to reach maximum uptake in a given tissue varies with the type and condition of tissue, i.e., different forms of neoplasm and also with tissues before and after therapy. Tissue uptake of FDG decreases with increasing blood glucose level, which affects the SUV. Excess body fat falsely elevates the SUV, which many investigators correct by using body lean mass instead of body weight. Also, many investigators found better values of SUVs using body surface area in place of body weight. The use of maximum pixel count density versus average value for all pixels in an ROI also affects the SUV values, although the average value now is less commonly used. Thus, SUVs reported in literature are not exactly comparable unless all these parameters are specified.

## Appendix F Answers to Selected Questions

#### Chapter 1

- 5. False
- 6. True
- 11. 85 keV
- 14. 110 keV
- 16. 220 min
- 18. 4.6 mCi
- 19. 31.1 mCi
- 20. 1.56 h
- 21. 1.55 h
- 23. (a) False, (b) False, (c) True
- 25. (a) False, (b) True
- 26. 325 keV
- 29. (a) 8.3 HVLs, (b) 9 HVLs
- 31. 2.56 cm

Chapter 2

- 4. (a)
- 5. (b)
- 6. *N*/2
- 7. (b)
- 8. (c)
- 11. (a) True, (b) False, (c) True
- 12. 120 cm
- 15. (c)
- 18. (c)

### Chapter 3

- 2. (a)
- 3. (b)

- 4. (b)
- 6. True
- 7. (c)
- 11. (a), (c)
- 12. true
- 14. 0.135
- 16. True
- 17. (b)
- 18. 5.6
- 19. True
- 21. A (b), B (a), C (a), D (a)
- 22. (a) False, (b) False
- 25. True (a), random (b), scatter (c)

### Chapter 4

- 5. 6 direct; 30 oblique
- 7. 0.313 mm
- 8. True
- 10. (b)

### Chapter 5

6. True

### Chapter 6

- 1. (c)
- 3. False
- 5.8mm
- 7. 1.98 mm
- 10. (c)
- 12. 2D: (a), 3D: (b)

13. (c)
17. True
18. (a) True, (b) False
19. (b)

### Chapter 7

- 5. True
- 6. 3.86 Ci
- 7. ~18h (6 half-lives of the radionuclide)
- 9. True
- 11. True

### Chapter 8

9. False

### Chapter 9

- 3. True
- 19. 9.76 mR
- 20. 2.61 cm
- 21. 10%
- 24. True

## Chapter 10

### 9. False

### Chapter 11

3. 1.6 cm of lead (assuming occupancy factor 1)

## Index

Absorbed dose <sup>18</sup>F-FDG, 225 <sup>82</sup>Rb-RbCl, 226 Acceptance tests count rate loss, 112-113 dead time loss, 112 noise equivalent count rate, 102 - 103random coincidences, 112-113 scatter fraction, 108–111 sensitivity, 111-112 spatial resolution, 108 Accreditation of PET center, 160-161 Activity definition, 6 radioactivity, 173 units of, 224 Agreement states, 156, 157 ALARA (as low as reasonably achievable), program, 166 Alpha ( $\alpha$ ) decay, 2 Ambulatory Payment Classification (APC) codes, 180-181, 183 Annihilation radiations coincidence detections in PET, 41-43.98 Antineutrino, 3 APC codes, 180-181 Atomic mass units, 217 Atomic number, 1, 217 Atomic structure structure of the nucleus, 2 Attenuation correction, PET methods of, 52-58

Attenuation of γ radiations half value layer, 13–15 linear attenuation coefficient, 13–15, 219 mass attenuation coefficient, 15 tenth value layer (TVL) and, 15 Auger electron, 4, 217 Auger process, 4, 5 Automated synthesis device, 139–141 Avogadro number, 123, 217

Barium fluoride detector, 23 Becquerel (Bq), 9, 217 Beta ( $\beta^-$ ) particle decay, 3 energy spectrum of, 3 range of, 10 Billing for reimbursement, 185–186 Biological half-life, 7, 217 Bismuth germanate (BGO) detector, 20–22 Bit, 88 Block detector, 25–27, 43 Build-up factor, 198–199 Byte, 88

<sup>11</sup>C (Carbon-11) acetate, 137 choline, 138–139 fumazenil structure of, 134 synthesis of, 137

L-methionine structure of. 134 synthesis of, 138 methylspiperone structure of, 134 synthesis of, 137-138 raclopride structure of, 134 synthesis of, 138 Cadmium-tellurium (CdTe), 23 Cadmium-zinc-tellurium (CZT), 23 Carrier-free, 125, 217 Cathode ray tube (CRT), 89 Caution signs and labels, 163-164 Centers for Medicare and Medicaid Services (CMS), 160, 179-188, 201 Characteristic x-rays, 4, 5, 12, 31 Charged particles interaction of, with matter, 10-12 linear energy transfer (LET), 11 ranges, 10 Coincidence detection random correction, 55 scatter correction, 56-58 true coincidences, 41, 42, 48 Coincidence scintillation camera, 29 - 30Committed dose equivalent, 162, 218 Component-based variation reduction method, 50 Compounding of PET radiopharmaceuticals, 141-143 Compton electron, 12, 13 Compton scattering, 12-14, 41, 55, 198 Contrast, image count density, 103, 104 film contrast, 104 noise, 104 patient motion, 104 scatter radiations, 104 size of lesion, 103, 104 Conversion electron. See Internal conversion Copper-62, 129 Co-registration of images, 30, 31, 33 Cost of PET/CT and cyclotron operation, 201-202

CPT codes. See Current Procedural Terminology codes Credentials of physicians, 158-160 Cross plane events, 48-49 Cross section in nuclear reaction, 123, 218 CT scanner features. 34 quality control, 113 CT transmission method, attenuation correction, 53 <sup>62</sup>Cu-pyruvaldehyde-bis (N<sup>4</sup>-methylthiosemicarbazonato) Copper (II), 139 Curie (Ci), 218 Current Procedural Terminology (CPT) codes, 180-181, 185 Cyclotron cyclotron-produced radionuclides, 122different vendors, 120, 121 equation for production of radionuclides, 123-125 facility, 194–195 nuclear reactions, 120, 122 operation, 117-119 targets, 122-123 Data acquisition cross plane event, 48-49 direct plane event, 48 2-D vs. 3-D. 47-49 electronic collimator, 41 factors affecting acquired data, 49-60 field of view (FOV), 44, 46, 49, 57, 59, 60, 64, 65 line of response (LOR), 44, 45, 50 PET/CT data acquisition, 60-67 whole body imaging, 46, 54, 62 Dead time in PET scanners loss, 58-59 Decay constant, 6, 7, 123, 197, 200, 201, 218 Decay energy, 3 Decay of radionuclides alpha ( $\alpha$ ), 2 beta  $(\beta^+), 3$ beta  $(\beta^{-}), 3$ 

electron capture, 3-4 equations general, 5-7 successive, 7-9 half-life, 6-7 isomeric transition (IT), 4-5 mean life, 7 positron or  $\beta^+$ , 3 schemes, 5 secular equilibrium, 9 transient equilibrium, 8 units of radioactivity, 9 Decay scheme of radionuclide, 5 Deep-dose equivalent, 162, 218 Department of Transportation (DOT), 36, 173-175 Design of PET center, 191-201 Detection efficiency, 21, 29, 30, 101, 102 Detectors bismuth germanate (BGO), 21-22 gadolinium oxyorthosilicate (GSO), 23 lutetium oxyorthosilicate (LSO), 21 - 23sodium iodide (Tl), 20, 21, 23, 29.30 Diagnosis (Dx) codes, 181–182 Diagnosis related groups (DRG), 183 DICOM. See Digital Imaging and Communications in Medicine Digital image matrix sizes in, 87 pixel size in, 87-88 Digital Imaging and Communications in Medicine (DICOM), 90-91 4-D Imaging, 66-67 Direct plane event, 48 Dispensing of PET radiopharmaceuticals, 143 Display CRT monitors, 89 LCD monitors, 89 Distance in radiation protection, 170 Distribution of <sup>18</sup>FDG, 175–176 Do's and don'ts in radiation protection, 173 Dose calibrator, use of, 168-169 Dose equivalent, 162, 163, 218, 220 Dose limits, occupational, 165

Dosimeter film badge, 165 thermoluminescent, 165-166 2-D Reconstruction, 71, 74, 82, 83 3-D Reconstruction, 81-83 3-D Reprojection, 82 Dual energy CT, 33 Dual-head coincidence cameras, 187 Dx codes, 181 Dynamic imaging, 46 Dynode of photomultiplier tube, 24 EC. see Electron capture Effective dose equivalent (effective dose), 162 Effective half-life, 7, 218 Electron capture (EC) decay, 3, 4, 122, 129, 218 Electronic collimation in PET, 41 Electronic structure of atom, 1–2 Electrons Auger, 4, 5, 218 conversion, 4, 218 properties of, 1, 2 Energy resolution, 20-23 Equilibrium secular, 9 transient. 8 Exploratory IND, 153-156 Exposure in survey, 166-168 Exposure rate constants, 170, 198, 200, 201 <sup>18</sup>F (Fluorine-18), 98, 106, 108, 109, 112, 122, 126-127, 170, 174 Factors affecting PET/CT data contrast agents, 63-64 metal objects, 62 positioning of patient, 62 respiratory movement, 66-67 truncation, 64-65 Factors affecting PET data dead time loss, 58-59 Field of view (FOV), 49, 57, 59, 60 normalization, 49-50 photon attenuation, 50-52 radial elongation, 59-60 random coincidences, 53, 55 scatter coincidence, 55-58

<sup>18</sup>F-BMS-747158-02 synthesis of, 135 <sup>18</sup>F-1-(5-fluoro-5-deoxy-αarabinofuranosyl) 2-nitroimidazole (FAZA) synthesis of, 136 <sup>18</sup>F-fluorodeoxyglucose (FDG) structure of, 132 synthesis of, 132-133, 140 <sup>18</sup>F-fluoromisonidazole (FMISO) structure of, 134 synthesis of, 135 <sup>18</sup>F-fluorothymidine (FLT), 134–135 Film badge for personnel monitoring, 165-166 Filtered backprojection filters, 75–77 Nyquist frequency, 75 6-18F-L-fluorodopa structure of, 134 synthesis of, 133-134 <sup>18</sup>F-O-(2-fluorethyl)-L-tyrosine (FET) synthesis of, 135 Food and Drug Administration (FDA), 141, 145, 151-156 Fourier method in image reconstruction filters, 75-77 Fourier transformation, 73, 74 Frame mode of data acquisition, 45,46 Frequency domain, 73-76, 82 Full width at half maximum (FWHM), 97, 98, 108, 110 68Ga (Gallium-68), 5, 129 Gadolinium oxyorthosilicate (GSO), 23 Gamma ray emission. 5 68Ge (Germanium-68), 129 Geiger-Müller (GM) counters, 19, 166, 167 General decay equations, 5-7 Geometric efficiency, 101 Gray (Gy), 162, 219 Half-life, in radioactive decay biological, 7, 217 definition, 6, 219

effective, 7, 218

physical, 6-7

Half-value layer (HVL), 14, 15, 171, 219 HCPCS codes. See Healthcare **Common Procedure Coding** System Healthcare Common Procedure Coding System (HCPCS), 180-181, 183. 185 High performance liquid chromatography (HPLC), 135-138, 146, 148 Hospital Information System (HIS), 91-92 HPLC. See High performance liquid chromatography ICD-9-CM. See International Classification of Diseases, Ninth Revision, Clinical Modification codes Image reconstruction filtered backprojection, 72-77, 82,83 iterative, 78-81 simple backprojection, 71–72 Infusion pump for <sup>82</sup>Rb, 139, 211–213 Interaction of radiation with matter annihilation, 11, 13 interaction of charged particles, 10 - 11interaction of  $\gamma$  radiations, 12–15 Internal conversion characteristic x-ray, 4, 5 conversion electron, 4 International Classification of Diseases, Ninth Revision, Clinical Modification (ICD-9-CM) codes, 181, 182, 185 Iodine, 128 Isobars, 1, 219 Isomeric transition gamma ray emission, 4, 5 internal conversion, 4, 5 Isomers, 1, 219 Isotones, 1, 219 Isotopes, 1, 219 Iterative reconstruction, 78-81 K characteristic x-rays, 4, 5, 12, 31

Lead shielding, 168, 169, 172, 194, 197, 201 License, 156-160 Linear attenuation coefficient of photons in absorber, 50, 51 Linear energy transfer definition, 11, 219 Line of response (LOR), 41-45, 50, 71, 72, 79, 82, 83, 98-99 List mode data acquisition, 45, 46 Local coverage determination (LCD), 179, 180 Lutetium oxyorthosilicate (LSO), 20-23, 26, 34, 102, 108, 111 Lutetium yttrium oxyorthosilicate (LYSO), 20, 23, 102, 108

Mass attenuation coefficient, 15, 53 Mass number, 1, 125, 219 Matrix in computers, 44 Maximum likelihood expectation maximization (MLEM), 79–80 Mean life of radionuclide, 7, 219 Medical cyclotrons, 120, 121, 194, 202 Metastable states of nucleus, 4, 220 Mobile PET or PET/CT, 36–38 Myocardial Metabolic PET or PET/CT imaging, 209–210 Myocardial Perfusion PET or PET/CT imaging, 210–211

<sup>13</sup>N (nitrogen-13), 127–128 NaI(Tl) detectors properties of, 20, 21 <sup>13</sup>N-ammonia, 136–137, 148 National Coverage Determination (NCD), 179, 180 National Oncologic PET Registry, 188 NCA. See No carrier added Neutrino, 3, 4, 220 Neutrons characteristics of, 2 n-15O-butanol, 136 No carrier added (NCA), 122, 126, 220 Noise effect of, on image contrast, 103 - 104

Noise equivalent count rate (NECR), 102–103, 112, 113 Normalization of PET data, 49–50 Nuclear reactions, 120, 122 Nuclear Regulatory Commission (NRC), 36, 156, 157, 166, 192 Nucleons, 1, 2, 220 Nucleus, 1 Nuclides definition of, 1 notation for, 1

 <sup>15</sup>O (oxygen-15), 128
Occupational dose limits, 165
Orbital electrons, 2, 10
Ordered subset expectation maximigation (OSEM), 79–81
<sup>15</sup>O-water, 136

PACS. See Picture Archival Communication System Pair production, 12-14 Partial volume effect in PET recovery coefficient, 83-84 Patient motion, 31, 52, 103, 104 Personnel monitoring, 165-166 PET center, 160-161, 191-202 PET/CT scanners data acquisition, 60-67 factors affecting PET/CT data, 62-67 features of, 33, 34 PET radiopharmaceuticals automated synthesis, 139-140 compounding, 141-143 quality control, 143-147 synthesis, 131-148 PET reimbursement, 179-188 PET scanners acceptance tests, 107-113 features, 22, 36 mobile, 36-38 performance data, 100 quality control, 104-107 small animal, 33-36 Phantoms NEMA (National Electrical Manufacturers Association), 107 Photocathode of photomultiplier tubes, 24Photoelectric effect, 12, 14 Photomultiplier (PM) tubes, 24-27, 43, 212 Photons annihilations, 11, 41, 46, 50, 98, 99 attenuation of, 14, 32, 50-52 Compton scattering of, 12-13, 41, 198 pair production of, 13, 14 photoelectric effect of, 14 Picture Archival Communication System (PACS), 91-94, 185, 207, 208, 210, 211 Pixels, 45, 46, 64, 71-73, 75, 78, 79, 87-89 Positron emission tomography (PET) annihilation coincidence detection in. 3. 11. 28. 41 attenuation correction in, 52-53, 80, 159, 206, 211 detectors in, 19-28 electronic collimation, 41 quality control tests, 104–107 radial elongation, 59-60 random coincidences, 53, 55 scatter coincidences, 55–58 sensitivity of, 49, 101-102 spatial resolution of, 97-100 Positrons ( $\beta^+$ ) annihilation of, 5, 11, 13, 42, 51, 55, 59,98 decay, 3, 106 Procedures for PET studies mvocardial metabolic PET imaging, 209-210 myocardial perfusion PET imaging, 210-211 whole body PET/CT imaging, 207-208 whole body PET imaging, 205-207 Production of positron-emitting radionuclides carbon-11, 127 copper-62, 129 fluorine-18, 126-127 germanium-68, 129 iodine-124, 128

nitrogen-13, 127–128 oxygen-15, 128 rubidium-82, 128–129 technetium-94m, 129 Protons atomic number, 1 properties of, 1, 2 Pulse height analyzers (PHA), 19, 25–28, 43 Pulse pileup, 29, 59 Pyrogen test LAL (limsulus amebocyte lysate) test, 147

Quality control of PET acceptance test, 107–113 daily, 105 weekly, 106–107 Quality control tests, radiopharmaceutical, 143–147 Quality factor (QF), 220

R (Roentgen), 162, 220 Rad, 162, 220 Radiation area high, 163, 164 very high, 163 Radiation protection activity, 173 ALARA (as low as reasonably achievable), 166 definition of radiation units, 162 - 163distance, 170 do's and don'ts in, 173 film badge, 165 personnel monitoring, 165-166 principles of, 170-173 radiation safety officer (RSO), 164-165 shielding, 171 thermoluminescent dosimeters (TLD), 165-166 time, 170 Radiation regulations agreement state, 156-157 ALARA (as low as reasonably achievable), 166

caution signs and labels, 163-164 Department of Transportation (DOT), 173-175 high radiation area, 163, 164 license, 156-160 Nuclear Regulatory Commission (NRC), 36 radiation area, 163, 164 radiation safety committee, 164 - 165radiation safety officer (RSO), 164-165 radioactive spill, 169 radioactive waste disposal, 167 receiving and monitoring of radioactive packages, 166 record keeping, 170 survey for exposure rate, 166 syringe and vial shields, 168 transportation of radioactive material, 173 Radiation Safety Committee (RSC), 164 - 165Radiation Safety Officer (RSO), 164-165, 173 Radiation units, 162-163 Radiation weighting factors (Wr), 162, 220Radioactive decay alpha ( $\alpha$ ) decay, 2 annihilation radiation in, 10-11 Auger electron, 4, 217 Auger process, 4 beta minus ( $\beta^{-}$ ) decay, 3 characteristic x-ray, 4, 5, 12 conversion electron, 4 electron capture (EC) decay, 3 - 4internal conversion, 4, 5 isomeric transition, 4-5 positron ( $\beta^+$ ) decay, 3 transition energy, 3 Radioactive decay equations calculation, 9-10 effective half-life, 7 general, 5-6 half-life, 6-7 mean life, 7, 219 secular equilibrium, 9

successive, 7-9 transient equilibrium, 8 units of radioactivity, 9 units of radioactivity in System Internationale, 9 Radioactive Drug Research Committee (RDRC), 155-156 Radioactive packages, receiving and monitoring, 166 Radioactive spill, 169 Radioactive waste disposal decay-in-storage, 167 Radioactivity decay, 2-9 general decay equations, 5-6 successive decay equations,  $7_{-9}$ units of. 9 Radiochemical purity, 145-146, 220 Radiology Information System (RIS), 91 Radionuclide(s) cyclotron produced, 122 decay of, 2-7 definition of, 1 production of, 125-129 Radionuclidic purity, 145, 220 Ramp filter in tomography, 75, 76 Random coincidences in PET correction for random events, 55 Ranges of charged particles in absorber, 10 RDRC (Radioactive Drug Research Committee), 155-156 Receiving of radioactive packages, 166 Reconstruction, image filtered backprojection method, 72 - 73iterative method, 78-81 Record keeping, 170 Regulations, radiation, see Radiation regulations Relative value unit (RVU), 184 Rem, 162, 220 Restricted areas, 163 R<sub>f</sub> value, 146 RIS, 91

Roentgen (R), 162, 220 Rubidium-82 rubidium-82 infusion pump, 211–213

Saturation factor in production of radionuclides, 123 Scatter coincidences corrections for, 56-58 Scatter fraction, 103, 108-111 Scatter radiations Compton, 12-13 Scintillation detectors detection efficiency, 19-20 energy resolution, 20-23 scintillation decay time, 20-23 Secular equilibrium in successive decay, 9 Sensitivity measurement of, in acceptance test, 107-108 Shallow dose equivalent, 162, 220 Shielding in PET center, 196-200 Shielding in radiation protection, 171 Sievert (Sv), 162, 220 Simple backprojection, 71-72 Sinogram, 44, 45, 79, 82, 83, 105 SI units gray, 162, 219 radioactivity, 162 sievert, 162, 220 Small animal PET scanner, 33-36 S, mean absorbed dose, 225 Sodium iodide detectors, see Scintillation detectors Software and DICOM, 90-91 Spatial resolution detector size, 97 different scanners, 109 localization of detector, 99-100 measurement of, in acceptance test, 107-108 non-colinearity, 98-99 positron range, 97–98 reconstruction method, 99 Specific activity of radionuclide, 125 Standard uptake value (SUV), 228 Static imaging, 46 Sterility tests, 146 Stopping power of detector, 20 Storage of images matrix size, 87-88 pixel size, 87-88, 210 Strontium-82, 128-129 Structure of the nucleus, 2 Successive decay equations, 7-9 Survey for exposure rate and contamination, 166 Survey meters Geiger-Müller, 19, 166 System Internationale (SI) unit Becquerel, 9, 217 gray, 162, 219 sievert, 162, 220

Target in production of radionuclides, 122 - 123Technetium-94m, 129 Teleradiology, 94-95 Tenth value layer (TVL), 15 Terms used in the text, 217-221 Thin layer chromatography, 146 Time in radiation protection, 170 Time of flight method, 46-47 Tissue weighting factors  $(W_T)$ , 162, 221 Total effective dose equivalent (TEDE), 163 Toxicity of PET radiopharmaceuticals LD<sub>50/60</sub>, 147, 219 Transient equilibrium in radioactive decay, 8 Transition energy in radioactive decay, 3 Transportation of radioactive materials, 173-176 Transport index (TI), 173

Units and constants, 223–224 Units of radioactivity, 9 Unrestricted area, 163 USP 797, 142 USP Chapter 823, 142 Waste disposal, radioactive decay-in-storage, 167 Whole body PET/CT imaging, 207–208 Whole body PET imaging, 205–207 Wipe test, 166, 168 Workflow, 87 Workstation, 89 X-rays characteristic, 4, 5, 12, 31 computed tomography (CT), 32, 33, 53, 60, 62, 159, 200

<sup>62</sup>Zn (Zinc-62), 129