Gopal B. Saha

Fundamentals of Nuclear Pharmacy

Seventh Edition



Fundamentals of Nuclear Pharmacy

Gopal B. Saha

Fundamentals of Nuclear Pharmacy

Seventh Edition



Gopal B. Saha, PhD Emeritus Staff Cleveland Clinic Cleveland, OH USA

ISBN 978-3-319-57579-7 ISBN 978-3-319-57580-3 (eBook) https://doi.org/10.1007/978-3-319-57580-3

Library of Congress Control Number: 2017959344

© Springer International Publishing AG 1979, 1984, 1992, 1998, 2004, 2010, 2018

This work is subject to copyright. All rights are reserved by the Publisher, whether the whole or part of the material is concerned, specifically the rights of translation, reprinting, reuse of illustrations, recitation, broadcasting, reproduction on microfilms or in any other physical way, and transmission or information storage and retrieval, electronic adaptation, computer software, or by similar or dissimilar methodology now known or hereafter developed.

The use of general descriptive names, registered names, trademarks, service marks, etc. in this publication does not imply, even in the absence of a specific statement, that such names are exempt from the relevant protective laws and regulations and therefore free for general use.

The publisher, the authors and the editors are safe to assume that the advice and information in this book are believed to be true and accurate at the date of publication. Neither the publisher nor the authors or the editors give a warranty, express or implied, with respect to the material contained herein or for any errors or omissions that may have been made. The publisher remains neutral with regard to jurisdictional claims in published maps and institutional affiliations.

Printed on acid-free paper

This Springer imprint is published by Springer Nature The registered company is Springer International Publishing AG

The registered company address is: Gewerbestrasse 11, 6330 Cham, Switzerland

With my heartfelt gratitude and respect to

Late Nishi Kumar Saha (grandfather), Late Binoy Bhushan Saha (uncle), Late Snehangshu Bimal Saha (brother-in-law), Late Amar Das (brother-in-law),

Whose unwavering love, inspiration, and support have made me what I am today!

Preface

Since the sixth edition of this book in 2010, armamentariums in nuclear medicine have changed with new additions and some deletions and hence the seventh edition. Obsolete and outdated radiopharmaceuticals and techniques have been removed, and new useful ones have been added. Like the previous editions, the book is aimed to the nuclear medicine and radiology fellows, residents, and technologists in preparation for their respective professional board examinations. Also nuclear medicine physicians and radiologists should find it a useful reference in their practice.

The organization of the book remains the same as the previous editions with a total of 16 chapters with the same titles. Chapters 1, 2, and 3 remain almost unchanged except the addition of a section on Gaussian distribution in Chap. 2 and a small section on PET/MR imaging in Chap. 3. A number of radionuclides have been added in Chap. 4, and the 227 Ac \rightarrow^{227} Th \rightarrow^{223} Ra generator has been added in Chap. 5. There is no change in Chaps. 6. 8, and 12. New US FDA-approved and some non-US FDA-approved radiopharmaceuticals for clinical use are described in Chap. 7. Several radiopharmacyrelated accessories have been added to Chap. 9, and radiation doses for new radiopharmaceuticals have been included in Chap. 10. Revised and new regulations of the US FDA as well as a brief update of European Union regulations have been cited in Chap. 11. Specific clinical uses of new radiopharmaceuticals described in Chap. 7 have been presented in Chap. 13. Chapter 14 contains two new sections - theranostics and translational medicine. The use of Xofigo in the treatment of castration-resistant prostate cancer has been added in Chap. 15. Chapter 16 has been revised with new information on adverse reactions from radiopharmaceutical administration to humans. Appendix F is a new addition containing the decay factors of ¹⁸F. Appropriate references and additional questions have been added in each chapter.

I would like to thank Dr. Guiyun Wu, staff of Nuclear Medicine at Cleveland Clinic, for providing a few images on neuroimaging. Many thanks are due to Ms. Stephanie Frost, developmental editor, for her skillful editing; Ms. Miranda Finch, editorial assistant, Clinical Medicine; and Ms. Margaret Moore, editor, Clinical Medicine, of Springer, for their sincere help and guidance during the production of the book. I thank Ms. Janet Foltin, former senior editor of Clinical Medicine of Springer, for her help in the initial phase of the book. Thanks and appreciation are due to Mr. Sivakumar Krishnamoorthy of SPi Global for a job well done in the production of the book. Finally, I am ever grateful to Springer Nature for its perpetual support through decades in my publication efforts.

Cleveland, OH, USA

Gopal B. Saha, PhD

Contents

1	The	Atom .		1
	1.1	Electr	onic Structure of the Atom	1
	1.2	Chem	ical Bonds	2
		1.2.1	Electrovalent or Ionic Bond	4
		1.2.2	Covalent Bond	4
		1.2.3	Coordinate Covalent Bond.	5
		1.2.4	Complex Formation	5
	1.3	Struct	ure of the Nucleus.	6
		1.3.1	Nomenclature	8
	Sugg	gested H	Reading	10
2	Rad	ioactiv	e Decav	11
	2.1	Decay	of Radionuclides	11
		2.1.1	Spontaneous Fission	11
		2.1.2	Alpha Decay (α -Decay)	12
		2.1.3	Beta Decay (β^{-} -Decay).	12
		2.1.4	Positron or β^+ -Decay	14
		2.1.5	Electron Capture	14
		2.1.6	Isomeric Transition	15
	2.2	Radio	active Decay Equations	18
		2.2.1	General Equation	18
		2.2.2	Half-Life and Mean Life	19
		2.2.3	Units of Radioactivity	21
		2.2.4	Calculations	22
	2.3	Succe	ssive Decay Equations	23
		2.3.1	General Equation	23
		2.3.2	Transient Equilibrium	24
		2.3.3	Secular Equilibrium	26
	2.4	Statist	tics of Counting	27
		2.4.1	Error, Accuracy, and Precision.	28
		2.4.2	Standard Deviation.	28
		2.4.3	Standard Deviation of Count Rates	30
		2.4.4	Propagation of Errors	30
	Sugg	gested I	Reading	32

3	Inst	rument	s for Radiation Detection and Measurement.	33
	3.1	Gas-Fi	Iled Detectors	33
		3.1.1	Dose Calibrators.	33
		3.1.2	Geiger–Müller Counters	35
	3.2	Scintil	lation-Detecting Instruments	36
		3.2.1	Collimator	36
		3.2.2	Detector	36
		3.2.3	Photomultiplier Tube	37
		3.2.4	Preamplifier	37
		3.2.5	Linear Amplifier.	38
		3.2.6	Pulse Height Analyzer	38
		3.2.7	Display or Storage	38
	3.3	Scintil	lation Camera.	39
		3.3.1	Collimator	39
		3.3.2	Detector	41
		3.3.3	X, Y Positioning Circuit.	41
		3.3.4	Pulse Height Analyzer	42
		3.3.5	Digital Image	42
		3.3.6	Display and Storage	43
	3.4	Tomog	raphic Imagers	43
		3.4.1	Single-Photon Emission Computed Tomography	44
		3.4.2	Positron Emission Tomography	44
		3.4.3	PET/CT. PET/MR. and SPECT/CT.	45
	Sug	gested R	leading	47
1	Dro	Justian	of Padionuclides	40
Τ.	4.1	Cuelet	ron Produced Radionuclides	49
	4.1			47
			Collium 67	50
		4.1.1	Gallium-67	52 52
		4.1.1 4.1.2	Gallium-67 Iodine-123	52 52
		4.1.1 4.1.2 4.1.3	Gallium-67 Iodine-123 Iodine-124	52 52 53
		4.1.1 4.1.2 4.1.3 4.1.4	Gallium-67 Iodine-123 Iodine-124 Germanium-68	52 52 53 53
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5	Gallium-67 Iodine-123 Iodine-124 Germanium-68. Strontium-82.	52 52 53 53 54
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6	Gallium-67 Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111.	52 52 53 53 54 54
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111 Copper-64	52 52 53 53 54 54 55
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 4.1.8	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201	52 52 53 53 54 54 55 55
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 4.1.8 4.1.9	Gallium-67. Iodine-123 Iodine-124 Germanium-68 Strontium-82 Indium-111 Copper-64 Thallium-201 Zirconium-89	52 52 53 53 54 54 54 55 55 55
		4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 4.1.8 4.1.9 4.1.10	Gallium-67. Iodine-123 Iodine-124 Germanium-68 Strontium-82 Indium-111 Copper-64 Thallium-201 Zirconium-89 Carbon-11	52 52 53 53 54 54 54 55 55 55 55
		$\begin{array}{c} \text{Cyclot}\\ 4.1.1\\ 4.1.2\\ 4.1.3\\ 4.1.4\\ 4.1.5\\ 4.1.6\\ 4.1.7\\ 4.1.8\\ 4.1.9\\ 4.1.10\\ 4.1.11\end{array}$	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201 Zirconium-89. Carbon-11 Nitrogen-13.	52 52 53 53 54 55 55 55 55 56 56
		$\begin{array}{c} \text{Cyclot}\\ 4.1.1\\ 4.1.2\\ 4.1.3\\ 4.1.4\\ 4.1.5\\ 4.1.6\\ 4.1.7\\ 4.1.8\\ 4.1.9\\ 4.1.10\\ 4.1.11\\ 4.1.12\end{array}$	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201 Zirconium-89. Carbon-11 Nitrogen-13 Oxygen-15.	52 52 53 53 54 54 55 55 55 55 56 56 56
		$\begin{array}{c} \text{Cyclot}\\ 4.1.1\\ 4.1.2\\ 4.1.3\\ 4.1.4\\ 4.1.5\\ 4.1.6\\ 4.1.7\\ 4.1.8\\ 4.1.9\\ 4.1.10\\ 4.1.11\\ 4.1.12\\ 4.1.13\end{array}$	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201 Zirconium-89 Carbon-11 Nitrogen-13 Oxygen-15 Copper-62	52 52 53 53 54 55 55 55 55 56 56 56 56
		$\begin{array}{c} \text{Cyclot}\\ \text{4.1.1}\\ \text{4.1.2}\\ \text{4.1.3}\\ \text{4.1.4}\\ \text{4.1.5}\\ \text{4.1.6}\\ \text{4.1.7}\\ \text{4.1.8}\\ \text{4.1.9}\\ \text{4.1.10}\\ \text{4.1.11}\\ \text{4.1.12}\\ \text{4.1.13}\\ \text{4.1.14} \end{array}$	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201 Zirconium-89 Carbon-11 Nitrogen-13 Oxygen-15 Copper-62 Fluorine-18.	52 52 53 54 54 55 55 55 56 56 56 56 57 57
	4.2	4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 4.1.8 4.1.9 4.1.10 4.1.11 4.1.12 4.1.13 4.1.14 Reactor	Gallium-67. Iodine-123 Iodine-124 Germanium-68. Strontium-82 Indium-111. Copper-64 Thallium-201 Zirconium-89. Carbon-11 Nitrogen-13. Oxygen-15. Copper-62 Fluorine-18. vr-Produced Radionuclides.	52 52 53 53 54 54 55 55 55 56 56 56 56 57 57
	4.2	4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 4.1.8 4.1.9 4.1.10 4.1.11 4.1.12 4.1.13 4.1.14 Reactor 4.2.1	Gallium-67. Iodine-123 Iodine-124 Germanium-68 Strontium-82 Indium-111 Copper-64 Thallium-201 Zirconium-89 Carbon-11 Nitrogen-13 Oxygen-15 Copper-62 Fluorine-18. r-Produced Radionuclides. Fission or (n, f) Reaction	52 52 53 53 54 54 55 55 55 55 56 56 56 56 56 57 57 57

	4.3	Target	and Its Processing	65
	4.4	Equation	on for Production of Radionuclides	65
	4.5	Specifi	c Activity	72
	Refe	rences a	and Suggested Reading	74
5	Rad	ionuclic	le Generators	77
	5.1	Princip	bles of a Generator	77
	5.2	Import	ant Radionuclide Generators	79
		5.2.1	⁹⁹ Mo– ^{99m} Tc Generator	79
		5.2.2	⁶⁸ Ge– ⁶⁸ Ga Generator (GalliaPharm)	88
		5.2.3	⁹⁰ Sr– ⁹⁰ Y Generator	88
		5.2.4	⁶² Zn– ⁶² Cu Generator.	89
		5.2.5	⁸² Sr- ⁸² Rb Generator (Cardiogen-82)	89
		5.2.6	$^{227}\text{Ac} \rightarrow ^{227}\text{Th} \rightarrow ^{223}\text{Ra}$ Generator	90
	Refe	rences a	and Suggested Reading	92
6	Rad	iopharr	naceuticals and General Methods	
	of R	adiolab	eling	93
	6.1	Definit	tion of a Radiopharmaceutical	93
	6.2	Ideal R	Radiopharmaceutical	94
		6.2.1	Easy Availability	94
		6.2.2	Short Effective Half-Life	94
		6.2.3	No Particle Emission	95
		6.2.4	Decay by Electron Capture or Isomeric Transition	96
		6.2.5	High Target-to-Nontarget Activity Ratio	97
	6.3	Design	of New Radiopharmaceuticals	97
		6.3.1	General Considerations	97
		6.3.2	Factors Influencing the Design of New	
			Radiopharmaceuticals	98
	6.4	Metho	ds of Radiolabeling 1	100
		6.4.1	Isotope Exchange Reactions	101
		6.4.2	Introduction of a Foreign Label	101
		6.4.3	Labeling with Bifunctional Chelating Agents	102
		6.4.4	Biosynthesis	102
	6.5	Import	ant Factors in Labeling 1	102
		6.5.1	Efficiency of Labeling	103
		6.5.2	Chemical Stability of Product 1	103
		6.5.3	Denaturation or Alteration	103
		6.5.4	Isotope Effect	103
		6.5.5	Carrier-Free or No-Carrier-Added State	103
		6.5.6	Storage Conditions	103
		6.5.7	Specific Activity	104
		6.5.8	Radiolysis	104
		6.5.9	Purification and Analysis 1	104
		6.5.10	Shelf-Life 1	105

	6.6	Specif	ic Methods of Labeling	105
		6.6.1	Radioiodination	105
		6.6.2	Labeling with ^{99m} Tc	110
		6.6.3	Structure of ^{99m} Tc-Complexes	114
		6.6.4	Oxidation States of ^{99m} Tc in ^{99m} Tc-Radiopharmaceuticals	115
		6.6.5	Oxidation States in ^{99m} Tc-Labeled Proteins	117
		6.6.6	Kits for ^{99m} Tc-Labeling	117
	6.7	Colloi	ds and Labeled Particles.	118
	6.8	Additi	ves and Preservatives	119
	Refe	erences	and Suggested Reading	121
7	Cha	racteris	stics of Specific Radiopharmaceuticals.	123
	7.1	^{99m} Tc-]	Labeled Radiopharmaceuticals	123
		7.1.1	^{99m} Tc-Sodium Pertechnetate	123
		7.1.2	^{99m} Tc-Macroaggregated Albumin	124
		7.1.3	^{99m} Tc-Phosphonate and Phosphate Radiopharmaceuticals .	124
		7.1.4	^{99m} Tc-Sulfur Colloid	125
		7.1.5	^{99m} Tc-Albumin Colloid (Nanocolloid)	127
		7.1.6	^{99m} Tc-Tilmanocept (Lymphoseek)	127
		7.1.7	^{99m} Tc-Pentetate (DTPA)	127
		7.1.8	^{99m} Tc-Labeled Red Blood Cells	128
		7.1.9	^{99m} Tc-Iminodiacetic Acid Derivatives	
			(Hepatolite, Mebrofenin)	129
		7.1.10	^{99m} Tc-Hexamethylpropylene Amine Oxime (Ceretec)	130
		7.1.11	^{99m} Tc-Sestamibi (Cardiolite, Miraluma)	132
		7.1.12	^{99m} Tc-Mercaptoacetylglycylglycylglycine (MAG3)	132
		7.1.13	^{99m} Tc-Ethyl Cysteinate Dimer (Neurolite)	133
		7.1.14	^{99m} Tc-Tetrofosmin (Myoview)	134
		7.1.15	^{99m} Tc-Dimercaptosuccinic Acid (Succimer)	134
		7.1.16	^{99m} Tc-Technegas	134
	7.2	Radioi	odinated Radiopharmaceuticals.	135
		7.2.1	¹³¹ I-Sodium Iodide	135
		7.2.2	¹²³ I-Sodium Iodide	135
		7.2.3	¹²⁵ I-Albumin	136
		7.2.4	¹²³ I-Ioflupane (DaTscan)	136
		7.2.5	¹²³ I- or ¹³¹ I-Metaiodobenzylguanidine (AdreView)	137
		7.2.6	¹²⁵ I-Sodium Iothalamate (Glofil)	137
	7.3	Miscel	llaneous Radiopharmaceuticals of Clinical Interest	137
		7.3.1	¹¹¹ In-DTPA	137
		7.3.2	¹³³ Xe Gas	138
		7.3.3	²⁰¹ Tl-Thallous Chloride	138
		7.3.4	⁶⁷ Ga-Citrate	138
		7.3.5	³² P-Sodium Orthophosphate	139
		7.3.6	⁸⁹ Sr-Strontium Chloride (Metastron)	139
		7.3.7	¹⁵³ Sm-Ethylenediaminetetramethylene Phosphonic Acid	
			(Quadramet)	. 139

	83	Record	d Keening	181
		873	Toyicity	101
		822	Apvrogenicity	179
	0.2	8.2.1	Sterility.	
	82	Biolog	vical Tests	177
		0.1.J 816	Radioassav	173
		0.1.4	Chemical Purity	103
		0.1.J 8 1 <i>1</i>	Radiochemical Purity	104
		0.1.2 9 1 2	Pri anu Ionic Suengui	104 164
		ð.1.1 8 1 2	Physical Unaracteristics	104
	8.1	Physic	Cocnemical lests	163
ð		DL CO	ntrol of Radiopharmaceuticals	163
0	0	14. C		162
	Refe	erences	and Suggested Reading	160
		7.6.4	²²³ Ra-Radium Chloride (Xofigo)	159
		7.6.3	⁹⁰ Y-SIR-Sphere (SIRTeX)	159
		7.6.2	⁹⁰ Y-TheraSphere	158
		7.6.1	¹¹¹ In- and ⁹⁰ Y-Ibritumomab Tiuxetan (Zevalin)	158
	7.6	Labeli	ng of Therapeutic Radiopharmaceuticals	158
		7.5.5	¹⁸ F-Flurpiridaz	157
		7.5.4	¹⁸ F-Fluorothymidine.	157
		7.5.3	¹⁸ F-Fluorodopa	150
		7.5.2	¹¹ C-Sodium Acetate	156
		751	¹⁵ O-Water	150
	1.5	of Pot	ential Use	156
	75	Non-I	IS FDA-Approved PFT Radiopharmaceuticals	133
		7.4.10	and DOTATATE	155
		7.4.9	⁶⁸ Ce and ¹⁷⁷ Ly Labeled DOTATOC	154
		7.4.8 7.4.0	⁸² Ph Pubidium Chloride	154
		1.4.1 7 1 0	¹³ NI Ammonia	154
		1.4.6	¹⁰ F-Florbetaben (Neuraceq)	153
		1.4.5	¹⁹ F-Flutemetamol (Vizamyl)	153
		7.4.4	¹⁹ F-Florbetapir (Amyvid)	152
		7.4.3	¹⁶ F-Fluciclovine (Axumin)	152
		7.4.2	¹⁸ F-Fluorodeoxyglucose	151
		7.4.1	¹⁸ F-Sodium Fluoride	151
	7.4	US FE	DA-Approved PET Radiopharmaceuticals	151
		7.3.13	Other Radiopharmaceuticals of Clinical Importance.	150
		7.3.12	Radiolabeled Peptides	150
		7.3.11	Radiolabeled Monoclonal Antibodies	143
		7.3.10	Radiolabeled Leukocytes and Platelets	140
		7.3.9	⁵¹ Cr-Labeled Red Blood Cells	140
		7.3.8	⁵⁷ Co- or ⁵⁸ Co-Cyanocobalamin	140

9	Nuc	lear Pha	armacy	185		
	9.1	Concep	ot	185		
	9.2	Design	of Nuclear Pharmacy Unit	185		
	9.3 USP General Chapter <797>: Pharmaceutical					
		Compo	bunding – Sterile Preparations	190		
	9.4	Operati	ion of Nuclear Pharmacy	192		
		9.4.1	Receiving and Monitoring of Radioactive Packages	192		
		9.4.2	Preparation of Radiopharmaceuticals	192		
		9.4.3	Quality Control of Radiopharmaceuticals	197		
		9.4.4	Storage	197		
		9.4.5	Dispensing	197		
		9.4.6	Radioactive Waste Disposal	198		
		9.4.7	Infectious Waste Disposal	200		
	9.5	Nuclea	r Pharmacist	200		
	9.6	Central	lized Nuclear Pharmacy	200		
	Refe	erences a	nd Suggested Reading	202		
10	Into	mal Da	diation Docimetry	202		
10	10.1	Dodio	tion Units	203		
	10.1	Raula	tion Desimetry	205		
	10.2	10.2.1	Calculation of Padiation Absorbed Dose	205		
		10.2.1	Radiation Dose in System International (SI) Units	203		
		10.2.2	Effective Dose Equivalent and Effective Dose	200		
	10.3	North	American Consensus Guidelines for Pediatric	217		
	10.5	Admi	nistered Radionharmaceutical Activities	216		
	Refe	rences a	nd Suggested Reading	218		
	non	lences a		210		
11	Rad	iation R	Regulations, Protection, and Uses	219		
	11.1	Food	and Drug Administration	219		
		11.1.1	Investigational New Drug	220		
		11.1.2	New Drug Application	221		
		11.1.3	Expanded Access IND	221		
		11.1.4	Exploratory IND	222		
		11.1.5	Radioactive Drug Research Committee	223		
		11.1.6	Difference Between RDRC and Exploratory IND	224		
		11.1.7	PET Radiopharmaceuticals	224		
		11.1.8	FDA Regulations for Compounding in			
			Nuclear Pharmacies	225		
		11.1.9	Drug Quality and Security Act.	226		
		11.1.10) State Boards of Pharmacy	228		
	11.2	Nucle	ar Regulatory Commission	229		
		11.2.1	Agreement States	229		
		11.2.2	Licenses	229		
		11.2.3	Accreditation of Nuclear Medicine Facilities	230		
		11.2.4	Radiation Protection.	232		

		11.2.5	Medical Uses of Radioactive Materials	242
		11.2.6	Report and Notification of Medical Event	247
		11.2.7	Report and Notification of Dose to Embryo/Fetus	
			or Nursing Child	248
		11.2.8	Release of Patients Administered with	
			Radiopharmaceuticals	248
		11.2.9	Verification Card for Radioactive Patients	250
		11.2.10	Record Keeping	250
	11.3	Depart	tment of Transportation	250
	11.4	Europe	ean Regulations Governing Radiopharmaceuticals	253
		11.4.1	Drug Registration.	254
		11.4.2	Good Manufacturing Practice	255
		11.4.3	European Pharmacopoeia.	255
		11.4.4	Guidelines for Small-Scale Radiopharmaceutical	
			Preparation	256
		11.4.5	Radiation Protection.	257
	Refe	rences ai	nd Suggested Reading	259
12	In Vi	itro and	In Vivo Nonimoging Tests	261
14	12.1	Radioi	mmunoassay	261
	12.1	12.1.1	Principle	261
		12.1.1	Methodology	261
		12.1.2	Sensitivity and Specificity	263
		12.1.5	Application	263
	12.2	Schilli	no Test	264
	12.2	Blood	Volume	264
	12.5	12.3.1	¹²⁵ I-I abeled Serum Albumin Method	265
		12.3.1	⁵¹ Cr-Labeled Red Blood Cell Method	265
		12.3.2	Application	265
	12.4	Red B	lood Cell Survival	266
	Sugo	rested Re	eading	267
	5455	,05100 110	adding	207
13	Diag	nostic U	Sees of Radiopharmaceuticals in Nuclear Medicine	269
	13.1	Centra	Il Nervous System.	269
		13.1.1	Anatomy and Physiology	269
		13.1.2	Radiopharmaceuticals and Imaging Techniques	271
		13.1.3		283
	13.2	Thyro	Id	283
		13.2.1	Anatomy and Physiology	283
		13.2.2	Radiopharmaceuticals and Imaging Techniques	285
	10.0	13.2.3	Diagnosis	287
	13.3	Lungs		287
		13.3.1	Anatomy and Physiology	287
		13.3.2	Radiopharmaceuticals and Imaging Techniques	289
		13.3.3	Diagnosis	294

	13.4	Liver.		294
		13.4.1	Anatomy and Physiology	294
		13.4.2	Radiopharmaceuticals and Imaging Techniques	295
		13.4.3	Diagnosis	300
	13.5	Spleer	 1	302
		13.5.1	Anatomy and Physiology	302
		13.5.2	Radiopharmaceuticals and Imaging Techniques	302
		13.5.3	Diagnosis	302
	13.6	Kidne	ys	303
		13.6.1	Anatomy and Physiology	303
		13.6.2	Radiopharmaceuticals and Imaging Techniques	304
		13.6.3	Diagnosis	311
	13.7	Skelet	on	311
		13.7.1	Anatomy and Physiology	311
		13.7.2	Radiopharmaceuticals and Imaging Techniques	311
		13.7.3	Diagnosis	313
	13.8	Heart.		313
		13.8.1	Anatomy and Physiology	313
		13.8.2	Radiopharmaceuticals and Imaging Techniques	317
		13.8.3	Diagnosis	332
	13.9	Misce	Ilaneous Imaging Procedures	332
		13.9.1	Tumor Imaging	332
		13.9.2	Thrombus Detection.	343
		13.9.3	Lymphoscintigraphy	344
		13.9.4	Gastric Emptying Imaging	345
		13.9.5	Meckel's Diverticulum Imaging	346
		13.9.6	Gastrointestinal Bleeding Detection	346
		13.9.7	Inflammatory Diseases and Infection Imaging	347
		13.9.8	Parathyroid Imaging.	349
	Refe	rences an	nd Suggested Reading	352
14	Mol	eular I	naging	355
14	14.1	Metho	dology of Molecular Imaging	356
	17.1	14 1 1	Conventional Molecular Imaging	356
		14.1.1	Gene-Based Molecular Imaging	356
		14.1.2	Oligodeoxynucleotide Antisense Probes	550
		14.1.5	to Image mRNA	350
		14 1 4	Reporter Genes for Imaging	360
	14.2	Gene '	Therapy	362
	17.2	14 2 1	Gene Delivery	362
		14.2.1 14.2.2	Specific Diseases	363
	143	Nanor	particle Imaging	365
	14.4	Thera	nostics	368
	14.5	Tranel	ational Medicine	369
	Refe	rences a	nd Suggested Reading	371
	nuit	i chices al	a suggested requiring	571

15	Therapeutic Uses of Radiopharmaceuticals in Nuclear Medicine	373
	15.1 Treatment of Hyperthyroidism.	373
	15.2 Treatment of Thyroid Cancer.	374
	15.2.1 Whole-Body Imaging.	375
	15.2.2 Treatment with ¹³¹ I	375
	15.3 Treatment of Bone Pain	376
	15.3.1 ³² P–Sodium Orthophosphate	377
	15.3.2 ⁸⁹ Sr-Strontium Chloride (Metastron)	377
	15.3.3 ¹⁵³ Sm-EDTMP (Quadramet)	378
	15.4 Treatment of Liver Cancer	378
	15.4.1 ⁹⁰ Y–TheraSpheres	378
	15.4.2 ⁹⁰ Y–SIR-Spheres (SIR-TeX)	379
	15.5 Treatment of Non-Hodgkin's Lymphoma	380
	15.5.1 ⁹⁰ Y–Ibritumomab Tiuxetan (Zevalin)	380
	15.6 Treatment of Polycythemia Vera and Leukemia	380
	15.7 Treatment of Prostate Cancer and Its Metastasis	381
	15.8 Pretargeted Radioimmunotherapy of Cancer	381
	References and Suggested Reading	383
	of Radiopharmaceuticals 16.1 Adverse Reactions 16.2 Iatrogenic Alterations in Biodistribution of Radiopharmaceuticals	385 385 386
	References and Suggested Reading	388
Appe	endix A: Abbreviations Used in the Text	389
Appe	endix B: Terms Used in the Text	393
Appe	endix C: Units and Constants	403
Appe	endix D: Radioactive Decay of ^{99m} Tc	405
Appe	endix E: Radioactive Decay of ¹³¹ I	407
Appe	endix F: Radioactive Decay of ¹⁸ F	409
Appe	endix G: Answers to Questions	411
Inde	X	415

The Atom

According to Bohr's atomic theory, an atom is composed of a nucleus at the center and one or more electrons rotating around the nucleus along different energy orbits. The nucleus is primarily composed of protons and neutrons, collectively called nucleons. For an atom of a given element, the number of electrons moving around the nucleus equals the number of protons, balancing the electrical charge of the nucleus. Protons are positively charged, electrons are negatively charged and neutrons have no charge. The size of an atom is of the order of 10^{-8} cm (1 angstrom, Å), and that of a nucleus is of the order of 10^{-13} cm (1 fermi, F). The electron configuration of the atom determines the chemical properties of an element, whereas the nuclear structure characterizes the stability and radioactive decay of the nucleus of an atom.

1.1 Electronic Structure of the Atom

The Bohr atomic theory states that electrons in an atom rotate around the nucleus in discrete *energy orbits* or *shells*. These energy shells, referred to as the K shell, L shell, M shell, N shell, and so forth, are stationary and arranged in order of increasing energy. When there is a transition of an electron from an upper orbit to a lower orbit, the energy difference between the two orbits is released as the photon radiation. If the electron is raised from a lower orbit to an upper orbit, the energy difference between the two orbits to an upper orbit, the energy difference between the two orbits to an upper orbit, the energy difference between the two orbits is absorbed and must be supplied for the transition to occur.

According to the quantum theory, each shell is designated by a quantum number n, called the *principal quantum number*, and denoted by integers, for example, 1 for the K shell, 2 for the L shell, 3 for the M shell, 4 for the N shell, and 5 for the O shell (Table 1.1). Each energy shell is subdivided into *subshells* or *orbitals*, which are designated as s, p, d, f, and so forth. For a principal quantum number n, there are n orbitals in the main shell. These orbitals are assigned *azimuthal quantum numbers*, l, which designate the electron's angular momentum and can assume numerical values of l = 0, 1, 2, ..., n - 1. Thus for the s orbital l = 0, the p orbital l = 1, the d

[©] Springer International Publishing AG 2018

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3_1

Principal	Principal		No. of electrons = $2(2 l + 1)$	
shell	quantumnumber (n)	Orbital (l)	in each orbital	$2n^2$
Κ	1	<i>s</i> (0)	2	2
L	2	<i>s</i> (0)	2	
		p(1)	6	8
М	3	<i>s</i> (0)	2	
		p(1)	6	
		d(2)	10	18
Ν	4	<i>s</i> (0)	2	
		<i>p</i> (1)	6	
		d(2)	10	
		<i>f</i> (3)	14	32
0	5	<i>s</i> (0)	2	
		<i>p</i> (1)	6	
		d(2)	10	
		<i>f</i> (3)	14	
		g(4)	18	50

Table 1.1 Electron configuration in different energy shells

orbital l = 2, and so forth. According to the above description, the *K* shell has one orbital, designated as 1*s*; the *L* shell has two orbitals, designated as 2*s* and 2*p*, and so forth. The orientation of the electron's magnetic moment in a magnetic field is described by the *magnetic quantum number*, *m*. The values of *m* can be m = -l, -(l - 1), ..., ..., (l - 1), *l*. Another quantum number, the *spin quantum number*, s(s = -1/2 or +1/2), is assigned to each electron in order to specify its rotation about its own axis. Each orbital can accommodate a maximum of 2(2l + 1) electrons, and the total number of electrons in a given shell is $2n^2$. Thus, the *K* shell can contain only 2 electrons, the next *L* shell 8 electrons. In atoms, the orbitals are filled in order of increasing energy; that is, the lowest energy orbital is filled in first. However, when *d* orbitals start filling, there are some exceptions to this rule as seen in the examples of the electron configurations of some elements given below:

11Na	$1s^2 2s^2 2p^6 3s^1$
18Ar	$1s^22s^2p^63s^2 3p^6$
₂₆ Fe	$s^2 2s^2 2p^6 3s^2 \ 3p^6 3d^6 4s^2$
₄₃ Tc	1s ² 2s ² 2p ⁶ 3s ² 3p ⁶ 3d ¹⁰ 4s ² 4p ⁶ 4d ⁶ 5s ¹
49In	$1s^22s^22p^63s^2$ $3p^63d^{10}4s^24p^64d^{10}5s^25p^1$

The electron configuration in different orbitals and shells is illustrated in Table 1.1, and, for example, the structure of $_{28}$ Ni is shown in Fig. 1.1.

1.2 Chemical Bonds

The electronic structure of the atom of an element determines to a large degree the chemical properties of the element. The periodic table has been devised to arrange the groups of elements of similar chemical properties in order of increasing atomic number. In the periodic table (Fig. 1.2), nine groups are presented vertically, and



Fig. 1.2 Periodic table of elements (Reproduced from http://periodic.lanl.gov/index.shtml under the rule of fair use of material)

seven periods are shown horizontally. Each group contains elements of similar chemical properties, whereas the periods consist of elements having the same number of electron shells but dissimilar chemical properties. As can be seen in Fig. 1.2,

group VIIB consists of manganese, technetium, and rhenium, whose chemical properties are very similar. Period 2 contains lithium, beryllium, boron, carbon, nitrogen, oxygen, fluorine, and neon, all of which have the K shell and L shell in common, but are widely different in their chemical behavior.

The *valence* of an element is the tendency of the atom to lose or gain electrons to achieve a stable electron configuration. It is primarily determined by the number of electrons present in the outermost shell, referred to as the *valence shell*. In the most stable and chemically inert elements, such as neon, argon, krypton, and xenon, the valence shell has the electron configuration ns^2np^6 . Helium, although a noble gas, has the configuration $1s^2$. The electrons in the valence shell are termed the *valence electrons*. To achieve the stable electron configurations ns^2np^6 , electrons can be added to or given up from the valence shell for chemical bond formation between the atoms of appropriate elements. All chemical bond formation is governed by the *octet rule*, which states that the electrons, with the exception of hydrogen and lithium atoms, which essentially assume the structure $1s^2$. The energy involved in chemical bond formation is of the order of a few electron volts (eV). An electron volt is the energy acquired by an electron accelerated through a potential difference of 1 V. There are three main types of chemical bonds, described below.

1.2.1 Electrovalent or Ionic Bond

An electrovalent or ionic bond is formed by the complete transfer of an electron from the valence shell of one atom to that of another atom. In ionic bonds, two oppositely charged ions are held together in the compound by coulombic forces. The compound NaCl is formed as follows:

$$Na^+ + Cl^- \rightarrow NaCl$$

The sodium atom has the structure $1s^22s^22p^63s^1$, which can spare the $1s^l$ electron to achieve the stable structure of neon, $1s^22s^22p^6$. On the other hand, the chlorine atom has the structure $1s^22s^22p^63s^23p^5$, which is short of one electron in achieving the electronic structure of argon, $1s^22s^22p^63s^23p^6$. Thus, in the formation of NaCl, the sodium atom loses one electron to become Na⁺, and the chlorine atom receives the electron to become Cl⁻. Both ions are then held by an electrovalent bond. Because of their ionic properties, compounds with electrovalent bonds conduct electricity in the solid state as well as in solution.

1.2.2 Covalent Bond

In covalent bonds, each of the two atoms participating in bond formation contributes one electron to the bond. Both electrons are shared equally by each atom and, unlike electrovalent bonds, do not belong exclusively to one atom alone. The shared electrons are localized in the region between the two atoms and the molecules are nonionic. The following molecules are examples of covalent bonds:

$$\begin{array}{ccccc} H_2 & H & \times & H \\ HCl & H & \times & Cl \\ BeCl_2 Cl & \times & Be & \times & Cl \end{array}$$

Here the symbols \times and \cdot represent electrons from separate partners in the bond. Because the compounds with covalent bonds are nonionic, they are poor conductors of electricity.

1.2.3 Coordinate Covalent Bond

In a coordinate covalent bond, the pair of electrons required for bond formation is donated by only one atom to another that can accommodate two electrons in octet formation. These bonds are also called semipolar bonds, because only a partial positive charge is generated on the donor atom and a partial negative charge on the acceptor atom. Some donor atoms with a lone pair of electrons are \dot{N} :, \ddot{O} :, \ddot{S} :, and so forth, and they can form coordinate covalent bonds with various metal ions to form metal complexes. The following molecules are examples of coordinate covalent bonds:

$$\begin{split} NH_4^+ & \begin{bmatrix} & H & & \\ & \ddots & & \\ H & \ddots & N & \ddots & H \\ & & \ddot{H} & & \end{bmatrix}^+ \\ H_3O^+ & \begin{bmatrix} H & \ddots & \ddot{O} & \ddots & H \\ & & \ddot{H} & & \end{bmatrix}^+ \end{split}$$

In these examples, nitrogen and oxygen atoms have donated their lone pair of electrons to a hydrogen ion.

1.2.4 Complex Formation

Metal complexes are produced by coordinate covalent bonds that are formed by the electrons donated by the chemical species having a lone pair of electrons. These complexes can be cationic, anionic, or neutral, examples of which are $[Co(NH_3)_6]^{3+}$, $[Fe(CN)_6]^{3-}$, and $[Ni(CO)_4]$, respectively.

Fig. 1.3 Molecular structure of DTPA

$$\begin{array}{c} \text{HOOCH}_2\text{C} & \text{CH}_2\text{COOH} \\ \text{N}-\text{CH}_2 & -\text{CH}_2 & -\text{CH}_2 & -\text{CH}_2 & -\text{N} \\ \text{HOOCH}_2\text{C} & \text{CH}_2\text{COOH} \end{array}$$

Diethylenetriaminepentaacetic Acid (DTPA; MW = 393)

The molecules containing NH₃, -CN, -SH, -COO, $-NH_2$, CO, etc. are called *ligands*, which may be neutral or ionic in structure. The common characteristic of the ligands is that they all possess an unshared pair of electrons that can be donated to a metal ion to form a complex. These ligands are firmly attached to the metal ion, and the number of ligands in a complex is called the *coordination number* of the complex. For example, Co in $[Co(NH_3)_6]^{3+}$ has the coordination number 6.

A single ligand molecule can possess more than one donor atom and can donate more than one pair of electrons in the complex, provided spatial configuration permits. In such cases, more than one coordinate covalent bond is formed in the complex, and the mechanism of bond formation is called *chelation* (from Greek, meaning "clawlike configuration"). Such ligands are called *chelating agents*. Ethylenediaminetetraacetic acid (EDTA) and diethylenetriaminepentaacetic acid (DTPA) are typical examples of chelating agents; the structure of the latter is shown in Fig. 1.3. Donor atoms are nitrogen in the amino groups and oxygen in carboxyl groups. Depending on the number of electron pair donating groups in the molecule, the ligands are named unidentate, bidentate, tridentate, and so on.

The stability of a metal complex is influenced by the sizes of the metal ion and the ligand and the dipole moment of the ligand molecule. The smaller the size of the metal ion and the ligand, the more stable the coordinate covalent bond. Ligands with larger dipole moments form more stable complexes. The stability of a complex is also increased by chelation and the number of electron donor atoms in the chelating agent.

Various ^{99m}Tc-radiopharmaceuticals, such as ^{99m}Tc-DTPA and ^{99m}Tcdimercaptosuccinate (DMSA), are complexes formed by coordinate covalent bonds between ^{99m}Tc and the chelating compounds. The coordination number of technetium in these complexes varies between 4 and 9 (see in Chap. 6).

1.3 Structure of the Nucleus

The nucleus of an atom is composed of protons and neutrons, collectively called *nucleons*. The characteristics of nucleons and electrons are summarized in Table 1.2. The number of protons in a nucleus is called the *atomic number* of the atom, denoted by Z. The number of neutrons is denoted by N. The total number of nucleons in a nucleus is referred to as the *mass number*, denoted by A. Thus, A is equal to Z + N. An elemental atom X having a mass number A, atomic number Z, and neutron

Particle	Charge	Mass (amu) ^a	Mass (kg)	Mass (MeV) ^b
Electron	-1	0.000549	0.9108×10^{-30}	0.511
Proton	+1	1.00728	1.6721×10^{-27}	938.78
Neutron	0	1.00867	1.6744×10^{-27}	939.07

Table 1.2 Characteristics of electrons and nucleons

^aamu, 1 atomic mass unit = 1.66×10^{-27} kg = one twelfth of the mass of ¹²C

^b1 atomic mass unit = 931 MeV

number *N* is represented by ${}^{A}_{Z}X_{N}$. For example, the stable aluminum nucleus has 13 protons (*Z*) and 14 neutrons (*N*), and therefore its mass number is 27. Thus it is designated as ${}^{27}_{13}$ Al₁₄. Since all the aluminum atoms have the same atomic number, and the neutron number can be calculated as *A*–*Z*, both the atomic number 13 and the neutron number 14 are omitted from its representation. Thus, the aluminum nucleus is normally designated as 27 Al. Alternatively, it is written as Al-27.

Different models have been postulated for the arrangement of the nucleons in a nucleus to explain various experimental observations. According to the Bohr liquid drop model, the nucleus is assumed to be spherical and composed of closely packed nucleons, and particle emission by the nucleus resembles evaporation of molecules from a liquid drop. This theory explains various phenomena, such as nuclear density, binding energy, energetics of particle emission by radioactive nuclei, and fission of heavy nuclei.

In the shell model, nucleons are arranged in discrete energy shells similar to the electron shells of the atom in the Bohr atomic theory. Nuclei containing 2, 8, 20, 50, 82, or 126 protons or neutrons are very stable, and these nucleon numbers are called *magic numbers*.

Nuclei are less stable if they contain an odd number of protons or neutrons, whereas nuclei with even number of protons and neutrons are more stable. The ratio of the number of neutrons to the number of protons (N/Z) is also an approximate index of the stability of an atom. This ratio equals 1 in the stable nuclei with a lower atomic number, such as ${}^{12}_{6}$ C, ${}^{16}_{8}$ O, and ${}^{14}_{7}$ N, and the ratio increases with the increasing atomic number of the nucleus. For example, it is 1.40 for ${}^{127}_{53}$ I and 1.54 for ${}^{208}_{82}$ Pb. Nuclei with N/Z different from that of stable nuclei are unstable and decay by β -particle emission or electron capture. The shell model explains various nuclear characteristics such as the angular momentum, magnetic moment, and parity of the nucleus.

According to the classical electrostatic theory, a nucleus should not hold as a single entity because of the electrostatic repulsive forces among the protons in the nucleus. However, its stable existence has been explained by the postulation of a binding force, referred to as the *nuclear force*, which is much stronger than the electrostatic force and binds equally protons and neutrons within the nucleus. The nuclear force exists only in the nucleus and has no influence outside the nucleus.

The short range of nuclear force results in the very small size ($\sim 10^{-13}$ cm) and very high density ($\sim 10^{14}$ g/cm³) of the nucleus.

The mass M of a nucleus is always less than the combined masses of the nucleons A in the nucleus. This difference in mass (M-A) is termed the mass defect, which has been used as energy in binding all the nucleons in the nucleus. This energy is the *binding energy* of the nucleus and needs to be supplied to separate all nucleons completely from each other. The binding energy of an individual nucleon has a definite value depending on the shell it occupies; the average energy is approximately equal to the total binding energy divided by the number of nucleons. This energy is about 6–9 MeV and has to be supplied to remove a single nucleon from the nucleus.

1.3.1 Nomenclature

Several nomenclatures are important and need to be mentioned here. An exact nuclear composition including the mass number A, atomic number Z, and arrangement of nucleons in the nucleus identifies a distinct species, called the *nuclide*. Some nuclides (~288 or so) are stable and naturally occurring of which nearly 54 nuclides have half-life of >50 million and are considered stable. There are about 3400 artificially produced nuclides which are unstable or radioactive and decay by spontaneous fission or emission of α -particle, β -particle, and γ -ray. This group of nuclides are termed *radionuclides*. Nuclides of the same atomic number are called isotopes and exhibit the same chemical properties. Examples of oxygen isotopes are ${}^{15}_{8}$ O, ${}^{16}_{8}$ O, ${}^{17}_{8}$ O, and ${}^{18}_{8}$ O. Nuclides having the same number of neutrons but different atomic numbers are called isotones. Examples are ${}^{59}_{26}$ Fe, ${}^{60}_{27}$ Co, and ${}^{62}_{29}$ Cu each having 33 neutrons. Isobars are nuclides with the same number of nucleons, that is, the same mass number, but a different number of protons and neutrons. For example, ${}^{67}_{29}$ Cu, ${}^{67}_{30}$ Zn, ${}^{67}_{31}$ Ga, and ${}^{67}_{32}$ Ge are isobars having the same mass number 67. Nuclides having the same number of protons and neutrons but differing in energy states and spins are called *isomers*. ⁹⁹Tc and ^{99m}Tc are isomers of the same nuclide. The lifetime of the isomeric states ranges from picoseconds to years, and those with long half-life are represented by "m" as in 99mTc.

The nuclides, both stable and radioactive, are arranged in the form of a chart, referred to as the *chart of the nuclides*, a section of which is presented in Fig. 1.4. Each nuclide is represented by a square containing various information such as the half-life, type and energy of radiations, and so forth, of the radionuclide and the neutron capture cross-section of the stable nuclides (see Chap. 4). The nuclides are arranged in increasing neutron number horizontally and in increasing proton number vertically. Each horizontal bar contains all isotopes of the same element; for example, all silicon isotopes are grouped in the horizontal block designated by the proton number 14. All isotones are grouped vertically; for example, ${}^{26}_{14}$ Si , ${}^{25}_{13}$ Al , and ${}^{24}_{12}$ Mg are isotones with 12 neutrons and are positioned in the vertical column identified by the neutron number 12. The diagonal nuclides in the chart are isobars, for example, ${}^{27}_{14}$ Si , ${}^{27}_{13}$ Al , and ${}^{27}_{12}$ Mg . The radionuclides ${}^{24}_{13}$ Al and ${}^{26}_{14}$ Al each have an isomer.





Questions

- 1. Describe the basic concept and significance of the Bohr atomic theory.
- 2. Write the electron configuration of ₆C, ₁₇Cl, ₅₄Xe, ₃₇Rb, ₄₃Tc, and ₄₉In.
- 3. What is the octet rule? Why is it necessary that the electron configuration of the atoms be ns^2np^6 in a chemical bond?
- 4. The compounds with electrovalent bonds dissociate mostly into ions in water, whereas those with covalent bonds rarely do so. Explain.
- 5. What are ligands and chelating agents? Define coordination number and explain complex formation.
- 6. Group the following nuclides into isotopes, isobars, isotones, and isomers: ${}^{13}_{6}C$, ${}^{14}_{6}C$, ${}^{14}_{5}B$, ${}^{17}_{7}N$, ${}^{17}_{8}O$, ${}^{19}_{10}Ne$, ${}^{113}_{49}In$, ${}^{57}_{27}Co$, ${}^{57}_{26}Fe$, and ${}^{57}_{28}Ni$.
- 7. Define mass defect and magic number. What does the mass defect account for?
- 8. Explain why the nuclear force differs from the electrostatic force in the nucleus of an atom.
- 9. Write the following nuclides in order of increasing stability: ${}^{88}_{39}$ Y, ${}^{88}_{38}$ Sr, and ${}^{87}_{39}$ Y.
- 10. What are the sizes of an atom and a nucleus? What is responsible for this size difference? What is the difference in magnitude between the chemical and nuclear binding energies?
- 11. The mass of ${}_{31}^{67}$ Ga is 66.9858. (a) Calculate the mass defect in MeV. (b) Calculate the average binding energy in MeV of each nucleon in ${}_{31}^{67}$ Ga.

Suggested Reading

- Cherry SR, Sorensen JA, Phelps ME. Physics in nuclear medicine. 4th ed. Philadelphia: Saunders; 2012.
- Friedlander G, Kennedy JW, Macias ES, Miller JM. Nuclear and radiochemistry. 3rd ed. New York: Wiley; 1981.
- Los Alamos National Laboratory website (URL: http://periodic.lanl.gov/index.shtml).

Radioactive Decay

2.1 Decay of Radionuclides

As mentioned in Chap. 1, some 3700 nuclides have been discovered thus far, and the majority of them are unstable. Unstable nuclei decay by spontaneous fission, α -particle, β -particle, γ -ray emission, or electron capture (EC) in order to achieve stability. The stability of a nuclide is governed by the structural arrangement and binding energy of the nucleons in the nucleus. One criterion of stability is the neutron-to-proton ratio (*N*/*Z*) of the stable nuclides; the radionuclides decay to achieve the *N*/*Z* of the nearest possible stable nuclide. Radioactive decay by particle emission or electron capture changes the atomic number of the radionuclide, whereas decay by γ -ray emission does not.

Radionuclides may decay by any one or a combination of six processes: spontaneous fission, α -decay, β^- -decay, β^+ -decay, electron capture, and isomeric transition (IT). In radioactive decay, particle emission or electron capture may be followed by isomeric transition. In all decay processes, the energy, mass, and charge of radionuclides must be conserved. Each of these decay processes is briefly described below.

2.1.1 Spontaneous Fission

Fission is a process in which a heavy nucleus breaks down into two fragments typically in the ratio of 60:40. This process is accompanied by the emission of two or three neutrons with a mean energy of 1.5 MeV and a release of nearly 200-MeV energy, which appears mostly as heat.

Fission in heavy nuclei can occur spontaneously or by bombardment with energetic particles. Spontaneous fission occurs due to dumbbell-shape structure of the heavy nucleus, the middle neck part of which is prone to breakage by molecular vibration causing fission. The probability of spontaneous fission is low and increases with mass number of the heavy nuclei. The half-life for spontaneous fission is 2×10^{17} years for ²³⁵U and only 55 days for ²⁵⁴Cf. It should be noted that spontaneous fission is an alternative to α -decay or γ -emission. An example of spontaneous fission of ²³⁵U is given below.

$$\overset{86}{_{37}}\text{Rb} + \overset{147}{_{55}}\text{Cs} + 2n$$

$$\overset{235}{_{92}}\text{U} \longrightarrow \overset{99}{_{42}}\text{Mo} + \overset{133}{_{50}}\text{Sn} + 3n$$

$$\overset{92}{_{38}}\text{Sr} + \overset{141}{_{54}}\text{Xe} + 2n$$

2.1.2 Alpha Decay (α-Decay)

Usually heavy nuclei such as radon, uranium, neptunium, and so forth decay by α -particle emission. The α -particle is a helium ion with two electrons stripped off the atom and contains two protons and two neutrons bound together in the nucleus. In α -decay, the atomic number of the parent nuclide is therefore reduced by 2 and the mass number by 4. An example of α -decay is

$$^{235}_{92}\text{U} \rightarrow ^{231}_{90}\text{Th} + \alpha \left[{}^{4}_{2}\text{He}^{+} \right]$$

An α -transition may be followed by β^{-} -emission or γ -ray emission or both. The α -particles are monoenergetic, and their range in matter is very short (on the order of 10^{-6} cm) and is approximately 0.03 mm in body tissue.

2.1.3 Beta Decay (β^- -Decay)

When a nucleus is "neutron rich" (i.e., has a higher *N/Z* ratio compared to the stable nucleus), it decays by β^- -particle emission along with an antineutrino. An *antineutrino* (\overline{v}) is an entity almost without mass and charge and is primarily needed to conserve energy in the decay. In β^- -decay, a neutron (n) essentially decays into a proton (p) and a β^- -particle; for example,

$n \rightarrow p + \beta^- + \overline{v}$

The β -particle is emitted with variable energy from zero up to the decay energy. The *decay or transition energy* is the difference in energy between the parent and daughter nuclides. An antineutrino carries away the difference between the β -particle energy and the decay energy. The β -decay may be followed by γ -ray emission, if the daughter nuclide is in an excited state, and the number of γ -rays emitted depends on the excitation energy. After β -decay, the atomic number of the daughter nuclide is one more than that of the parent nuclide; however, the mass number remains the same for both nuclides.

Some examples of β -decay are

 $^{131}_{53}$ I \rightarrow^{131}_{54} Xe + β^- + $\overline{\nu}$

$${}^{59}_{26} \operatorname{Fe} \rightarrow {}^{59}_{27} \operatorname{Co} + \beta^{-} + \overline{\nu}$$

$${}^{99}_{42} \operatorname{Mo} \rightarrow {}^{99m}_{43} \operatorname{Te} + \beta^{-} + \overline{\nu}$$

$${}^{60}_{27} \operatorname{Co} \rightarrow {}^{60}_{28} \operatorname{Ni} + \beta^{-} + \overline{\nu}$$

. .

The radioactive decay of nuclides is represented schematically by decay schemes, and examples of the decay schemes of ¹³¹I and ⁹⁹Mo are given in Figs. 2.1 and 2.2, respectively.

The β -particles emitted by radionuclides can produce what is called *bremsstrahlung* by interaction with surrounding medium. Electrons passing through matter are decelerated in the Coulomb field of atomic nuclei, and as a result, the loss in



electron energy appears as continuous X-rays. These X-rays are called bremsstrahlung (German for "braking" or "slowing down" radiation) and are used in radiographic procedures. The probability of producing bremsstrahlung increases with increasing electron energy and increasing atomic number of the medium. In tungsten, for example, a 10-MeV electron loses about 50% of its energy by bremsstrahlung, whereas a 100-MeV electron loses more than 90% of its energy by this process.

2.1.4 Positron or β^+ -Decay

Nuclei that are "neutron deficient" or "proton rich" (i.e., have an *N/Z* ratio less than that of the stable nuclei) can decay by β^+ -particle emission accompanied by the emission of a neutrino (ν), which is an opposite entity of the antineutrino. After β^+ -particle emission, the daughter nuclide has an atomic number that is 1 less than that of the parent. The range of positrons is short in matter. At the end of the path of β^+ -particles, positrons combine with electrons and are thus annihilated, each event giving rise to two photons of 511 keV that are emitted in opposite directions. These photons are referred to as *annihilation radiations*.

In β^+ -decay, a proton transforms into a neutron by emitting a β^+ -particle and a neutrino; for example,

$$p \rightarrow n + \beta^+ + \nu$$

Since a β^+ -particle can be emitted with energy between zero and decay energy, the neutrino carries away the difference between decay energy and β^+ -energy. We know that a neutron is equivalent to one proton plus an electron. Therefore, in β^+ decay, a mass equivalent of two electrons is created by the conversion of a proton to a neutron, as shown in the above equations, i.e., 1.02 MeV is needed to create these two particles. So positron emission takes place only when the energy difference between the parent and daughter nuclides is equal to or greater than 1.02 MeV. Some examples of β^+ -decay are

$${}^{64}_{29}\text{Cu} \rightarrow {}^{64}_{28}\text{Ni} + \beta^+ + \nu$$
$${}^{18}_{9}\text{F} \rightarrow {}^{18}_{8}\text{O} + \beta^+ + \nu$$
$${}^{15}_{8}\text{O} \rightarrow {}^{15}_{7}\text{N} + \beta^+ + \nu$$
$${}^{52}_{26}\text{Fe} \rightarrow {}^{52}_{25}\text{Mn} + \beta^+ + \nu$$

The decay scheme of ¹⁸F is presented in Fig. 2.3.

2.1.5 Electron Capture

When a nucleus has a smaller N/Z ratio compared to the stable nucleus, as an alternative to β^+ -decay, it may also decay by the so-called electron capture



process, in which an electron is captured from the extranuclear electron shells, thus transforming a proton into a neutron and emitting a neutrino. For this process to occur, the energy difference between the parent and daughter nuclides is usually, but not necessarily, less than 1.02 MeV. Nuclides having an energy difference greater than 1.02 MeV may also decay by electron capture. The larger the energy difference, the higher the positron decay. The atomic number of the parent is reduced by 1 in this process. Some examples of electron capture decay are

Usually the *K*-shell electrons are captured because of their proximity to the nucleus; the process is then called *K* capture. Thus, in *L* capture, an *L*-shell electron is captured and so on. The vacancy created in the *K* shell after electron capture is filled by the transition of electrons from an upper level (probably the *L* shell and possibly the *M* or *N* shell). The difference in energies of the electron shells will appear as an X-ray that is characteristic of the daughter nucleus. These X-rays are termed characteristic *K* X-rays, *L* X-rays, and so on belonging to the daughter nuclide. The probability of electron capture increases with increasing atomic number, because electron shells in these nuclei are closer to the nucleus. The decay scheme of ¹¹¹In is given in Fig. 2.4.

2.1.6 Isomeric Transition

A nucleus can remain in several excited energy states above the ground state that are defined by quantum mechanics. All these excited states are referred to as *isomeric states* and decay to the ground state, with a lifetime of fractions of picoseconds to many years. The decay of an upper excited state to a lower excited state is called the



isomeric transition. In β^{-} , β^{+} , or electron capture decay, the parent nucleus may reach any of these isomeric states of the daughter nucleus in lieu of the ground state, and therefore these decay processes are often accompanied by isomeric transition. In isomeric transition, the energy difference between the energy states may appear as γ -rays. When isomeric states are long lived, they are referred to as *metastable states* and can be detected by appropriate instruments. The metastable state is denoted by "m" as in ^{99m}Tc. The decay scheme of ^{99m}Tc is given in Fig. 2.5. Some examples of isomeric transitions are given below:

$${}^{99m}\text{Tc} \rightarrow {}^{99}\text{Tc} + \gamma$$

$${}^{113m}\text{In} \rightarrow {}^{113}\text{In} + \gamma$$

$${}^{58m}\text{Co} \rightarrow {}^{58}\text{Co} + \gamma$$

There is a probability that instead of emitting a γ -ray photon, the excited nucleus may transfer its excitation energy to an electron in the extranuclear electron shell of its own atom, particularly the *K* shell, which is then ejected, provided the excitation energy is greater than the binding energy of the *K*-shell electron (Fig. 2.6). The ejected electron is referred to as the *conversion* electron and will have the kinetic energy equal to $E_{\gamma} - E_{B}$, where E_{γ} is the excitation energy and E_{B} is the binding energy of the ejected electron. This process is an alternative to γ -ray emission and is termed *internal conversion*. The ratio of the conversion electrons (N_e) to the observed γ -rays (N_{γ}) is referred to as the conversion coefficient, given by $\alpha = N_e/N_{\gamma}$. The larger the conversion coefficient, the smaller the number of observed γ -rays. The probability of internal conversion is higher when the transition energy is low.

When an electron is ejected from, for example, the *K* shell by internal conversion, an upper shell electron will fall into the vacancy of the *K* shell, and the difference in energy between the two shells will appear as an X-ray called the characteristic *K* X-ray, which is characteristic of the daughter nuclide. The corresponding conversion coefficient is designated as $\alpha_{\rm K}$. Similarly, it is also probable that instead of *K*-shell electrons, *L*, *M*, ... shell electrons are ejected, followed by the emission of *L*, *M*, ... X-rays in this process. The corresponding conversion coefficients then will



Fig. 2.6 Internal conversion process. Nuclear excitation energy is transferred to a *K*-shell electron, which is then emitted, and the vacancy is filled by the transition of an electron from the *L* shell. The energy difference between the *L* shell and the *K* shell appears as the characteristic *K* X-ray

be α_L , α_M The total conversion coefficient is given by the sum of all possible conversion coefficients; that is, $\alpha_T = \alpha_K + \alpha_L + \cdots$.

As an alternative to characteristic X-ray emission in either electron capture or internal conversion process, the transition energy between the two shells can be transferred to an orbital electron, which is then emitted from the atom, if energetically permitted. The process is referred to as the *Auger process*. The electron

emitted is called an Auger electron and is similar to a conversion electron in internal conversion. The vacancy in the shell due to an Auger process is filled by an electron transition from the upper shells, followed by emission of characteristic X-rays or Auger electrons as in internal conversion. Whether a particular vacancy in a given shell will result in the emission of a characteristic X-ray or an Auger electron is a matter of probability. The fraction of vacancies in a given shell that is filled with accompanying X-ray emission and no Auger electron is referred to as the *fluorescence yield*. The fluorescence yield increases with the increasing atomic number of the atom. The transition energy (i.e., the characteristic X-ray energy) between the two shells is always less than the binding energy of an electron in the lower shell and therefore cannot eject it. For example, the characteristic K X-ray energy is always less than the binding energy of an electron, so the latter cannot undergo the Auger process and cannot be emitted as an Auger electron.

2.2 Radioactive Decay Equations

2.2.1 General Equation

As already mentioned, radionuclides are unstable and decay by particle emission, electron capture, or γ -ray emission. The decay of radionuclides is a random process, that is, one cannot tell which atom from a group of atoms will decay at a specific time. Therefore, one can only talk about the average number of radionuclides disintegrating during a period of time. This gives the disintegration rate of that particular radionuclide.

The number of disintegrations per unit time (disintegration rate), -dN/dt, of a radionuclide at any time is proportional to the total number of radioactive atoms present at that time. Mathematically,

$$-dN / dt = \lambda N \tag{2.1}$$

where *N* is the number of radioactive atoms and λ is a *decay constant* that is defined as the probability of disintegration per unit time for the radioactive atom. The disintegration rate, -dN/dt, is termed the radioactivity or simply the activity of a radionuclide and denoted by *A*. It should be clearly understood from the above equation that the same amount of radioactivity means the same disintegration rate for any radionuclide, but the total number of atoms present and the decay constant may be different for different radionuclides. From the above statements, the following equation can be written:

$$A = \lambda N \tag{2.2}$$

From a knowledge of the decay constant and radioactivity of a radionuclide, one can calculate the total number of atoms or the total mass of the radionuclide present (using Avogadro's number, $1 \text{ g} \cdot \text{atom} (\text{g} \cdot \text{atom}) = 6.02 \times 10^{23} \text{ atoms}$).



Equation (2.1) is a differential equation and can be solved by proper integration. The solution of this equation leads to

$$N_t = N_0 e^{-\lambda t} \tag{2.3}$$

where N_0 and N_t are the number of radioactive atoms present at t = 0 and time t, respectively. Equation (2.3) represents the exponential decay of any radionuclide. In terms of radioactivity, Eq. (2.3) may be written as

$$A_t = A_0 e^{-\lambda t} \tag{2.4}$$

The graphical representations of the above equation are given in Figs. 2.7 and 2.8 on linear and semilogarithmic plots, respectively.

2.2.2 Half-Life and Mean Life

Every radionuclide is characterized by a *half-life*, which is defined as the time required to reduce its initial activity to one half. It is usually denoted by $t_{1/2}$ and is

unique for a given radionuclide. The decay constant λ of a radionuclide is related to half-life by

$$\lambda = 0.693 / t_{1/2} \tag{2.5}$$

To determine the half-life of a radionuclide, its radioactivity is measured at different time intervals and plotted on semilogarithmic paper, resulting in a straight line as in Fig. 2.8. The slope of the straight line is λ , from which the half-life is determined by Eq. (2.5). It can also be simply read from the graph as the time difference between the two values of activities where one value is one half of the other. For a very long-lived radionuclide, it is determined by Eq. (2.2) from the knowledge of its activity and the number of atoms present.

From the definition of half-life, it is understood that A_0 is reduced to $A_0/2$ in one half-life of decay, to $A_0/4$, that is, $A_0/2^2$ in two half-lives, to $A_0/8$, that is, $A_0/2^3$ in three half-lives, and so forth. In *n* half-lives of decay, it is reduced to $A_0/2^n$. Thus, the radioactivity A_t at time *t* can be calculated from the initial radioactivity A_0 by

$$A_t = \frac{A_0}{2^n} = \frac{A_0}{2^{(t/t_{1/2})}}$$
(2.6)

Here, the number of half-lives *n* is equal to $(t/t_{1/2})$, where *t* is the time of decay and $t_{1/2}$ is the half-life of the radionuclide. As an example, suppose a radioactive sample with a half-life of 10 days contains 250-mCi radioactivity. The radioactivity of the sample after 23 days would be $250/2^{(23/10)} = 250/2^{2.3} = 250/4.92 = 50.8$ mCi.





Another relevant quantity of a radionuclide is its *mean life*, which is the average life of a group of the radioactive atoms. It is denoted by τ and related to decay constant λ and half-life $t_{1/2}$ as follows:

$$\tau = 1/\lambda \tag{2.7}$$

$$\tau = t_{1/2} / 0.693 = 1.44 t_{1/2} \tag{2.8}$$

In one mean life, the activity of a radionuclide is reduced to 37% of its initial value.

2.2.3 Units of Radioactivity

Radioactivity is expressed in units called *curies*. Historically, it was initially defined as the disintegration rate of 1-g radium, which was considered to be 3.7×10^{10} disintegrations per second. Later the disintegration rate of 1-g radium was found to be slightly different from this value, but the original definition of curie was still retained:

lcurie (Ci)	
$= 3.7 \times 10^{10}$ disintegrations per second	(dps)
= 2.22×10^{12} disintegrations per minute	(dpm)
1millicurie (mCi)	
$=3.7\times10^7$ dps	
$= 2.22 \times 10^{9} \text{dpm}$	
1microcurie (μ Ci)	
$=3.7\times10^4$ dps	
$= 2.22 \times 10^6 \mathrm{dpm}$	

The System Internationale (SI) unit for radioactivity is *becquerel* (Bq), which is defined as one disintegration per second. Thus,

1 becquerel (Bq) = $1dps = 2.7 \times 10^{-11}$ Ci 1 kilobecquerel (kBq) = $10^{3} dps = 2.7 \times 10^{-8}$ Ci 1 megabecquerel (MBq) = $10^{6} dps = 2.7 \times 10^{-5}$ Ci 1 gigabecquerel (GBq) = $10^{9} dps = 2.7 \times 10^{-2}$ Ci 1 terabecquerel (TBq) = $10^{12} dps = 27$ Ci

Similarly,

 $1Ci = 3.7 \times 10^{10} Bq = 37 GBq$ $1mCi = 3.7 \times 10^{7} Bq = 37 MBq$ $1\mu Ci = 3.7 \times 10^{4} Bq = 37 kBq$
2.2.4 Calculations

Two examples of calculations related to radioactivity are presented below.

Problem 2.1

Calculate the total number of atoms and total mass of ¹³¹I present in 5-mCi (185 MBq) ¹³¹I ($t_{1/2} = 8$ d).

Answer

$$\lambda \text{ for}^{131}\text{I} = \frac{0.693}{8 \times 24 \times 60 \times 60} = 1.0 \times 10^{-6} \text{ sec}^{-1}$$

$$A = 5 \times 3.7 \times 10^7 = 1.85 \times 10^8 \text{ dps}$$

Using Eq. (2.2),

$$N = \frac{A}{\lambda} = \frac{1.85 \times 10^8}{1 \times 10^{-6}} = 1.85 \times 10^{14} \text{ atoms}$$

Since 1 g \cdot atom ¹³¹I = 131 g ¹³¹I = 6.02 × 10²³ atoms of ¹³¹I (Avogadro's number),

Mass of ¹³¹I in 5mCi (185 MBq) = $\frac{1.85 \times 10^{14} \times 131}{6.02 \times 10^{23}}$ = 40.3×10⁻⁹ g = 40.3 ng

Therefore, 5-mCi (185 MBq) 131 I contains 1.85×10^{14} atoms and 40.3-ng 131 I.

Problem 2.2

At 11:00 a.m., the ^{99m}Tc radioactivity was measured as 9 mCi (333 MBq) on a certain day. What was the activity at 8:00 a.m. and 4:00 p.m. on the same day ($t_{1/2}$ for ^{99m}Tc = 6 h)?

Answer

Time from 8:00 a.m. to 11:00 a.m. is 3 h;

$$A_t = 9\text{mCi}(333\text{MBq})$$
$$A_0 = ?$$

Using Eq. (2.4),

$$9 = A_0 e^{+0.1155 \times 3}$$
$$A_0 = 9 \times e^{0.3465}$$
$$= 12.7 \text{mCi} (470 \text{ MBq}) \text{ at } 8:00 \text{ a.m.}$$

Time from 11:00 a.m. to 4:00 p.m. is 5 h;

$$A_0 = 9 \text{ mCi}$$

 $A_t = ?$

Using Eq. (2.4),

$$A_t = 9 \times e^{-0.1155 \times 5}$$

= 9 \times e^{-0.5775}
= 5.05 mCi (187 MBq) at 4:00 p.m.

2.3 Successive Decay Equations

2.3.1 General Equation

In the above section, we have derived equations for the activity of any radionuclide that is decaying. Here, we shall derive equations for the activity of a radionuclide that is growing from another radionuclide and, at the same time, is itself decaying.

If a parent radionuclide p decays to a daughter radionuclide d, which in turn decays, then the rate of growth of radionuclide d becomes

$$\frac{dN_d}{dt} = \lambda_p N_p - \lambda_d N_d \tag{2.9}$$

 $\lambda_p N_p$ is the growth rate of the daughter from the parent, and $\lambda_d N_d$ is the decay rate of the daughter. By integration, Eq. (2.9) becomes

$$\left(A_{d}\right)_{t} = \lambda_{d}N_{d} = \frac{\lambda_{d}\left(A_{p}\right)_{0}}{\lambda_{d} - \lambda_{p}} \left(e^{-\lambda_{p}t} - e^{-\lambda_{d}t}\right)$$
(2.10)

Equation (2.10) gives the net activity of radionuclide *d* at time *t* due to the growth from the decay of radionuclide *p*. If there is an initial activity $(A_d)_0$ of radionuclide *d*, then the term $(A_d)_0 e^{-\lambda_d t}$ has to be added to Eq. (2.10). Thus,

$$\left(A_{d}\right)_{t} = \lambda_{d}N_{d} = \frac{\lambda_{d}\left(A_{p}\right)_{0}}{\lambda_{d} - \lambda_{p}} \left(e^{-\lambda_{p}t} - e^{-\lambda_{d}t}\right) + \left(A_{d}\right)_{0}e^{-\lambda_{d}t}$$
(2.11)

2.3.2 Transient Equilibrium

If $\lambda_d > \lambda_p$, that is, $(t_{1/2})_d < (t_{1/2})_p$, then $e^{-\lambda_d t}$ in Eq. (2.11) is negligible compared to $e^{-\lambda_p t}$ when *t* is sufficiently long. Equation (2.11) then becomes

$$\left(A_{d}\right)_{t} = \frac{\lambda_{d}\left(A_{p}\right)_{0}}{\lambda_{d} - \lambda_{p}} e^{-\lambda_{p}t} = \frac{\lambda_{d}\left(A_{p}\right)_{t}}{\lambda_{d} - \lambda_{p}}$$
(2.12)

This relationship is called the *transient equilibrium*. This equilibrium holds true when $(t_{1/2})_p$ and $(t_{1/2})_d$ differ by a factor of about 10–50. It can be seen from Eq. (2.12) that the daughter activity is always greater than the parent activity. Initially, the daughter activity grows owing to the decay of the parent radionuclide, reaches a maximum followed by an equilibrium, and then decays with a half-life of the parent. The time to reach maximum activity is given by

$$t_{\max} = \frac{1.44 \times (t_{1/2})_p \times (t_{1/2})_d \times \ln\left[(t_{1/2})_p / (t_{1/2})_d\right]}{\left[(t_{1/2})_p - (t_{1/2})_d\right]}$$
(2.13)

A typical example of transient equilibrium is ⁹⁹Mo ($t_{1/2} = 66$ h) decaying to ^{99m}Tc ($t_{1/2} = 6.0$ h) represented in Fig. 2.9. Because overall 87% of ⁹⁹Mo decays to ^{99m}Tc, the ^{99m}Tc activity is lower than the ⁹⁹Mo activity in the time activity plot (Fig. 2.9). The ^{99m}Tc activity reaches a maximum in about 23 h, i.e., about four half-lives of ^{99m}Tc, followed by the equilibrium.



Problem 2.3

Yttrium-87 ($t_{1/2}$ = 80 h) decays to ^{87m}Sr ($t_{1/2}$ = 2.83 h). The activity of a pure sample of ⁸⁷Y is calibrated at noon on Wednesday and measured to be 300 mCi (11.1 GBq). Calculate the activity of ^{87m}Sr at 6:00 p.m. on Wednesday and at 6:00 p.m. on Thursday.

Answer

In Eq. (2.10), we have

$$\lambda_p = \frac{0.693}{80} = 0.0087 \,\mathrm{h}^{-1}$$

$$\lambda_d = \frac{0.693}{2.83} = 0.2449 \mathrm{h}^{-1}$$

$$\frac{\lambda_d}{\lambda_d - \lambda_p} = \frac{0.2449}{0.2449 - 0.0084} = 1.0368$$

$$\left(A_{\rm p}\right)_0 = 300 \,\mathrm{mCi}$$

t = 6h (from noon to 6p.m.Wednesday)

$$e^{-\lambda_p t} = e^{-0.0087 \times 6} = 0.9491$$

 $e^{-\lambda_p t} = e^{-0.2449 \times 6} = 0.2301$
 $(A_d)_t = ?$

Using the above values in Eq. (2.10), the activity of 87m Sr at 6:00 p.m. on Wednesday can be calculated as

$$(A_d)_t = 1.0368 \times 300 \times (0.9491 \quad 0.2301) = 223.6 \,\mathrm{mCi}(8.27 \,\mathrm{GBq})$$

For the activity of ^{87m}Sr at 6:00 p.m. on Thursday, we assume a transient equilibrium between ⁸⁷Y and ^{87m}Sr because the half-lives of the parent and daughter nuclides differ by a factor of 28 and more than ten half-lives (i.e., 30 h) of the daughter nuclide have elapsed between noon on Wednesday and 6:00 p.m. on Thursday. Using Eq. (2.12), we have

$$t = 30 \text{h}$$

 $(A_p)_t = 300 \times e^{-0.0087 \times 30} = 231.1 \text{mCi}$
 $(A_d)_t = 1.0368 \times 231.1 = 239.6 \text{mCi}$

Therefore, the activity of ^{87m}Sr at 6:00 p.m. on Thursday is 239.6 mCi (8.87 GBq).

2.3.3 Secular Equilibrium

When $\lambda_d \gg \lambda_p$, that is, the parent half-life is much longer than that of the daughter nuclide, in Eq. (2.12), we can neglect λ_p compared to λ_d . Then Eq. (2.12) reduces to

$$\left(A_d\right)_t = \left(A_p\right)_t \tag{2.14}$$

Equation (2.14) is called the *secular equilibrium* and is valid when the half-lives of the parent and the daughter differ by more than a factor of 100. In secular equilibrium, the parent and daughter radioactivities are equal and both decay with the half-life of the parent nuclide. A typical example of secular equilibrium is ¹³⁷Cs ($t_{1/2} = 30$ y) decaying to ^{137m}Ba ($t_{1/2} = 2.6$ min). A graphical representation of secular equilibrium between ¹¹³Sn ($t_{1/2} = 117$ d) and ^{113m}In ($t_{1/2} = 100$ min) is shown in Fig. 2.10.



Problem 2.4

Germanium-68 has a half-life of 280 days and decays to ⁶⁸Ga, whose half-life is 68 min. The activity of a pure sample of ⁶⁸Ge is calibrated to be 450 mCi (16.7 GBq) at noon on Tuesday. Calculate the activity of ⁶⁸Ga at midnight on Tuesday and at 5:00 p.m. on Wednesday.

Answer

The time from Tuesday noon to midnight Tuesday is 12 h, and the time from Tuesday noon until 5:00 p.m. Wednesday is 29 h. Since the half-lives of ⁶⁸Ge and ⁶⁸Ga differ by a factor of about 5800, a secular equilibrium is established between the two nuclides within 12 h (~11 half-lives of ⁶⁸Ga) and 29 h. The decay of ⁶⁸Ge in a 29-h period is negligible, and therefore the activity of ⁶⁸Ge at both midnight Tuesday and 5:00 p.m. on Wednesday would be approximately 450 mCi (16.7 GBq). Then, according to Eq. (2.14), the activity of ⁶⁸Ga at these times would also be 450 mCi (16.7 GBq).

2.4 Statistics of Counting

Although it is beyond the scope of this book to discuss the details of statistics related to radioactive disintegration, it would be appropriate to describe briefly the salient points of statistics as applied to the measurement of radioactivity. Since nuclear pharmacists and technologists are routinely involved in radioactive counting, the following discussion of statistics will be helpful in determining how long a radioactive sample should be counted and how many counts should be accumulated for better precision and accuracy.

2.4.1 Error, Accuracy, and Precision

In the measurement of any quantity, an *error* or a deviation from the true value of the quantity is likely to occur. There are two types of errors – systematic and random. Systematic errors arise from malfunctioning equipment and inappropriate experimental conditions and can be corrected by rectifying the situation. Random errors arise from random fluctuations in the experimental conditions, for example, high-voltage fluctuations or fluctuations in the quantity to be measured, such as the radioactive decay.

The *accuracy* of a measurement indicates how closely it agrees with the "true" value. The *precision* of a series of measurements describes the reproducibility of the measurement and indicates the deviation from the "average" value. Remember that the average value may be far from the true value of the measurement. The closer the measurement is to the average value, the higher is the precision, whereas the closer the measurement is to the true value, the more accurate is the measurement. Precision can be improved by eliminating the random errors, whereas both the random and systematic errors must be eliminated for better accuracy.

2.4.2 Standard Deviation

The standard deviation for a group of measurements indicates the precision of the measurements. Radioactive disintegration follows the Poisson distribution law, and from this, one can show that if a radioactive sample gives an average or mean count of \bar{n} , then its standard deviation σ is given by

$$\sigma = \sqrt{\overline{n}} \tag{2.15}$$

The mean count with standard deviation is then expressed as

$$\overline{n} \pm \sigma$$

The standard deviations in radioactive measurements indicate the statistical fluctuation of radioactive disintegration. If we make a large number of measurements repeatedly on a radioactive sample giving a mean count \bar{n} , the data are distributed around \bar{n} in a Gaussian form as illustrated in Fig. 2.11. From this distribution, it is found that 68% of these measurements would fall within one standard deviation (σ) on either side of the mean, that is, in the range of $\bar{n} - \sigma \operatorname{to} \bar{n} + \sigma$. This is called the «68% confidence level» for \bar{n} . Similarly, 95% of the measurements will fall within two standard deviations ($\bar{n} - 2\sigma \operatorname{to} \bar{n} + 2\sigma$) and 99% of the data within three standard deviations ($\bar{n} - 3\sigma \operatorname{to} \bar{n} + 3\sigma$). These are designated as the 95% and 99% confidence levels, respectively. Note that Gaussian distribution is symmetrical around \bar{n} with half of the measurements below \bar{n} and the other half above it.

If a single count, *n*, of a radioactive sample is quite large, then n can be estimated as close to \overline{n} and substitute for it in Eq. (2.15) (i.e., $\sigma = \sqrt{n}$). For example, the





standard deviation of the measurement of a radioactive sample giving 10,000 counts will be 100.

A more useful quantity in the statistical analysis of the counting data is the percent standard deviation, which is given by

$$\%\sigma = \frac{\sigma}{n} \times 100 = \frac{100\sqrt{n}}{n} = \frac{100}{\sqrt{n}}$$
 (2.16)

Equation (2.16) indicates that as *n* increases, the $\% \sigma$ decreases, and hence the precision of the measurement increases. Thus, the precision of a count of a radioactive sample can be increased by accumulating a large number of counts. For a count of 10,000, $\% \sigma$ is 1%, whereas for 1,000,000, $\% \sigma$ is 0.1%.

Problem 2.5

How many counts should be collected in a sample in order to have a 1% error at 95% confidence level?

Answer

95% confidence level is 2σ , i.e., $2\sqrt{n}$

$$1\% \operatorname{error} = \frac{2\sigma \times 100}{n} = \frac{2\sqrt{n} \times 100}{n}.$$

Therefore, $1 = \frac{200}{\sqrt{n}}$
 $\sqrt{n} = 200$
 $n = 40,000 \operatorname{counts}$

2.4.3 Standard Deviation of Count Rates

The standard deviation of a count rate σ_c is

 $\sigma_c = \sigma / t$

where σ is the standard deviation of the total count *n* obtained in time *t*. Since *n* is equal to the count rate *c* times the time of counting *t*,

$$\sigma_c = \sqrt{n} / t = \sqrt{ct} / t = \sqrt{c/t}$$
(2.17)

Problem 2.6

A radioactive sample is counted for 8 min and gives 3200 counts. Calculate the count rate and standard deviation for the sample.

Answer

Count rate c = 3200/8 = 400 counts per minute (cpm) Standard deviation $\sigma_c = \sqrt{c/t} = \sqrt{400/8} \approx 7$ Therefore, the average count rate is 400 ± 7 cpm.

S

2.4.4 Propagation of Errors

Situations may arise in which two quantities, *x* and *y*, with their respective standard deviations, σ_x and σ_y , are either added, subtracted, multiplied, or divided. The standard deviations of results of these arithmetic operations are expressed by the following equations:

Addition:
$$\sigma_{x+y} = \sqrt{\sigma_x^2 + \sigma_y^2}$$
 (2.18)

Subtraction :
$$\sigma_{x-y} = \sqrt{\sigma_x^2 + \sigma_y^2}$$
 (2.19)

Multiplication:
$$\sigma_{(x \times y)} = (x \times y) \sqrt{(\sigma_x / x)^2 + (\sigma_y / y)^2}$$
 (2.20)

Division :
$$\sigma_{(x/y)} = (x/y)\sqrt{(\sigma_x/x)^2 + (\sigma_y/y)^2}$$
 (2.21)

Problem 2.7

A radioactive sample gives an average count of 9390 ± 95 , and the counting time for each count is 20 ± 1 min. Calculate the average count rate and its standard deviation.

Answer

Count rate
$$c = \frac{9390}{20} = 470 \text{ cpm}$$

Standard deviation $\sigma_c = (9390/20)\sqrt{(95/9390)^2 + (1/20)^2}$
 $= 470\sqrt{0.0026}$
 $= 470 \times 0.051$
 $= 24$

Thus, the average count rate is 470 ± 24 cpm.

Questions

- 1. Describe how the *N*/*Z* ratio of a radionuclide determines whether a radionuclide would decay by β^- or β^+ -emission or electron capture.
- 2. Why is an antineutrino emitted in β -decay?
- 3. What is the threshold energy for β^+ -emission? If the decay energy between two radionuclides is 1.3 MeV, are both β^+ -emission and electron capture possible?
- 4. Discuss bremsstrahlung and internal conversion. What are the common characteristics of electron capture and internal conversion?
- 5. An excited nucleus with 190-keV energy ejects a *K*-shell electron of an atom by internal conversion. What is the kinetic energy of the electron if the binding energy of the *K*-shell electron is 20 keV?
- 6. The internal conversion coefficient of a 0.169-MeV photon is 0.310. Calculate the abundance in percent of the photon emission.
- 7. Calculate (a) the disintegration rate per minute and (b) the activity in curies and becquerels present in $1\mu g^{111}$ In ($t_{1/2} = 2.8$ d).
- 8. Calculate the total number of atoms and total mass of 99m Tc present in 15-mCi (555 MBq) 99m Tc activity ($t_{1/2} = 6$ h).
- 9. If the radioactivity of ¹⁹⁷Hg ($t_{1/2} = 65$ h) is 100 mCi (3.7 GBq) on Wednesday noon, what is its activity (a) at 8 a.m. the Tuesday before and (b) at noon the Friday after?
- 10. State the specific conditions of transient equilibrium and secular equilibrium.
- 11. The half-lives of ⁹⁹Mo and ^{99m}Tc are 66 h and 6 h, respectively, and both are in transient equilibrium in a sample. If the ⁹⁹Mo activity is 75 mCi (2.8 GBq), what is the activity of ^{99m}Tc? (Assume 87% ⁹⁹Mo decay to ^{99m}Tc.)
- 12. How long will it take for a 10-mCi (370 MBq) sample of ³²P ($t_{1/2} = 14.3$ d) and a 100-mCi (3.7 GBq) sample of ⁶⁷Ga ($t_{1/2} = 3.2$ d) to possess the same activity?
- 13. What is the time interval during which 67 Ga ($t_{1/2} = 3.2$ d) decays to 37% of the original activity?

- 14. For the treatment of a thyroid patient, 100-mCi (3.7 GBq) ¹³¹I is required. What amount of ¹³¹I should be shipped if transportation takes 3 days?
- 15. How much time would it take for the decay of eight ninth of a sample of ⁶⁸Ge whose half-life is 270.8 days?
- 16. What is the half-life of a radionuclide if a sample of it gives 10,000 cpm and 2 h later gives 3895 cpm?
- 17. Iodine-127 is the only stable isotope of iodine. What modes of decay would you expect for ¹²⁵I and ¹³²I?
- 18. If a radionuclide decays for a time interval equal to the mean life of the radionuclide, what fraction of the original activity has decayed?
- 19. Draw a graph of the following activity versus time and find the half-life of the radionuclide.

Time (h)	cpm
4	8021
9	5991
15	4213
20	3153
26	2250
30	1789
38	1130

- 20. A radioactive sample gives 12,390 counts in 12 min. (a) What are the count rate and standard deviation of the sample? (b) If the sample contained a background count rate of 50 cpm obtained from a 2-min count, what would be the net count rate of the sample and its standard deviation?
- 21. How many counts of a radioactive sample are to be collected in order to have a 2% error at 95% confidence level?
- 22. How many standard deviations of a mean count of 82,944 is 576?
- 23. What is the minimum number of counts that would give 1 standard deviation confidence level and no more than a 3% error?

Suggested Reading

- Cherry SR, Sorensen JA, Phelps ME. Physics in nuclear medicine. 4th ed. Philadelphia: Saunders; 2012.
- Friedlander G, Kennedy JW, Macias ES, Miller JM. Nuclear and radiochemistry. 3rd ed. New York: Wiley; 1981.
- Saha GB. Physics and radiobiology of nuclear medicine. 4th ed. New York: Springer; 2013.

Instruments for Radiation Detection and Measurement

In nuclear medicine, it is necessary to ascertain the presence, type, intensity, and energy of radiations emitted by radionuclides, and these are accomplished by radiation-detecting instruments. The two commonly used devices are gas-filled detectors and scintillation detectors with associated electronics. These instruments are described below.

3.1 Gas-Filled Detectors

The operation of a gas-filled detector is based on the ionization of gas molecules by radiations, followed by collection of the ion pairs as current with the application of a voltage between two electrodes. The measured current is primarily proportional to the applied voltage and the amount of radiations. A schematic diagram of a gas-filled detector is shown in Fig. 3.1.

The two most commonly used gas-filled detectors are ionization chambers and Geiger–Müller (GM) counters. The primary difference between the two devices lies in the operating voltage that is applied between the two electrodes. Ionization chambers are operated at 50–300 V, whereas the GM counters are operated at around 1000 V. Examples of ionization chambers are "Cutie-Pie" counters and dose calibrators, which are used for measuring high-intensity radiation sources, such as output from X-ray machines (Cutie-Pie) and activity of radiopharmaceuticals (dose calibrators). The GM counters are used for detecting low-level beta and gamma radiations.

3.1.1 Dose Calibrators

The dose calibrator is one of the most essential instruments in nuclear medicine for measuring the activity of radionuclides for formulating and dispensing radiopharmaceuticals. It is a cylindrically shaped, sealed chamber made with two concentric

[©] Springer International Publishing AG 2018

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3_3



walls and a central well. It is filled with argon and traces of halogen at high pressure. Its operating voltage is about 150 V. A typical dose calibrator is shown in Fig. 3.2.

Because radiations of different types and energies produce different amounts of ionization (hence current), equal activities of different radionuclides generate different quantities of current. For example, current produced by 1 mCi (37 MBq)^{99m}Tc is different from that by 1 mCi (37 MBq)¹³¹I. Isotope selectors are the feedback resistors to compensate for differences in ionization (current) produced by different radionuclides so the equal activities produce the same reading. In most dose calibrators, the isotope selectors for commonly used radionuclides are push-button types,



whereas those for other radionuclides are set by a continuous dial. The settings of isotope selectors are basically the calibration factors for different radionuclides, which are determined by measuring the current produced by 1 millicurie of each radionuclide. The unknown activity of a radionuclide is then measured by the current it produces divided by the calibration factor for that radionuclide, which is displayed in the appropriate unit on the dose calibrator. An activity range selector is a variable resistor that adjusts the range of activity (μ Ci, mCi, Ci or MBq, GBq) for display.

For measurement of the activity of a radionuclide, one first sets the calibration factor for the radionuclide using the appropriate push-button or dial setting. Then the sample in a syringe, vial, or any other appropriate container is placed inside the chamber well of the dose calibrator, whereupon the reading of activity is displayed on the digital meter of the dose calibrator. The quality control methods of the dose calibrators are discussed in Chap. 8.

3.1.2 Geiger–Müller Counters

The GM counters are used for the measurement of exposure delivered by a radiation source and called *survey meters*. A typical GM survey meter is shown in Fig. 3.3. The GM counter is one of the most sensitive detectors and can be constructed in different configurations. One end of the detector is made of a thin mica window that allows passage of β -particles and low-energy gamma radiations that would otherwise be stopped by the metal cover provided for detection of gamma radiations. It is usually battery operated and operates as a ratemeter. The readings are given in microroentgen (μ R) per hour, milliroentgen (mR) per hour, roentgen (R) per hour, or counts per minute (cpm). The GM counters do not have any energy-discriminative capabilities. Some GM counters are equipped with audible alarms or flashing light alarms that are triggered by radiations above a preset intensity. The latter kind is called an *area monitor*. The GM counters are primarily used for area survey for contamination with lowlevel activity. According to Nuclear Regulatory Commission (NRC) regulations, these survey meters must be calibrated annually with standard sources such as ²²⁶Ra and ¹³⁷Cs.

3.2 Scintillation-Detecting Instruments

A variety of scintillation- or γ -ray-detecting equipment is currently used in nuclear medicine. The well counters, thyroid probes, and γ or scintillation cameras are most commonly used. All these instruments are γ -ray-detecting devices and consist of a collimator (excluding well counter); sodium iodide detector; photomultiplier tube; preamplifier; pulse height analyzer; *X*, *Y* positioning circuit (only in scintillation cameras); and display or storage. Basically, γ -rays from a source interact in the sodium iodide detector, and light photons are emitted. The latter strike the photocathode of a photomultiplier (PM) tube, and a pulse is generated at the end of the PM tube. The pulse is first amplified by a preamplifier and then by a linear amplifier. A pulse height analyzer sorts out the amplified pulses according to the desired energy of the γ -ray and finally feeds the pulse into a scaler, magnetic tape, computer, cathode ray tube, or X-ray film.

3.2.1 Collimator

In all nuclear medicine equipment for imaging, a collimator is attached to the face of a sodium iodide detector to limit the field of view so that all radiations from outside the field of view are prevented from reaching the detector. Collimators are made of lead and have a number of holes of different shapes and sizes. In thyroid probes, they are single bore and cylindrical in shape. In scintillation cameras, collimators are classified as parallel hole, diverging, pinhole, and converging (see later), depending on the type of focusing.

When the number of holes in a collimator is increased, the sensitivity of the detector increases, but there is a comparable loss of septal thickness that results in septal penetration by relatively high-energy γ -rays and hence a loss in spatial resolution. One can increase the resolution¹ or the detail of the image by decreasing the size of the holes in a given collimator or increasing the length of the collimator. This results in a decrease in the sensitivity (i.e., γ -ray detection efficiency) of the camera.

3.2.2 Detector

For γ -ray detection, a sodium iodide crystal doped with a very small amount of thallium [NaI(Tl)] is most commonly used. Other detectors such as lithium-drifted germanium detector [Ge(Li)], bismuth germanate (BGO), barium fluoride (BaF₂),

¹Resolution is the minimum distance between two points in an image that can be detected by a detecting device.

gadolinium oxyorthosilicate (GSO), and lutetium oxyorthosilicate (LSO) are also used for scintillation detection.

The choice of NaI(Tl) crystals for γ -ray detection is primarily due to their reasonable density (3.67 g/cm³) and high atomic number of iodine (Z = 53) that result in efficient production of light photons (about one light photon per approximately 30 eV) upon interaction with γ -rays in the presence of a trace amount of thallium (0.1–0.4 mole %). The light generated in the crystal is directed toward the PM tube by coating the outside surface of the crystal with reflector material such as magnesium oxide or by using light pipes between the crystal and the PM tube. Sodium iodide is hygroscopic, and absorbed water causes color changes that distort light transmission to the PM tubes. Therefore, the crystals are hermetically sealed in aluminum containers. Room temperature should not be abruptly changed, because such changes in temperatures can cause cracks in the crystal. Also, mechanical stress must be avoided in handling them, because NaI crystals are very fragile.

The NaI(Tl) detectors of different sizes are used in different instruments. In welltype NaI(Tl) detectors, the crystals have a hole in the middle deep enough to cover the counting sample almost completely. In these crystals, counting efficiency is very high and no collimator is needed. In thyroid probes and well counters, the smaller cylindrical but thicker (7.6×7.6 cm or 12.7×12.7 cm) NaI(Tl) crystals are used, whereas in scintillation cameras, the larger rectangular (33-59 cm) and thinner (0.64-1.9 cm) crystals are employed.

3.2.3 Photomultiplier Tube

A PM tube consists of a light-sensitive photocathode at one end, a series (usually ten) of metallic electrodes called dynodes in the middle, and an anode at the other end – all enclosed in a vacuum glass tube. The PM tube is fixed on to the NaI(Tl) crystal with the photocathode facing the crystal with a special optical grease. The number of PM tubes in the thyroid probe and the well counter is one, whereas in scintillation cameras it varies from 19 to 94 which are attached on the back face of the NaI(Tl) crystal.

A high voltage of ~1000 V is applied from the photocathode to the anode of the PM tube in steps of ~100 V between dynodes. When a light photon from the NaI(Tl) crystal strikes the photocathode, photoelectrons are emitted, which are accelerated toward the immediate dynode by the voltage difference between the electrodes. The accelerated electrons strike the dynode, and more secondary electrons are emitted, which are further accelerated. The process of multiplication of secondary electrons continues until the last dynode is reached, where a pulse of 10^{5} – 10^{8} electrons is produced. The pulse is then attracted to the anode and finally delivered to the preamplifier.

3.2.4 Preamplifier

The pulse from the PM tube is small in amplitude and must be amplified before further processing. It is initially amplified with a preamplifier that is connected to the PM tube. A preamplifier is needed to adjust the voltage of the pulse shape and match the impedance levels between the detector and subsequent components so that the pulse is appropriately processed by the system.

3.2.5 Linear Amplifier

The output pulse from the preamplifier is further amplified and properly shaped by a linear amplifier. The amplified pulse is then delivered to a pulse height analyzer for analysis as to its voltage. The amplification of the pulse is defined by the amplifier gain given by the ratio of the amplitude of the outgoing pulse to that of the incoming pulse, and the gain can be adjusted in the range of 1-1000 by gain controls provided on the amplifier. The amplitudes of output pulses normally are of the order of 0-10 V.

3.2.6 Pulse Height Analyzer

Gamma rays of different energies can arise from a source, either from the same radionuclide or from different radionuclides, or due to scattering of γ -rays in the source. The pulses coming out of the amplifier may then be different in amplitude due to differing γ -ray energies. The pulse height analyzer (PHA) is a device that selects for counting only those pulses falling within preselected voltage amplitude intervals or "channels" and rejects all others. This selection of pulses is made by control knobs, called the lower level and upper level, or the base and window, provided on the PHA. Proper choice of settings of these knobs determines the range of γ -ray energies that will be accepted for further processing such as recording, counting, and so on. In scintillation cameras, these two knobs are normally replaced by a peak voltage control and a percent window control. The peak voltage control relates to the desired γ -ray energy, and the percent window control indicates the window width in percentage of the desired γ -ray energy, which is set symmetrically on each side of the peak voltage.

The above mode of counting is called *differential counting*, in which only pulses of preselected energy are counted. If γ -rays of all energies or all γ -rays of energies above a certain preselected energy need to be counted, the mode of counting is called *integral counting*, in which case only the lower level or baseline is operative and the window mechanism is bypassed.

A pulse height analyzer normally selects only one range of pulses and is called a *single-channel analyzer* (SCA). A multichannel analyzer (MCA) is a device that can simultaneously sort out pulses of different energies into a number of channels. By using an MCA, one can obtain simultaneously a spectrum of γ -rays of different energies arising from a source (Fig. 3.4).

3.2.7 Display or Storage

Information processed by the PHA is normally given in the form of pulses and counts that are stored for further processing. Counts can be recorded for preset counts or time. In thyroid probes and well counters, counts are displayed on a scaler,



Fig. 3.4 A γ -ray spectrum of different photon energies taken with a NaI(Tl) detector coupled to a multichannel analyzer

whereas in scintillation cameras, these counts are stored in a computer and processed further to form images.

3.3 Scintillation Camera

A scintillation camera, also known as a gamma camera, basically operates on the same principles as described above. It consists of a collimator; detector; X, Y positioning circuit; PHA; and display or storage. Although PM tubes, preamplifiers, and linear amplifiers are also basic components of gamma cameras, their functions are the same as described above and, therefore, will not be discussed further here. A schematic electronics diagram of a scintillation camera is illustrated in Fig. 3.5, and a typical scintillation camera is shown in Fig. 3.6.

3.3.1 Collimator

As already mentioned, classification of collimators used in scintillation cameras depends primarily on the type of focusing, and also on the septal thickness of the holes. Depending on the type of focusing, collimators are classified as parallel hole, pinhole, converging, and diverging types; these are illustrated in Fig. 3.7.

Pinhole collimators are used in imaging small organs such as thyroid glands. Converging collimators are employed when the target organ is smaller than the size of the detector, whereas diverging collimators are used in imaging organs such as lungs that are larger than the size of the detector. Parallel hole collimators are most commonly used in nuclear medicine procedures.



Fig. 3.5 A schematic electronics diagram of a scintillation camera







Pinhole collimator



Converging collimator

Fig. 3.7 Several collimator designs

Fig. 3.6 A SPECT scintillation camera, Philips BrightView X (Courtesy of Philips Healthcare) Parallel hole collimators are classified as high-resolution, all-purpose, and highsensitivity types. Most manufacturers keep the size and number of holes the same for all these collimators, but only change the thickness. High-sensitivity collimators are made with smaller thickness than all-purpose collimators, whereas high-resolution collimators are made thickest of all. The deterioration in spatial resolution is related to the thickness of the collimator; thus, the high-sensitivity collimator shows the sharpest drop in spatial resolution, followed in order by the all-purpose and high-resolution collimators. For all parallel hole collimators, the spatial resolution is best at the collimator face and deteriorates with increasing distance between the collimator and the object. It is therefore desirable to image patients in close proximity to the collimator face.

3.3.2 Detector

The NaI(Tl) crystals used as the detector in scintillation cameras are mostly rectangular in shape and have the dimension between 33×43 cm and 37×59 cm with thickness varying between 0.64 cm and 1.9 cm. The most common thickness is 0.95 cm. The 0.64-cm thick detectors are usually used in portable cameras for nuclear cardiac studies.

Increasing the thickness of a crystal increases the probability of complete absorption of γ -rays and hence the sensitivity of the detector. However, there is a probability of multiple interactions of a γ -ray in a thick crystal, and the *X*, *Y* coordinates of the point of γ -ray interaction can be obscured (see later). This results in poor resolution of the image of the organ. For this reason, thin NaI(Tl) crystals are used in scintillation cameras, but this decreases the sensitivity of the camera since many γ -rays escape from the detector without interaction and only a few γ -rays interact in the detector.

3.3.3 X, Y Positioning Circuit

When a γ -ray interacts in the crystal, its exact location is determined by the *X*, *Y* positioning circuit in conjunction with an array of PM tubes. Many PM tubes (19–94) are mounted on the NaI(Tl) crystal in scintillation cameras. After γ -ray interaction in the crystal, a maximum amount of light will be received by the PM tube nearest to the point of interaction, whereas other PM tubes will receive an amount of light directly proportional to the solid angle subtended by the PM tube at the point of interaction. The *X*, *Y* positioning circuit sums up the output of different PM tubes and produces *X* and *Y* pulses in direct proportion to the *X*, *Y* coordinates of the point of interaction of γ -rays and thus gives an image of the distribution of activity in a source. The pulses are stored in a computer, for further processing.

The larger the number of PM tubes, the better the depiction on the image of the X, Y coordinates of the point of γ -ray interaction, that is, better resolution of the image. Also, the higher the energy of γ -rays, the better the resolution, because they produce more light in the crystal. However, it should be remembered that very high-energy γ -rays can penetrate the collimator septa and thus blur the image.

Low-energy γ -rays (<80 keV) are largely scattered in the source and the crystal and give poor resolution.

3.3.4 Pulse Height Analyzer

It is a circuit that sums up the output of all PM tubes to produce a pulse known as the Z pulse that represents the energy of a γ -ray. The SCA analyzes the amplitude of the Z pulses and selects only those of desired energy by the use of appropriate peak energy and percent window settings. In many scintillation cameras, the energy selection is made automatically by push-button-type isotope selectors designated for different radionuclides such as ¹³¹I, ^{99m}Tc, and so on. In some scintillation cameras, two or three SCAs are used to select simultaneously two or three γ -rays of different energies, particularly while imaging with ⁶⁷Ga and ¹¹¹In that possess two or three predominant γ -rays. For most studies, a 20% window, centered on the photopeak, is used.

It should be pointed out that X, Y pulses are accepted only if the Z pulse is within the energy range selected by the PHA. If the Z pulses are outside this range, then X, Y pulses are discarded.

3.3.5 Digital Image

The following discussion is presented for understanding the principle of image formation with pulses produced by interaction of radiation with detectors. Because computers used in nuclear medicine operate with digital numbers, they cannot process analog signals from scintillation cameras that are continuous in time. The analog signals need to be digitized, which is accomplished by an electronic circuit called the analog-to-digital (ADC) circuit. Digitization is performed by converting the amplitudes of the X and Y signals into binary digits (bits). In the binary system, bits are expressed by only two digits, 0 and 1, raised to the powers of 2, instead of the powers of 10 in the decimal system. Typically, 6-bit $(2^6 = 64)$, 8-bit $(2^8 = 256)$, or 12-bit (2^{12} = 4096) ADCs are available for digitization. A 6-bit ADC will digitize the X and Y pulses to be stored in a 64×64 matrix in the computer memory. Each element of the matrix is called a pixel. Since the maximum values of X and Y pulses are assumed to equal the diameter of the detector, the detector area is considered to be equal to the matrix size, i.e., 64×64 , and each pixel of the matrix in the computer memory corresponds to a specific location of the detector. X and Y signals of varying magnitude arising from the different positions of the detector would fall into corresponding pixels between (0, 0) and (64, 64) after digitization by the ADC.

Following an interaction of a photon in the detector, the Z pulse (energy) is digitized by the ADC in appropriate bits, and if it falls within the acceptable range of energy, then it triggers the digitization of the corresponding X and Y signals by the ADC. Based on the digitized values of X, Y signals, one count is added to the corresponding (X, Y) pixel in the matrix in the computer. Many counts are accumulated for statistical accuracy in the same pixel corresponding to the X, Y signals of the same magnitude from many photon interactions. A digital image is generated after X, Y signals from all photon interactions are processed for a set period of time. The image can be displayed later on a monitor in different color shades. Nowadays, most modern gamma cameras use digital techniques in image formation and are called the digital scintillation cameras.

3.3.6 Display and Storage

Currently, most cameras employ digital computers in acquiring, storing, and processing of image data. Some cameras have built-in computers and use a single console for both the camera and the computer, while others have stand-alone computers that are custom-designed for the specific camera. In institutions having several scintillation cameras, a single, large-capacity computer is interfaced with all cameras to acquire and process the data. Instant images can be seen on a computer monitor as the data are collected. This is essential for positioning the detector on the organ of interest. Data are collected for a preset time or counts. Software for different purposes is normally provided by the commercial vendors. However, software for specific needs can be developed by an experienced computer specialist, if available in the nuclear medicine department. Data from patient studies are archived for later processing. This is accomplished by storing them in a computer with a large memory using picture archiving communication systems (PACS).

3.4 Tomographic Imagers

Detailed description for tomographic imagers is available in standard nuclear medicine physics books, and only a brief outline is presented here. A basic limitation of the scintillation cameras is that they depict images of three-dimensional activity distributions in two-dimensional displays. Images of structures in the third dimension, depth, are obscured by the underlying and overlying structures. One way to solve this problem is to obtain images at different angles around the patient such as anterior, posterior, lateral, and oblique projections. However, success of the technique is limited because of the complexity of structures surrounding the organ of interest. Currently, tomographic techniques are employed to delineate the depth of the object of imaging.

The common tomographic technique is computed tomography, which is based on rigorous mathematical algorithms, to reconstruct the images at distinct focal planes (slices). Simulated illustrations of four tomographic slices of the heart are shown in Fig. 3.8. In nuclear medicine, two types of computed tomography are employed based on the type of radionuclides used: single-photon emission computed tomography (SPECT), which uses γ -emitting radionuclides such as ^{99m}Tc, ¹²³I, ⁶⁷Ga, ¹¹¹In, and so forth, and positron emission tomography (PET), which uses β^+ emitting radionuclides such as ¹¹C, ¹³N, ¹⁵O, ¹⁸F, ⁶⁸Ga, ⁸²Rb, and so forth.



3.4.1 Single-Photon Emission Computed Tomography

The most common SPECT systems consist of a typical gamma camera with one to three NaI(Tl) detector heads mounted on a gantry, an online computer for acquisition and processing of data, and a display system. The detector head rotates around the long axis of the patient at small angle increments $(3-10^{\circ})$ for 180° or 360° angular sampling. The data are stored in a 64×64 or 128×128 matrix in the computer for later reconstruction of the images of the planes (slices) of interest. Transverse, sagittal, and coronal images are obtained from the collected data. Examples of SPECT images are shown in Chap. 13. Details of SPECT are available in standard nuclear medicine physics books.

3.4.2 Positron Emission Tomography

The PET is based on the detection in coincidence of the two 511-keV photons emitted in opposite directions after annihilation of a positron from a positron emitter and an electron in the medium. Two photons are detected by two detectors in coincidence, and data collected over many angles around the body axis of the patient are used to reconstruct the image of the activity distribution in the slice of interest. Such coincidence counting obviates the need for a collimator to define the field of view. A schematic diagram of the PET system using four pairs of detectors is illustrated in Fig. 3.9.

The detectors are primarily made of bismuth germanate (BGO), NaI(Tl), lutetium oxyorthosilicate (LSO), gadolinium oxyorthosilicate (GSO), or lutetium yttrium oxyorthosilicate (LYSO). Different manufacturers use detectors of their choice.

PET systems use multiple detectors distributed in two to eight circular, hexagonal, or octagonal circumferential rings around the patient. Each detector is connected to the opposite detector by a coincidence circuit. Thus, all coincident counts from different slices over 360° angles around the patient are acquired simultaneously in a



Fig. 3.9 Schematic diagram of a PET system using four pairs of detectors

 64×64 , 128×128 , or higher matrix in a computer. The data are then processed to reconstruct the images depicting the activity distribution in each slice. Examples of PET images are illustrated in Chap. 13. Readers are referred to books on physics in nuclear medicine for further details.

3.4.3 PET/CT, PET/MR, and SPECT/CT

For precise localization of lesions, PET or SPECT images are often fused with CT or MR images, resulting in PET/CT(MR) or SPECT/CT(MR) images, which are particularly useful in assessing the effectiveness of tumor treatments. In this method, functional PET or SPECT images are coregistered with anatomical CT or MR images by aligning the two images with respect to the matrix size, the voxel intensity, and the rotation. Algorithm has been developed by commercial vendors for coregistration of images of different modalities, namely, Siemens Medical Solutions' Syngo fusion D and TrueD, Philips Healthcare's Syntegra, MIM VISTA's MIM, and so on. Coregistered images are displayed side by side or overlaid on each other in color or gray scale. Patient's motion and involuntary movement of internal organs add to the uncertainty of coregistration. An overall error of 2–3 mm in alignment is not uncommon. To circumvent uncertainty in positioning of images from different equipment, an integrated system have been developed, in which both PET and CT units or SPECT and CT units are mounted on a common support with the CT unit in the front and the PET or SPECT unit in the back next to CT. Both units use the same gantry and a common imaging table. The CT unit is an X-ray producing unit, which consists of a cathode filament that emits electrons by application of a voltage and a rotating tungsten anode. Bremsstrahlung and characteristic X-rays are produced when accelerated electrons impinge upon the tungsten target. The CT

transmits the X-ray beam through the patient's body, and the transmitted beam is detected by solid detectors such as ceramics, gemstone, etc. In the full-ring method, the X-ray unit is rotated around the patient, and the transmitted beam is detected by an array of fixed detectors around 360°, whereas in the arc method, the X-ray tube and the detector mechanically tied at 180° are rotated together around the patient. Data acquired are stored in the computer, and images are formed by using various reconstruction algorithms. CT scanners can provide many slices of images such as 6, 16, 32, 64, 128, etc. Next, PET or SPECT images of the patient are obtained, and fusion of these images with CT images is accomplished by various algorithms mentioned above.

When X-rays are projected through the patient's body, the beam is attenuated by the tissue. The extent of attenuation depends on the density of the body tissue affecting the image formation. Algorithms have been developed for attenuation correction using CT scans in PET/CT or SPECT/CT scanning, obviating the need for a separate lengthy transmission scan using a radioactive source. Initially, a bank CT scan is obtained without the patient in the scanner, followed by a CT transmission scan of the patient, and then PET or SPECT images are obtained. Attenuation correction factors are calculated from the blank and transmission scans and are then applied to the PET or SPECT images. Attenuation corrections are easier to apply in PET/CT than SPECT/CT, because of the nature of physics involved in the coincidence detection of photons in PET. While PET/CT is more commonly practiced in nuclear medicine, SPECT/CT, however, is growing rapidly with the enormous advancement in software development and improved attenuation correction. Readers are referred to standard physics books on these topics for further details.

MR imaging is based on the magnetic behavior of nuclear spins (protons) in living species. When a patient is placed in side the bore of a MR machine, the protons in the body randomly line up parallel or antiparallel to the magnetic field (Bo) of the machine, although parallel spins are somewhat more in number causing a net magnetization (M_z). When a radiofrequency (RF) pulse is applied parallel to M_z , the latter flips toward the X, Y plane at 90° or 180° depending on the direction of RF pulse, and spins remain excited. When RF is shut off, the flipped spins reverse to original M_z losing excitation energy by spin–lattice interaction (T1) and spin–spin (T2) interaction. The loss in energy appears as an MR signals that are used in the formation of an image. The MR image is coregistered with the PET image for better delineation of lesions in patients. Since MR does not involve any radiation, unlike in PET/CT, attenuation correction in PET/MR is complicated, and readers are referred to MR physics books.

Questions

- 1. What are the differences between an ionization chamber and a Geiger–Müller counter?
- 2. What is the function of a push-button isotope selector on a dose calibrator?

- Can you discriminate between 140-keV and 364-keV γ-rays by a Geiger– Müller counter?
- 4. What type of instruments would you use for detection of (a) X-ray beam exposure, (b) spill of 1 mCi (37 MBq) ²⁰¹Tl, and (c) 10 mCi (370 MBq) ^{99m}Tc?
- 5. Describe how a scintillation camera works. Explain why the following are used in a scintillation camera: (a) a collimator, (b) many PM tubes, and (c) a thin NaI(Tl) crystal.
- 6. Define the resolution and sensitivity of a scintillation camera.
- 7. Describe how a digital computer works.
- 8. Describe the principles of tomographic imaging.
- 9. What is the difference between SPECT and PET?
- 10. In PET/CT imaging, what are the two purposes of CT imaging?
- 11. What is the common collimator used in nuclear medicine?
- 12. What is the common thickness of NaI(Tl) in scintillation cameras?

Suggested Reading

Bushberg JT, Seibert JA, Leidholdt EM Jr, Boone JM. The essential physics of medical imaging. 3rd ed. Philadelphia: Lippincott Williams & Wilkins; 2011.

Cherry SR, Sorensen JA, Phelps ME. Physics in nuclear medicine. 4th ed. Philadelphia: Saunders; 2012.

Hendee WR, Ritenour ER. Medical imaging physics. 4th ed. Hoboken: Wiley; 2002.

Saha GB. Physics and radiobiology of nuclear medicine. 4th ed. New York: Springer; 2013.

Production of Radionuclides

In 1896, Becquerel discovered the natural radioactivity in potassium uranyl sulfate. Since then, Pierre and Marie Curie, E. Rutherford, and F. Soddy all made tremendous contributions to the discovery of many other radioactive elements. The work of all these scientists has shown that all elements found in nature with an atomic number greater than 83 (bismuth) are radioactive. Artificial radioactivity was first reported by I. Curie and F. Joliot in 1934. These scientists irradiated boron and aluminum targets with α -particles from polonium and observed positrons emitted from the target even after the removal of the α -particle source. This discovery of induced or artificial radioactivity opened up a brand new field of tremendous importance. Around the same time, the discovery of the cyclotron, neutron, and deuteron by various scientists facilitated the production of many more artificial radioactivities. At present, more than 3400 radionuclides have been produced artificially in the cyclotron, the reactor, and the linear accelerator.

Radionuclides used in nuclear medicine are mostly artificial ones. These are primarily produced in a cyclotron or a reactor. The type of radionuclide produced in a cyclotron or a reactor depends on the irradiating particle, its energy, and the target nuclei. Since they are expensive, the facilities having such equipment are limited and supply radionuclides to remote facilities that do not possess them. Very shortlived radionuclides are available only in the institutions that have the cyclotron or reactor facilities; they cannot be supplied to remote institutions or hospitals because they decay rapidly. For remote facilities, however, there is a secondary source of radionuclides, particularly short-lived ones, which is called a radionuclide generator discussed in detail in the next chapter.

4.1 Cyclotron-Produced Radionuclides

In a cyclotron, charged particles such as protons, deuterons, α -particles, ³He particles, and so forth are accelerated in circular paths in so-called dees A and B under vacuum by means of an electromagnetic field (Fig. 4.1). These accelerated particles

[©] Springer International Publishing AG 2018

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3_4



can possess a few kiloelectron volts (keV) to several billion electron volts (BeV) of energy depending on the design and type of the cyclotron. Since the charged particles move along the circular paths under the magnetic field with gradually increasing energy, the larger the radius of the particle trajectory, the higher the energy of the particle. In a given cyclotron, this relationship of energy to radius is definitely established. The particle beam can be deflected by a deflector D to provide an external beam through a window W. Heavy ions such as ¹⁶O, ¹⁴N, and ³²S have also been successfully accelerated in heavy-ion accelerators.

When targets of stable elements are irradiated by placing them in the external beam of the accelerated particles or in the internal beam at a given radius in a cyclotron, the accelerated particles irradiate the target nuclei and nuclear reactions take place. In a nuclear reaction, the incident particle may leave the nucleus after interaction, leaving some of its energy in it, or it may be completely absorbed by the nucleus, depending on the energy of the incident particle. In either case, a nucleus with excitation energy is formed, and the excitation energy is disposed of by the emission of nucleons (i.e., protons and neutrons). Particle emission is followed by γ -ray emission when the former is no longer energetically feasible. Depending on the energy deposited by the incident particle, a number of nucleons are emitted randomly from the irradiated target nucleus, leading to the formation of different nuclides. As the energy of the irradiating particle is increased, more nucleons are emitted, and therefore a much greater variety of nuclides are produced.

Each nuclear reaction for the production of a nuclide has a definite threshold or Q energy, which is either absorbed or released in the reaction. This energy requirement arises from the difference between the masses of the target nucleus plus the irradiating particle and the masses of the product nuclide plus the emitted particles. In nuclear reactions requiring the absorption of energy, the irradiating particles must

possess energy above the threshold energy; otherwise, the nuclear reaction would not take place. Furthermore, if the irradiating or emitted particles are charged, then an additional Coulomb energy due to the Coulomb barrier between the charged particle and the target nucleus or the emitting nucleus must be added to the Q value for the nuclear reaction to occur.

An example of a simple cyclotron-produced radionuclide is ¹¹¹In, which is produced by irradiating ¹¹¹Cd with 12-MeV protons in a cyclotron. The nuclear reaction is written as follows:

111
Cd(p,n)¹¹¹In

where ¹¹¹Cd is the target, the proton p is the irradiating particle, the neutron n is the emitted particle, and ¹¹¹In is the product radionuclide. In this case, a second nucleon may not be emitted because there may not be enough energy left after the emission of the first neutron. The excitation energy that is not sufficient to emit any more nucleons will be dissipated by γ -ray emission.

As another example, relatively high-energy nuclear reactions induced in ⁸⁹Y by irradiation with 40-MeV protons are listed below:

⁸⁹ Y + p(40 MeV)
$$\rightarrow$$
⁸⁹ Zr + n
 \rightarrow ⁸⁹ Y + p
 \rightarrow ⁸⁸ Zr + 2n
 \rightarrow ⁸⁸ Y + pn
 \rightarrow ⁸⁸ Sr + 2p
 \rightarrow ⁸⁷ Zr + 3n
 \rightarrow ⁸⁷ Y + p2t

Although all reactions mentioned in the above example are feasible, the most probable reactions are (p, 3n) and (p, p2n) reactions with 40-MeV protons.

As can be understood, radionuclides produced with atomic numbers different from those of the target isotopes theoretically should not contain any stable ("cold" or "carrier") isotope detectable by ordinary analytical methods, and such preparations are called *carrier-free*. In practice, however, it is impossible to have these preparations without the presence of any stable isotopes. Another term for these preparations is *no carrier added* (NCA), meaning that no stable isotope has been added purposely to the preparations.

The target material for irradiation must be pure and preferably monoisotopic or at least enriched isotope in order to avoid the production of extraneous radionuclides. The energy and type of the irradiating particle must be chosen so that contamination with undesirable radionuclides resulting from extraneous nuclear reactions can be avoided. Since various isotopes of different elements may be produced in a particular irradiating system, it is necessary to isolate isotopes of a single element; this can be accomplished by appropriate chemical methods such as solvent extraction, precipitation, ion exchange, and distillation. Cyclotron-produced radionuclides are usually neutron deficient and therefore decay by β^+ -emission or electron capture. Considerable interest has developed for the production of short-lived radionuclides and their clinical uses because of the availability of the positron emission tomography (PET) imaging systems. Among them are the key radionuclides such as ¹¹C, ¹³N, ¹⁵O, and ¹⁸F, which decay by positron emission (hence annihilation radiations of 511 keV). These positron emitters are useful in imaging by PET. Because of the short half-lives, these are produced in medical cyclotrons normally located in healthcare facilities. A medical cyclotron is a small version of a cyclotron that provides low-energy charged particles of high intensity and is used primarily for production of radionuclides for medical applications. In some medical cyclotrons, both deuterons and protons can be accelerated alternately, as needed.

Methods of preparation of several useful cyclotron-produced radionuclides are described below.

4.1.1 Gallium-67

Gallium-67 ($t_{1/2}$ = 78.2 h) decays to ⁶⁷Zn by 100% EC with concomitant γ -ray emissions of 93 keV (40%), 184 keV (20%), 300 keV (17%), and 393 keV (5%). Gallium-67 is produced by several nuclear reactions such as ⁶⁶Zn (d, n) ⁶⁷Ga (deuteron is denoted d), ⁶⁸Zn (p, 2n) ⁶⁷Ga, and ⁶⁴Zn (α , p) ⁶⁷Ga. A pure natural zinc target or enriched zinc isotope in the form of oxide is irradiated with 20-MeV protons, 8-MeV deuterons, or 23-MeV α -particles in a cyclotron at a certain beam current for a specified time. After irradiation the target is dissolved in 7.5 *N* hydrochloric acid (HCl), and carrier-free ⁶⁷Ga is extracted with isopropyl ether (IAEA 2008). The organic phase is then evaporated to dryness in a water bath, and the residue is taken up in dilute HCl for supply as gallium chloride. It may be complexed with citric acid to form gallium citrate, which is most commonly used in nuclear medicine.

Natural zinc targets can lead to impurities such as ⁶⁶Ga, which has a half-life of 9 h, as compared to the 78.2-h half-life of ⁶⁷Ga. The radiocontaminant ⁶⁶Ga can, however, be eliminated by allowing it to decay completely before the chemical processing of ⁶⁷Ga. Enriched zinc isotope targets produce less radioactive impurities, but they are expensive to prepare.

4.1.2 lodine-123

Iodine-123 is very useful in nuclear medicine because it has favorable radiation characteristics such as decay by electron capture, half-life of 13.2 h, and γ -ray emission of 159 keV. It is produced directly or indirectly in a cyclotron by several nuclear reactions (IAEA 2008). Direct nuclear reactions are those reactions whereby ¹²³I is produced directly and likely to be contaminated with other iodine radioisotopes such as ¹²⁴I and ¹²⁵I, depending on the type of target and the irradiating particle. Examples of such reactions are ¹²¹Sb (α , 2n) ¹²³I, ¹²³Te (p, n) ¹²³I, ¹²²Te (d, n) ¹²³I, and ¹²⁴Te (p, 2n) ¹²³I. Depending on the target composition and energy of the irradiating particles, other side reactions may produce various radioisotopes of iodine. In the

direct methods, after irradiation the target is dissolved in mineral acid, and iodine is collected by distillation into dilute sodium hydroxide (NaOH).

In the indirect method, the nuclear reaction is so chosen that ¹²³Xe is produced initially, which then decays with a half-life of 2.1 h to produce ¹²³I. These reactions allow the production of ¹²³I free of other radioisotopes of iodine. Various reactions include ¹²²Te (α , 3n) ¹²³Xe using 42- to 46-MeV α -particles, ¹²²Te (³He, 2n) ¹²³Xe using 20- to 30-MeV ³He particles, ¹²³Te (³He, 3n) ¹²³Xe using 25-MeV ³He particles, and ¹²⁷I (p, 5n) ¹²³Xe using 60- to 70-MeV protons. In all cases except the last, the target consists of natural or enriched tellurium powder coated inside a water-cooled chamber that is irradiated with α or ³He particles. During irradiation, helium gas is passed through the target, sweeping ¹²³Xe and some directly produced iodine isotopes. The gas mixture is initially passed through a trap maintained at -79 °C with solid carbon dioxide to remove iodine and then through another trap maintained at -196 °C with liquid nitrogen to remove ¹²³Xe. Iodine can be removed simply by leaching the nitrogen trap. The major contaminant in these samples is 124 I ($t_{1/2} = 4.2$ d). For the 127 I (p, 5n) ¹²³Xe reaction, the target is dissolved in aqueous potassium iodide, and ¹²³Xe is removed by helium gas bubbled through the solution and isolated by a liquid nitrogen trap. Such preparations contain ¹²⁵I as contaminant.

Another important method of producing pure ¹²³I is by the ¹²⁴Xe (p, 2n) ¹²³Cs reaction, in which case ¹²³Cs ($t_{1/2} = 5.9$ min) decays to ¹²³Xe. The ¹²⁴Xe gas is contained under pressure in a chamber and the chamber is irradiated with protons. Sufficient time is allowed for ¹²³Cs to decay completely to ¹²³Xe, which is then processed as above to yield ¹²³I. Such preparations are ¹²⁴I-free.

4.1.3 lodine-124

Iodine-124 has a half-life of 4.2 days and decays to ¹²⁴Te by two β^+ -emissions (net 23%), some β^- -emissions, and several high-energy γ -radiations. It is produced in a medical cyclotron via the ¹²⁴Te (p, n) ¹²⁴I reaction by irradiation of 99.8% enriched ¹²⁴Te oxide with 10–20-MeV protons (Braghirolli et al. 2014). Sometimes 5% Al₂O₃ is mixed with TeO₂ for better heat exchange in the target. ¹²⁴I is separated from the Te target matrix by dry distillation at 750°C and flushing ¹²⁴I with oxygen, whereby the ¹²⁴Te oxide target remains intact for further irradiation. The iodine vapor is then taken up in NaOH solution for further use.

Because of the positron emission and reasonable half-life, it has been used to label a variety of tracers for PET imaging. However, low abundance of β^+ and the presence of high-energy photons cause problems in imaging.

4.1.4 Germanium-68

Germanium-68 has a half-life of 270.8 days and decays by 100% electron capture to ⁶⁸Ga (100%). ⁶⁸Ge can be produced by the ⁶⁶Zn (α , 2n) ⁶⁸Ge reaction, or the 25-MeV proton irradiation of a gallium target leading to the ⁶⁹Ga (p, 2n) ⁶⁸Ge and

⁷¹Ga (p, 4n) ⁶⁸Ge reactions, or by spallation reaction in a molybdenum target bombarded with high-energy protons. The irradiated target is dissolved in dilute HCl and the solution is passed through a Sephadex-25 column followed by washing with citrate buffer, which elute impurities (Zn, Ga, Co) (Fitzsimmons and Mausner 2015). ⁶⁸Ge is then eluted with dilute HCl as Ge chloride with radiochemical purity of 99%. The yield can be as high as 1 MBq/ μ A-h at EOB.

⁶⁸Ge decays to ⁶⁸Ga ($t_{1/2}$ = 68 min) which is used in positron emission tomography. Because of the half-life difference, the ⁶⁸Ge–⁶⁸Ga generator has been manufactured and commercially available. The solid ⁶⁸Ge source has been used as a transmission source for attenuation correction in PET imaging.

4.1.5 Strontium-82

Strontium-82 ($t_{1/2}$ = 25.5 d) decays to ⁸²Rb ($t_{1/2}$ = 75 s) by 100% electron capture and is primarily produced by the 40–90-MeV proton irradiation of rubidium chloride or by 500–700-MeV proton spallation reaction on ⁹⁹Mo in accelerators, although the former is the most common. In the USA, the accelerators at the Brookhaven National Laboratory and Los Alamos National Laboratory are used, and ⁸²Sr is abundantly produced by the ⁸⁵Rb (p, 4n) ⁸²Sr nuclear reaction along with contaminants ⁸³Sr $(t_{1/2} = 1.3 \text{ d})$ and ⁸⁵Sr $(t_{1/2} = 64.8 \text{ d})$. Prior to chemical separation after irradiation, time is allowed for ⁸³Sr to decay, but ⁸⁵Sr remains the major contaminant. The ⁸⁵Sr/⁸²Sr ratio varies from 0.4 to 5.0 at the end of bombardment. ⁸²Sr is chemically separated by two steps: First, rubidium target is dissolved in water and the solution is allowed through a Chelex 100 cation-exchange column whereby ⁸²Sr²⁺ is adsorbed on the column and ${}^{82}Rb^+$ passes through. Second, ${}^{82}Sr^{2+}$ is desorbed from the column with HCl and, for further purification, loaded onto an AG 50W-X8 cation-exchange column, which is washed with HCl to remove traces of Rb. Finally, the column is eluted with diluted HCl to yield high-purity 82Sr. The activity can be produced in the range of 2-12 mCi (74-445 GBq).

Sr-82 is primarily used to manufacture the ⁸²Sr/⁸²Rb generator to provide ⁸²Rb that is used to evaluate myocardial perfusion.

4.1.6 Indium-111

In-111 decays by 100% EC to ¹¹¹Cd with a half-life of 2.8 days and emits two useful γ -rays of 171 keV (90%) and 245 keV (94%). Indium-111 is produced by the ¹¹¹Cd (p, n) ¹¹¹In and ¹⁰⁹Ag (α , 2n) ¹¹¹In reactions (Lahiri et al. 2013). After irradiation with 15-MeV protons, the cadmium target is dissolved in mineral acid and the acidity is adjusted to 1 *N* in HCl. The solution is passed through anion-exchange resin (Dowex-1). Indium-111 is removed by elution with 1 *N* hydrochloric acid, leaving cadmium on the column. Similarly, the silver target is dissolved in mineral acid after irradiation with 30-MeV α -particles, and pure and high-yield ¹¹¹In is separated by the solvent extraction method. It is used for labeling various ligands for detection of different diseases.

4.1.7 Copper-64

Copper-64 has a half-life of 12.1 h and decays by 17.9% emission to ⁶⁴Ni, 39.0% β -decay to ⁶⁴Zn, 43% EC to ⁶⁴Ni, and 0.48% γ -emission/internal conversion. It is abundantly produced by the ⁶⁴Ni (p, n) ⁶⁴Cu reaction by 10–12-MeV proton irradiation of an enriched ⁶⁴Ni target in a medical cyclotron. The target is dissolved in HCl and the solution is passed through an ion-exchange column, whereby ⁶⁴Ni washes out and ⁶⁴Cu is retained on the column, which is then eluted with water (IAEA 2008). With enrichment of 95% ⁶⁴Ni, the radionuclidic purity of ⁶⁴Cu is nearly 99%. Because of the low natural abundance (0.93%) of ⁶⁴Ni, the recovery of the irradiated target is required for reuse.

Because of the positron emission, ⁶⁴Cu has been used to label a variety of molecules such as antibodies and nanoparticles for PET imaging. An example is ⁶⁴Cu-ATSM, which has been approved by the US FDA for measurement of hypoxia in tumor by PET imaging.

4.1.8 Thallium-201

Thallium-201 decays to ⁸⁰Hg with a half-life of 73 h by 100% EC and emits 69–83-keV X-rays (93%) and a photon of 167 keV (99.4%). It is primarily produced by the ²⁰³Tl (p, 3n) ²⁰¹Pb reaction, whereby ²⁰¹Pb decays to ²⁰¹Tl with a half-life of 9.4 h (Lebowitz et al. 1975). ²⁰¹Tl obtained in this way is pure and free of other contaminants. After irradiation with 35- to 45-MeV protons, the natural thallium target is dissolved in concentrated nitric acid and then evaporated to dryness. The residue is dissolved in 0.025 M EDTA and passed through a Dowex resin column. Most of the thallium is adsorbed on the column, while ²⁰¹Pb passes through. The eluate is purified once more by passing through another Dowex resin column. The eluate containing ²⁰¹Pb is allowed to decay for 30–35 h to produce ²⁰¹Tl and is then passed through a Dowex 1 × 8 column. ²⁰¹Tl³⁺ adheres to the column and ²⁰¹Pb passes through. ²⁰¹Tl³⁺ is eluted with hydrazine-sulfate solution, reducing Tl³⁺ to Tl¹⁺. The eluate is evaporated to dryness with HNO₃ and HCl and finally taken up with NaOH to give >99% pure TlCl. It is used for the study of myocardial perfusion and occasionally for parathyroid disease.

4.1.9 Zirconium-89

Zirconium-89 has a half-life of 78.1 h and decays to ⁸⁹Y by 23% β^+ -emission and 77% EC accompanied by a high-energy γ -ray of 909 keV (100%). Proton irradiation of natural ⁸⁹Y target at 11 MeV in a cyclotron produces ⁸⁹Zr by the ⁸⁹Y (p, n) ⁸⁹Zr reaction (Holland et al. 2009). The target is dissolved in HCl and the solution is loaded on a hydroxamate resin column. ⁸⁹Zr is eluted with 1 M oxalic acid; the solution is further purified by passing through a Sep-Pak anion-exchange resin, wherein ⁸⁹Zr is retained on the column and oxalic acid passes through. ⁸⁹Zr is finally eluted with water or 0.9% NaCl solution. Its radionuclide purity is 99.9%. BV Cyclotron VU University Medical Center supplies this product commercially in concentrations of 20–50 mCi/mL

(740–1850 MBq/mL). Because of the convenient half-life and positron emission, ⁸⁹Zr has been chelated to many antibodies for PET imaging in human and animal research, but is not yet approved by the US FDA for clinical use.

4.1.10 Carbon-11

Carbon-11 has a half-life of 20.4 min and can be produced by ¹⁰B (d, n) ¹¹C, ¹¹B (p, n) ¹¹C, and ¹⁴N (p, α) ¹¹C reactions in the cyclotron. In the first two reactions, B₂O₃ is the target and nitrogen gas in the third. Both ¹¹CO and ¹¹CO₂ are produced in boron targets, which are then flushed out by neutral gases. Either ¹¹CO is oxidized to have all the gas in ¹¹CO₂ form or ¹¹CO₂ is reduced to have all the gas in ¹¹CO form. Both ¹¹CO and ¹¹CO₂ are commonly used as precursors in the preparation of various clinically useful compounds, such as ¹¹C-palmitate for myocardial perfusion imaging by PET.

The ¹⁴N(p, α) ¹¹C reaction is carried out by bombardment of a mixture of N₂ + H₂ to give ¹¹C, which reacts with N₂ to give ¹¹CN, followed by radiolysis of ¹¹CN to give ¹⁴CH₄ (95–100% radiochemical yield). Carbon-11-methane is allowed to react with NH₃ over platinum at 1000 °C to give a 95% overall yield of H¹¹CN. Various biological molecules such as aliphatic amines, amino nitriles, and hydantoins have been labeled with ¹¹C using ¹¹CN as a precursor.

¹¹C-methyl iodide is often utilized as a precursor to label many clinically useful tracers. It is prepared in two steps: First, ¹¹C-CO₂ is converted to ¹¹C-methane by reduction at -180° using a Ni catalyst, which is then converted to ¹¹C-methyl iodide by simple iodination. The total synthesis takes about 7 min and the non-decay-corrected radiochemical yield of ¹¹C-methyl iodide is better than 50%.

4.1.11 Nitrogen-13

Nitrogen-13 decays to ¹³C by 100% β^+ -emission with a half-life of 10 min and is commonly used as NH₃. It is produced by the ¹²C (d, n) ¹³N reaction by bombarding Al₄C₃ or methane with 6- to 7-MeV deuterons or by the ¹⁶O (p, α) ¹³N or ¹³C (p, n) ¹³N reaction (Kumar et al. 2009). In the latter two reactions, a target of slurried mixture of ¹³C powder and water is used for irradiation with 11- to 12-MeV protons. Nitrogen-13 is converted to NH₃ in aqueous medium. However, for ¹³N-ammonia production, the ¹⁶O (p, α) ¹³N reaction is commonly used on an ethanol target by irradiation with 12-MeV protons. ¹³NH₃ in the form of NH₄⁺ ion is used primarily for myocardial perfusion imaging by PET. ¹³NH₃ is also used to label glutamine and asparagine for assessment of viability of tissues.

4.1.12 Oxygen-15

Oxygen-15 decays to ¹⁵N by 100% β^+ -emission with a half-life of 2 min and is produced by the ¹⁴N (d, n) ¹⁵O reaction by deuteron irradiation of gaseous nitrogen or

by the ¹⁵N (p, n) ¹⁵O reaction by proton bombardment of enriched ¹⁵N target (Powell and O'Neal 2005). ¹⁵O₂ is then passed over activated charcoal heated at 600°C to convert it to C¹⁵O and C¹⁵O₂, which are then used for labeling hemoglobins and for clinical investigations of pulmonary and cardiac malfunctions. Oxygen-15-labeled water is prepared by mixing the N₂ target with 5% H₂ gas and, after irradiation, by passing the mixture over the palladium catalyst at 175°C. ¹⁵O-water is recovered in saline and is useful for cerebral and myocardial perfusion studies.

4.1.13 Copper-62

Copper-62 has a half-life of 9.7 min and decays by 98% β^+ -emission and 2% EC providing scope for PET imaging. Because of its short half-life and 62 Zn ($t_{1/2} = 9.3$ h) decays to 62 Cu, the 62 Zn– 62 Cu generator has been devised conveniently to supply this radionuclide, which is marketed by Proportional Technologies, Inc., Houston. Zinc-62 is produced by the 63 Cu (p, 2n) 62 Zn reaction by bombarding a 99% pure 63 Cu foil target with 25–30-MeV protons in a cyclotron (Green et al. 1990). The irradiated target is etched with hot nitric acid, the solution evaporated to dryness, and then taken up in HCl. The solution is passed through an AG 1 x 8 anion-exchange column, whereby 62 Zn is retained on the column, which is eluted with water. The typical yield is about 4.5 mCi (166.5 MBq)/µAh at EOB. 62 Zn is reconstituted in 2 N HCl and loaded on a Dowex 1 x 8 anion-exchange column to manufacture the 62 Zn- 62 Cu generator. 62 Cu is eluted with 2 N HCl and is used for synthesis of several radiopharmaceuticals. 62 Cu-PTSM has been synthesized and used for measurement of perfusion in the heart, brain, and kidneys.

4.1.14 Fluorine-18

Fluorine-18 ($t_{1/2} = 110$ min) decays to ¹⁸O by 97% β^+ -emission and 3% EC. It is commonly produced by the ¹⁸O (p, n) ¹⁸F reaction on a pressurized ¹⁸O-water target. ¹⁸F is recovered as F⁻ ion from water by passing the mixture through a column of quaternary ammonium resins, and recovered ¹⁸O-water can be reused as the target. Fluorine-18 is used primarily to label glucose to give ¹⁸F-labeled fluorodeoxyglucose (FDG) for myocardial and cerebral metabolic studies using PET imaging. It is also used to label many potential ligands for a variety of tumors, and currently ¹⁸F-NaF is used for bone imaging.

4.2 Reactor-Produced Radionuclides

A variety of radionuclides are produced in nuclear reactors. A nuclear reactor is constructed with fuel rods made of fissile materials such as enriched ²³⁵U and ²³⁹Pu (Fig. 4.2). These fuel nuclei undergo spontaneous fission with extremely low probability. Fission is defined as the breakup of a heavy nucleus into two fragments of



Fig. 4.2 A schematic illustration of a nuclear reactor

approximately equal mass, accompanied by emission of two to three neutrons with mean energies of about 1.5 MeV. In each fission, there is a concomitant energy release of 200 MeV that appears as heat and is usually removed by heat exchangers to produce electricity in the nuclear power plant.

Neutrons emitted in each fission can cause further fission of other fissionable nuclei in the fuel rod provided the right conditions exist. This obviously can initiate a chain reaction, ultimately leading to a possible meltdown situation in the reactor. This chain reaction must be controlled, which is accomplished by the proper size, shape, and mass of the fuel material and other complicated and ingenious engineering techniques. To control a self-sustained chain reaction, excess neutrons (more than one) are removed by positioning cadmium rods (called control rods) in the fuel core (cadmium has a high probability of absorbing a thermal neutron). Even in controlled state of reactor operation, there is a huge release of heat which is removed by circulating a coolant such as water, helium, and liquid sodium metal.

The fuel rods of fissile materials are interspersed in the reactor core with spaces in between. Neutrons emitted with a mean energy of 1.5 MeV from the surface of the fuel rod have a low probability of interaction with other nuclei and therefore do not serve any useful purpose. It has been found, however, that neutrons with thermal energy (0.025 eV) interact with many nuclei, efficiently producing various radionuclides. To make the high-energy or so-called fast neutrons more useful, they are thermalized or slowed down by interaction with low molecular weight materials, such as water, heavy water, beryllium, and graphite, which are distributed in the spaces between the fuel rods. These materials are called *moderators*. The flux or intensity of the thermal neutrons so obtained ranges from 10¹¹ to 10¹⁴ neutrons/ (cm².s), and they are utilized in the production of many radionuclides. When a target element is inserted in the reactor core, a thermal neutron will interact with the target nucleus with a definite probability to produce another nuclide. The probability of formation of a radionuclide by thermal neutrons varies from element to element.
In the reactor, two types of interaction with thermal neutrons are of considerable importance in the production of various useful radionuclides: fission of heavy elements and neutron capture or (n, γ) reaction. These two reactions are described below.

4.2.1 Fission or (n, f) Reaction

As already mentioned, fission is a breakup of a heavy nucleus into two fragments of approximately equal mass. When a target of heavy elements is inserted in the reactor core, heavy nuclei absorb thermal neutrons and undergo fission. Fissionable heavy elements are ²³⁵U, ²³⁹Pu, ²³⁷Np, ²³³U, ²³²Th, and many others having atomic numbers greater than 90, although 235U fission of heavy elements may also be induced in a cyclotron by irradiation with high-energy charged particles, but the fission probability depends on the type and energy of the irradiating particle. Nuclides produced by fission may range in atomic number from about 28 to nearly 65. These isotopes of different elements are separated by appropriate chemical procedures that involve precipitation, solvent extraction, ion exchange, chromatography, and distillation. These methods are described in detail in Chap. 8. The fission radionuclides are normally carrier-free or NCA, and therefore isotopes of high specific activity are available from fission. Since the chemical behavior of isotopes of many different elements is similar, contamination often becomes a serious problem in the isolation of a desired radionuclide; therefore, meticulous methods of purification are needed to remove the contaminants. The fission products are usually neutron rich and decay by β^{-} -emission.

Many clinically useful radionuclides such as ⁹⁹Mo, ¹³¹I, ¹³³Xe, ¹³⁷Cs, etc. are produced by fission of ²³⁵U. An example of thermal fission of ²³⁵U is presented below, showing only a few representative radionuclides:

$${}^{235}_{92} U + {}^{1}_{0} n \rightarrow {}^{236}_{92} U \rightarrow {}^{131}_{53} I + {}^{102}_{39} Y + {}^{1}_{0} n \rightarrow {}^{99}_{42} Mo + {}^{135}_{50} Sn + {}^{1}_{0} n \rightarrow {}^{117}_{46} Pd + {}^{117}_{46} Pd + {}^{1}_{0} n \rightarrow {}^{133}_{54} Xe + {}^{101}_{38} Sr + {}^{1}_{0} n \rightarrow {}^{137}_{55} Cs + {}^{97}_{37} Rb + {}^{1}_{0} n \rightarrow {}^{155}_{62} Sm + {}^{78}_{30} Zn + {}^{1}_{0} n \rightarrow {}^{156}_{62} Sm + {}^{77}_{30} Zn + {}^{1}_{0} n$$

It should be understood that many other nuclides besides those mentioned in the example are also produced. A good review of reactor-produced radionuclides is given in an article by (Mirzadeh et al. 2003).

Yttrium-90

Yttrium-90 decays to ⁹⁰Zr by 2.28-MeV β^- -emission with a half-life of 64.1 h and is obtained from a ⁹⁰Sr/⁹⁰Y generator. ⁹⁰Sr ($t_{1/2} = 28.8$ y) is produced by fission of ²³⁵U in a reactor and decays to ⁹⁰Y by 100% β^- -emission. There are several methods of

making the ⁹⁰Sr/⁹⁰Y generator including column chromatography and electrolytic method, but the column chromatographic method has disadvantage of the resin being damaged by high-energy β^- -radiations from ⁹⁰Sr over the acceptable period of generator use. The electrolytic method involves two steps. First, ⁹⁰Sr-nitrate is electrolyzed for 90 min in nitric acid with pH adjusted to 3.0 using two platinum electrodes. In the second electrolysis, the cathode containing ⁹⁰Y from the first electrolysis is used as the anode and a cylindrical platinum electrode as the cathode. After 45 min of electrolysis, ⁹⁰Y deposited on the cylindrical electrolytic cell and is allowed to grow ⁹⁰Y for subsequent extraction. The yield of ⁹⁰Y is 97–98% after each electrolysis and the radiochemical purity is 99.99% (IAEA 2009). ⁹⁰Y is complexed with a variety of chelating agents suitable for targeted therapy of various cancers. It has been incorporated in glass microspheres which are used to treat hepatocellular carcinoma.

Molybdenum-99

As the primary source of ^{99m}Tc, ⁹⁹Mo is the most important radionuclide produced by the fission of ²³⁵U. Irradiation of ²³⁵U in a reactor with a neutron flux of 10¹⁴ neurons/cm².s for 5 to 7 days would produce nearly maximum ⁹⁹Mo. Approximately 6% of the fission products are ⁹⁹Mo atoms. Even at maximum production of ⁹⁹Mo, only 3% of the ²³⁵U is used up and the remainder of the target is treated as waste.

The irradiated uranium target is cooled in water for half a day, and then for ⁹⁹Mo separation, two methods of processing are employed (National Research Council (US) Committee 2009). In one method, the target (containing Al covering) is dissolved in NaOH whereby sodium molybdate (Na₂MoO₄) and sodium aluminate (NaAlO₂) are formed in solution along with a solid residue containing uranium and most fission products. The residue is removed by filtration and the solution is passed through an alumina (Al₂O₃) column whereby molybdate is adsorbed on the column. Molybdate is eluted with an ammonium hydroxide solution to give ammonium molybdate ((NH₄)₂MoO₄), which is further purified by ion exchange for use in the manufacture of ⁹⁹Mo–^{99m}Tc generators discussed in Chap. 5.

In the second method, the target is dissolved in nitric acid and the solution is adsorbed on an alumina (Al_2O_3) column. The column is then washed with nitric acid to remove uranium and other fission product cations in the wash. Molybdenum is then eluted with ammonium hydroxide. The eluted ammonium molybdate is further purified by adsorption on Dowex-1 anion-exchange resin and washing of the column with concentrated HCl to remove other impurities. Ammonium molybdate is eluted with dilute HCl and used in manufacturing ⁹⁹Mo–^{99m}Tc generators discussed in Chap. 5.

The entire process of ⁹⁹Mo separation by both methods is carried out in a hot cell. The yield of ⁹⁹Mo in both methods is greater than 85–90%. The ⁹⁹Mo radionuclide produced by fission is carrier-free or NCA and its common contaminants are ¹³¹I and ¹⁰³Ru.

Over more than a decade, the nuclear medicine community has faced several times an acute shortage of ⁹⁹Mo worldwide due to closing or maintenance of several aging reactors, affecting the supply of ^{99m}Tc and hence patient care. Natural uranium

consists of 99.3% nonfissionable ²³⁸U and 0.7% fissile ²³⁵U. For efficient operation of a reactor, highly enriched ²³⁵U (HEU; 20% or more enrichment) is conventionally used. But for the potential shutdown of these reactors affecting adversely patient care in the future, many stakeholders are advocating, and even some are adopting, the idea of using lowly enriched ²³⁵U (LEU; less than 20% enrichment) for production of ⁹⁹Mo. However, the quantity of ⁹⁹Mo produced by this method is less than the global need, and also it requires longer irradiation and a tedious and expensive conversion of the reactor from HEU to LEU system. Because of the uncertainty in ⁹⁹Mo supply from the current HEU reactors, the US Congress is encouraging the adoption of LEU ⁹⁹Mo with financial incentive to the care providers.

lodine-131

Iodine-131($t_{1/2} = 8$ d) decays by 100% β^- -emission to ¹³¹Xe, followed by three γ -emissions of 364 keV (81%), 637 keV (7%), and 284 keV (6%). It is produced by fission of ²³⁵U in a reactor. For chemical separation of ¹³¹I from the irradiated target, the latter is dissolved in 18% NaOH by heating, and hydroxides of many metal ions are precipitated by cooling. The supernatant containing sodium iodide is acidified with sulfuric acid in a closed distillation system. Iodide is oxidized to iodine by the acid, and iodine is collected in a NaOH solution by distillation, with high radio-chemical yield. It is available in the form of sodium iodide, and to prevent oxidation of iodide to iodine, a reducing agent is added, although it may interfere with iodination of many organic compounds. It is used for the detection and treatment of thyroid disease and for labeling various ligands for different diseases.

Xenon-133

Xenon-133 has a half-life of 5.3 days and decays to ¹³³Cs by 100% β^- -emission and 81-keV γ -emission (37%). It is produced by the fission of ²³⁵U in a reactor, and gaseous products including ¹³³Xe are recovered from the solution of the target in a mixture of NaOH and NaNO₃ and passing nitrogen gas as carrier. Further purification involves adsorption of the gas mixture in activated charcoal at low temperature of liquid nitrogen, where ¹³³Xe and krypton isotopes are trapped. Krypton is flushed out first by passing helium at room temperature and ¹³³Xe is desorbed by flushing with heated (60°C) helium (Jao et al. 1989). It is dispensed in closed vials containing 10 and 20 mCi (370 and 740 MBq) of the gas mixture of 5% ¹³³Xe and 95% carbon dioxide for ventilation study of the lungs. It is supplied as solution in 0.9% NaCl for blood flow study in the brain.

4.2.2 Neutron Capture or (n, γ) Reaction

In neutron capture reaction, the target nucleus captures a thermal neutron in the reactor resulting in an excited nucleus that releases the excitation energy as a γ -ray to produce an isotope of the same element. The radionuclide so produced is therefore not carrier-free and its specific activity (described later) is relatively low. This reaction takes place in almost all elements with varying probability. Since the target

and the product nuclei belong to the same element, chemical separation is obviously unnecessary unless impurities develop due to decay of various radioisotopes or extraneous radionuclides produced by impurities in the target. In all these cases, chemical separation must be carried out.

Various useful radionuclides produced by this reaction are ¹³¹Te (which produces ¹³¹I by β^{-} -decay with a half-life of 25 min), ⁹⁹Mo, ¹⁹⁷Hg, ⁵⁹Fe, ⁵¹Cr, and many more. These radionuclides are often neutron rich and therefore decay by β^{-} -emission. Some examples of neutron capture reactions are ⁹⁸Mo (n, γ) ⁹⁹Mo, ¹⁹⁶Hg (n, γ) ¹⁹⁷Hg, and ⁵⁰Cr (n, γ) ⁵¹Cr. Molybdenum-99 so produced is called the irradiated molybdenum as opposed to the fission molybdenum described earlier, and its specific activity is very low making it unsuitable for the ⁹⁹Mo–^{99m}Tc generator.

It should be pointed out that the neutron capture reaction is the basis of the neutron activation analysis of various trace metals. A sample containing trace metals is irradiated with thermal neutrons, and the trace metal atom captures a neutron to produce a radionuclide that can be detected by radiation detectors. Neutron activation analysis has proved to be an important tool in detecting the presence of trace elements in forensic, industrial, and biological sciences.

The following are some examples of neutron capture reactions.

Phosphorus-32

Phosphorus-32 ($t_{1/2} = 14.3$ d) is a 100% 1.18-keV β^- -emitting radionuclide decaying to ³²S. It is produced by the ³²S (n, p) ³²P or ³¹P (n, γ) ³²P reaction in the reactor, although the former method is more commonly used. After irradiation the target is dissolved in 0.01 N HCl, and after further chemical processing, it is recovered as sodium orthophosphate for clinical use. For an irradiation period of 60 days in the reactor, the yield is approximately 4.05 Ci (150 GBq) of high-purity ³²P and specific activity of 5500 Ci (200TBq) (Vimalnath et al. 2014). It is used in the form of sodium orthophosphate for the treatment of leukemia and polycythemia vera.

Strontium-89

Strontium-89 has a half-life of 50.6 days and decays to ⁸⁹Y by 100% β^- -emission. It is produced by the ⁸⁹Y (n, γ) ⁸⁹Sr in a high-neutron-flux reactor using a ⁸⁸Sr carbonate target (IAEA 2003). The irradiated target is dissolved in 1 M HCl, evaporated to dryness, and taken up in water for assaying and dispensing. The radiochemical purity is 99.9% and specific activity is 94–170 µCi (3.5–6.3 MBq)/mg Sr. It is supplied in a concentration of 1 mCi (37 MBq)/ml and at pH 4–7. Because of its $\beta^$ emission, long half-life, and avidity for bone matrix in the body, it has been used for palliation of bone pain from metastatic cancer.

lodine-125

Iodine-125 decays with a half-life of 60 days to ¹²⁵Te by 100% EC. It emits 7% 35 keV and 140% X-rays. It is produced by the ¹²⁴Xe (n, γ) ¹²⁵I reaction. ¹²⁵I is commercially available in dilute sodium hydroxide solution with high chemical and radiochemical purity. Its radioactive concentration lies at 4–11 GBq/ml. It is commonly used for in vitro studies and brachytherapy using ¹²⁵I seeds.

Gadolinium-153

Gadolinium-153 (¹⁵³Gd) has a half-life of 241.6 days and decays by 100% electron capture to europium-153 (¹⁵³Eu) accompanied by γ -emissions of 97 keV (28%) and 103 keV (20%). It is produced by the neutron capture reaction, ¹⁵²Gd (n, γ) ¹⁵³Gd, on natural gadolinium (Gd₂O₃) target in a reactor (IAEA 2003). Irradiation is carried out for 2 months and the target is cooled for 2 weeks to allow the short-lived isotopes to decay. The target is dissolved in 3 N HCl by heating and the solution is diluted to a concentration of 0.1 N HCl for intended use. About 50 mCi (1.85 GBq) of ¹⁵³Gd is produced by 2 months of irradiation of a target of 50-mg natural Gd with a neutron flux of 6 × 10¹³ n/cm².s, and its specific activity is >700 MBq/g of Gd. Alternatively, it can be produced by the ¹⁵¹Eu (n, γ) ¹⁵²Eu reaction by bombarding a β -

¹⁵¹Eu target in the reactor, followed by the ¹⁵²Eu \rightarrow ^{$\beta-152$}Gd (n, γ) ¹⁵³Gd reaction. ¹⁵³Gd is used for absorptiometry of bone to assess the bone density and also for photon attenuation correction in SPECT studies.

Samarium-153

Samarium-153 decays to ¹⁵³Eu with a half-life of 1.9 days emitting 100% (825 keV) β^- -emission and 103-keV (28%) and 70-keV (5%) γ -emissions. It is produced in a high-neutron-flux reactor by the ¹⁵²Sm (n, γ) ¹⁵³Sm reaction on a samarium oxide (Sm₂O₃) target, which is 98% enriched in ¹⁵²Sm. After irradiation for 2 days, the target is dissolved in HCl, and ¹⁵³Sm is separated from other isotope impurities by the ion-exchange method (IAEA 2003). The radionuclidic purity is 99%. ¹⁵³Sm-ethylenediamine tetramethylene phosphonic acid (¹⁵³Sm-EDTMP) is easily prepared by directly dissolving the target in an alkaline solution of EDTMP and heating at 75–80°C for 45–60 min and is used for palliation of bone pain due to metastasis of cancer.

Lutetium-177

Lutetium-177 is a lanthanum isotope that decays with a half-life of 6.65 days to ¹⁷⁷Hf by β^{-} -emission of energies 497 keV, 384 keV, and 176 keV. Natural lutetium contains ¹⁷⁵Lu (97.4%) and ¹⁷⁶Lu (2.6%). It is produced directly by the (n, γ) reaction on enriched ¹⁷⁶Lu (82%) by bombarding the target (Lu₂O₃) or indirectly by ¹⁷⁶Yb (n, γ) 177 Yb \rightarrow 177 Lu in high-neutron-flux reactors for 5–30 days (Dash et al. 2015). In the direct reaction, the target is dissolved in dilute HCl, the solution is evaporated, and 1^{177} LuCl₃ is taken up in water. In the indirect reaction, chemical separation of Lu from Yb target is quite complicated due to similarities in their chemical behavior and has been achieved by ion exchange, solvent extraction, electrochemical method, etc. with limited success. For this reason the direct method is preferred producing ¹⁷⁷Lu with a specific activity of 20-30 mCi (740-1110 MBq)/mg, sufficient for preparing radiopharmaceuticals for targeted radionuclide therapy. There is slight contamination with 177m Lu ($t_{1/2} = 160.1$ d), which is produced by the 176 Lu (n, γ) 177m Lu reaction in small quantity because of low cross-section for production. However, radiation dose to the patient due to such small contamination of 177mLu is considered insignificant, provided ¹⁷⁷Lu is used within a week from the end of bombardment. ¹⁷⁷Lu has been bound to antibodies specific for a variety of cancers.

Rhenium-186

Rhenium-186 decays by β -emission (92%) and electron capture (8%) with a halflife of 3.8 days. It is produced in a nuclear reactor by the ¹⁸⁵Re (n, γ) ¹⁸⁶Re reaction and chemically separated from the target as sodium perrehnate. However, production by this method yields low specific activity of ¹⁸⁶Re, thus limiting its clinical use. Alternatively, it can be produced in a cyclotron by the ¹⁸⁶W (p, n) ¹⁸⁶Re or ¹⁸⁶W (d, 2n) ¹⁸⁶Re reaction in accelerators with higher specific activity (Fassbender et al. 2013). After irradiating the enriched WO³ target in the accelerator at low energy (~resin column, whereby rhenium is retained and Na₂WO₄ is eluted; rhenium is then rinsed from 15 MeV), the target is dissolved in NaOH solution, and the solution is loaded on a Bio-Rad AG 1-X8 column with HNO3, the solution evaporated to dryness, and ¹⁸⁶Re finally taken up in HCl. ¹⁸⁶Re can be produced with a batch yield of 42.7 µCi (1.6 MBq)/µAh at 15.5-MeV proton bombardment with radiochemical purity of 97% and specific activity of 1900 Ci (70.3 TBq)/mmol at the end of bombardment.

Since technetium and rhenium belong to the same group in the periodic table, they have similar chemical behavior, and so ¹⁸⁶Re can be used like ^{99m}Tc to prepare radiopharmaceuticals for clinical use. This radionuclide has not yet been approved by the US FDA for clinical use.

Tungsten-188

Tungsten-188 has a half-life of 69.8 days and decays to ¹⁸⁸Re ($t_{1/2}$ = 16.9 h) by 100% β^- -emission. ¹⁸⁸Re decays to ¹⁸⁸Os by 100% β^- -emission (2.12 MeV) followed by a 155-keV γ -emission (15%). Since it chemically behaves like ^{99m}Tc, it can be tagged to various antibodies and chelating agents for clinical use, particularly for treatment of cancers. Because of the half-life difference, ¹⁸⁸W–¹⁸⁸Re radionuclide generators have been manufactured for as-needed supply of ¹⁸⁸Re for clinical use. ¹⁸⁸W is produced by irradiation of solid-enriched ¹⁸⁶W oxide targets or pressed and sintered metallic tungsten targets in a high-neutron-flux reactor by double-neutron capture reactions [¹⁸⁶W (n, γ) ¹⁸⁷W, ¹⁸⁷W (n, γ) ¹⁸⁸W] (IAEA 2003). The yield of ¹⁸⁸W is 4–5 mCi (148–155 MBq)/mg with a purity of 99%. The target is dissolved in NaOH and the solution is converted to tungstic acid, which is then adsorbed on alumina in a glass column. ¹⁸⁸Re is eluted with 0.9% NaCl solution (saline) with a radiochemical purity of 75–85%. The generator strength ranges from 250 mCi to 3 Ci (9.25–111 GBq).

Because ¹⁸⁸Re belongs to the periodic group of ^{99m}Tc, it can be used to prepare radiopharmaceuticals similar to ^{99m}Tc and has shown promise in experimental studies. No ¹⁸⁸Re radiopharmaceutical has been approved yet by the US Food and Drug Administration for clinical use.

Radium-223

Radium-223 decays with a half-life of 11.4 days by emission of 95.3% 5.9-MeV α -particles, 3.6% β -particles, and 1.1% γ -radiations. For its production, ²²⁶Ra is irradiated in a reactor to produce ²²⁷Ra by neutron capture. The latter decays with a half-life of 42 min by β -emission to ²²⁷Ac ($t_{1/2} = 21.8$ y), which in turn decays by

 β^{-} -emission to ²²⁷Th ($t_{1/2} = 18.7$ d), and ²²³Ra is produced from the α -decay of ²²⁷Th (Package insert from Bayer Pharmaceuticals Inc, 2016). The difference in half-lives of ²²⁷Ac, ²²⁷Th, and ²²³Ra makes them ideal nuclides for a radionuclide generator, ²²⁷Ac \rightarrow ²²⁷Th \rightarrow ²²³Ra, to provide sufficient supply of ²²³Ra. ²²³Ra chloride is primarily used in the treatment of castration-resistant prostate cancer.

4.3 Target and Its Processing

Various types of targets have been designed and used for both reactor and cyclotron irradiation. In the design of targets, primary consideration is given to heat deposition in the target by irradiation with neutrons in the reactor or by charged particles in the cyclotron. In both cases, the temperature can rise to 1000°C, and, if proper material is not used or a method of heat dissipation is not properly designed, the target is likely to be burned. For this reason, water cooling of the cyclotron probe to which the target is attached is commonly adopted. In the case of the reactor, the core cooling is sufficient to cool the target. Most often, the targets are designed in the form of a foil to maximize the heat dissipation.

The target element ideally should be monoisotopic or at least an enriched isotope to avoid extraneous nuclear reactions. The enrichment of a given isotope is made by an isotope separator, and the degree of enrichment depends on the percent abundance of the isotope in the natural element. If the interfering nuclear reactions are minimal, then targets of natural abundance also can be used.

The common form of target is metallic foil, for example, copper, aluminum, uranium, vanadium, and so on. Other forms of targets are oxides, carbonates, nitrates, and chlorides contained in an aluminum tubing which is then flattened. Aluminum tubing is used because of its high melting point. In some cases, compounds are deposited on the appropriate metallic foil by vacuum distillation or by electrodeposition, and the products are then used as targets. A pneumatic tube is often used to carry the target to and from the inside of the reactor or the cyclotron. In special cases, such as in the production of ¹²³I, a chamber whose inside is coated with tellurium powder is used as the target (discussed earlier).

After irradiation, the target must be dissolved in an appropriate solvent, either an acid or an alkali. Various chemical methods, such as precipitation, ion exchange, solvent extraction, distillation, and gel chromatography, are employed to separate different isotopes from the target solution. These methods are described in detail in Chap. 8 (the chemical separation methods of all elemental radionuclides have been described in the Nuclear Science Series published by National Academy of Sciences – National Research Council of the USA).

4.4 Equation for Production of Radionuclides

While irradiating a target for the production of a radionuclide, it is essential to know various parameters affecting its production, preferably in mathematical form, in

order to estimate how much of it would be produced for a given set of parameters. These parameters are therefore discussed and presented in some detail in a mathematical form.

The activity of a radionuclide produced by irradiation of a target material with charged particles in a cyclotron or with neutrons in a nuclear reactor is given by

$$A = IN\sigma\left(1 - e^{-\lambda t}\right) \tag{4.1}$$

where:

A = the activity in disintegrations per second of the radionuclide produced.

I = the intensity or flux of the irradiating particles [number of particles/(cm².s)].

N = the number of target atoms.

 σ = the formation cross-section (probability) of the radionuclide (cm²); it is given in units of "barn," which is equal to 10^{-24} cm².

 λ = the decay constant given by $0.693/t_{1/2}(s^{-1})$.

t = the duration of irradiation (s).

Equation (4.1) indicates that the amount of radioactivity produced depends on the intensity and energy (related to the cross-section σ) of the incident particles, the amount of the target material, the half-life of the radionuclide produced, and the duration of irradiation. The term $(1 - e^{-\lambda t})$ is called the saturation factor and approaches unity when *t* is approximately five to six half-lives of the radionuclide in question. At that time, the yield of the product nuclide becomes maximum and its rates of production and decay become equal. For a period of irradiation of five to six half-lives, Eq. (4.1) becomes

$$A = IN\sigma \tag{4.2}$$

A graphic representation of Eq. (4.1) and Eq. (4.2) is given in Fig. 4.3.

The intensity of the irradiating particles is measured by various physical techniques, and the description of which is beyond the scope of this book; however, the values are available from the operator of the cyclotron or the reactor. The crosssections of various nuclides are determined by experimental methods using Eq. (4.1), and they have been compiled and published by many investigators. The number of atoms *N* of the target is calculated from the weight *W* of the material irradiated, the atomic weight A_w and natural abundance *K* of the target atom, and Avogadro's number (6.02×10^{23}) as follows:

$$N = \frac{W \times K}{A_w} \times 6.02 \times 10^{23} \tag{4.3}$$

After irradiation, isotopes of different elements may be produced and therefore separated by appropriate chemical methods. These radionuclides are identified and quantitated by the NaI(Tl) or Ge(Li) detectors coupled to a multichannel pulse height analyzer. They may also be assayed in an ionization chamber if the amount of radioactivity is high.

We shall now do two problems using Eq. (4.1) to calculate the radioactivity of the commonly used radionuclides produced by irradiation in a cyclotron and a reactor.



Fig. 4.3 Production of radionuclides in a reactor or a cyclotron. The activity produced reaches a maximum (saturation) in five to six half-lives of the radionuclide

Problem 4.1

In a reactor, 10 g ²³⁵U is irradiated with 2×10^{14} neutrons/(cm².s) for 10 days. Calculate the radioactivity of ⁹⁹Mo produced if its $t_{1/2}$ is 66 h and formation cross-section by fission is 10^{-26} cm².

Answer

Number of g.atoms in 10 g 235 U = 10/235 Number of atoms of 235 U = (10/235) × 6.02 × 10 23 = 2.56 × 10 22

$$\lambda \text{ for}^{99}\text{Mo} = \frac{0.693}{66 \times 60 \times 60} = 2.91 \times 10^{-6} \text{ s}^{-1}$$

 $I = 2 \times 10^{14}$ neutrons/cm².s

 $t = 10 \times 24 \times 60 \times 60 = 8.64 \times 10^5$ s

Using Eq. (4.1),

$$A(dps) = 2 \times 10^{14} \times 2.56 \times 10^{22} \times 10^{-26} \times \left[1 - \exp(-2.91 \times 10^{-6} \times 8.64 \times 10^{5})\right]$$

= 4.71×10¹⁰ dps(47.1GBq)

Since 1 Ci = 3.7×10^{10} dps, the activity A of ⁹⁹Mo is calculated as

$$A = \frac{4.71 \times 10^{10}}{3.7 \times 10^{10}} = 1.27$$
 Ci

Problem 4.2

Calculate the radioactivity of ¹¹¹In produced by irradiation of 1 g ¹¹¹Cd with a proton beam current of 1 microampere (μ A) per cm² in a cyclotron for a period of 10 h. The half-life of ¹¹¹In is 2.8 days and its cross-section for formation by the (p, n) reaction is 1 barn.

Answer

Since 1 ampere is equal to 1 coulomb (C)/s and one proton carries 1.6×10^{-19} C, the number of protons in 1 μ A/cm² is

$$I = \frac{1 \times 10^{-6}}{1.6 \times 10^{-19}} = 6.25 \times 10^{12} \text{ protons} / (\text{cm}^2.\text{s})$$
$$N = \frac{1}{111} \times 6.02 \times 10^{23} = 5.42 \times 10^{21} \text{ atoms}^{111} \text{Cd}$$
$$\lambda = \frac{0.693}{2.8 \times 24 \times 60 \times 60} = 2.86 \times 10^{-6} \text{ s}^{-1} \text{ for}^{111} \text{In}$$
$$t = 10 \times 60 \times 60 = 3.60 \times 10^{4} \text{ s}$$

Using Eq. (4.1),

$$A(dps) = 6.25 \times 10^{12} \times 5.42 \times 10^{21} \times 10^{-24} \\ \times \left[1 - \exp(-2.86 \times 10^{-6} \times 3.6 \times 10^{4})\right] \\ = 3.39 \times 10^{10} \times (1 - 0.9022) \\ = 3.32 \times 10^{9} dps(3.32 GBq)$$

$$A = \frac{3.32 \times 10^9}{3.7 \times 10^7} \text{ mCi}$$

= 89.7 mCi

Using this example, activities of ⁶⁷Ga, ¹²³I, and other cyclotron-produced radionuclides can be calculated from the knowledge of all the relevant parameters.

In Table 4.1, the radiation characteristics and production methods of several useful radionuclides are summarized.

Nuclides	Physical half-life	Mode of decay (%)	γ-Ray energy ^a (MeV)	Abundance (%)	Common production method	
$^{3}_{1}\mathrm{H}$	12.3 у	$\beta^{-}(100)$	-	-	$^{6}\text{Li}(n, \alpha)^{3}\text{H}$	
¹¹ ₆ C	20.4 min	$\beta^{+}(100)$	0.511 (annihilation)	200	$^{10}B(d, n)^{11}C$ $^{14}N(p, \alpha)^{11}C$	
$^{13}_{7}N$	10 min	$\beta^{+}(100)$	0.511 (annihilation)	200	$^{12}C(d, n)^{13}N$ $^{16}O(p, \alpha)^{13}N$ $^{13}C(p, n)^{13}N$	
¹⁴ ₆ C	5730 у	$\beta^{-}(100)$	-	-	$^{14}N(n, p)^{14}C$	
¹⁵ ₈ O	2 min	$\beta^{+}(100)$	0.511 (annihilation)	200	$^{14}N(d, n)^{15}O$ $^{15}N(p, n)^{15}O$	
¹⁸ ₉ F	110 min	$\beta^{+}(97)$ EC(3)	0.511 (annihilation)	194	$^{18}O(p, n)^{18}F$	
$^{32}_{15}P$	14.3 d	$\beta^{-}(100)$	-	-	${}^{32}S(n, p){}^{32}P$	
⁵¹ ₂₄ Cr	27.7 d	EC(100)	0.320	9	${}^{50}\mathrm{Cr}(\mathrm{n},\gamma){}^{51}\mathrm{Cr}$	
⁵² ₂₆ Fe	8.3 h	β ⁺ (56) EC(44)	0.165 0.511 (annihilation)	100 112	${}^{55}Mn(n, 4n){}^{52}Fe$ ${}^{50}Cr(\alpha, 2n){}^{52}Fe$	
⁵⁷ ₂₇ Co	271 d	EC(100)	0.014 0.122 0.136	9 86 11	⁵⁶ Fe(d, n) ⁵⁷ Co	
⁵⁸ ₂₇ Co	71 d	β ⁺ (14.9) EC(85.1)	511 (annihilation) 0.811	30 99.5	55 Mn(α , n) 58 Co	
⁵⁹ ₂₆ Fe	45 d	$\beta^{-}(100)$	1.099 1.292	56 43	58 Fe(n, γ) 59 Fe	
⁶⁰ ₂₇ Co	5.2 у	$\beta^{-}(100)$	1.173 1.332	100 100	⁵⁹ Co(n, γ) ⁶⁰ Co	
⁶² ₂₉ Cu	9.7 min	β ⁺ (97) EC(3)	0.511 (annihilation)	194	${}^{62}\mathrm{Ni}(p, n){}^{62}\mathrm{Cu}$ ${}^{62}\mathrm{Zn} \xrightarrow[\beta^+, \mathrm{EC}]{}^{9.3 \mathrm{h}} \xrightarrow{62} \mathrm{Cu}$	

 Table 4.1
 Characteristics of common radionuclides

(continued)

Nuclides	Physical half-life	Mode of decay (%)	γ-Ray energy ^a (MeV)	Abundance (%)	Common production method
⁶⁴ ₂₉ Cu	12.1 h	$\beta^{+(17.9)}$ $\beta^{-(39)}$ EC(43)	511 (annihilation)	36	⁶⁴ Ni (p, n) ⁶⁴ Cu
⁶⁷ ₂₉ Cu	2.6 d	$\beta^{-}(100)$	0.185 0.92	49 23	⁶⁷ Zn(n, p) ⁶⁷ Cu
⁶² ₃₀ Zn	9.3 h	β ⁺ (8) EC(92)	0.420 0.511 (annihilation) 0.548 0.597	25 16 15 26	⁶³ Cu(p, 2n) ⁶² Zn
⁶⁷ ₃₁ Ga	78.2 h	EC(100)	0.093 0.184 0.300 0.393	40 20 17 5	⁶⁸ Zn(p, 2n) ⁶⁷ Ga
⁶⁸ ₃₁ Ga	68 min	$\beta^{+}(89)$ EC(11)	0.511 (annihilation)	178	⁶⁸ Zn(p, n) ⁶⁸ Ga
⁶⁸ ₃₂ Ge	270.8 d	EC(100)	-	-	66 Zn(α , 2n) 68 Ge
⁸² 37 Rb	75 s	β ⁺ (95) EC(5)	0.511 (annihilation) 776	190 13	$\stackrel{^{82}}{}Sr \xrightarrow{^{25.5days}}_{EC} \stackrel{^{82}}{}Rb$
$^{82}_{38}{ m Sr}$	25.5 d	EC(100)	-	-	⁸⁵ Rb(p, 4n) ⁸² Sr Mo(p, spallation) ⁸² Sr
⁸⁹ ₃₈ Sr	50.6 d	$\beta - (100)$	-	-	88 Sr(n, γ) 89 Sr
⁹⁰ ₃₈ Sr	28.6 у	$\beta - (100)$	-	-	²³⁵ U(n, f) ⁹⁰ Sr
90 39 Y	2.7 d	$\beta - (100)$	-	-	⁸⁹ Y(n, γ) ⁹⁰ Y ⁹⁰ Sr $\xrightarrow{\beta^{-}}_{28.6y}$ ⁹⁰ Y
⁸⁹ ₄₀ Zr	78.1 h	β ⁺ (23) EC(77)	0.511 (annihilation) 909	46 100	⁸⁹ Y (p, n) ⁸⁹ Zr
⁹⁹ ₄₂ Mo	66 h	β ⁻ (100)	0.181 0.740 0.780	6 12 4	⁹⁸ Mo(n, γ) ⁹⁹ Mo ²³⁵ U(n, f) ⁹⁹ Mo
^{99m} ₄₃ Tc	6.0 h	IT(100)	0.140	90	99 Mo $\stackrel{66 \text{ hr}}{\xrightarrow{\beta^-}} ^{99\text{m}}$ Tc
¹¹¹ ₄₉ In	2.8 d	EC(100)	0.171 0.245	90 94	$^{111}Cd(p, n)^{111}In$
^{113m} ₄₉ In	100 min	IT(100)	0.392	64	$^{112}Sn(n, \gamma)^{113}Sn$ $^{113}Sn _{EC} ^{113m}In$

Table 4.1 (continued)

Nuclides	Physical half-life	Mode of decay (%)	γ-Ray energy ^a (MeV)	Abundance (%)	Common production method
¹²³ ₅₃ I	13.2 h	EC(100)	0.159	83	121 Sb $(\alpha, 2n)^{123}$ I
¹²⁴ ₅₃ I	4.2 d	β ⁺ (23) EC(77)	0.511 (annihilation)	46	124 Te(p, n) 124 I
¹²⁵ ₅₃ I	60 d	EC(100)	0.035 X-ray(0.027– 0.032)	7 140	124 Xe(n, γ) 125 Xe 125 Xe $\xrightarrow{17 \text{ hours}}_{\text{EC}}$ 125 I
¹³¹ ₅₃ I	8.0 d	β ⁻ (100)	0.284 0.364 0.637	6 81 7	¹³⁰ Te(n, γ) ¹³¹ Te ²³⁵ U(n, f) ¹³¹ Te ¹³¹ Te $\xrightarrow{25 \text{ min}}_{\beta^-}$ ¹³¹ I ²³⁵ U(n, f) ¹³¹ I
¹³³ ₅₄ Xe	5.3 d	$\beta^{-}(100)$	0.081	37	235 U(n, f) 133 Xe
¹³⁷ ₅₅ Cs	30.0 y	$\beta^{-}(100)$	0.662	85	²³⁵ U(n, f) ¹³⁷ Cs
¹⁵³ ₆₂ Sm	1.9 d	$\beta^{-}(100)$	70 103	5 28	152 Sm(n, γ) 153 Sm
¹⁵³ ₆₄ Gd	241.6 d	EC (100)	97 103	28 20	$^{152}\text{Gd}(n,\gamma)^{153}\text{Gd}$
¹⁷⁷ ₇₁ Lu	6.65 d	β ⁻ (100)	-	-	¹⁷⁶ Yb(n, γ) ¹⁷⁷ Yb ¹⁷⁷ Yb $\xrightarrow{\beta^{-}}_{1.9h}$ ¹⁷⁷ Lu
¹⁸⁶ ₇₅ Re	3.8 d	$\beta^{-}(92)$ EC(8)	137	9	185 Re(n, γ) 186 Re
$^{188}_{74}{ m W}$	69.8 d	$\beta^{-}(100)$	155	15	$^{186}W~(n,\gamma)^{187}W,~^{187}W \\ (n,\gamma)^{188}W$
²⁰¹ ₈₁ Tl	73 h	EC(100)	167 X-ray (0.069–0.083)	9.4 93	${}^{203}\text{Tl}(p, 3n)^{201}\text{Pb}$ ${}^{201}\text{Pb} \xrightarrow[\text{EC}]{}^{9.3\text{hr}} \;\;^{201}\text{Tl}$
²²³ ₈₈ Ra	11.4 d	α (95.3) β ⁻ (3.6)			$\stackrel{226}{\xrightarrow{\beta^{-}}} Ra (n, \gamma) \stackrel{227}{\xrightarrow{\rho^{-}}} Ra \xrightarrow{\beta^{-}} \stackrel{227}{\xrightarrow{\rho^{-}}} Ac \xrightarrow{\beta^{-}} \stackrel{227}{\xrightarrow{\rho^{-}}} Th$

Table 4.1 (continued)

Note: IT isomeric transition, *EC* electron capture, *f* fission, *d* deuteron or day, *n* neutron, *p* proton, α alpha particle

 $^{a}\gamma$ -Rays with abundance less than 4% and those having energy less than 20 keV have not been cited. Data are from many different references available in literature and websites

4.5 Specific Activity

Specific activity is defined as the radioactivity per unit mass of a radionuclide or a labeled compound. For example, suppose that 100-mg ¹³¹I-labeled albumin contains 150-mCi (5.55 GBq) ¹³¹I radioactivity. Its specific activity would be 150/100, that is, 1.5 mCi/mg or 55.5 MBq/mg. Sometimes it is confused with concentration, which is defined as the radioactivity per unit volume of a sample. A 10-ml solution containing 45-mCi (1.67 GBq) radioactivity will have a concentration of 4.5 mCi/ml (167 MBq/ml). Specific activity is at times expressed in terms of the radioactivity per mole of a labeled compound, for example, mCi/mole (MBq/mole) or mCi/ μ mole (MBq/ μ mole) for ³H-, ¹⁴C-, and ³⁵S-labeled compounds.

The specific activity of a carrier-free radionuclide sample is related to the halflife of the radionuclide: the shorter the half-life, the higher the specific activity. For example, carrier-free ^{99m}Tc and ¹³¹I have specific activities of 5.27×10^6 mCi/mg $(1.95 \times 10^5 \text{ GBq/mg})$ and 1.25×10^5 mCi/mg $(4.6 \times 10^3 \text{ GBq/mg})$, respectively. The derivation of these values should be understood from the following problem.

Problem 4.3 What is the specific activity of carrier-free ¹¹¹In ($t_{1/2} = 67$ h)?

Answer In 1 mg ¹¹¹In, the number of atoms N of ¹¹¹In is

$$N = \frac{1 \times 10^{-3} \times 6.02 \times 10^{23}}{111}$$

The decay constant λ of ¹¹¹In is

$$\lambda = \frac{0.693}{67 \times 60 \times 60} \, \mathrm{s}^{-1}$$

In 1 mg ¹¹¹In, the number of atoms N of ¹¹¹In is

$$N = \frac{1 \times 10^{-3} \times 6.02 \times 10^{23}}{111}$$

The decay constant λ of ¹¹¹In is

$$\lambda = \frac{0.693}{67 \times 60 \times 60} \, \mathrm{s}^{-1}$$

$$A = \lambda N$$

= $\frac{0.693 \times 10^{-3} \times 6.02 \times 10^{23}}{67 \times 60 \times 60 \times 111}$ dps
= 1.56×10^{13} dps
= 4.22×10^{5} mCi

Therefore, the specific activity of ¹¹¹In is 4.22×10^5 mCi/mg or 1.56×10^4 GBq/mg.

The specific activity of a carrier-free or NCA radionuclide can be calculated by the following formula:

Specific activity (mCi / mg) =
$$\frac{3.13 \times 10^9}{A \times t_{1/2}}$$
 (4.4)

where *A* is the mass number of the radionuclide and $t_{1/2}$ is the half-life in hours of the radionuclide.

The specific activity of a radiopharmaceutical is an important information for a particular nuclear medicine test and is often provided on the label posted on the vial. Low specific activity is of little value in some labeling procedures because the cold atoms compete with radioactive atoms for the binding sites of the reacting molecules and thus lower the labeling yield. Similarly in nuclear medicine studies, cold atoms in low-specificity sample compromises the uptake of the tracer in the tissue of interest in vivo. On the other hand, high specific activity can cause radiolysis in the solution of a compound, resulting in the breakdown of the compound into undesirable impurities. Proteins are denatured by high specific activities.

Questions

- 1. Describe the different methods of production of radionuclides and discuss the merits and disadvantages of each method.
- 2. If ¹²⁷I is irradiated with protons in a cyclotron and three neutrons are emitted from the nucleus, what is the product of the nuclear reaction? Write the nuclear reaction.
- 3. In fission, how many neutrons are emitted and what is their average energy? What is the average energy released in fission?
- 4. Why are cadmium rods and graphite used in the reactor?
- 5. Which are the important therapeutic radiopharmaceuticals in nuclear medicine?
- 6. Outline the procedure for separating ¹³¹I and ⁹⁹Mo from the fission products of ²³⁵U.

- 7. (a) Calculate the activity in millicuries of ¹²³I produced by the ¹²¹Sb (α , 2n) ¹²³I reaction, when 200-mg natural antimony (natural abundance of ¹²¹Sb is 57.3%) is irradiated for 2 h with an α -particle beam of 25-MeV energy and an intensity of 10¹⁴ particles/(cm².s). The cross-section for formation of ¹²³I ($t_{1/2} = 13.2$ h) is 28 mbarns.
- 8. After how many half-lives of irradiation does the radionuclide yield reach maximum?
- 9. (b) What is the number of 123 I atoms produced after irradiation?
- 10. (c) What is the activity of 123 I 6 h after irradiation?
- 11. Calculate the specific activities of carrier-free or NCA ¹³¹I, ^{99m}Tc, ³²P, and ⁶⁷Ga ($t_{1/2} = 8 \text{ d}, 6 \text{ h}, 14.3 \text{ d}, \text{ and } 78 \text{ h}, \text{ respectively}$).
- 12. Why is the specific activity of radionuclides higher in fission than in the (n, γ) reaction?
- 13. Is the specific activity higher for radionuclides having a longer half-life?
- 14. Calculate the duration of irradiation necessary to produce 600 mCi (22.2 GBq) of ⁹⁹Mo by irradiating 4 g of ²³⁵U in the nuclear reactor whose thermal neutron flux is 2×10^{14} neutrons/(cm².s). (Assume the formation cross-section of ⁹⁹Mo is 20 mbarns and the half-life of ⁹⁹Mo is 66 h.)
- 15. Describe what type of radiations is needed for therapeutic radiopharmaceuticals and diagnostic radiopharmaceuticals.

References and Suggested Reading

- Braghirolli AMS, Waissmann W, Da Silva JB, et al. Production of iodine-124 and its applications in nuclear medicine. Appl Radiat Isot. 2014;90:138.
- Browne E, Firestone RB. Table of radioactive isotopes. New York: Wiley; 1986.
- Dash A, Raghavan M, Pillai A, et al. Production of ¹⁷⁷Lu for targeted radionuclide therapy: available options. Nucl Med Mol Imaging. 2015;49:85.
- Fassbender ME, Ballard B, Birnbaum ER, et al. Proton irradiation parameters and chemical separation procedure for the bulk production of high specific activity ¹⁸⁶gRe using WO₃ targets. Radiochim Acta. 2013;101:339.
- Fitzsimmons JM, Mausner L. Production scale purification of Ge-68 and Zn-65 from irradiated gallium metal. Appl Radiat Isot. 2015;101:60.
- Friedlander G, Kennedy JW, Macias ES, Miller JM. Nuclear and radiochemistry. 3rd ed. New York: Wiley; 1981.
- Green MA, Mathias CJ, Welch MJ, et al. Copper-62-labeled Pyruvaldehyde Bis(N4-Methylthiosemicarbazonato)copper II: synthesis and evaluation as a positron emission tomography tracer for cerebral and myocardial perfusion. J Nucl Med. 1990;31:1989.
- Holland JP, Sheh Y, Lewis JS. Standardized methods for the production of high specific activity zirconium-89. Nucl Med Biol. 2009;36:729.
- International Atomic Energy Agency. Cyclotron produced radionuclides: principles and practice. Technical report series no 465. 2008.
- International Atomic Energy Agency. Manual for reactor produced radioisotopes. IAEA-TECDOC-1340. 2003.
- International Atomic Energy Agency. Production of long-lived parent nuclides for generators: ⁶⁸Ge, ⁸²Sr, ⁹⁰Sr and ¹⁸⁸W. IAEA Radioisotopes and Radiopharmaceuticals Series No. 2. 2010.

- International Atomic Energy Agency. Therapeutic radionuclide generators: ⁹⁰Sr/⁹⁰Y and ¹⁸⁸W/¹⁸⁸Re generators. Vienna. Technical Report Series No. 470. 2009.
- Jao Y, Cheng WL, Ting G. Chromatographic separation and purification of xenon-133. J Chromatogr. 1989;462:191.
- Kumar R, Singh H, Jacob M. Production of nitrogen-13-labeled ammonia by using 11MeV medical cyclotron: our experience. Hell J Nucl Med. 2009;12:248.
- Lahiri S, Maiti M, Ghosh K. Production and separation of ¹¹¹In: an important radionuclide in life sciences: a mini review. J Radioanal Nucl Chem. 2013;297:309.
- Lebowitz E, Greene MW, Fairchild R, et al. Thallium 201 for medical use. J Nucl Med. 1975;16:151.
- Mirzadeh S, Mausner LF, Garland MA. Reactor produced medical radionuclides. In: Vértes A, Nagy S, Klencsár Z, editors. Handbook of nuclear chemistry, vol. 4. Dordrecht: Kluwer; 2003.
- National Research Council (US) Committee on Medical Isotope Production Without Highly Enriched Uranium. Medical isotope production without highly enriched uranium. Washington (DC): National Academies Press (US); 2009. 2, Molybdenum-99/Technetium-99m Production and Use. Available from: https://www.ncbi.nlm.nih.gov/books/NBK215133/.
- Package insert from Bayer Pharmaceuticals Inc, 2016.
- Poggenburg JK. The nuclear reactor and its products. Semin Nucl Med. 1974;4:229.
- Powell J, O'Neil JP. Production of [150]-water at low-energy proton cyclotrons. Scholarship; Univ of California, Berkeley, 2005.
- Quaim SM. Cyclotron production of medical radionuclides. In: Vértes A, Nagy S, Klencsár Z, editors. Handbook of nuclear chemistry, vol. 4. Dordrecht: Kluwer; 2003.
- Saha GB. Miscellaneous radiotracers for imaging. In: GVS R, editor. Radiotracers for medical applications, vol. II. Boca Raton: CRC Press; 1983. p. 119.
- Saha GB, MacIntyre WJ, Go RT. Cyclotrons and positron emission tomography for clinical imaging. Semin Nucl Med. 1992;22:150.
- Vimalnath KV, Shetty P, Rajeswari A, et al. Reactor production of ³²P for medical applications: an assessment of ³²S (n, p) ³²P and ³¹P (n, γ) ³²P methods. J Radioanal Nucl Chem. 2014;301:555.

Radionuclide Generators

5

5.1 Principles of a Generator

The use of short-lived radionuclides has grown considerably, because larger dosages of these radionuclides can be administered to the patient with only minimal radiation dose and produce excellent image quality. This increasing appreciation of short-lived radionuclides has led to the development of radionuclide generators that serve as convenient sources of their production (Guillaume and Brihaye 1986; Rösch and Knapp 2003). A generator is constructed on the principle of the decay–growth relationship between a long-lived parent radionuclide and its short-lived daughter radionuclide. The chemical property of the daughter nuclide must be distinctly different from that of the parent nuclide so that the former can be readily separated. In a generator, basically a long-lived parent nuclide is allowed to decay to its short-lived daughter nuclide, and the latter is then chemically separated. The importance of radionuclide generators lies in the fact that they are easily transportable and serve as sources of short-lived radionuclides in institutions far from the site of a cyclotron or reactor facility.

A radionuclide generator consists of a glass or plastic column fitted at the bottom with a fritted disk. The column is filled with adsorbent material such as cation- or anion-exchange resin, alumina, and zirconia, on which the parent nuclide is adsorbed. The daughter radionuclide grows as a result of the decay of the parent until either a transient or a secular equilibrium is reached within several half-lives of the daughter, after which the daughter appears to decay with the same half-life as the parent. Because there are differences in chemical properties, the daughter activity is eluted in a carrier-free state with an appropriate solvent, leaving the parent on the column. After elution, the daughter activity starts to grow again in the column until an equilibrium is reached in the manner mentioned above; the elution of activity can be made repeatedly. A schematic of a typical generator is presented in Fig. 5.1. The vial containing the eluent is first inverted onto needle A, and another evacuated vial is inverted onto the other needle B. The vacuum in the vial on needle B draws the eluent through the column and elutes the daughter nuclide, leaving the parent nuclide on the column.

https://doi.org/10.1007/978-3-319-57580-3_5



Fig. 5.1 Typical generator system. The daughter activity grown by the decay of the parent is separated chemically from the parent. The eluent in vial A is drawn through the column, and the daughter nuclide is collected in vial B under vacuum

A radionuclide generator must be sterile and pyrogen-free. The generator system may be sterilized either by autoclaving the entire column or by preparing it from sterile materials under aseptic conditions. Often, bacteriostatic agents are added to the generator column to maintain sterility, or a membrane filter unit is attached to the end of the column. Elution or "milking" of the generator is carried out under aseptic conditions.

An ideal radionuclide generator should be simple, convenient, and rapid to use and give a high yield of the daughter nuclide repeatedly and reproducibly. It should be properly shielded to minimize radiation exposure and sturdy and compact for shipping. The generator eluate should be free from the parent radionuclide and the adsorbent material. Other extraneous radioactive contaminants should be absent in the eluate. The daughter nuclide should decay to a stable or very long-lived nuclide so that the radiation dose to the patient is minimal. Even though the parent activity may be eluted in an extremely small quantity $(10^{-5}-10^{-6}$ times the daughter activity), the radiation dose to the patient may become appreciable if it has a long effective half-life (see Chap. 6).

The first commercial radionuclide generator was the ¹³²Te ($t_{1/2} = 78$ h)–¹³²I ($t_{1/2} = 2.3$ h) system developed at the Brookhaven National Laboratory in the early 1960s. Since then, a number of other generator systems have been developed and tried for routine use in nuclear medicine. Only a few of these generators are of importance in nuclear medicine; they are the ⁹⁹Mo–^{99m}Tc, ⁸²Sr–⁸²Rb, and ⁶⁸Ge–⁶⁸Ga systems. Several generator systems, including those above, are presented in Table 5.1 along with their properties.

Parent	Parent $t_{1/2}$	Nuclear reaction	Daughter	Daughter $t_{1/2}$	Mode of daughter decay	Principal photon energy (keV) (% abundance)	Column	Eluent
⁹⁹ Mo	66 h	Fission, ⁹⁸ Mo(n, γ)	^{99m} Tc	6 h	IT	140 (90)	Al ₂ O ₃	0.9% NaCl
⁶⁸ Ge	270.8 d	⁶⁹ Ga(p, 2n)	⁶⁸ Ga	68 min	$\beta^{\scriptscriptstyle +}$	511 (178)	TiO ₂	0.1HCl
							SnO ₂	0.6 N HCl
⁶² Zn	9.3 h	⁶³ Cu(p, 2n)	⁶² Cu	9.7 min	$\beta^{\scriptscriptstyle +}$	511 (194)	Dowex 1X8	2 N HCl
⁸¹ Rb	4.6 h	⁷⁹ Br(α , 2n)	^{81m} Kr	13 s	IT	190 (67)	Bio-Rad AG 50	Water or air
⁸² Sr	25.5 d	⁸⁵ Rb(p, 4n)	⁸² Rb	75 s	$\beta^{\scriptscriptstyle +}$	511 (190)	SnO ₂	0.9% NaCl
90Sr	28.6 y	Fission	⁹⁰ Y	64.1 h	β^-	-	Dowex 50	0.03 <i>M</i> EDTA
²²⁷ Ac ↓ ²²⁷ Th	21.8 y 18.7 d	$^{227}Ac \rightarrow ^{227}Th$	²²³ Ra	11.2 d	α	-	EHMDP on silica	1 M HCl

 Table 5.1
 Several generator systems useful in nuclear medicine

IT isomeric transition. Data are collected from many sources in literature

5.2 Important Radionuclide Generators

5.2.1 ⁹⁹Mo-^{99m}Tc Generator

The ⁹⁹Mo radionuclide has a half-life of 66 h and decays by β^- -emission; 87% of its decay goes ultimately to the metastable state ^{99m}Tc and the remaining 13% to the ground state ⁹⁹Tc. It has photon transitions of 740 and 780 keV. The radionuclide ^{99m}Tc has a half-life of 6 h and decays to ⁹⁹Tc by isomeric transition of 140 keV. Approximately 10% of these transitions are via internal conversion. The ground state ⁹⁹Tc has a half-life of 2.1 × 10⁵ years and decays to stable ⁹⁹Ru by β^- -emission.

Because the half-lives of ⁹⁹Mo and ^{99m}Tc differ by a factor of about 11, these two radionuclides lend themselves to the construction of a useful generator. The extreme usefulness of this generator is due to the excellent radiation characteristics of ^{99m}Tc, namely, its 6-h half-life, little electron emission, and a high yield of 140-keV γ -rays (90%), which are nearly ideal for the current generation of imaging devices in nuclear medicine (Eckelman and Coursey 1982).

Liquid Column Generator

The ⁹⁹Mo–^{99m}Tc generator was first introduced at the Brookhaven National Laboratory. Before this generator was developed, the ^{99m}Tc radioactivity used to be extracted with methyl ethyl ketone (MEK) from a 20% NaOH solution (pH ~ 10–12) of ⁹⁹Mo. After extraction, the organic phase was evaporated, and the ^{99m}Tc O_4^- dissolved in isotonic saline for clinical use. This method of solvent extraction has been employed to construct the liquid–liquid extractor type of generator for the

⁹⁹Mo–⁹⁹mTc system. The basic principle involves placing the 20% NaOH solution of ⁹⁹Mo in a glass column and then letting MEK flow through the column from the bottom. MEK will extract ⁹⁹mTc O_4^- leaving ⁹⁹Mo in the aqueous solution. Repeated elutions of the column can be made after or before the transient equilibrium between ⁹⁹Mo and ⁹⁹mTc is reached. The advantage of this generator is that the cost of ⁹⁹mTc is low. But the disadvantage is that it needs a lot of manipulation in the overall method. It is rarely used in nuclear medicine.

Solid Column Generator

The solvent extraction technique has been replaced by the solid column generator for obtaining ^{99m}Tc. The ⁹⁹Mo–^{99m}Tc or "Moly" generator is constructed with alumina (Al₂O₃) loaded in a plastic or glass column. The amount of alumina used is of the order of 5–10 g, depending on the total activity of ⁹⁹Mo. The ⁹⁹Mo radioactivity is adsorbed on alumina in the chemical form Mo O₄^{2–} (molybdate) and in various amounts. The column is thoroughly washed with 0.9% NaCl solution to remove any undesirable activity. Currently, all generators are made with fission-produced ⁹⁹Mo.

The generator columns are shielded with lead for radiation protection. Some commercial firms use depleted uranium in lieu of lead for shielding high ⁹⁹Mo activity generators (8.3–16.6 Ci or 307–614 GBq) because ²³⁸ U has higher Z and therefore attenuates γ -rays more efficiently (depleted uranium is natural uranium from which ²³⁵U has been removed, leaving only ²³⁸U).

After adsorption of ⁹⁹Mo on alumina, ^{99m}Tc grows by the decay of ⁹⁹Mo according to Eq. (2.10) until its maximum activity is reached after approximately four half-lives of ^{99m}Tc. At equilibrium and thereafter, the ^{99m}Tc radioactivity follows the half-life of ⁹⁹Mo. The typical decay–growth relationship between ⁹⁹Mo and ^{99m}Tc is illustrated in Fig. 5.2 for a 100-mCi (3.7-GBq) generator.

Fig. 5.2 Typical decay-growth relationship of 99Mo and 99mTc activities in a Moly generator. On day 2, 99mTc activity is eluted with saline and then starts growing after elution. The yield of 99mTc is approximately 80-90%. It takes approximately 24 h to reach maximum activity of 99mTc after elution. Positions a and b indicate elutions of 99mTc activity at 8 and 17 h after elution on day 4



The ^{99m}Tc radionuclide is eluted as sodium pertechnetate (Na^{99m}TcO₄) with a 0.9% NaCl solution (saline without any additives). After elution, the ^{99m}Tc radioactivity starts to grow again in the column. Elution may be carried out, if needed, even before equilibrium is reached (*a* and *b* in Fig. 5.2). The amount of ^{99m}Tc activity obtained in this case will depend on the time elapsed between the previous and present elutions.

The ⁹⁹Mo–^{99m}Tc generators are available from several commercial suppliers. In some commercial generators, isotonic saline is provided in a bottle that is placed inside the generator housing, and aliquots of saline are used up to elute ^{99m}Tc-pertechnetate (^{99m}Tc O_4^-) using evacuated vials. Evacuated vials of different volumes are supplied by vendors for elution in order to have approximately the same daily concentrations of ^{99m}Tc activity on consecutive days. Larger volume vials are used in the beginning of the week, and smaller volume vials are used in the latter part of the week. In other generators, vials with definite volumes of saline for each elution are provided. A generator supplied by Mallinckrodt Pharmaceuticals is shown in Fig. 5.3.



Fig. 5.3 A ⁹⁹Mo–^{99m}Tc generator (Ultra-Technekow DTE) (Courtesy of Mallinckrodt Pharmaceuticals)

There are two types of solid Moly generators, wet column generators and dry column generators, supplied by different manufacturers. The difference between the two types is that in a dry column generator after routine elution, the leftover saline in the column is drawn out by using an evacuated vial without adding any more saline or the vacuum in the evacuated eluent vial is sufficient to remove all saline from the column. The suggestion for a dry column generator came from the fact that radiation can cause radiolysis of water in a wet generator resulting in the formation of hydrogen peroxide (H₂O₂) and perhydroxyl free radical (HO[•]₂). These species are oxidants and, if present in the ^{99m}Tc-eluate, can interfere with the technetium chemistry outlined in Chap. 6. The radiolysis of water is likely to be greater in high-activity generators. Also, in wet column generators, saline in the tubing may possibly freeze in extremely cold weather during shipping, thus preventing elution until thawed.

Yield of ^{99m}Tc

It is often necessary to calculate the theoretical yield of ^{99m}Tc one would obtain after elution from a generator at a given time Holland et al. 1986a, b. The yields at various times can be calculated from Eq. (2.10) as follows (the mass numbers of ^{99m}Tc and ⁹⁹Mo have been omitted in equations in order to avoid complications in representing different symbols):

$$\lambda_{Mo} = 0.693 / 66 = 0.0105 h^{-1}$$
$$\lambda_{Tc} = 0.693 / 6 = 0.1155 h^{-1}$$

Then Eq. (2.10) becomes

$$A_{\rm Tc} = 1.1 (A_{\rm Mo})_0 (e^{-0.0105t} - e^{-0.1155t})$$
(5.1)

where *t* is the time in hours elapsed after the previous elution. If there is any activity of 99m Tc left from the previous elution, that should also be added. Thus,

$$A_{\rm Tc} = 1.1 (A_{\rm Mo})_0 (e^{-0.0105t} - e^{-0.1155t}) + (A_{\rm Tc})_0 e^{-0.1155t}$$
(5.2)

Since 87% of all ⁹⁹Mo nuclides ultimately decay to ^{99m}Tc, this factor should be included in the above equation by multiplying A_{Mo} by 0.87. Taking this factor into consideration, Eq. (5.2) reduces to

$$A_{\rm Tc} = 0.957 (A_{\rm Mo})_0 (e^{-0.0105t} - e^{-0.1155t}) + (A_{\rm Tc})_0 e^{-0.1155t}$$
(5.3)

From Eq. (5.3), one can calculate the theoretical yield of ^{99m}Tc from a Moly generator at a given time. For practical reasons, it is not possible to obtain a complete yield of ^{99m}Tc from a generator as predicted by Eq. (5.3). The yield may be reduced by a column defect, such as channeling in the adsorbent bed, or by autoradiolysis due to high radioactivity whereby the chemical form of ^{99m}Tc changes. The practical yield of ^{99m}Tc varies from generator to generator and usually ranges from 80% to 90% of the theoretical value. The concentration of ^{99m}Tc activity in the eluate initially increases, then reaches a maximum, and finally decreases with increasing volume of the eluate (Fig. 5.4).



It is important to note that in a Moly generator, $(A_{Tc})_0$ is zero at the time of loading ⁹⁹Mo on the generator column. Afterward, if it is eluted only once daily, the amount of $(A_{Tc})_0$ (~5–15%) would have decayed to less than 1% in 24 h and would not be significant enough to be considered in the calculation of the theoretical yield of ^{99m}Tc the next day. However, if the time difference between the two successive elutions is only several hours, the contribution of $(A_{Tc})_0$ could be appreciable and must be taken into account. If $(A_{Tc})_0$ is neglected in the daily elution of a generator, then the maximum activity of ^{99m}Tc is achieved in about four half-lives (i.e., in approximately 24 h). Thereafter, the transient equilibrium between ⁹⁹Mo and ^{99m}Tc will be reached and Eq. (5.3) becomes

$$A_{\rm Tc} = 0.957 (A_{\rm Mo})_{\rm r}$$
(5.4)

where

$$(A_{\rm Mo})_t = (A_{\rm Mo})_0 e^{-0.0105t}$$
 (5.5)

It should be pointed out that ^{99m}Tc decays by 140-keV γ -transition (90%) and via internal conversion (10%). Therefore, one has to multiply the above A_{Tc} values by 0.90 in order to estimate the number of photons available for imaging.

Usually the amount of ⁹⁹Mo along with the date and time of calibration is recorded on the generator by the commercial supplier. Different suppliers use different days of the week for calibration. As required by the US Food and Drug Administration (FDA), ⁹⁹Mo radioactivity is calibrated as of the day of shipping and must be so stated on the label posted on the generator. The amount of calibrated ⁹⁹Mo activity in a given generator can vary from 0.22 to 3 Ci (8.1–111 GBq) depending on the manufacturer. In a 3-Ci (111-GBq) Covidien (formerly Mallinckrodt) generator calibrated for Friday 8:00 p.m. (shipping day), the ⁹⁹Mo activity reduces to 600 mCi (22.2 GBq) at 8:00 a.m. the following Friday. One manufacturer uses 8.3–16.6 Ci (307–614 GBq) ⁹⁹Mo in generators. These generators are used by large institutions in lieu of two to three 2–3-Ci (74–111-GBq) generators. An institution or a commercial nuclear pharmacy purchases a given-size Moly generator depending on its need so that enough ⁹⁹Tc activity is available on the last day of the workweek.

Problem 5.1

A 2.6-Ci (96.2-GBq) Moly generator calibrated for Wednesday noon was received on Tuesday before. What would be the total ^{99m}Tc activity eluted at 8:00 a.m. on Friday?

Answer

It is assumed that by the time the generator is received, the equilibrium between ⁹⁹Mo and ^{99m}Tc has been reached and still exists at 8:00 a.m. on Friday. The time from Wednesday noon to Friday 8:00 a.m. is 44 h.

⁹⁹ Mo activity on Wednesday noon = 2.6 Ci(96.2 GBq) ⁹⁹ Mo activity at 8:00 a.m.on Friday = $2.6 \times \exp(-0.0105 \times 44)$ = 1.64 Ci(61GBq)

Assuming complete elution, according to Eq. (5.4), 99m Tc activity at 8:00 a.m. on Friday will be

 99m Tcactivity = 0.957 × 1.64Ci = 1.57Ci(58.1GBq)

Problem 5.2

A 3000-mCi (111-GBq) Moly generator calibrated for Friday 8:00 p.m. was eluted at 8:00 a.m. the following Wednesday. Assuming that 80% of ^{99m}Tc activity was eluted, what would be the theoretical activity of ^{99m}Tc on the column at 1:00 p.m. on the same day (Wednesday)?

Answer

The time from Friday 8:00 p.m. to Wednesday 8:00 a.m. is 108 h. Therefore, ⁹⁹Mo activity at 8:00 a.m. on Wednesday

 $= 3000 \times \exp(-0.0105 \times 108) = 965 \text{mCi}(35.7 \text{GBq})$

Assuming transient equilibrium, according to Eq. (5.4),

$99m$
Tc activity = 0.957 × 965 = 923mCi(34.2GBg)

With 80% elution, 20% remained in the generator; i.e., $0.2 \times 923 = 184.6$ -mCi (6.83 GBq) ^{99m}Tc remained on the column. This is $(A_{Tc})_0$ in Eq. (5.3).

The time from 8:00 a.m. to 1:00 p.m. on Wednesday is 5 h. From Eq. (5.3),

$$A_{\rm Tc} = 0.957 \times 965 \left[\exp(-0.0105 \times 5) - \exp(-0.1155 \times 5) \right] \\ +184.6 \times \exp(-0.1155 \times 5) \\ = 923(0.9489 - 0.5613) + 103.6 \\ = 461.4 \text{mCi}(17.1\text{GBq})$$

^{99m}Tc Content in ^{99m}Tc-Eluate

Both ⁹⁹Mo (13%) and ^{99m}Tc decay to ⁹⁹Tc, and, therefore, both ⁹⁹Tc and ^{99m}Tc are present in the Tc-eluate from the Moly generator. Because of the rapid decay of ^{99m}Tc, the fraction of ^{99m}Tc in the generator eluate decreases, and that of ⁹⁹Tc increases over time after elution and as the time between generator elutions increases. Since ⁹⁹Tc competes with ^{99m}Tc in chemical binding, it can reduce the labeling efficiency in radiopharmaceutical kits containing small amounts of stannous ion. This situation becomes critical when the generators are left without elution over the weekend and then first eluted on Monday or Tuesday. In some radiopharmaceutical preparations, limits on the content of ⁹⁹Tc in the Tc-eluate are implicitly specified in that only the ^{99m}Tc eluted at specific times can be used. For example, in ^{99m}Tc-HMPAO preparation for brain imaging, the ^{99m}Tc-eluate must not be more than 2-h old and also must be obtained from a generator that was eluted at least once in the past 24 h.

The 99m Tc content in the Tc-eluate is given by the mole fraction (*F*) of 99m Tc expressed as follows:

$$F = \frac{N_{\rm A}}{N_{\rm A} + N_{\rm B}} \tag{5.6}$$

where N_A and N_B are the number of atoms of ^{99m}Tc and ⁹⁹Tc, respectively. The F at any time *t* can be calculated from the following expression (Lamson et al. 1975):

$$F = \frac{0.87\lambda_1 \left(\exp(-\lambda_1 t) - \exp(-\lambda_2 t) \right)}{(\lambda_2 - \lambda_1) \left(1 - \exp(-\lambda_1 t) \right)}$$
(5.7)

where λ_1 and λ_2 are decay constants of ⁹⁹Mo and ^{99m}Tc, respectively, and the factor 0.87 indicates that 87% of ⁹⁹Mo decays to ^{99m}Tc. Using $\lambda_1 = 0.0105$ h⁻¹ and $\lambda_2 = 0.1155$ h⁻¹, the values of F at various times are calculated and tabulated in Table 5.2. It can be seen that, for example, at 24 h after elution, only 27.9% of Tc atoms are ^{99m}Tc in the eluate, and the remaining 72.1% are ⁹⁹Tc.

Days after elution	Hours after elution								
	0	3	6	9	12	15	18	21	
0		0.7346	0.6254	0.5366	0.4641	0.4044	0.3550	0.3138	
1	0.2791	0.2498	0.2249	0.2035	0.1851	0.1691	0.1551	0.1428	
2	0.1319	0.1222	0.1136	0.1059	0.0990	0.0927	0.0869	0.0817	
3	0.0770	0.0726	0.0686	0.0649	0.0614	0.0583	0.0553	0.0526	
4	0.0500	0.0476	0.0454	0.0432	0.0413	0.0394	0.0377	0.0360	

Table 5.2 Mole fractions of ^{99m}Tc in Tc-eluate at different times after elution

Since the total number (*N*) of Tc atoms affects the labeling yield of 99m Tc radiopharmaceuticals, its prior knowledge is important in many preparations. It can be calculated by the following formula using F from Table 5.2:

$$N_{(\text{Total})} = \frac{99\text{m}\,\text{Tc Activity}}{0.1155 \times F}$$
(5.8)

Quality Control of ^{99m}Tc-Eluate

Since ^{99m}Tc activity is used for humans, several quality control tests of the ^{99m}Tceluate are mandatory. These tests are discussed below in some detail.

⁹⁹Mo Breakthrough

This is ⁹⁹Mo contamination in the ^{99m}Tc-eluate and originates from the small quantity of ⁹⁹Mo that may be eluted with ^{99m}Tc. The *US Pharmacopeia* (*USP 39*) limit [also the NRC limit] is $0.15-\mu$ Ci ⁹⁹Mo/mCi (0.15 kBq/MBq) ^{99m}Tc at the time of administration. For ⁹⁹Mo–^{99m}Tc generators, the ⁹⁹Mo breakthrough must be determined for every elution. The ⁹⁹Mo contamination is measured by detecting 740-keV and 780-keV photons of ⁹⁹Mo in a dose calibrator or a NaI(Tl) detector coupled to a pulse height analyzer. The eluate vial is placed in a lead pot (about 6-mm thick) to stop all 140-keV photons from ^{99m}Tc and to count only 740-keV and 780-keV photons from ⁹⁹Mo. The shielded vial is then assayed in the dose calibrator using the ⁹⁹Mo setting. Molybdenum-99 along with ⁹⁸Mo (from the molybdenum target) can also be detected by adding phenylhydrazine to the eluate and observing the color change due to the Mo-phenylhydrazine complex by the use of a colorimeter.

The A_{Mo}/A_{Tc} ratio increases with time because ⁹⁹Mo ($t_{1/2} = 66$ h) decays more slowly than ^{99m}Tc ($t_{1/2} = 6$ h). The time at which the A_{Mo}/A_{Tc} ratio will exceed 0.15 can be calculated by

$$0.15 = \frac{\left(A_{\rm Mo}\right)_0 e^{-0.0105t}}{\left(A_{\rm Tc}\right)_0 e^{-0.1155t}}$$

where $(A_{Mo})_0$ is the activity of ⁹⁹Mo in microcurie, $(A_{Tc})_0$ is the activity of ^{99m}Tc in millicurie at the time of elution, and *t* is the time after initial elution. Rearranging the equation, *t* in hours can be calculated as

$$t = \frac{-\ln\left[\left(A_{\rm Mo}\right)_0 / \left(A_{\rm Tc}\right)_0\right]}{0.105} - 18.07$$
(5.9)

 99m Tc O₄⁻ obtained from the Moly generator has an expiration period of 12 h for clinical use. For valid use of 99m TcO₄⁻ for 12 h, the $(A_{Mo})_0/(A_{Tc})_0$ ratio at the initial elution can be calculated by Eq. (5.9) to be 0.043 µCi of 99 Mo/mCi of 99m Tc or 0.043 kBq of 99 Mo/MBq of 99m Tc.

Other Radionuclide Contamination

In generators using fission-produced molybdenum, a number of extraneous activities such as those of ¹⁰³Ru, ¹³²Te, ¹³¹I, ⁹⁹Zr, ¹²⁴Sb, ¹³⁴Cs, ⁸⁹Sr, ⁹⁰Sr, and ⁸⁶Rb may remain in the eluate as contaminants. The *USP 39* limits of these radionuclides in ^{99m}Tc-eluate are ¹³¹I, 0.05- μ Ci/mCi (0.05 Bq/kBq) ^{99m}Tc; ¹⁰³Ru, 0.05- μ Ci/mCi (0.05 Bq/kBq) ^{99m}Tc; ⁸⁹Sr, 0.0006- μ Ci/mCi (0.0006 Bq/kBq) ^{99m}Tc; ⁹⁰Sr, 0.00006- μ Ci/mCi (0.00006 Bq/kBq) ^{99m}Tc; ⁹⁰Sr, 0.00006- μ Ci/mCi (0.0016 Bq/kBq) ^{99m}Tc; ⁹⁰Sr, 0.00006- μ Ci/mCi (0.001 Bq/MBq) ^{99m}Tc. These contaminants can be checked by a multichannel pulse height analyzer after allowing ^{99m}Tc, ⁹⁹Mo, and other relatively short-lived radionuclides to decay completely. Usually these tests are performed by the manufacturer.

Aluminum Breakthrough

The aluminum contamination originates from the alumina bed of the generator. The presence of aluminum in the ^{99m}Tc-eluate interferes with the preparation of ^{99m}Tc-sulfur colloid; particularly phosphate buffer in colloid preparations tends to precipitate with excessive aluminum. It also interferes with the labeling of red blood cells with ^{99m}Tc, causing their agglutination. The *USP 39* limit is $10\mu g$ Al/ml ^{99m}Tc for fission-produced ⁹⁹Mo.

The presence of aluminum can be detected by the colorimetric method using aurintricarboxylic acid or methyl orange and can be quantitated by comparison with a standard solution of aluminum. Test kits are commercially available for the determination of aluminum. In these kits, strips containing a color complexing agent are provided along with a standard solution of aluminum (~10 μ g/ml). In a routine test, one drop each of the ^{99m}Tc-eluate and the standard aluminum solution are spotted on a test strip, and the intensities of the colors of the two spots are visually compared. If the ^{99m}Tc-eluate spot is denser than the standard aluminum spot, then the amount of aluminum is considered excessive, and the ^{99m}Tc-eluate should be discarded. Excessive amounts of aluminum in the eluate indicate lack of stability of the column.

рΗ

The pH of the eluate should be between 4.5 and 7.5; this can be checked quantitatively with a pH meter or qualitatively with pH paper. The actual pH of the 99m Tceluate from the generator is about 5.5. The pH of the 99m Tc solution obtained by methyl ethyl ketone extraction is slightly higher (~6–7).

Radiochemical Purity

The radiochemical impurities of the 99m Tc-eluate are different chemical forms of radioactivity other than 99m Tc O_4^- . These impurities should be checked by suitable analytical methods. These methods are described in Chap. 8.

As already mentioned in Chap. 4, because of the uncertainty of ⁹⁹Mo supply, alternative methods are being sought for ^{99m}Tc production. A viable option is the use of a medium-energy cyclotron, in which ^{99m}Tc is directly produced by the ¹⁰⁰Mo (p, 2n) ^{99m}Tc reaction. Nearly 74.3 Ci (2.75 GBq) of ^{99m}Tc should be produced by two 6-h bombardments using 24-MeV protons and a beam current of 500 μ A (Scholten et al. 1999), which would provide nearly 800 dosages of ^{99m}Tc dosages – sufficient for a metropolitan of ~5–7 million people.

5.2.2 ⁶⁸Ge–⁶⁸Ga Generator (GalliaPharm)

Germanium-68 decays to ⁶⁸Ga by electron capture with a half-life of 270.8 days, and ⁶⁸Ga ($t_{1/2}$ = 68 min) decays by positron emission and hence 511-keV annihilation radiations. This generator is made up of titanium dioxide (TiO₂) loaded in a plastic or glass column on which carrier-free ⁶⁸Ge is loaded. ⁶⁸Ga is eluted from the column with 0.1 N HCl solution with a typical yield of more than 60%. Alternatively, ⁶⁸Ge is adsorbed on a stannous dioxide (SnO₂) column, and ⁶⁸Ga is eluted with 0.6 N HCl with the same yield. The generator can be eluted quite frequently, because the maximum growth of ⁶⁸Ga is achieved in several hours. If the generator has not been eluted for 3 days or more, it should be pre-eluted with 10 ml of sterile 0.1 N HCl 7–24 h prior to elution for clinical use. It should be stored at room temperature and has a shelf-life of 12 months.

The ⁶⁸Ge–⁶⁸Ga generator is approved in Europe for clinical use, particularly for preparation of ⁶⁸Ga-DOTATATE and ⁶⁸Ga-DOTATOC for detecting neuroendocrine tumors and is marketed by Eckert & Ziegler under the brand name of GalliaPharm. The strength of the generator ranges from 20 to 50 mCi (0.74 to 1.65 GBq). Because of the equilibrium between ⁶⁸Ge and ⁶⁸Ga, ⁶⁸Ge is used as standard sealed sources for transmission scans for attenuation correction of images in PET imaging.

5.2.3 ⁹⁰Sr–⁹⁰Y Generator

Strontium-90 has a half-life of 28.6 years and decays by β^- -emission to 64.1 h ⁹⁰Y. This generator is manufactured by loading ⁹⁰Sr onto a Dowex 50 cationexchange resin, and ⁹⁰Y is eluted with 0.03 M ethylenediaminetetraacetic acid (EDTA) with a yield of almost 98% and negligible ⁹⁰Sr breakthrough. ⁹⁰Y-EDTA is converted to ⁹⁰Y-acetate at pH 6, which is then used to label a variety of ligands useful for radiotherapy. ⁹⁰Y-labeled Zevalin is an example of such compounds that is used for the treatment of non-Hodgkin's lymphoma. Because of the potential dangers in handling and spill of ⁹⁰Sr, this generator is not installed in hospital-based nuclear pharmacies and is usually supplied by commercial sources with appropriate GMP processing facilities.

5.2.4 ⁶²Zn–⁶²Cu Generator

Zinc-62 decays to ⁶²Cu ($t_{1/2} = 9.7$ min) by positron emission with a $t_{1/2}$ of 9.3 h. In this generator, ⁶²Zn is loaded onto a Dowex 1X8 anion-exchange column, and ⁶²Cu is eluted with 2 *N* hydrochloric acid, which is used to label ligands for imaging. Because of the short half-life, it is produced and supplied daily by the manufacturer. ⁶²Cu forms a complex with PTSM, which is used for perfusion studies in the heart, brain, and kidneys using PET.

5.2.5 ⁸²Sr-⁸²Rb Generator (Cardiogen-82)

Strontium-82 has a half-life of 25.5 days and decays to ⁸²Rb by electron capture. Rubidium-82 decays by β^+ -emission (95%) with a half-life of 75 s. The ⁸²Sr is loaded on a SnO₂ column, and ⁸²Rb is eluted with 0.9% NaCl solution (Saha et al. 1990). Because of its short half-life, ⁸²Rb can be eluted repeatedly every 10–15 min with maximum yield. Because of its short half-life, ⁸²Rb is administered to the patient using an infusion system for myocardial perfusion imaging by the PET technique. Bracco Diagnostics supplies this generator under the brand name Cardiogen-82 to the customers every 6 weeks. Normally 100–110-mCi (3.7– 41.1 GBq) ⁸²Sr is supplied in each generator. However, the fivefold (about 500 mCi [18.5 GBq]) amount of ⁸⁵Sr ($t_{1/2} = 65$ d) is also present, which is produced during the cyclotron production of ⁸²Sr. ⁸⁵Sr emits 510-keV photons.

Because of the short half-life of ⁸²Rb, an infusion system is required to elute ⁸²Rb for patient administration (Fig. 5.5). It consists of a cart in which the generator is installed in a lead castle. The cart is equipped with several electronic controls on a console to select flow rate (ml/min), dosage (mCi/s or MBq/s) and total volume (ml),



Fig. 5.5 A schematic diagram of an infusion pump used for the elution of ⁸²Rb from the ⁸²Sr-⁸²Rb generator showing the flow of activity to the patient

and calculated dosage (mCi or MBq) administered. An electrical pump draws the required volume of saline for elution from a supply bottle into a syringe through a polyethylene tubing and delivers it into the generator by means of a check valve. The pump action elutes the ⁸²Rb activity from the generator and pushes through a positron probe to monitor the activity. Afterward, the eluate is either diverted to a wash bottle or to the patient using a divergence valve. Before a patient study is started, the low-activity volume is flushed out to the wash bottle, which is emptied daily. When the activity starts flowing, it is directed to the patient line. After the set dosage is administered, the pump stops and all parameters are printed out. The system must be calibrated daily according to the manufacturer's recommendation. The generator is replaced every 6 weeks and the old generator is returned to the vendor.

Jubilant DraxImage has developed a similar ⁸²Sr–⁸²Rb generator with the brand name RUBY-FILL generator, which is recently approved for clinical use by the US FDA. The approval requires the concomitant use of a specially designed elution system similar to Bracco's infusion system to elute the generator.

The ⁸²Rb obtained from ⁸²Sr–⁸²Rb generator is used for myocardial perfusion studies using PET. Since ⁸²Rb is eluted from the ⁸²Sr–⁸²Rb generator for patient administration, there is a likelihood of ⁸²Sr and ⁸⁵Sr breakthrough in the elution, which must be determined prior to administration. The NRC requires a limit of 0.02 μ Ci of ⁸²Sr per mCi of ⁸²Rb (0.02 kBq of ⁸²Sr per MBq of ⁸²Rb) and 0.2 μ Ci of ⁸⁵Sr per mCi of ⁸²Rb (0.2 kBq ⁸⁵Sr per MBq of ⁸²Rb). The breakthrough of both radionuclides is measured as follows: Before any patient is administered, the generator is eluted with 50 ml of 0.9% NaCl solution, and immediately the ⁸²Rb activity is measured and decay corrected to end of elution. Then, the activity is allowed to decay for an hour, and the breakthrough activity A in μ Ci is measured, which contains both ⁸²Sr and ⁸⁵Sr. The ratio K of ⁸⁵Sr/⁸²Sr on the calibration day and ratio factors F for subsequent days of use are supplied by the manufacturer. The ratio of ⁸⁵Sr/⁸²Sr on the day of measurement is calculated by

$$R = K \times F \tag{5.10}$$

It is further corrected for contribution from ⁸⁵Sr using a factor Q(0.478) given in the following equation. Thus, the total ⁸²Sr activity in the elution is

$$^{82}\operatorname{Sr}(\mu\operatorname{Ci}) = A/(1+R\times Q)$$
(5.11)

The ⁸²Sr activity in Eq. (5.11) is divided by the ⁸²Rb activity at the end of elution to obtain the ⁸²Sr breakthrough, which should be less than 0.02.

The ⁸⁵Sr breakthrough is obtained by multiplying the ⁸²Sr breakthrough by the F factor for the day of measurement given by the manufacturer, which should be less than 0.2.

5.2.6 227 Ac $\rightarrow ^{227}$ Th $\rightarrow ^{223}$ Ra Generator

The availability of ²²³Ra from a generator has been described in Chap. 4. Briefly, the difference in half-lives of ²²⁷Ac, ²²⁷Th, and ²²³Ra makes them ideal nuclides for a

radionuclide generator, ²²⁷Ac \rightarrow ²²⁷Th \rightarrow ²²³Ra. The ²²⁷Ac/²²⁷Th nuclides are loaded on a chromatographic column containing P,P'-di(2-ethylhexyl)methanediphosphonic acid (EHMDP) on silica, and high-purity, carrier-free ²²³Ra is eluted with 1 M hydrochloric acid as chloride from the generator. It is supplied by Bayer HealthCare Pharmaceutical Inc. under the brand name Xofigo. The supplied vial contains 178 µCi (6600 kBq) of activity in 6 ml of 0.9% NaCl solution at a concentration of 29.7 µCi (1100 kBq)/ml. Because of α emission, ²²³Ra chloride is ideal for the treatment of castration-resistant prostate cancer and symptomatic bone metastasis.

Questions

- 1. Describe the principles of a radionuclide generator.
- 2. List the ideal characteristics of a radionuclide generator.
- 3. Describe in detail the construction of a Moly generator. What are the common radionuclide contaminants in this generator?
- 4. A 1700-mCi (62.9-GBq) Moly generator calibrated for Friday noon was eluted at 9:00 a.m. on the following Tuesday. (a) Calculate the activity of ^{99m}Tc assuming 90% yield. (b) Calculate the activity of ⁹⁹Mo at 1:00 p.m. on the following Wednesday.
- 5. A 10-mCi (370-MBq) sample of the 99m Tc-eluate is found to contain 20- μ Ci (0.74 MBq) 99 Mo. Can this preparation be used for injection into humans?
- 6. A 100-mCi (3.7-GBq) sample of ^{99m}Tc-DTPA contains 60-μCi (2.22 MBq) ⁹⁹Mo. If a brain scan requires 10-mCi (370 MBq) ^{99m}Tc-DTPA, can you use this for the patient?
- 7. Suppose an institution regularly purchases a 2200-mCi (81.4-GBq) Moly generator calibrated for Friday noon and the elution volume of the eluent as provided by the supplier is 5 ml. On the following Wednesday morning at 8:00 a.m., what volumes of activity would you draw from the ^{99m}Tc-eluate in order to prepare (a) 50-mCi (1.85 GBq) ^{99m}Tc-methylene diphosphonate, (b) 30-mCi (1.11 GBq) ^{99m}Tc-sulfur colloid, and (c) 20-mCi (740 MBq) ^{99m}Tc-labeled macroaggregated albumin (assume 80% elution)?
- 8. Why is aluminum undesirable in the ^{99m}Tc-eluate? What is the permissible limit of aluminum concentration in the ^{99m}Tc-eluate?
- 9. A 50-mCi (1.85 GBq) 99m Tc-DISIDA sample contains 5- μ Ci (0.185 MBq) 99 Mo. If a patient is to be injected with 5-mCi (185 MBq) 99m Tc-DISIDA for hepatobiliary studies 6 h later, can you administer this radiopharmaceutical to the patient?
- 10. A 1350-mCi (50-GBq) ⁹⁹Mo-^{99m}Tc generator calibrated for Wednesday 8:00 a.m. was eluted daily at 7:00 a.m. for 3 days starting from the calibration day. What would be the ^{99m}Tc activity in the generator at 12:00 noon on the fifth day after calibration?
- 11. Describe the construction principle of GalliaPharm generator.
- 12. What and why is ²²³Ra used for in nuclear medicine?

References and Suggested Reading

- Eckelman WC, Coursey BM. Technetium-99m: generators, chemistry and preparation of radiopharmaceuticals. Int J Appl Radiat Isot. 1982;33:793.
- Guillaume M, Brihaye C. Generators for short-lived gamma and positron emitting radionuclides: current status and prospects. Nucl Med Biol. 1986;13:89.
- Holland ME, Deutsch E, Heineman HR. Studies on commercially available 99Mo/99mTc radionuclide generators: I. Comparison of five analytical procedures for determination of total technetium in generator eluants. Appl Radiat Isot. 1986a;37:165.
- Holland ME, Deutsch E, Heineman HR. Studies on commercially available ⁹⁹Mo/^{99m}Tc radionuclide generators: II. Operating characteristics and behavior of ⁹⁹Mo/^{99m}Tc generators. Appl Radiat Isot. 1986b;37:173.
- Knapp FF Jr, Butler TA. Radionuclide generators: new systems for nuclear medicine applications. Advances in chemistry series, no. 241. Washington, DC: American Chemical Society; 1984.
- Lamson ML 3rd, Kirschner AS, Hotte CE. Generator-produced ^{99m}TcO₄-carrier free. J Nucl Med. 1975;16:639.
- Noronha OPD, Sewatkar AB, Ganatra RD, et al. Fission-produced ⁹⁹Mo–^{99m}Tc generator system for medical use. J Nucl Biol Med. 1976;20:32.
- Rösch F, Knapp FF. Radionuclide generators. In: Vértes A, Nagy S, Klencsár Z, Rösch F, editors. Handbook of nuclear chemistry, vol. 4. Dordrecht: Kluwer; 2003.
- Saha GB, Go RT, MacIntyre WJ, et al. Use of the ⁸²Sr/⁸²Rb generator in clinical PET studies. Nucl Med Biol. 1990;17:763.
- Scholten B, Lambrecht RM, Cogneau, et al. Excitation functions for the cyclotron production of ^{99m}Tc and ⁹⁹Mo. Appl Radiat Isot. 1999;51:69.
- United States Pharmacopeial Convention. U.S. Pharmacopeia 39 & National Formulary 34. Rockville: United States Pharmacopeial Convention; 2016.

Radiopharmaceuticals and General Methods of Radiolabeling

6

6.1 Definition of a Radiopharmaceutical

A radiopharmaceutical is a radioactive compound used for the diagnosis and therapeutic treatment of human diseases. In nuclear medicine nearly 90% of the radiopharmaceuticals are used for diagnostic purposes, while the rest are used for therapeutic treatment. Radiopharmaceuticals usually have minimal pharmacologic effect, because in most cases they are used in tracer quantities. Therapeutic radiopharmaceuticals can cause tissue damage by radiation. Because they are administered to humans, they should be sterile and pyrogen-free and should undergo all quality control measures required of a conventional drug. A radiopharmaceutical may be a radioactive element such as ¹³³Xe or a labeled compound such as ¹³¹I-iodinated proteins and ^{99m}Tc-labeled compounds.

Although the term *radiopharmaceutical* is most commonly used, other terms such as *radiotracer*, *radiodiagnostic agent*, and *tracer* have been used by various groups. We shall use the term *radiopharmaceutical* throughout, although the term *radiotracer* or *tracer* will be used occasionally.

Another point of interest is the difference between radiochemicals and radiopharmaceuticals. The former are not usable for administration to humans due to possible lack of sterility and nonpyrogenicity. On the other hand, radiopharmaceuticals are sterile and nonpyrogenic and can be administered safely to humans.

A radiopharmaceutical has two components: a radionuclide and a pharmaceutical. The usefulness of a radiopharmaceutical is dictated by the characteristics of these two components. In designing a radiopharmaceutical, a pharmaceutical is first chosen on the basis of its preferential localization in a given organ or its participation in the physiologic function of the organ. Then a suitable radionuclide is tagged onto the chosen pharmaceutical such that after administration of the radiopharmaceutical, radiations emitted from it are detected by a radiation detector. Thus, the morphologic structure or the physiologic function of the organ can be assessed. The pharmaceutical of choice should be safe and nontoxic for human administration. Radiations from the radionuclide of choice should be easily detected by nuclear instruments, and the radiation dose to the patient should be minimal.

6.2 Ideal Radiopharmaceutical

Since radiopharmaceuticals are administered to humans, and because there are several limitations on the detection of radiations by currently available instruments, radiopharmaceuticals should possess some important characteristics. The ideal characteristics for radiopharmaceuticals are elaborated below.

6.2.1 Easy Availability

The radiopharmaceutical should be easily produced, inexpensive, and readily available in any nuclear medicine facility. Complicated methods of production of radionuclides or labeled compounds increase the cost of the radiopharmaceuticals. The geographic distance between the user and the supplier also limits the availability of short-lived radiopharmaceuticals.

6.2.2 Short Effective Half-Life

A radionuclide decays with a definite half-life, which is called the physical half-life, denoted T_p (or $t_{1/2}$). The physical half-life is independent of any physicochemical condition and is a characteristic for a given radionuclide. It has been discussed in detail in Chap. 2.

Radiopharmaceuticals administered to humans disappear from the biological system through fecal or urinary excretion, perspiration, or other mechanisms. This biologic disappearance of a radiopharmaceutical follows an exponential law similar to that of radionuclide decay. Thus, every radiopharmaceutical has a biologic half-life (T_b). It is the time needed for half of the radiopharmaceutical to disappear from the biologic system and therefore is related to a decay constant, $\lambda_b = 0.693/T_b$.

Obviously, in any biologic system, the loss of a radiopharmaceutical is due to both the physical decay of the radionuclide and the biologic elimination of the radiopharmaceutical. The net or effective rate λ_e of the loss of radioactivity is then related to the physical decay constant λ_p and the biologic decay constant λ_b . Mathematically, this is expressed as

$$\lambda_{\rm e} = \lambda_{\rm p} + \lambda_{\rm b} \tag{6.1}$$

Since $\lambda = 0.693/t_{1/2}$, it follows that

$$\frac{1}{T_{\rm e}} = \frac{1}{T_{\rm p}} + \frac{1}{T_{\rm b}}$$
(6.2)

or

$$T_{\rm e} = \frac{T_{\rm p} \times T_{\rm b}}{T_{\rm p} + T_{\rm b}} \tag{6.3}$$

The effective half-life T_e is always less than the shorter of T_p or T_b . For a very long T_p and a short T_b , T_e is almost equal to T_b . Similarly, for a very long T_b and a short T_p , T_e is almost equal to T_p .

Problem 6.1

The physical half-life of ¹¹¹In is 67 h and the biologic half-life of ¹¹¹In-DTPA used for measurement of the glomerular filtration rate is 1.5 h. What is the effective half-life of ¹¹¹In-DTPA?

Answer

Using Eq. (6.3),

$$T_{\rm e} = \frac{1.5 \times 67}{67 + 1.5} = \frac{100.5}{68.5} = 1.47 \,\rm{hr}$$

Radiopharmaceuticals should have a relatively short effective half-life, which should not be longer than the time necessary to complete the study in question. The time to start the imaging of the tracer varies with different studies depending on the in vivo pharmacokinetics of the tracer. The faster the accumulation of the tracer in the organ of interest, the sooner imaging should start. However, the duration of imaging depends primarily on the amount of activity administered, the fraction thereof accumulated in the target organ, and the window setting of the gamma camera.

6.2.3 No Particle Emission

Radionuclides decaying by α - or β -particle emission should not be used as the label in diagnostic radiopharmaceuticals, because they cause more radiation damage to the tissue than do γ -rays. Although γ -ray emission is preferable, many
β -emitting radionuclides, such as ¹³¹I-iodinated compounds, are often used for clinical studies. However, α -emitters should never be used for in vivo diagnostic studies because they give a high radiation dose to the patient. But α - and β -emitters are useful for therapy, because of the effective radiation damage to abnormal cells.

6.2.4 Decay by Electron Capture or Isomeric Transition

Because radionuclides emitting particles are less desirable, the diagnostic radionuclides used should decay by electron capture or isomeric transition without any internal conversion. Whatever the mode of decay, for diagnostic studies, the radionuclide must emit a γ -radiation with an energy preferably between 30 keV and 300 keV. Below 30 keV, γ -rays are absorbed by tissue and are not detected by the NaI(Tl) detector. Above 300 keV, effective collimation of γ -rays cannot be achieved with commonly available collimators and can penetrate through the collimator septa and interact in the detector. This degrades the spatial resolution. However, manufacturers have made collimators for 511-keV photons, which have been used for planar or SPECT imaging using ¹⁸F-FDG. The phenomenon of collimation with 30–300-keV photons is illustrated in Fig. 6.1. γ -Rays should be monochromatic and have an energy of approximately 150 keV, which is most suitable for present-day commonly used collimators. Moreover, the photon abundance should be high so that imaging time can be minimized.

Fig. 6.1 Photon interaction in the NaI(Tl) detector using collimators. A 30-keV photon is absorbed by the tissue. A > 300-keV photon may penetrate through the collimator septa and strike the detector or may escape the detector without any interaction. Photons of 30-300 keV may escape the organ of the body, pass through the collimator holes, and interact in the detector



6.2.5 High Target-to-Nontarget Activity Ratio

For a diagnostic study, it is desirable that the radiopharmaceutical be localized preferentially in the organ under study since the activity from nontarget areas can obscure the structural details of the picture of the target organ. Therefore, the targetto-nontarget activity ratio should be high.

An ideal radiopharmaceutical should have all the above characteristics to provide maximum efficacy in the diagnosis of diseases and a minimum radiation dose to the patient. However, it is difficult for a given radiopharmaceutical to meet all these criteria, and the one of choice is the best of many compromises.

6.3 Design of New Radiopharmaceuticals

6.3.1 General Considerations

Continual effort is being made to discover newer radiopharmaceuticals to improve diagnostic accuracy and therapeutic efficacy in nuclear medicine studies. A radiopharmaceutical for a particular organ study is designed on the basis of the mechanism of its localization in the organ. The following are the different mechanisms of localization that are commonly applied to development of radiopharmaceuticals for nuclear medicine imaging.

- 1. Passive diffusion: ^{99m}Tc-DTPA in brain imaging, ^{99m}Tc-DTPA aerosol and ¹³³Xe in ventilation imaging, ¹¹¹In-DTPA in cisternography.
- 2. Ion exchange: uptake of ^{99m}Tc-phosphonate complexes in bone.
- 3. Capillary blockage: ^{99m}Tc-macroaggregated albumin (MAA) particles trapped in the lung capillaries.
- 4. Phagocytosis: removal of ^{99m}Tc-sulfur colloid particles by the reticuloendothelial cells in the liver, spleen, and bone marrow.
- 5. Active transport: ¹³¹I uptake in the thyroid, ²⁰¹Tl uptake in the myocardium.
- 6. Cell sequestration: sequestration of heat-damaged ^{99m}Tc-labeled red blood cells by the spleen.
- 7. Metabolism: ¹⁸F-FDG uptake in myocardial and brain tissues.
- 8. Receptor binding: ¹¹C-dopamine binding to the dopamine receptors in the brain.
- Compartmental localization: ^{99m}Tc-labeled red blood cells used in the gated blood pool study.
- 10. Antigen–antibody complex formation: ¹³¹I-, ¹¹¹In-, and ^{99m}Tc-labeled antibody to localize tumors.
- 11. Chemotaxis: ¹¹¹In-labeled leukocytes to localize infections.

Once a radiopharmaceutical is conceptually designed, a definite protocol is developed based on the physicochemical properties of the basic ingredients to prepare the radiopharmaceutical. The method of preparation should be simple, easy, and reproducible and should not alter the desired property of the labeled compound. Optimum conditions of temperature, pH, ionic strength, and molar ratios should be established and maintained for maximum efficacy of the radiopharmaceutical.

The clinical efficacy of a well-formulated radiopharmaceutical must be evaluated first in animals and then in humans. For use in humans, one needs to have a Notice of Claimed Investigational Exemption for a New Drug (IND) from the US Food and Drug Administration (FDA), which strictly regulates the human trials of drugs. If there is any severe adverse effect in humans due to administration of the radiopharmaceutical or if intended biodistribution is not achieved, then the radiopharmaceutical is discarded.

6.3.2 Factors Influencing the Design of New Radiopharmaceuticals

The following factors need to be considered before, during, and after the preparation of a new radiopharmaceutical.

Compatibility

When a labeled compound is to be prepared, the first criterion to consider is whether the label can be incorporated into the molecule to be labeled. This may be assessed from the knowledge of the chemical properties of the two partners. For example, ¹¹¹In ion can form coordinate covalent bonds, and DTPA is a chelating agent containing nitrogen and oxygen atoms with lone pairs of electrons that can be donated to form coordinated covalent bonds. Therefore, when ¹¹¹In ion and DTPA are mixed under appropriate physicochemical conditions, ¹¹¹In-DTPA is formed and remains stable for a long time. If, however, ¹¹¹In ion is added to benzene or similar compounds, it does not label them. Iodine primarily binds to the tyrosyl group of proteins. Mercury radionuclides bind to the sulfhydryl group of proteins. These examples illustrate the point that only specific radionuclides label certain compounds, depending on their chemical structure and behavior.

Stoichiometry

In preparing a new radiopharmaceutical, one needs to know the correct amount of each component to be added. This is particularly important in tracer level chemistry and in ^{99m}Tc chemistry. The concentration of ^{99m}Tc in the ^{99m}Tc-eluate is approximately 10⁻⁹ M. Although for reduction of this trace amount of ^{99m}Tc only an equivalent amount of Sn²⁺ is needed, 1000–1,000,000 times more of the latter is added to the preparation in order to ensure complete reduction. Similarly, enough chelating agent, such as DTPA or MDP, is also added to use all the reduced ^{99m}Tc. The stoichiometric ratio of different components can be obtained by setting up the appropriate equations for the chemical reactions. An unduly high or low concentration of any one component may sometimes affect the integrity of the preparation.

Charge of the Molecule

The charge on a radiopharmaceutical determines its solubility in various solvents. The greater the charge, the higher the solubility in aqueous solution. Nonpolar molecules tend to be more soluble in organic solvents and lipids.

Size of the Molecule

The molecular size of a radiopharmaceutical is an important determinant in its absorption in the biologic system. Larger molecules (mol. wt. > -60,000) are not filtered by the glomeruli in the kidney. This information should give some clue as to the range of molecular weights of the desired radiopharmaceutical that should be chosen for a given study.

Protein Binding

Almost all drugs, radioactive or not, bind to plasma proteins to variable degrees. The primary candidate for binding is albumin, although many compounds specifically bind to globulin and other proteins as well. Indium, gallium, and many metallic ions bind firmly to transferrin in plasma. Protein binding is greatly influenced by a number of factors, such as the charge on the radiopharmaceutical molecule, the pH, the nature of protein, and the concentration of anions in plasma. At a lower pH, plasma proteins become more positively charged, and therefore anionic drugs bind firmly to them. The nature of a protein, particularly its content of hydroxyl, carboxyl, and amino groups and their configuration in protein structure, determines the extent and strength of its binding to the radiopharmaceutical. Metal chelates can exchange the metal ions with proteins because of the stronger affinity of the metal for the protein. Such a process is called "transchelation" and leads to in vivo breakdown of the complex. For example, ¹¹¹In-chelates exchange ¹¹¹In with transferrin to form ¹¹¹In-transferrin.

Protein binding affects the tissue distribution and plasma clearance of a radiopharmaceutical and its uptake by the organ of interest. Therefore, one should determine the extent of protein binding of any new radiopharmaceutical before its clinical use. This can be accomplished by precipitating the proteins with trichloroacetic acid from the plasma after administration of the radiopharmaceutical and then measuring the activity in the precipitate.

Solubility

For injection, the radiopharmaceutical should be in aqueous solution at a pH compatible with blood pH (7.4). The ionic strength and osmolality of the agent should also be appropriate for blood. In many cases, lipid solubility of a radio-pharmaceutical is a determining factor in its localization in an organ; the cell membrane is primarily composed of phospholipids, and unless the radiopharmaceutical is lipid soluble, it will hardly diffuse through the cell membrane. The higher the lipid solubility of a radiopharmaceutical, the greater the diffusion through the cell membrane and hence the greater its localization in the organ. Protein binding reduces the lipid solubility of a radiopharmaceutical. Ionized drugs are less lipid soluble, whereas nonpolar drugs are highly soluble in lipids and hence easily diffuse through cell membranes. The radiopharmaceutical

¹¹¹In-oxine is highly soluble in lipid and is hence used specifically for labeling leukocytes and platelets.

Stability

The stability of a labeled compound is one of the major concerns in labeling chemistry. It must be stable both in vitro and in vivo. In vivo breakdown of a radiopharmaceutical results in undesirable biodistribution of radioactivity. For example, dehalogenation of radioiodinated compounds gives rise to free radioiodide, which raises the background activity in the clinical study. Temperature, pH, and light affect the in vitro stability of many compounds, and the optimal range of these physicochemical conditions must be established for the preparation and storage of labeled compounds.

Biodistribution

The study of biodistribution of a radiopharmaceutical is essential in establishing its efficacy and usefulness. This includes tissue distribution, plasma clearance, urinary excretion, and fecal excretion after administration of the radiopharmaceutical.

In tissue distribution studies, the radiopharmaceutical is injected into animals such as mice, rats, and rabbits. The animals are then sacrificed at different time intervals, and different organs are removed. The activities in these organs are measured and compared. The tissue distribution data will tell how good the radiopharmaceutical is for imaging the organ of interest. At times, human biodistribution data are obtained by gamma camera imaging.

The rate of localization of a radiopharmaceutical in an organ is related to its rate of plasma clearance after administration. The plasma clearance half-time of a radiopharmaceutical is defined by the time required to reduce its initial plasma activity to one half. It can be measured by collecting serial samples of blood at different time intervals after injection and measuring the plasma activity. From a plot of activity versus time, one can determine the half-time for plasma clearance of the tracer.

Urinary and fecal excretions of a radiopharmaceutical are important in its clinical evaluation. The faster the urinary or fecal excretion, the less the radiation dose. These values are determined by collecting the urine or feces at definite time intervals after injection and measuring the activity in the samples.

Toxic effects of radiopharmaceuticals must also be evaluated. These effects include damage to the tissues, physiologic dysfunction of organs, and even the death of the species. These considerations are discussed in Chap. 8.

6.4 Methods of Radiolabeling

In the medical field, compounds labeled with β^- -emitting radionuclides are mainly restricted to in vitro experiments and therapeutic treatment, whereas those labeled with γ -emitting radionuclides have much wider applications, particularly in diagnosis of diseases. The latter are particularly useful for in vivo imaging of different organs.

Isotope exchange	¹²⁵ I-labeled T3 and T4
	¹⁴ C-, ³⁵ S-, and ³ H-labeled compounds
Introduction of a foreign label	All 99mTc-radiopharmaceuticals
	¹²⁵ I-labeled proteins
	¹²⁵ I-labeled hormones
	¹¹¹ In-labeled cells
	¹⁸ F-fluorodeoxyglucose
Labeling with bifunctional chelating agent	¹¹¹ In-DTPA-albumin
	^{99m} Tc-DTPA-antibody
Biosynthesis	⁷⁵ Se-selenomethionine
	⁵⁷ Co-cyanocobalamin
	¹⁴ C-labeled compounds
Recoil labeling	³ H-labeled compounds
	Iodinated compounds
Excitation labeling	¹²³ I-labeled compounds (from ¹²³ Xe decay)
	⁷⁷ Br-labeled compounds (from ⁷⁷ Kr decay)

 Table 6.1
 General methods of radiolabeling

In a radiolabeled compound, atoms or groups of atoms of a molecule are substituted by similar or different radioactive atoms or groups of atoms. In any labeling process, a variety of physicochemical conditions can be employed to achieve a specific kind of labeling. There are essentially six methods employed in the preparation of labeled compounds for clinical use (Table 6.1). These methods and various factors affecting the labeled compounds are discussed below.

6.4.1 Isotope Exchange Reactions

In isotope exchange reactions, one or more atoms in a molecule are replaced by isotopes of the same element having different mass numbers. Since the radiolabeled and parent molecules are identical except for the isotope effect, they are expected to have the same biologic and chemical properties.

Examples are ¹²⁵I-triiodothyronine (T3), ¹²⁵I-thyroxine (T4), and ¹⁴C-, ³⁵S-, and ³H-labeled compounds. These labeling reactions are reversible and are useful for labeling iodine-containing material with iodine radioisotopes and for labeling many compounds with tritium.

6.4.2 Introduction of a Foreign Label

In this type of labeling, a radionuclide is incorporated into a molecule that has a known biologic role, primarily by the formation of covalent or coordinate covalent bonds. The tagging radionuclide is foreign to the molecule and does not label it by the exchange of one of its isotopes. Some examples are ^{99m}Tc-labeled albumin, ^{99m}Tc-DTPA, ⁵¹Cr-labeled red blood cells, and many iodinated proteins and enzymes. In several instances, the in vivo stability of the material is uncertain, and one should

be cautious about any alteration in the chemical and biologic properties of the labeled compound.

In many compounds of this category, the chemical bond is formed by chelation, that is, more than one atom donates a pair of electrons to the foreign acceptor atom, which is usually a transition metal. Most of the ^{99m}Tc-labeled compounds used in nuclear medicine are formed by chelation. For example, ^{99m}Tc binds to DTPA, gluceptate, and other ligands by chelation.

6.4.3 Labeling with Bifunctional Chelating Agents

In this approach, a bifunctional chelating agent is conjugated to a macromolecule (e.g., protein, antibody) on one side and to a metal ion (e.g., Tc) by chelation on the other side. Examples of bifunctional chelating agents are DTPA, metallothionein, diamide dimercaptide (N_2S_2), hydrazinonicotinamide (HYNIC), and dithiosemicarbazone.

There are two methods – the preformed radiometal chelate method and the indirect chelator-antibody method. In the preformed radiometal chelate method, a radiometal chelate is initially preformed using chelating agents such as diamidodithiol, cyclam, and so on, which are then used to label macromolecules by forming bonds between the chelating agent and the protein. In contrast, in the indirect method, the bifunctional chelating agent is initially conjugated with a macromolecule, which is then allowed to react with the metal ion to form a metal–chelate–macromolecule complex. Various antibodies are labeled by the latter method. Because of the presence of the chelating agent, the biological properties of the labeled protein may be altered and must be assessed before clinical use.

6.4.4 Biosynthesis

In biosynthesis, a living organism is grown in a culture medium containing the radioactive tracer, the tracer is incorporated into metabolites produced by the metabolic processes of the organism, and the metabolites are then chemically separated. For example, vitamin B₁₂ is labeled with ⁶⁰Co or ⁵⁷Co by adding the tracer to a culture medium in which the organism *Streptomyces griseus* is grown. Other examples of biosynthesis include ¹⁴C-labeled carbohydrates, proteins, and fats.

Two other methods – recoil method and excitation method – are of little significance in nuclear medicine because of low yield and are not discussed.

6.5 Important Factors in Labeling

The majority of radiopharmaceuticals used in clinical practice are relatively easy to prepare in ionic, colloidal, macroaggregated, or chelated forms, and many can be made using commercially available kits. Several factors that influence the integrity of labeled compounds should be kept in mind. These factors are described briefly below.

6.5.1 Efficiency of Labeling

A high labeling yield is always desirable, although it may not be achievable in many cases. However, a lower yield is sometimes acceptable if the product is pure and not damaged by the labeling method, the expense involved is minimal, and no better method of labeling is available.

6.5.2 Chemical Stability of Product

Stability is related to the type of bond between the radionuclide and the compound. Compounds with covalent bonds are relatively stable under various physicochemical conditions. The stability constant of the labeled product should be large for greater stability.

6.5.3 Denaturation or Alteration

The structure and/or the biologic properties of a labeled compound can be altered by various physicochemical conditions during a labeling procedure. For example, proteins are denatured by heating, at pH below 2 and above 10, and by excessive iodination, and red blood cells are denatured by heating.

6.5.4 Isotope Effect

The isotope effect results in different physical (and perhaps biologic) properties due to differences in isotope weights. For example, in tritiated compounds, H atoms are replaced by ³H atoms, and the difference in mass numbers of ³H and H may alter the property of the labeled compounds. It has been found that the physiologic behavior of tritiated water is different from that of normal water in the body. The isotope effect is not as serious when the isotopes are heavier.

6.5.5 Carrier-Free or No-Carrier-Added State

Radiopharmaceuticals tend to be adsorbed on the inner walls of the containers if they are in a carrier-free or no-carrier-added (NCA) state. Techniques have to be developed in which the labeling yield is not affected by the low concentration of the tracer in a carrier-free or NCA state.

6.5.6 Storage Conditions

Many labeled compounds are susceptible to decomposition at higher temperatures. Proteins and labeled dyes are degraded by heat and therefore should be stored at proper temperatures; for example, albumin should be stored under refrigeration. Light may also break down some labeled compounds and these should be stored in the dark. The loss of carrier-free tracers by adsorption on the walls of the container can be prevented by the use of silicon-coated vials.

6.5.7 Specific Activity

Specific activity is defined as the activity per gram of the labeled material and has been discussed in Chap. 4. In many instances, high specific activity is required in the applications of radiolabeled compounds, and appropriate methods should be devised to this end. In others, high specific activity can cause more radiolysis (see below) in the labeled compound and should be avoided.

6.5.8 Radiolysis

Many labeled compounds are decomposed by radiations emitted by the radionuclides present in them. This type of decomposition is called radiolysis. The higher the specific activity, the greater the effect of radiolysis. When the chemical bond breaks down by radiations from its own molecule, the process is termed "autoradiolysis." Radiations may also decompose the solvent, producing free radicals that can break down the chemical bond of the labeled compounds; this process is indirect radiolysis. For example, radiations from a labeled molecule can decompose water to produce hydrogen peroxide or perhydroxyl free radical, which oxidizes another labeled molecule. To help prevent indirect radiolysis, the pH of the solvent should be neutral because more reactions of this nature can occur at alkaline or acidic pH.

The longer the half-life of the radionuclide, the more extensive is the radiolysis, and the more energetic the radiations, the greater is the radiolysis. In essence, radiolysis introduces a number of radiochemical impurities in the sample of labeled material, and one should be cautious about these unwanted products. These factors set the guidelines for the expiration date of a radiopharmaceutical.

6.5.9 Purification and Analysis

Radionuclide impurities are radioactive contaminants arising from the method of production of radionuclides. Fission in a reactor is likely to produce more impurities than nuclear reactions in a cyclotron because fission of the heavy nuclei produces many product nuclides. Target impurities also add to the radionuclidic contaminants. The removal of radioactive contaminants can be accomplished by various chemical separation techniques, usually at the radionuclide production stage.

Radiochemical and chemical impurities arise from incomplete labeling of compounds and can be estimated by various analytical methods such as solvent extraction, ion exchange, paper, gel, or thin-layer chromatography, and electrophoresis. Often these impurities arise after labeling from natural degradation as well as from radiolysis. This subject is discussed in detail in Chap. 8.

6.5.10 Shelf-Life

A labeled compound has a shelf-life during which it can be used safely for its intended purpose. The loss of efficacy of a labeled compound over a period of time may result from radiolysis and/or chemical decomposition depends on the physical half-life of the radionuclide, the solvent, any additive, the labeled molecule, the nature of emitted radiations, and the nature of the chemical bond between the radionuclide and the molecule. Usually a period of one to three physical half-lives or a maximum of 6 months is suggested as the limit for the shelf-life of a labeled compound. The shelf-life of ^{99m}Tc-labeled compounds varies between 0.5 h and 18 h, the most common value being 6 h.

6.6 Specific Methods of Labeling

In nuclear medicine, ^{99m}Tc-labeled compounds constitute nearly 80% of all radiopharmaceuticals used in nuclear medicine, and ¹²³I- and ¹³¹I-labeled compounds and other radionuclides account for the rest. The general principles of iodination and ^{99m}Tc-labeling are discussed below.

6.6.1 Radioiodination

Iodination is used extensively for labeling the compounds of medical and biological interest. Iodine is an element belonging to the halogen group VIIA. Its atomic number is 53 and its only stable isotope is ¹²⁷I. A number of iodine radioisotopes are commonly used for radioiodination, and those of clinical importance are presented in Table 4.1. Of all iodine isotopes, ¹²³I is most suitable for in vivo diagnostic procedures because it has a convenient half-life (13.2 h) and photon energy (159 keV) and gives a low radiation dose to the patient. It is a cyclotron-produced isotope and therefore is expensive. The isotope ¹²⁵I is commonly used for producing radiolabeled antigens and other compounds for in vitro procedures and has the advantage of a long half-life (60 d). However, its low-energy (27–35 keV) photons make it unsuitable for in vivo imaging. The isotope ¹³¹I has an 8-day half-life and 364-keV photons and is used for thyroid uptake and scan. However, its β^{-1} emission gives a larger radiation dose to the patient than ¹²³I, and it is exclusively used for thyroid treatment.

In ¹²³I preparations, ¹²⁴I remains an undesirable radionuclidic impurity that is produced by the α -particle bombardment of Te targets, because of its long half-life (4.2 d) and its annihilation and other high-energy radiations [511 keV (46%), 603 keV (61%), 723 keV (10%), and 1.69 MeV (10.4%)]. These high-energy

photons degrade resolution of scintigraphic images because of their septal penetration of the collimator and also spillover of the scattered radiations in the 159-keV window of ¹²³I. Therefore, high-purity ¹²³I needs to be produced via appropriate nuclear reactions described in Chap. 4.

Principles of Iodination

Iodination of a molecule is governed primarily by the oxidation state of iodine. In the oxidized form, iodine binds strongly to various molecules, whereas in the reduced form, it does not. Commonly, iodine is available as NaI and I⁻ oxidized to I⁺ by various oxidizing agents. The free molecular iodine has the structure of I⁺–I⁻ in aqueous solution. In either case the electrophilic species I⁺ does not exist as a free species but forms complexes with nucleophilic entities such as water or pyridine:

$$I_2 + H_2 O \rightleftharpoons H_2 O I^+ + I^-$$
(6.4)

$$I_2 + OH^- \rightleftharpoons HOI + I^-$$
 (6.5)

The hydrated iodonium ion, H_2OI^+ and hypoiodous acid, HOI, are believed to be the iodinating species in the iodination process. Iodination occurs by electrophilic substitution of a hydrogen ion by an iodonium ion in the molecule of interest, or by nucleophilic substitution (isotope exchange) where a radioactive iodine atom is exchanged with a stable iodine atom that is already present in the molecule. These reactions are represented as follows:

Nucleophilic substitution:

$$\mathbf{R} - \mathbf{I} + \mathbf{N}\mathbf{a}^{131}\mathbf{I} \rightleftharpoons \mathbf{R} - {}^{131}\mathbf{I} + \mathbf{N}\mathbf{a}\mathbf{I} + \mathbf{H}_2\mathbf{O}$$
(6.6)

Electrophilic substitution:

$$\mathbf{R} - \mathbf{I} + \mathbf{H}_2 \mathbf{O}^{131} \mathbf{I} \rightleftharpoons \mathbf{R} - {}^{131} \mathbf{I} + \mathbf{H} \mathbf{I} + \mathbf{H}_2 \mathbf{O}$$
(6.7)

In protein iodination, the phenolic ring of tyrosine is the primary site of iodination, and the next important site is the imidazole ring of histidine. The pH plays an important role in protein iodination. The optimum pH is 7–9. Temperature and duration of iodination depend on the type of molecule to be iodinated and the method of iodination used. The degree of iodination affects the integrity of a protein molecule and generally depends on the type of protein and the iodination method. Normally, one atom of iodine per protein molecule is desirable.

Methods of Iodination

There are several methods of iodination, and principles of only the important ones are described below.

Triiodide Method

The triiodide method essentially consists of adding radioiodine to the compound to be labeled in the presence of a mixture of iodine and potassium iodide:

$$I_2 + KI + {}^{131}I_2 + 2RH \rightarrow R^{131}I + K^{131}I + RI + 2HI$$
 (6.8)

where RH is an organic compound being labeled. In the case of protein labeling by this method, minimum denaturation of proteins occurs, but the yield is low, usually about 10–30%. Because cold iodine is present, the specific activity of the labeled product is considerably diminished.

Iodine Monochloride Method

In the iodine monochloride (ICl) method, radioiodine is first equilibrated with stable ¹²⁷I in iodine monochloride in dilute HCl, and then the mixture is added directly to the compound of interest for labeling at a specific pH and temperature. Yields of 50–80% can be achieved by this process. However, cold iodine of ICl can be introduced in the molecule, which lowers the specific activity of the labeled compound, and the yield becomes unpredictable, depending on the amount of ICl added.

Chloramine-T Method

Chloramine-T is a sodium salt of *N*-monochloro-*p*-toluenesulfonamide and is a mild oxidizing agent. In this method of iodination, first the compound for labeling and then chloramine-T are added to a solution of ¹³¹I-sodium iodide. Chloramine-T oxidizes iodide to a reactive iodine species, which labels the compound. In the absence of cold iodine, high specific activity compounds can be obtained by this method, and the labeling efficiency can be very high (~90%). However, chloramine-T is a highly reactive substance and can cause denaturation of proteins. Sometimes milder oxidants such as sodium nitrite and sodium hypochlorite can be used in lieu of chloramine-T.

Electrolytic Method

Many proteins can be radioiodinated by the electrolytic method, which consists of the electrolysis of a mixture of radioiodide and the material to be labeled. In the electrolytic cell, the anode and cathode compartments are separated by a dialyzing bag that contains the cathode immersed in saline, whereas the anode compartment contains the electrolytic mixture. Electrolysis releases reactive iodine, which labels the compound. Slow and steady liberation of iodine causes uniform iodination of the compound, and in the absence of any carrier iodine, a labeling yield of almost 80% can be achieved.

Enzymatic Method

In enzymatic iodination, enzymes, such as lactoperoxidase and chloroperoxidase, and nanomolar quantities of H_2O_2 are added to the iodination mixture containing radioiodine and the compound to be labeled. Hydrogen peroxide oxidizes iodide to form reactive iodine, which in turn iodinates the compound. Denaturation of proteins or alteration in organic molecules is minimal because only a low concentration of hydrogen peroxide is added. Yields of 60–85% and high specific activity can be achieved by this method. This method is mild and useful in the iodination of many proteins and hormones.

Conjugation Method

In the conjugation method, initially *N*-succinimidyl-3(4-hydroxyphenyl)-propionate (*N*-SHPP) is radioiodinated by the chloramine-T method and separated from the reaction mixture. The radioiodinated *N*-SHPP in dry benzene is available commercially. Proteins are labeled by this agent by allowing it to react with the protein molecule, resulting in an amide bond with lysine groups of the protein. The labeling yield is not very high, but the method does not cause alteration of the tyrosine moieties of protein molecules, although in vivo dehalogenation is encountered in some instances.

Demetallation Method

To improve the in vivo stability of iodinated proteins, various organometallic intermediates such as organothallium, organomercury, organosilane, organoborane, and organostannane have been used to iodinate the aromatic ring of the precursor. The carbon-metal bond has a lower binding energy than the corresponding carbonhydrogen bond and is easily cleaved by radioiodination. Of all these, organostannane [example, succinimidyl para-tri-*n*-butylstannyl benzoate (SBSB)] is most attractive because of the ease of preparation, stability, and easy exchange reaction with radioiodine. SBSB is first radioiodinated by a suitable method whereby tributylstannyl group is substituted by radioiodine (Fig. 6.2). Protein is then coupled to SBSB by mixing the two at alkaline pH. This method is mild to the protein and in vivo dehalogenation is minimal. Tamoxifen, vinyl estradiol, and phenyl fatty acids have been iodinated by this technique.



Fig. 6.2 Principle of the demetallation method

Iodogen Method

Proteins and cell membranes can be radioiodinated by the iodogen method. Iodogen or chloramide (1,3,4,6-tetrachloro- 3α , 6α -diphenylglycoluril) dissolved in methylene chloride is evaporated in tubes to obtain a uniform film coating inside the tube. The radioiodide and protein are mixed together in the tube for 10–15 min, and the mixture is removed by decantation. Iodogen oxidizes iodide, and iodine then labels the protein. The unreacted iodide is separated by column chromatography of the mixture using Sephadex gel or DEAE ion exchange material. The denaturation of protein is minimal, because the reaction occurs on a solid phase of iodogen, which is poorly soluble in water. The labeling yield is of the order of 70–80%.

Iodo-Bead Method

In the iodo-bead method, iodo-beads are used to iodinate various peptides and proteins containing a tyrosine moiety. Iodo-beads consist of the oxidant *N*-chlorobenzenesulfonamide immobilized on 2.8-mm diameter nonporous polystyrene spheres. These spheres are stable for at least 6 months if stored in an amber bottle at 4°C. Radioiodination is carried out by simply adding five to six iodo-beads to a mixture of protein (~100 µg) and ¹²⁵I- or ¹³¹I-sodium iodide in 0.5 ml of phosphate buffer solution contained in a capped polystyrene tube. The reaction is allowed for 15 min at room temperature. The iodination mixture can be removed by pipetting, and iodinated protein is then separated by conventional techniques. This method has been claimed to be very successful with little denaturation of the protein. The labeling yield is almost 99%.

Radioiodinated Compounds

After radioiodination the residual free iodide is removed by precipitation, anion exchange, gel filtration, or dialysis; the particular method of choice depends on the iodinated compound. Many iodinated compounds can be sterilized by autoclaving, but sterilization of labeled proteins must be carried out by membrane filtration because autoclaving denatures proteins.

In general, iodine binds firmly and irreversibly to aromatic compounds, but its binding to aliphatic compounds is rather reversible. Iodine binds with amino and sulfhydryl groups, but these reactions are reversible. Partially unsaturated aliphatic fatty acids and neutral fats (e.g., oleic acid and triolein) can be labeled with radioiodine. However, iodination saturates the double bond in these molecules and thus alters their chemical and perhaps biological properties.

Various examples of radioiodinated compounds are ¹²⁵I-, or ¹³¹I-labeled human serum albumin, fibrinogen, insulin, globulin, and many hormones, antibodies, and enzymes. The major drawback of ¹³¹I-labeled compounds is the high radiation dose to the patient and high-energy photons (364 keV). The radiation characteristics of ¹²³I are suitable for use in vivo, and with their increasing availability, many ¹²³I-radiopharmaceuticals are prepared for clinical use in nuclear medicine. In many institutions, ¹²³I-sodium iodide is used routinely for thyroid studies.

6.6.2 Labeling with ^{99m}Tc

General Properties of Technetium-99m

As previously mentioned, nearly 80% of radiopharmaceuticals used in nuclear medicine are ^{99m}Tc-labeled compounds. The reason for such a preeminent position of ^{99m}Tc in clinical use is its favorable physical and radiation characteristics. The 6-h physical half-life and the small amount of electron emission permit the administration of millicurie amounts of ^{99m}Tc radioactivity without significant radiation dose to the patient. In addition, the monochromatic 140-keV photons are readily collimated to give images of superior spatial resolution. Furthermore, ^{99m}Tc is readily available in a sterile, pyrogen-free, and carrier-free state from ⁹⁹Mo-^{99m}Tc generators.

Chemistry of Technetium

Technetium is a transition metal of silvery gray color belonging to group VIIB (Mn, Tc, and Re) and has the atomic number 43. No stable isotope of technetium exists in nature. The ground state ⁹⁹Tc has a half-life of 2.1×10^5 years. The electronic structure of the neutral technetium atom is $1s^22s^22p^63s^23p^63d^{10}4s^24p^64d^65s^1$. Technetium can exist in eight oxidation states, namely, 1- to 7+, which result from the loss of a given number of electrons from the 4d and 5 s orbitals or gain of an electron to the 4d orbital. The stability of these oxidation states depends on the type of ligands and chemical environment. The 7+ and 4+ states are most stable and exist in oxides, sulfides, halides, and pertechnetates. The lower oxidation states, 1-, 1+, 2+, and 3+, are normally stabilized by complexation with ligands, for example, Tc^{1+} complexed with six isonitrile groups in ^{99m}Tc-sestamibi (see Chap. 7). Otherwise, they are oxidized to the 4+ state and finally to the 7+ state. The Tc⁵⁺ and Tc⁶⁺ species frequently disproportionate into Tc⁴⁺ and Tc⁷⁺ states:

$$3Tc^{5+} \rightarrow 2Tc^{4+} + Tc^{7+}$$
 (6.9)

$$3Tc^{6+} \rightarrow Tc^{4+} + 2Tc^{7+}$$
 (6.10)

The coordination number of ^{99m}Tc-complexes can vary between 4 and 9.

The low concentration of carrier-free 99m Tc(~10⁻⁹ *M*) in many 99m Tc-labeled compounds presents a difficult problem in assessing its chemistry. Most of the information regarding the chemistry of technetium has been obtained from that of 99 Tc, which is available in concentrations of 10⁻⁴ to 10⁻⁵ *M*, by applying various analytic techniques such as polarography, mass spectrometry, X-ray crystallography, chromatography, and so on.

The principles of dilute solutions play an important role in the chemistry of ^{99m}Tc, because the concentration of ^{99m}Tc in ^{99m}Tc-radiopharmaceuticals is very low. For example, a 20 ml 3-Ci (111-GBq) sample of the ^{99m}Tc-eluate from the Moly generator would have a ^{99m}Tc concentration of about $2.8 \times 10^{-7} M$. Because ⁹⁹Tc competes with ^{99m}Tc in all chemical reactions, the chemistry of ^{99m}Tc-radiopharmaceuticals is further complicated by the presence of ⁹⁹Tc, which arises from the 13% direct decay of ⁹⁹Mo and the decay of ^{99m}Tc over time. In preparations

containing only a limited amount of Sn²⁺, the total amount of both ^{99m}Tc and ⁹⁹Tc may be too high to undergo complete reduction by Sn²⁺, thus lowering the labeling yield. For example, the tin content in HMPAO kits is limited, and therefore freshly eluted ^{99m}Tc is required for maximum labeling yield. Thus it is essential to have knowledge of the relative proportions of ^{99m}Tc and ⁹⁹Tc in the Tc-eluate to estimate the labeling yield of a ^{99m}Tc-radiopharmaceutical.

It has been found that the amount of Sn^{2+} available for ^{99m}Tc labeling in typical lyophilized kits is much lower than expected from the original amount added to the formulation. This has been attributed to the likely formation of colloidal tin oxide during the later phase of lyophilization. At present, there is no method to prevent this loss of Sn^{2+} .

Reduction of 99mTcO₄

The chemical form of ^{99m}Tc obtained from the Moly generator is sodium pertechnetate (^{99m}Tc-NaTcO₄). The pertechnetate ion, ^{99m}Tc O₄⁻, having the oxidation state 7+ for ^{99m}Tc, resembles the permanganate ion, $Mn O_4^-$, and the perthenate ion, $Re O_4^-$. It has a configuration of a pyramidal tetrahedron with Tc⁷⁺ located at the center and four oxygen atoms at the apex and corners of the pyramid. Chemically, ^{99m}Tc O₄⁻ is a rather nonreactive species and does not label any compound by direct addition. In ^{99m}Tc-labeling of many compounds, prior reduction of ^{99m}Tc from the 7+ state to a lower oxidation state is required. Various reducing agents that have been used are stannous chloride (SnCl₂·2H₂O), stannous citrate, stannous tartrate, concentrated HCl, sodium borohydride (NaBH₄), dithionite, and ferrous sulfate. Among these, stannous chloride is the commonly used reducing agent in most preparations of ^{99m}Tc-labeled compounds. Another method of reduction of ^{99m}Tc⁺ involves the electrolysis of a mixture of sodium pertechnetate and the compound to be labeled using an anode of zirconium.

The chemical reactions that occur in the reduction of technetium by stannous chloride in acidic medium can be stated as follows:

$$3\mathrm{Sn}^{2+} \rightleftharpoons 3\mathrm{Sn}^{4+} + 6\mathrm{e}^{-}$$
 (6.11)

$$2^{99m} \operatorname{TcO}_{4}^{-} + 16\mathrm{H}^{+} + 6\mathrm{e}^{-} \rightleftharpoons 2^{99m} \operatorname{Tc}^{4+} + 8\mathrm{H}_{2}\mathrm{O}$$
(6.12)

Adding the two equations, one has

$$2^{99m} \text{TcO}_{4}^{-} + 16\text{H}^{+} + 3\text{Sn}^{2+} \rightleftharpoons 2^{99m} \text{Tc}^{4+} + 3\text{Sn}^{4+} + 8\text{H}_{2}\text{O}$$
(6.13)

Equation (6.12) indicates that ${}^{99m}Tc^{7+}$ has been reduced to ${}^{99m}Tc^{4+}$. Other reduced states such as ${}^{99m}Tc^{3+}$ and ${}^{99m}Tc^{5+}$ may be formed under different physicochemical conditions. It may also be possible for a mixture of these species to be present in a given preparation. Experiments with millimolar quantities of ${}^{99}Tc$ have shown that Sn^{2+} reduces ${}^{99}Tc$ to the 5+ state and then slowly to the 4+ state in citrate buffer at pH 7. Technetium-99 is reduced to the 4+ state by Sn^{2+} in concentrated HCl.

The amount of 99m Tc atoms in the 99m Tc-eluate is very small (~10⁻⁹ *M*), and therefore only a minimal amount of Sn²⁺ is required for reduction of such a small quantity of 99m Tc; however, enough Sn²⁺ is added to ensure complete reduction. The ratio of Sn²⁺ ions to 99m Tc atoms may be as large as 10⁶.

Labeling with Reduced Technetium

The reduced ^{99m}Tc species are chemically reactive and combine with a wide variety of chelating agents. A schematic reaction would be

Reduced^{99m}Tc + chelating agent
$$\rightleftharpoons$$
 ^{99m}Tc-chelate (6.14)

The chelating agent usually donates lone pairs of electrons to form coordinate covalent bonds with reduced ^{99m}Tc. Chemical groups such as $-COO^-$, $-OH^-$, $-NH_2$, and -SH are the electron donors in compounds such as DTPA, gluceptate, and so on. Several investigators proposed that tin is incorporated into the ^{99m}Tc-chelate, for example, ^{99m}Tc-labeled DTPA, N[N'-(2,6-dimethylphenyl)carbamoylmethyl] iminodiacetic acid (HIDA), methylene diphosphonate (MDP), pyrophosphate (PYP), hydroxyethylidene diphosphonate (HEDP), and gluconate do not contain any tin in the structure of the complex.

Free Pertechnetate in ^{99m}Tc-Radiopharmaceuticals

In a typical preparation of ^{99m}Tc-radiopharmaceutical in the kit vial, the quantity of free pertechnetate usually remains within the acceptable limit. However, the presence of oxygen in the vial, particularly before the addition of ^{99m}Tc, can cause oxidation of the stannous ion to stannic ion whereby the amount of stannous ion available for reduction of Tc⁷⁺ decreases. This results in an increase in free ^{99m}TcO₄⁻ in ^{99m}Tc-radiopharmaceuticals. Further, the high activity of ^{99m}Tc in the presence of oxygen can cause radiolysis of water or other products in the sample producing hydroxy(OH), alkoxy(RO), and peroxy(RO₂) free radicals. These species interact with ^{99m}Tc-chelates producing free ^{99m}TcO₄⁻ in the sample. However, limits of ^{99m}Tc activity suggested for adding to the commercial kits are sufficiently low such that the radiolytic effects are normally negligible.

The above effects can be mitigated by using sufficient quantity of stannous ion and by avoiding oxygen, air, or any oxidizing agent in the vial throughout its shelflife. It is a common practice to flush the kit vials with N_2 gas to maintain inert gas atmosphere in them. In some kits such as MDP and HDP kits, antioxidants (e.g., ascorbic acid and gentisic acid) are added to prevent oxidation.

Hydrolysis of Reduced Technetium and Tin

There is a possibility that reduced ^{99m}Tc may undergo hydrolysis in aqueous solution. In this case, reduced ^{99m}Tc reacts with water to form various hydrolyzed species depending on the pH, duration of hydrolysis, and presence of other agents. An analysis of chemical reactions shows that hydrolyzed technetium is a compound of ^{99m}TcO₂ complexed with other ingredients (e.g., SnO, MoO₃, or Al). This hydrolysis competes with the chelation process of the desired compound and thus reduces the yield of the ^{99m}Tc-chelate. The hydrolyzed species can also interfere with the diagnostic test in question if they are present in large quantities in the radiopharmaceutical.

The use of stannous chloride has a disadvantage in that the Sn^{2+} ion also readily undergoes hydrolysis in aqueous solution at pH 6–7 and forms insoluble colloids.

These colloids bind to reduced 99m Tc and thus compromise the labeling yield. For this reason, an acid is added to prevent the hydrolysis of Sn²⁺ before the reduction of technetium if the preparation is made using basic ingredients rather than a kit.

These two disadvantages, namely, the hydrolysis of reduced ^{99m}Tc and Sn²⁺, can be circumvented by adding enough chelating agents. The latter will bind to reduced ^{99m}Tc and Sn²⁺ and thus prevent their hydrolysis. The ratio of the chelating agent to Sn²⁺ should be large enough to ensure complete binding. Binding between the chelating agent and reduced ^{99m}Tc or Sn²⁺ is highly dependent on the affinity constant of the chelating agent. If it is a weak chelating agent (e.g., phosphate compounds), then hydrolyzed species in the ^{99m}Tc-labeled preparation tend to be relatively high. However, if the chelating agent has a high affinity constant (e.g., DTPA), then the amount of hydrolyzed species will be minimal.

At any rate, in a preparation of a ^{99m}Tc-labeled compound, three ^{99m}Tc species may be present:

- 1. "Free" 99m Tc as 99m TcO₄⁻ that has not been reduced by Sn²⁺.
- "Hydrolyzed" ^{99m}Tc, such as ^{99m}TcO₂ that did not react with the chelating agent; this includes reduced ^{99m}Tc bound to hydrolyzed Sn²⁺ [Sn(OH)₂].
- "Bound" ^{99m}Tc-chelate, which is the desired compound formed by binding of reduced ^{99m}Tc to the chelating agent.

In most routine preparations, the major fraction of radioactivity is in the bound form. The free and hydrolyzed fractions are undesirable and must be removed or reduced to a minimum level so that they do not interfere significantly with the diagnostic test in question. Analysis of ^{99m}Tc- and ⁹⁹Tc-HEDP samples by high-performance liquid chromatography has revealed that there are at least seven Tc-containing species of unknown oxidation states. The distribution of different components in these mixtures depends on reaction time and the presence of molecular oxygen.

Formation of ^{99m}Tc-Complexes by Ligand Exchange

The ligand exchange method, also termed the *transchelation*, involves first forming a ^{99m}Tc-complex with a weak ligand in aqueous media and then allowing the complex to react with a second ligand, which is relatively more stable. Because of the difference in stability of the two ligands, a ligand exchange occurs, forming a more stable ^{99m}Tc-complex with the second ligand. For example, in the preparation of ^{99m}Tc-labeled mercaptoacetylglycylglycylglycine (MAG3), ^{99m}Tc-tartrate or ^{99m}Tc-gluconate is first formed by reduction of ^{99m}Tc O_4^- with stannous ion in the presence of sodium tartrate or gluconate. Subsequent heating with MAG3 results in ^{99m}Tc-MAG3. The following are the sequences of reactions for ^{99m}Tc-MAG3:

$19m$
TcO₄⁻ + Sn²⁺ \rightleftharpoons Reduced^{99m}Tc + Sn⁴⁺ (6.15)

Reduced^{99m}Tc + tartrate \rightleftharpoons ^{99m}Tc - tartrate (6.16)

^{99m} Tc-tartrate + MAG3
$$\rightarrow$$
 ^{99m} Tc-MAG3+ tartrate (6.17)

Stronger ligands such as MAG3, isonitrile, and ECD are less soluble in aqueous solution and require heating or a long time without heating to dissolve. In contrast, weaker ligands such as tartrate, citrate, and EDTA are highly soluble in aqueous solution. In kits containing both weak and strong ligands, stannous ions primarily remain bound to weaker ligands rather than stronger ligands because of the ready solubility of the former. After the addition of ^{99m}Tc O_4^- , Tc⁷⁺ is reduced by Sn²⁺ ions, and the reduced Tc readily forms ^{99m}Tc-chelate with the weaker ligands. Upon heating or with a long reaction time, stronger ligands dissolve and ligand exchange occurs between the stronger ligand and ^{99m}Tc-chelate.

The addition of a weaker chelating agent is necessary to stabilize the reduced Tc, particularly in the lower oxidation states. Because the reaction between the stronger ligand and the reduced Tc is slow due to poor solubility of the ligand, the stronger ligand alone, in the absence of a weaker ligand, would tend to precipitate most of the reduced Tc as colloid.

Based on these principles, several kits for ^{99m}Tc-labeling have been formulated containing both weak and stronger ligands along with stannous ions. Examples are tartrate and MAG3 for renal imaging, EDTA and ethyl cysteine dimer (ECD) for brain imaging, and hexakis-methoxyisobutyl isonitrile and sodium citrate for myo-cardial imaging.

6.6.3 Structure of ^{99m}Tc-Complexes

The oxidation state of technetium in many ^{99m}Tc-complexes is not known with certainty. Polarographic measurements and iodometric titrations have been employed to determine the oxidation state of technetium in these compounds. In ^{99m}Tc-DTPA, the oxidation state of technetium has been reported to be ^{99m}Tc⁴⁺, whereas in ^{99m}Tclabeled albumin it has been suggested to be ^{99m}Tc⁵⁺. Various physicochemical factors influence the reduction of ^{99m}Tc⁷⁺ and hence the oxidation state of technetium in a ^{99m}Tc-complex.

Various methods such as electronic and vibrational spectroscopy, X-ray crystallography, solvent extraction, electrophoresis, and mass spectrometry are employed in the separation and characterization of ^{99m}Tc-complexes. It has been shown that many ^{99m}Tc-complexes studied thus far have technetium in the 5+ oxidation state. It has also been found that most of these compounds are stabilized by oxo groups and contain oxotechnetium (^{99m}Tc = O) cores such as ^{99m}TcO³⁺, *trans*-^{99m}TcO⁴, and ^{99m}Tc₂O⁴⁺ (Jones and Davison 1982). The structures of ^{99m}TcO³⁺ and *trans*-^{99m}TcO⁴ are illustrated in Fig. 6.3. In the figure, "L" represents ligands in the cis position that form coordinate covalent bonds with technetium of the ^{99m}Tc = O core. In Fig. 6.3b, there is an oxygen atom in the *trans*-position to the ^{99m}Tc = O core. Figure 6.3a is an illustration of a five-coordinate complex and Fig. 6.3b represents a six-coordinate complex. The oxygen in the *trans*-position may become labile by the influence of the electronic structure of the cis ligands and can easily undergo solvolysis in alcohols and water.

The charge of a 99m Tc-complex is determined by adding the charges of the ligands to that of the 99m Tc = O core. The coordination number of 99m Tc-complexes can vary



from four to nine depending on the nature of the ligands. The pentavalent Tc $({}^{99m}Tc^{5+})$ is coordinated by four thiolates of two DMSA ligands and an apical oxo group, and the complex has the formula $[TcO(DMSA)_2]^{-3}$ with coordination number 5, as shown in Fig. 6.4.

The biodistribution and in vivo kinetics of ^{99m}Tc-radiopharmaceuticals are influenced by their stereochemical structures. The latter depend on the ligand stereochemistry, the number, type and arrangement of donor atoms, chelate ring size and conformation, the coordination geometry of the metal, and the number of possible ways a ligand can arrange around the metal. The majority of stereochemical studies on ^{99m}Tc-radiopharmaceuticals have been made with six-coordinate octahedral complexes containing two or more bidentate ligands and five-coordinate square pyramidal Tc = O complexes. For example, ^{99m}Tc-hexamethylpropyleneamine oxime (HMPAO) is an octahedral complex having the *d*,*l* stereoisomer as well as the mesoisomer, and ^{99m}Tc-ECD has the five-coordinate square pyramidal structure giving rise to *l*,*l*, *d*,*d*, and mesoisomers. However, *d*,*l* HMPAO and *l*,*l* ECD isomers only are used for clinical purposes, because of their preferential localization in the brain.

6.6.4 Oxidation States of ^{99m}Tc in ^{99m}Tc-Radiopharmaceuticals

As already mentioned, technetium can exist in various oxidation states from 1- to 7+. The Tc⁵⁺ oxidation state is most common in ^{99m}Tc-complexes, although compounds containing ^{99m}Tc in other oxidation states exist and are being developed in

increasing numbers. Various 99m Tc-complexes in different oxidation states are discussed below. No useful Tc⁶⁺, Tc²⁺, and Tc⁰ complexes have been developed for clinical use, and therefore, these complexes have been omitted.

Tc⁷⁺

This state is most stable and is found in pertechnetate ($^{99m}Tc O_4^-$) and technetium heptasulfide ($^{99m}Tc_2S_7$).

Tc⁵⁺

This oxidation state exists in ^{99m}Tc-citrate, ^{99m}Tc-gluconate, and ^{99m}Tc-gluceptate prepared by SnCl₂ reduction of pertechnetate in aqueous solution. Tc⁵⁺ forms complexes with various dithiols (containing sulfur) in which the coordination number of the complex is 5 in the solid state. The four sulfur atoms occupy the four corners of the square base plane and an oxygen atom at the apex of the square pyramid. In solution, six-coordinate compounds are formed, in which case the octahedral structure renders the molecule more labile. One example of this type is diaminodithiol (DADT) compounds. The oxidation state of ^{99m}Tc in these complexes is 5+, and the complexes are neutral, stable, and lipophilic. Other Tc⁵⁺ complexes include EDTA, pyridine, and imidazole ligands containing nitrogen bases. X-ray crystallography of the ^{99m}Tc-HMPAO complex shows Tc⁵⁺ to have five-coordinate groups with an oxo group at the apex and four nitrogen atoms at the corners of the square base of a pyramid. Loss of a hydrogen atom from two amine groups and an oxime group in the ligand results in a neutral complex.

Tc⁴⁺

The common examples of the Tc⁴⁺ oxidation state are found in TcO₂ and hexahalo complexes. ^{99m}TcO₂·xH₂O is produced by reduction of pertechnetate with zinc in HCl. But in this process, 20% of the technetium is reduced to metal. Hydrolysis of hexaiodo complex results in a pure TcO₂·xH₂O product. Hexahalo complexes are stable only in a nonaqueous solution, whereas they undergo hydrolysis in aqueous solution.

The oxidation state of 99m Tc in 99m Tc-hydroxyethylidene diphosphonate (HEDP) has been reported to be variable, depending on the pH of the preparation. The Tc³⁺ state exists at acidic pH, the Tc⁵⁺ in alkaline solution, and the Tc⁴⁺ at neutral pH. Since a slight variation of pH can alter the oxidation state, 99m Tc may exist in a mixture of 3+, 4+, and 5+ states in 99m Tc-HEDP.

Tc³⁺

^{99m}Tc-complexes of DTPA, EDTA, dimercaptosuccinic acid (DMSA), and HIDA all are found to have the Tc³⁺ state when prepared in acid solutions. However, the Tc⁴⁺ state is found in both alkaline and neutral solutions of DTPA and EDTA.

Various arsine and phosphine complexes of Tc^{3+} have been prepared mostly for myocardial imaging. These complexes are of the type $[TcD_2X_2]^+$ where D stands for a chelating diphosphine ligand and X represents a halogen. The organic ligands include [1,2 bis-diphenylphosphino] ethane (DPPE), [bis (1,2-dimethylphosphino)

ethane] (DMPE), and [*o*-phenylene bis (dimethylarsine)], whereas the halogen and halogen-like ligands are Cl, Br, and SCN. The structure of DPPE is found to be octahedral, in which the centrally located Tc is coordinated with four equatorial phosphorus atoms and two transaxial halogen atoms. The electrochemistry of these compounds shows that complexes with Cl⁻ and Br⁻ are highly stable.

The Tc³⁺ state exists in ^{99m}Tc-labeled oxime complex and the most common example of this type is ^{99m}Tc-labeled dimethylglyoxime, which is prepared by Sn²⁺ reduction of ^{99m}TcO₄⁻ in the presence of dimethylglyoxime. In this compound, Sn²⁺ is found to be incorporated in the structure of the complex.

Another class of compounds, called BATOs (boronic acid adducts of technetium dioxime complexes), is found to contain the Tc³⁺ state in the structure, when complexed with ^{99m}Tc. ^{99m}Tc-teboroxime (Cardiotec; Squibb Diagnostics, Princeton, NJ) belongs to this group and was once used for myocardial imaging. In the structure of ^{99m}Tc-teboroxime, technetium is coordinated to three N-bonded dioxime molecules and one Cl atom in an axial position. However, its very rapid washout from the myocardium made it impractical to collect meaningful data using the SPECT technique.

Tc¹⁺

This oxidation state is primarily stabilized in aqueous medium by coordination bonds with various ligands. For example, Tc^{1+} in ^{99m}Tc -sestamibi is stabilized by the isonitrile groups. Other isonitrile complexes such as tert-butyl, methyl, cyclohexile, and phenyl isocyanide groups form stable compounds with ^{99m}Tc in the 1+ oxidation state. These compounds are stable in air and water.

6.6.5 Oxidation States in ^{99m}Tc-Labeled Proteins

The oxidation state of technetium in 99m Tc-labeled protein depends on the reducing agents used in the preparation. For example, when concentrated HCl is used as the reducing agent, Tc⁴⁺ is the likely oxidation state in 99m Tc-albumin. However, when ascorbic acid is used as the reducing agent, Tc⁵⁺ is the probable oxidation state. This is true in the case of direct labeling method (described later). In the case of indirect labeling in which a bifunctional chelating agent is added as a spacer between the Tc and the protein (antibody), Tc exists primarily in the Tc⁴⁺ state, where one end of the chelator binds to Tc, while the other end is bound to the protein.

6.6.6 Kits for ^{99m}Tc-Labeling

The introduction of kits for many ^{99m}Tc-radiopharmaceuticals has facilitated the practice of nuclear pharmacy significantly. The kits have a long shelf-life and can be purchased and stored well ahead of daily preparation; ^{99m}Tc-labeling can be accomplished simply by adding ^{99m}TcO₄⁻ to most kits.

Kits for most ^{99m}Tc-radiopharmaceuticals are prepared from a "master" solution consisting of the compound to be labeled mixed with an acidic solution of a

stannous compound in appropriate proportions. The pH of the solution is adjusted to 5–7 with dilute NaOH, purged with nitrogen, and aliquots of the solution are dispensed into individual kit vials. The solution is then lyophilized (freeze-dried) and the vial flushed and filled with sterile nitrogen. Lyophilization renders the dried material in the vial readily soluble in aqueous solution and thus aids in labeling by chelation. The preparation is carried out using sterile materials and under strict aseptic conditions in a laminar flow hood filled with nitrogen under positive pressure.

Various stannous compounds, such as stannous chloride, stannous fluoride, stannous citrate, stannous tartrate, stannous pyrophosphate, and so on, have been used by different commercial manufacturers, although stannous chloride is most commonly used. In the kit preparation, when the acidic solution of Sn^{2+} is added, a complex is formed between Sn^{2+} and the chelating agent:

$$\operatorname{Sn}^{2+}$$
 + chelating agent \rightleftharpoons Sn-chelate (6.18)

When the pH of the solution is raised, hydrolysis of Sn^{2+} does not occur because Sn^{2+} is already chelated in the presence of a large amount of the chelating agent.

The chemistry of tin as described earlier prevails when the ${}^{99m}\text{Tc}O_4^-$ solution is added to the lyophilized chelating agent in the kit vial. ${}^{99m}\text{Tc}^{7+}$ is reduced by Sn²⁺ in the Sn-chelate or by the free Sn²⁺ at equilibrium in Eq. (6.18). The amount of Sn²⁺ in the kit should be more than sufficient to reduce the nanomolar quantity of ${}^{99m}\text{Tc}^{7+}$ added to the kit.

In each kit, the initial amounts of Sn²⁺ and chelating agent in the master solution are very important. If too much tin is used, the possibility of hydrolysis of tin increases, in which case hydrolyzed tin may coprecipitate some of the reduced ^{99m}Tc to form ^{99m}Tc-Sn-colloid and other Sn-complexes, thus diminishing the yield of the labeled chelate. Too little tin may lead to incomplete reduction of ^{99m}Tc to the desired oxidation state and hence an unreliable yield of the ^{99m}Tc-complex along with unreacted ^{99m}Tc O₄⁻. A large excess of the chelating agent should be used to keep the tin complexed. This prevents the hydrolysis of tin and technetium at pH 6 to 7 after the addition of ^{99m}Tc O₄⁻ to the kit and thus results in an improved yield of ^{99m}Tc-complex. For a weak chelating agent, the ratio of chelating agent to tin should be even higher. However, the optimum value of this ratio must be established for each kit by trial and error.

6.7 Colloids and Labeled Particles

In true solutions, such as those of sucrose, sodium chloride, and so on, the particles of a solute dissolved in the solvent are believed to be of molecular size. The particle size is less than 1 nm (1 nm = 10^{-9} m), and the particles are not visible under the microscope. On the other hand, a suspension or emulsion contains particles large enough to be visible to the naked eye or at least under the light microscope. These particles are greater than 1 µm (1 µm = 10^{-6} m = 10^{-4} cm). Colloidal particles fall

between the two extremes of true solutions and suspensions. The size of colloidal particles ranges between 10 nm and 1 μ m, and they are usually electrically charged. The surface charge of the particles (immobile) is balanced by an equal and opposite charge of the mobile layer of the solvent. The potential developed between the two layers is called the ζ -potential. Addition of electrolytes (salts, acids, or bases) to a colloid breaks down this potential and eventually causes aggregation or flocculation of colloids.

Stabilizing agents such as gelatin, polyvinylpyrrolidone, or carboxymethyl cellulose are added to many colloidal preparations to prevent aggregation. The stability and characteristics of a colloid depend on many factors such as size, primary charge, ζ -potential, valence of the ions, surface tension, viscosity, and polarity of the dispersion medium. Colloidal particles are not visible under the light microscope but can be detected under the ultramicroscope or electron microscope. Colloids are sometimes referred to as "macroaggregates", although many investigators define the latter as having a size range of 0.5–5 µm. An example of a colloid used in nuclear medicine is ^{99m}Tc-sulfur colloid. These particles are removed by reticuloendothelial cells and therefore can be used for imaging the liver, spleen, and bone marrow. Colloids of smaller sizes, such as ^{99m}Tc-antimony sulfide colloid, have been used for lymphoscintigraphy.

Larger particles, or macroaggregates as they are often called, are larger than 5 μ m and can be seen under the light microscope. The size of these particles can be measured using a hemocytometer under a light microscope. Examples of larger particles are ^{99m}Tc-MAA particles, which range in size between 15 and 100 μ m. These particles are trapped in the capillary bed of the lungs and are used widely for imaging the lungs.

6.8 Additives and Preservatives

Additives, or preservatives as they are sometimes called, are added to many radiopharmaceuticals or labeled compounds to preserve their integrity and efficacy. As previously mentioned, labeled compounds are prone to degradation by radiolysis, and there is a possibility of bacterial growth in many radiopharmaceuticals. In many cases additives prevent these complications. A preservative can function as a stabilizer, an antioxidant, or a bactericidal agent, and some additives can perform all these functions simultaneously. Additives must not react with any ingredient of the radiopharmaceutical preparation.

Stabilizers are added to maintain the integrity of a radiopharmaceutical or a labeled compound in its original state. They are very important in radiopharmaceutical preparations, particularly if the preparations are to be preserved for a long time. Ascorbic acid, gentisic acid, citrates, and acetates are all stabilizers for many ^{99m}Tc-labeled preparations. Gelatin is a widely used stabilizer for colloidal preparations, but its property as a growth medium tends to encourage bacterial growth. For this reason, proper sterilization and aseptic handling of preparations containing gelatin are essential.

Bactericidal agents are used to prevent bacterial growth in a solution. Benzyl alcohol in a concentration of 0.9% is widely used for this purpose. Such a low concentration of this compound is used because it has a vasodilating effect. Benzyl alcohol also reduces radiolysis in the radiopharmaceutical preparation. Sometimes ethanol (2.0%) is used as a bactericidal agent. These agents are not usually added to ^{99m}Tc-radiopharmaceuticals.

The pH of a radiopharmaceutical is very important for its stability and biological properties; maintenance of the proper pH of the solution is achieved by adding acid, alkali, or suitable buffers such as Tris buffer or phosphate buffers to the radiopharmaceutical preparation.

The loss of radioiodine due to oxidation of iodide in an iodide solution is often prevented by the addition of a reducing agent such as sodium thiosulfate, sodium sulfite, or ascorbic acid or by maintaining an alkaline pH.

Questions

- 1. Discuss various factors that should be considered in the labeling procedure.
- 2. (a) What is the oxidation state of ¹³¹I required for iodination? (b) What is the optimum pH for protein labeling? (c) What is the binding site in iodination of protein? (d) What is believed to be the iodinating species? (e) What are the two types of iodination reactions?
- Describe various methods of iodination and their merits and disadvantages.
- 4. What is the most common reducing agent used in ^{99m}Tc-labeling?
- 5. In ^{99m}Tc-labeling, it is often desirable that the chelating agent be added in excess. Explain.
- 6. What are the three species of ^{99m}Tc present in a ^{99m}Tc-MDP preparation? Explain how the hydrolyzed ^{99m}Tc originates in the sample. Can you suggest a method to prevent this?
- Oxygen or oxidizing agents should not be present in ^{99m}Tc-preparations. Why?
- 8. Write the general chemical equations for ^{99m}Tc-labeling of a chelating agent. Describe the preparation of kits for ^{99m}Tc-labeled compounds.
- State the oxidation states of ^{99m}Tc in the following compounds: (a) ^{99m}Tc-DTPA, (b) ^{99m}Tc-labeled albumin, and (c) ^{99m}Tc-HIDA.
- 10. What are colloids? What are they used for? Name the common additive used in ^{99m}Tc-sulfur colloid.
- 11. Discuss the importance of the oxotechnetium core in the structure of ^{99m}Tc-complexes.

References and Suggested Reading

- Clark MJ, Podbielski L. Medical diagnostic imaging with complexes of Tc-99m. Coord Chem Rev. 1987;78:253.
- Deutsch E, Nicolini M, Wagner HN Jr. Technetium in chemistry and nuclear medicine. Verona: Cortina International; 1983.
- Dewanjee MK. The chemistry of 99mTc-labeled radiopharmaceuticals. Semin Nucl Med. 1990;20:5.
- Dewanjee MK. Radioiodination: theory, practice and biomedical application. Boston: Kluwer Academic; 1992.
- Eckelman WC, Steigman J, Paik CH. Radiopharmaceutical chemistry. In: Harpert J, Eckelman WC, Neumann RD, editors. Nuclear medicine: diagnosis and therapy. New York: Thieme Medical; 1996. p. 213.
- Jones AG, Davison A. The relevance of basic technetium chemistry to nuclear medicine. J Nucl Med. 1982;23:1041.
- Nicolini M, Bandoli G, Mazzi U, editors. Technetium in chemistry and nuclear medicine. Verona: Cortina International; 1986.
- Richards P, Steigman J. Chemistry of technetium as applied to radiopharmaceuticals. In: Subramanian G, Rhodes BA, Cooper JF, Sodd VJ, editors. Radiopharmaceuticals. New York: Society of Nuclear Medicine; 1975. p. 23.
- Srivastava SC, Meinken G, Smith TD, Richards P. Problems associated with stannous ^{99m}Tcradiopharmaceutical. In: Welch MJ, editor. Radiopharmaceuticals and other compounds labelled with short-lived radionuclides. New York: Pergamon Press; 1977. p. 83.
- Steigman J, Eckelman WC. The chemistry of technetium in medicine. Nuclear medicine series. NAS-NS-3204. Washington, DC: National Head Press; 1992.
- Wilbur DS, Hadley SW, Hylarides MD, et al. Development of a stable radioiodinating reagent to label monoclonal antibodies for radiotherapy of cancer. J Nucl Med. 1989;30:216.

Characteristics of Specific Radiopharmaceuticals

In this chapter, the practical aspects of preparation, labeling yield, stability, storage conditions, and other characteristics of radiopharmaceuticals most commonly used in nuclear medicine are discussed below.

7.1 ^{99m}Tc-Labeled Radiopharmaceuticals

The basic principle of ^{99m}Tc-labeling involves reduction of ^{99m}Tc⁷⁺ to an oxidation state that binds to a chelating molecule of interest. In most cases, kits for ^{99m}Tc-radiopharmaceuticals are commercially available for routine clinical use. These kits contain the chelating agent of interest and the reducing agent in appropriate quantities. In some kits, suitable stabilizers are added. Limits of volume and activity of ^{99m}Tc that can be added to specific kit vials and expiration time are given in the package inserts provided by the manufacturer. For most ^{99m}Tc-radiopharmaceuticals, the expiration time is 6 h, equal to the physical half-life of ^{99m}Tc ($t_{1/2} = 6$ h). Also included in the package inserts are storage temperatures for the kits before and after the formulation with ^{99m}Tc. The following is a description of the characteristics of the routinely used ^{99m}Tc-radiopharmaceuticals.

7.1.1 ^{99m}Tc-Sodium Pertechnetate

^{99m}Tc-NaTcO₄ ($t_{1/2} = 6$ h) is eluted from the ⁹⁹Mo–^{99m}Tc generator in saline solution. These generators are supplied by Mallinckrodt Pharmaceuticals and Lantheus Medical Imaging. The ^{99m}TcO₄⁻ solution obtained from the generator is tested for ⁹⁹Mo and Al breakthrough, and aliquots are used to prepare different kits, as described below. The shelf-life of ^{99m}TcO₄⁻ is 12 h after elution and can be stored at room temperature. The oxidation state of technetium in ^{99m}TcO₄⁻ is 7+.

 99m Tc O_4^- is primarily used for preparation of 99m Tc-labeled radiopharmaceuticals, but is used as such for thyroid imaging and Meckel's diverticulum detection.

[©] Springer International Publishing AG 2018 G.B. Saha, *Fundamentals of Nuclear Pharmacy*, https://doi.org/10.1007/978-3-319-57580-3_7

7.1.2 ^{99m}Tc-Macroaggregated Albumin

The macroaggregated albumin (MAA) is prepared by heating a mixture of human serum albumin (HSA) and stannous chloride or tartrate in acetate buffer (pH 5; isoelectric point of albumin) at 80–90°C for about 30 min. The particles are washed with saline to remove any free stannous ion and resuspended in saline. The suspension is then aliquoted into vials for later use as kits.

Commercial kits are available in lyophilized form from Jubilant DraxImage Inc. and usually contain MAA particles, stannous chloride dihydrate or tartrate, and HCl or NaOH added for pH adjustment. The number of particles varies from 1 to 12 million particles per milligram of aggregated albumin. The shape of the particles is irregular, and the size ranges between 10 and 90 μ m, with no particles larger than 150 μ m. The kits should be stored at 2–8°C before labeling with ^{99m}Tc.

The preparation of 99m Tc-MAA using a commercial kit involves initial warming up of the vial to room temperature followed by the addition of 99m TcO₄⁻. Some kits require that the vials stand for 2–15 min for maximum tagging. The labeling efficiency is greater than 90%. The preparations are good for 6–8 h and must be stored at 2–8°C after formulation.

The ^{99m}Tc-MAA preparations must be checked for particle size with a hemocytometer (grid size = 50 μ m) under a light microscope, and suspensions containing particles larger than 150 μ m should be discarded. Before drawing a dosage for a patient, the contents of the vial should be agitated gently to make a homogeneous suspension. Similarly, the contents of the syringe also should be thoroughly mixed before administration.

^{99m}Tc-MAA is the agent of choice for lung perfusion imaging. It is also used in venography for detecting deep vein thrombi in lower extremities.

7.1.3 99mTc-Phosphonate and Phosphate Radiopharmaceuticals

Phosphonate and phosphate compounds localize avidly in bone and, therefore, are suitable for bone imaging. However, phosphonate compounds are more stable in vivo than phosphate compounds because the P–O–P bond in phosphate is easily broken down by phosphatase enzyme, whereas the P–C–P bond in diphosphonate is not. For this reason, diphosphonate complexes labeled with ^{99m}Tc are commonly used for bone imaging, although ^{99m}Tc-pyrophosphate (PYP) is used for myocardial infarct imaging. Of several phosphonate compounds, methylene diphosphonate (MDP) and hydroxymethylene diphosphonate (HDP) are most commonly used in nuclear medicine. The molecular structures of PYP, MDP, and HDP are shown in Fig. 7.1.

Commercial kits for PYP, MDP, and HDP are available from different manufacturers (Jubilant DraxImage, Bracco Diagnostics, Pharmalucence, GE Healthcare). The composition of each kit varies from vendor to vendor in quantities of the chelating agent and stannous ions. All ^{99m}Tc-diphosphonate agents are weak chelates and



Fig. 7.1 Molecular structures of phosphate and phosphonate compounds used in bone imaging

tend to degrade with time, producing $^{99m}\text{Tc}\text{O}_4^-$ impurity in the presence of oxygen and free radicals produced by radiations, as discussed in Chap. 6. These oxidative reactions can be prevented by increasing the amount of tin, purging the kits with nitrogen, and/or adding antioxidants. It should be noted that a suitable tin-to-chelating agent ratio must be maintained for optimal bone imaging without undesirable $^{99m}\text{Tc}-\text{Sn}-\text{colloid formation}$.

When bone kits containing large amounts of Sn^{2+} were used for bone imaging, subsequent brain scanning with ^{99m}TcO₄⁻ indicated ^{99m}Tc-labeling of red blood cells for up to 2 weeks after administration of ^{99m}Tc-PYP. This mimics the situation encountered in in vivo labeling of red blood cells by first administering stannous pyrophosphate followed by pertechnetate administration. The excess Sn^{2+} ions left after the reduction of ^{99m}TcO₄⁻ in diphosphonate kits are available in the plasma for further radiolabeling of the red blood cells. For this reason, the tin content was lowered in subsequent bone kits, which were further stabilized with nitrogen purging and using antioxidants such as gentisic acid.

The storage temperature for most kits is $15-30^{\circ}$ C both before and after labeling. Labeling is carried out by simply adding ^{99m}Tc O₄⁻ to the vial and mixing. The labeling yield is greater than 95%. The ^{99m}Tc-MDP preparation is good for 6 h after labeling, except for HDP kits for which an expiration time of 8 h has been indicated. The oxidation state of Tc in bone kits has been reported to be 3+.

^{99m}Tc-MDP and ^{99m}Tc-HDP are used for bone imaging, whereas ^{99m}Tc-PYP is used for myocardial infarct imaging. The latter is also used in red blood cell labeling for use in gated blood pool and gastrointestinal blood loss studies.

7.1.4 ^{99m}Tc-Sulfur Colloid

The basic principle of 99m Tc-sulfur colloid (SC) preparation is to add an acid to a mixture of 99m TcO₄⁻ and sodium thiosulfate and then heat it at 95–100°C in a water bath for 5–10 min. The pH of the mixture is adjusted to 6–7 with a suitable buffer. The labeling yield is greater than 99%. Kits of 99m Tc-SC are available commercially from Pharmalucence. To these kits, besides the basic ingredients of thiosulfate and an acid, the manufacturer adds gelatin as a protective colloid and EDTA to remove by chelation any aluminum ion present in the 99m Tc-eluate.

The shelf-life of the kits is usually 1 year from the time of manufacture. ^{99m}Tc-SC can be stored at room temperature and dispensed within 6–12 h after labeling. The particle size ranges from 0.1 to 1 μ m, with a mean size of 0.3 μ m, and the size distribution can vary from preparation to preparation. The presence of Al³⁺ or any other polyvalent ions interferes with colloid formation by flocculation, particularly in the presence of phosphate buffer, and the problem is remedied by the addition of EDTA to the kit. EDTA forms a complex with Al³⁺ and thus prevents flocculation of ^{99m}Tc-SC. The ^{99m}Tc-eluate containing more than 10- μ g aluminum/ml should not be used. If there is aggregation, larger particles will be trapped in the pulmonary capillaries, and therefore, the preparation should be discarded.

There are two steps in the labeling process of 99m Tc-SC. In the first step, the acid reacts with sodium thiosulfate in the presence of 99m TcO₄⁻ and forms colloidal 99m Tc₂S₇ as given in Eq. (7.1).

$$2Na^{99m}TcO_4 + 7Na_2S_2O_3 + 2HCl \rightarrow {}^{99m}Tc_2S_7 + 7Na_2SO_4 + H_2O + 2NaCl$$
(7.1)

In the second step, colloidal sulfur is precipitated as shown in Eq. (7.2).

$$Na_{2}S_{2}O_{3} + 2 HCl \rightarrow H_{2}SO_{3} + S + 2 NaCl$$

$$(7.2)$$

The ^{99m}Tc-SC formation is faster than the colloidal sulfur formation. It has been shown that colloidal sulfur forms at least in part on ^{99m}Tc-SC which serves as its nucleus (Eckelman et al. 1996). At the same time, colloidal sulfur can also form independently. Smaller particles generally contain relatively small quantities of colloidal sulfur but a significant amount of ^{99m}Tc-SC, and, conversely, larger particles contain more colloidal sulfur than ^{99m}Tc-SC. Thus, if more Tc (⁹⁹Tc plus ^{99m}Tc) atoms are added, as in the pertechnetate obtained from a generator that has not been previously eluted for a long period, small-size particles increase in number due to an increase in the number of both ⁹⁹Tc- and ^{99m}Tc-SC particles and less amount of colloidal sulfur. The colloidal sulfur on the Tc-SC particles can be dissolved by heating in mild alkaline solution giving rise to smaller particles. It should be noted that the oxidation state of ^{99m}Tc in ^{99m}Tc₂S₇ is 7+, and therefore no reduction of Tc⁷⁺ occurs.

^{99m}Tc-sulfur colloid is most useful in liver and spleen imaging and at times in imaging bone marrow. It is also used for gastrointestinal blood loss studies and for making ^{99m}Tc-labeled egg sandwich for gastric emptying studies.

7.1.4.1 Filtered 99mTc-Sulfur Colloid

Lymphoscintigraphy is successfully performed by using smaller size (<1 μ m) ^{99m}Tc-SC. These particles are obtained by filtering the ^{99m}Tc-SC (prepared as above) through a 0.2- or 0.1- μ m membrane filter. In the case of high concentration of activity, the sample is diluted to the desired concentration and then filtered. The concentration of particles in these preparations is reduced.

7.1.5 ^{99m}Tc-Albumin Colloid (Nanocolloid)

An albumin colloid kit under the brand name Nanocoll and Nanotop is supplied by ROTOP Pharmaka in Europe. This kit is not approved by the US FDA. This kit contains the HSA colloid (also called the nanocolloid) and stannous dihydrate and is characterized by very small-size particles (almost 95% of the particles are less than 0.08 µm in size with a mean size of 0.03 µm). Labeling is carried out by adding ^{99m}TcO₄⁻ to the kit vial and incubating the mixture for 5–10 min at room temperature. The labeling yield of ^{99m}Tc-albumin colloid is quantitative. Because of the smaller size of the particles, more nanocolloid localizes in the bone marrow (~15%) relative to ^{99m}Tc-SC (2–5%). The kit is stored at 2–8°C before reconstitution and at room temperature after reconstitution. ^{99m}Tc-albumin colloid is useful for 6 h after formulation.

^{99m}Tc-albumin colloid is useful for bone marrow imaging, inflammation scintigraphy, and lymphoscintigraphy because of their smaller size.

7.1.6 ^{99m}Tc-Tilmanocept (Lymphoseek)

^{99m}Tc-tilmanocept kit, marketed by Navidea Biopharmaceuticals as brand name Lymphoseek, is used for the detection of lymph nodes and guiding sentinel lymph node biopsy in patients with breast cancer, melanoma, and head and neck cancer. Tilmanocept is a macromolecule comprising multiple units of DTPA and mannose, each covalently bound to a dextran molecule. The kit contains five tilmanocept vials each containing 250 µg of tilmanocept and five diluent vials containing 4.5-ml buffered saline. The kit is reconstituted by adding appropriate amount of ^{99m}TcO₄⁻ to the reaction vial and allowing to stand for 15 min. The ^{99m}TcO₄⁻ solution should be used within 8 h after elution from the generator. It is diluted with sufficient volume of buffered saline as required for injections. On reconstitution, ^{99m}Tc binds to the chelating agent DTPA moieties of tilmanocept. The radiochemical purity as determined by ITLC is more than 90%. Its shelf-life is 6 h after formulation and it is stored at room temperature.

7.1.7 ^{99m}Tc-Pentetate (DTPA)

The DTPA kits are supplied by Jubilant DraxImage, Canada. The commercial DTPA kits are usually made up of pentasodium or calcium trisodium salt of DTPA containing an appropriate amount of stannous chloride dihydrate in lyophilized form under nitrogen atmosphere. Labeling is performed by adding oxidant-free 99m TcO₄⁻ to the kit vial and mixing. The labeling yield is greater than 95%. 99m Tc-DTPA has a shelf-life of 6 h after reconstitution. The recommended storage temperature for the kit is 15–30°C before and after labeling.

Using ⁹⁹Tc in millimolar quantities, it has been shown that in ⁹⁹Tc-DTPA prepared by stannous ion reduction, the oxidation state of technetium is 4+. It is not known, however, if these data can be extrapolated to the tracer level of ^{99m}Tc in ^{99m}Tc-DTPA.

The primary use of ^{99m}Tc-DTPA is for renal flow study, glomerular filtration rate (GFR) measurement, and aerosol preparation in lung ventilation studies. It is also used in stress and rest radionuclide ventriculography. For GFR measurement, ^{99m}Tc-DTPA should be used within 1 h of preparation, because the breakdown of ^{99m}Tc-DTPA may raise the blood background and thus give an erroneous GFR. It has also been used for the study of cerebral shunt patency and cerebrospinal fluid leaks. For such use, however, ^{99m}Tc-DTPA must be tested specifically for pyrogens after reconstitution, because the cerebrospinal system is very sensitive to pyrogens.

7.1.8 99mTc-Labeled Red Blood Cells

The basic principle of labeling of red blood cells (RBCs) with ^{99m}Tc involves mixing RBCs with Sn^{2+} ions followed by the addition of ^{99m}TcO₄⁻. The Sn²⁺ ion enters into the red blood cell, and subsequently ^{99m}TcO₄⁻ ion diffuses into it, whereupon Sn²⁺ reduces Tc⁷⁺ to a lower oxidation state, nearly 80% of which then binds to the beta chain of the globin part of hemoglobin and 20% to heme. Although various chelates of Sn²⁺ have been proposed, stannous citrate, stannous gluceptate, and stannous pyrophosphate are almost exclusively used for ^{99m}Tc-labeling of RBCs. Direct addition of RBCs to a mixture of ^{99m}TcO₄⁻ and Sn²⁺ does not label RBCs.

There are three methods currently employed in the labeling of RBCs with ^{99m}Tc: the in vitro method, the in vivo method, and the modified in vivo method. Each method has its own merits and disadvantages and they are described below.

7.1.8.1 In Vitro Method

In the in vitro method, blood is drawn from the subject, and RBCs are separated by centrifugation and washing. The packed cells are incubated with appropriate amount of Sn^{2+} (usually stannous citrate) and washed to remove excess tin. The "tinned" RBCs are then incubated with an appropriate amount of $^{99\text{m}}\text{TcO}_4^-$ to yield $^{99\text{m}}\text{Tc-RBCs}$. The labeling efficiency is higher than 97%.

The commercially available kit supplied by Mallinckrodt Pharmaceuticals consists of a lyophilized mixture of stannous citrate along with acid citrate dextrose (ACD). One milliliter of heparinized blood is incubated initially for 5 min in the kit, and then a sodium hypochlorite solution is added, followed by ACD solution. Hypochlorite oxidizes excess Sn^{2+} to Sn^{4+} , and citrate removes plasma-bound tin as Sn-citrate complex. ^{99m}Tc-RBCs are obtained by adding ^{99m}TcO₄⁻ and incubating for 15 min. The labeling efficiency is better than 97%. This kit is marketed under the trade name of Ultratag RBC.

The in vitro method is useful in the gastrointestinal blood loss study, hemangioma study, gated blood pool study, and also for imaging the spleen. In the latter case, the cells are denatured by heating the labeled cells at 50°C for about 20 min and then injected into patients.

7.1.8.2 In Vivo Method

In the in vivo method, the Sn-PYP kit is reconstituted with isotonic saline, and a sufficient volume of the solution to give $10-20-\mu g/\text{kg Sn}^{2+}$ ion is injected intravenously into the patient. After 20–30 min of waiting, 20–30-mCi (0.74–1.11 GBq) ^{99m}TcO₄⁻ is injected, which tags the RBCs immediately. The tagging efficiency is somewhat lower (80–90%), partly due to extravascular distribution such as thyroid trapping, gastric secretion, and renal excretion. Certain drugs such as heparin, dextran, doxorubicin, penicillin, hydralazine, and iodinated contrast media often inhibit Sn²⁺ transport through the RBC membrane and diminish ^{99m}Tc-labeling of RBCs. In these subjects, in vitro labeling methods should be employed.

This method is commonly used in the gated blood pool study. It has the added advantage of injecting ${}^{99m}\text{Tc}O_4^-$ in a small volume as a bolus to perform the first pass radionuclide ventriculography followed by gated blood pool study (discussed in Chap. 13).

7.1.8.3 Modified In Vivo Method

The modified in vivo method is a modification of the above in vivo method (Callahan et al. 1982). A butterfly infusion set containing heparinized saline (10 units/ml of blood) is secured into the vein of the patient, while the open end is connected to a three-way stopcock. One port of the stopcock is connected to a syringe containing 20–30-mCi (740–1111 MBq) ^{99m}TcO₄⁻ and the other to a syringe containing heparinized saline. Residual heparin in the infusion line acts as anticoagulant. Twenty minutes after injection of Sn-PYP, 3 ml of blood is drawn into the ^{99m}Tc syringe and incubated for 10 min with gentle shaking. The labeled cells are then injected back into the patient followed by flushing with saline. This method gives better labeling yield (>95%) and is useful in gastrointestinal blood loss studies and gated blood pool studies.

7.1.9 ^{99m}Tc-Iminodiacetic Acid Derivatives (Hepatolite, Mebrofenin)

The first iminodiacetic acid (IDA) derivative employed in nuclear medicine was 2,6-dimethylphenylcarbamoylmethyl iminodiacetic acid or HIDA (its generic name is lidofenin). HIDA is synthesized by refluxing a mixture of equal molar quantities of ω -chloro-2,6-dimethylacetanilide and disodium iminodiacetate in ethanol: water (3:1) solvent (Loberg et al. 1976). Since the first use of HIDA for hepatobiliary imaging, several N-substituted iminodiacetic acid derivatives have been prepared, among which 2,6-diethyl (DIDA or etilfenin), paraisopropyl (PIPIDA or iprofenin), parabutyl (BIDA or butilfenin), diisopropyl (DISIDA or disofenin), and bromotrimethyl (mebrofenin) analogs have undergone considerable clinical and experimental research. The chemical structures of some derivatives and a ^{99m}Tc-IDA complex are illustrated in Fig. 7.2.

Kits for DISIDA (Hepatolite; Pharmalucence, USA) and mebrofenin (Choletec; Pharmalucence, Bracco Diagnostics) are commercially available and usually contain the IDA derivative and stannous chloride or fluoride dihydrate as the reducing agent. Labeling is accomplished by adding 99m TcO⁻₄ to the kit and mixing well. The



Fig. 7.2 Molecular structures of different IDA derivatives and their 99mTc-complexes

labeling yield is greater than 95%. The shelf-life for 99m Tc-DISIDA is given to be 6 h after reconstitution, whereas 99m Tc-mebrofenin has a shelf-life of 18 h after preparation. The storage temperature for DISIDA and mebrofenin is recommended to be 15–30°C both before and after labeling.

The ^{99m}Tc-labeled IDA derivatives are commonly used as hepatobiliary agents to evaluate hepatic function, biliary duct patency, and mainly in cholescintigraphy. Of all IDA complexes, DISIDA and mebrofenin are claimed to be the hepatobiliary agents of choice.

7.1.10 ^{99m}Tc-Hexamethylpropylene Amine Oxime (Ceretec)

Hexamethylpropylene amine oxime (HMPAO) is a lipophilic substance that forms a neutral complex with ^{99m}Tc after reduction with Sn²⁺ ion. The United States Adopted Names (USAN) use the term *exametazime* for this substance. HMPAO exists in two stereoisomers: *d*,*l*-HMPAO and meso-HMPAO. The cerebral uptake of the former isomer is much higher than that of the latter, and so the *d*,*l* form must be separated from the meso form by repeated crystallization before complexation with ^{99m}TcO₄⁻.

Commercial kits are available from GE Healthcare under the brand name Ceretec. The kit is made up of a lyophilized mixture of exametazime (pure d,l-HMPAO) and stannous chloride. Addition of ^{99m}TcO₄⁻ to the kit vial gives greater than 80% labeling yield of ^{99m}Tc-HMPAO. There are conditions on the quality of ^{99m}TcO₄⁻ to be

used. 99m TcO₄⁻ must not be older than 2 h after elution from the generator and must be eluted from a generator that has been eluted in the past 24 h.

The primary ^{99m}Tc-HMPAO complex that is formed after the addition of ^{99m}TcO₄⁻ to the kit is lipophilic and crosses the blood–brain barrier. However, it breaks down with time to a secondary complex that is less lipophilic and shows little brain uptake. As a result, ^{99m}Tc-HMPAO must be used within 30 min after preparation. Also, a strict quality control measure using thin-layer chromatography must be performed to ascertain the labeling efficiency (>80%).

The instability of ^{99m}Tc-HMPAO has been attributed to three factors: (1) high pH (9–9.8) after reconstitution, (2) the presence of radiolytic intermediates such as hydroxyl free radicals, and (3) excess stannous ions. To offset these factors, a phosphate buffer and methylene blue have been included separately in the new version of Ceretec kits. These agents are added after the normal preparation of ^{99m}Tc-HMPAO. Phosphate buffer lowers the pH around 6 at which the decomposition of ^{99m}Tc-HMPAO is minimal. Methylene blue acts as a scavenger of free radicals and oxidizes excess stannous ions. Even though decomposition still occurs to some extent at pH 6 in the presence of a phosphate buffer, the combination of both phosphate buffer and methylene blue together reduces the decomposition significantly. The shelf-life of these new kits is 4 h after reconstitution.

The molecular structure of 99m Tc-HMPAO is shown in Fig. 7.3a. X-ray crystallography of the complex shows Tc⁵⁺ to have five coordinate groups with an oxo group at the apex and four nitrogen atoms at the corners of the base of a square



Fig. 7.3 Molecular structures of ^{99m}Tc-labeled complexes. **a** Tc-HMPAO. **b** Tc-sestamibi. **c** Tc-MAG3. **d** Tc-ECD. **e** Tc-tetrofosmin

pyramid (Troutner et al. 1984). Loss of hydrogen atoms from two amine groups and one oxime group in the ligand results in a neutral complex.

The primary use of ^{99m}Tc-HMPAO is in brain perfusion imaging. Since it is lipophilic, it is used for labeling of leukocytes, substituting for ¹¹¹In-oxine. However, phosphate buffer and methylene blue are excluded in the formulation of ^{99m}Tc-HMPAO, when used for leukocyte labeling.

7.1.11 99mTc-Sestamibi (Cardiolite, Miraluma)

^{99m}Tc-sestamibi is a lipophilic cationic complex used as a myocardial perfusion imaging agent. It was initially patented and manufactured by DuPont under the brand name Cardiolite for myocardial imaging and Miraluma for breast imaging. It was later acquired by Bristol–Myers Squibb and then by Lantheus Medical Imaging under the original patent right. In 2008, the patent expired providing the scope of generic sestamibi, and now several manufacturers, namely, Jubilant DraxImage and Pharmalucence, are marketing the kits of generic sestamibi. Sestamibi is methoxyisobutylisonitrile (MIBI) with an isonitrile group that forms a complex with ^{99m}Tc after reduction with stannous ions. Initially, ^{99m}Tc-citrate is formed, which then undergoes ligand exchange with sestamibi to form ^{99m}Tc-sestamibi.

Sestamibi is supplied in a kit containing a lyophilized mixture of the chelating agent in the form of a copper (I) salt of tetrakis(2-MIBI)tetrafluoroborate, stannous chloride, sodium citrate, mannitol, and L-cysteine hydrochloride monohydrate. Labeling is carried out by adding sufficient amount of 99m TcO₄⁻ to the kit vial and heating the mixture in a boiling water bath for 10 min. The pH of the reconstituted product is 5.5. The labeling efficiency is greater than 90%. The kit is stored at 15–30°C before and after reconstitution. ^{99m}Tc-sestamibi is good for use for 6 h after formulation.

^{99m}Tc-sestamibi has the structure shown in Fig. 7.3b and has a net charge of 1+. It has a coordination number of 6 with six isonitrile ligand groups (Abrams et al. 1983).

^{99m}Tc-sestamibi is used primarily for the detection of myocardial perfusion abnormalities in patients, particularly myocardial ischemia and infarcts. It is also useful for the assessment of myocardial function using the first pass radionuclidic ventriculographic technique. ^{99m}Tc-sestamibi is also used for the detection of breast tumors (Miraluma) and hyperparathyroidism.

7.1.12 99mTc-Mercaptoacetylglycylglycylglycine (MAG3)

^{99m}Tc-mercaptoacetylglycylglycylglycine (MAG3), also known as ^{99m}Tc-mertiatide, is a peptide supplied by Mallinckrodt Pharmaceuticals under the brand name Technescan MAG3. It contains a lyophilized mixture of betiatide (*N-N-*(benzoylthio)acetylglycylglycylglycine), stannous chloride dihydrate, sodium
tartrate dihydrate, and lactose monohydrate under argon atmosphere. Labeling is carried out by adding ^{99m}TcO₄⁻ to the kit vial followed by introduction of filtered air and heating at 100°C in a water bath for 10 min followed by cooling for 15 min. Air is introduced to oxidize the excess Sn²⁺. The reactions involve initial reduction of pertechnetate by Sn²⁺ followed by the formation of ^{99m}Tc-tartrate. Subsequent heating of this complex in the presence of MAG3 ligand results in the formation of ^{99m}Tc-mertiatide (disodium (*N*-(*N*-(mercaptoacetyl)glycyl) glycyl) glycinato(2–)-*N*, *N'*, *N''*, *S'*) oxotechnetate (2–)) (^{99m}Tc-MAG3) by ligand exchange. The pH of the preparation is 5–6. The labeling efficiency should be greater than 90%. The kit is recommended for 6 h of use after reconstitution. The storage temperature is 15–30°C both before and after labeling. MAG3 is light sensitive and therefore the kits should be protected from light until use.

The structure of 99m Tc-MAG3 is shown in Fig. 7.3c. It has a core of Tc = ON₃S with a carboxylic group on the third nitrogen (Fritzberg et al. 1986). 99m Tc has a coordination number of 5, and the complex has a negative charge of 1–. 99m Tc-MAG3 is used routinely for assessment of renal function, particularly in renal transplants.

7.1.13 99mTc-Ethyl Cysteinate Dimer (Neurolite)

Ethyl cysteinate dimer (ECD), also known as bicisate, exists in two stereoisomers, l,l-ECD and d,d-ECD. Both l,l-ECD and d,d-ECD isomers diffuse into the brain by crossing the blood-brain barrier, but only l,l-ECD is metabolized by an enzymatic process to a polar species that is trapped in the human brain cell. Thus, only purified l,l-ECD is used for ^{99m}Tc-ECD formulation.

The kit for ^{99m}Tc-ECD supplied by Lantheus Medical Imaging under the brand name Neurolite contains two vials. Vial A contains a lyophilized mixture of *l*,*l*-ECD·2HCl, stannous chloride dihydrate, sodium edetate, and mannitol under nitrogen atmosphere. Vial B contains phosphate buffer, pH 7.5, under air atmosphere. To prepare ^{99m}Tc-ECD, isotonic saline is added to dissolve the contents in vial A. Labeling is carried out by adding ^{99m}TcO₄⁻ to vial B followed by the addition of an aliquot from vial A and allowing the mixture to incubate for 30 min at room temperature.

The reaction involves initial reduction of ^{99m}Tc⁷⁺ to a lower oxidation state followed by the formation of the ^{99m}Tc-EDTA complex. Subsequent incubation causes ligand exchange between ^{99m}Tc-EDTA and ECD to form ^{99m}Tc-ECD (Dewanjee 1990). The yield is consistently greater than 90% as determined by ITLC. The kits should be stored at 15–30°C before and after labeling with ^{99m}Tc. ^{99m}Tc-ECD remains stable for 6 h after formulation.

The molecular structure of 99m Tc-*l*,*l*-ECD is shown in Fig. 7.3d. It has the core structure of Tc = ON₂S₂, with a coordination number of 5. It is a neutral lipophilic complex (Edwards et al. 1990).

The clinical use of ^{99m}Tc-ECD is mainly for brain perfusion imaging.

7.1.14 ^{99m}Tc-Tetrofosmin (Myoview)

Tetrofosmin [6,9-bis(2-ethoxyethyl)-3,12-dioxa-6,9-diphospha-tetradecane], also known as exametazime, is supplied by GE Healthcare in a kit form under the brand name Myoview and is used for myocardial perfusion imaging. The kit contains tetro-fosmin, stannous chloride dihydrate, disodium sulfosalicylate, sodium d-gluconate, and sodium hydrogen carbonate.

Labeling is carried out by adding 99m TcO₄⁻ to the kit vial and incubating the mixture for 15 min at room temperature. 99m Tc-gluconate is initially formed with reduced Tc, which is obtained by stannous ion reduction, and then ligand exchange between 99m Tc-gluconate and the tetrofosmin group gives 99m Tc-tetrofosmin. The pH should be 8.3–9.1 and the labeling yield exceeds 90%. The kit is stored at room temperature before and after reconstitution, and 99m Tc-tetrofosmin is good for 8 h after formulation.

^{99m}Tc-tetrofosmin is a lipophilic cationic complex and has the structure shown in Fig. 7.3e. The chemical formula of the ^{99m}Tc-complex is [^{99m}Tc(tetrofosmin)₂O₂]⁺ with a charge of 1+. The oxidation state of Tc in the complex is 5+. The structure shows a linear trans-oxo core, with the four phosphorus atoms of the two bidentate diphosphine ligands forming a planar array (Kelly et al. 1993).

^{99m}Tc-tetrofosmin is indicated for the detection of reversible myocardial ischemia and myocardial infarction.

7.1.15 99mTc-Dimercaptosuccinic Acid (Succimer)

Dimercaptosuccinic acid (DMSA) contains about 90% mesoisomer and 10% *d*,*l*-isomer in the kit supplied by GE Healthcare under the brand name Succimer. Each kit vial contains DMSA and stannous chloride dihydrate in lyophilized form. Labeling is accomplished by adding an appropriate amount ^{99m}TcO₄⁻ to the kit vial and incubating the mixture for 10 min at room temperature. The labeling yield is greater than 95%, and the product is good for use up to 6 h after preparation. Due to the sensitivity to light, the kits should be stored in the dark at 15–30°C.

^{99m}Tc-DMSA is prepared in acidic pH, and the oxidation state of Tc is 3+ in this complex. When ^{99m}Tc-DMSA is prepared in alkaline pH, the oxidation state of Tc in the complex is 5+, and the biological behavior of the complex is different from that of the Tc³⁺-complex. The pentavalent Tc is coordinated by four thiolates of two DMSA ligands and an apical oxo group, and the complex has the formula [TcO(DMSA)₂]⁻¹.

^{99m}Tc³⁺ DMSA is used for renal cortical imaging, whereas ^{99m}Tc⁵⁺ DMSA is used for the detection of medullary thyroid cancer.

7.1.16 ^{99m}Tc-Technegas

^{99m}Tc-Technegas is a radiolabeled aerosol produced in a commercially available Technegas generator, which is supplied by Cyclomedica, Australia. Its on-site preparation involves initial evaporation of 5-mCi (185 MBq) ^{99m}Tc-eluate in 0.1–0.3-ml saline to dryness in a graphite crucible at 1500°C (this stage is called the "simmer"), followed by heating at 2500°C in an atmosphere of argon (this stage is called the "burn" stage). The particle size varies from 5 to 150 nm.

One theory suggests that 99m Tc-Technegas is composed of 99m Tc atoms attached to C₆₀ molecules. Another theory suggests that salt aerosols are initially produced by the vaporization of salt in the simmer stage. At the burn stage, some graphite vaporizes, which condenses on the salt aerosols acting as a nucleation center.

^{99m}Tc-Technegas aerosol is used for the ventilation scintigraphy of the lungs. This product is not approved by the US FDA, whereas it is commercially available in Europe and Australia.

7.2 Radioiodinated Radiopharmaceuticals

7.2.1 ¹³¹I-Sodium lodide

Iodine-131 ($t_{1/2} = 8$ d) is separated in the form of sodium iodide (NaI) from the products of uranium fission or neutron irradiation of tellurium. It is available in NCA state, and, according to the *USP* 39, other chemical forms of activities should not exceed 5% of the total radioactivity. It is supplied in either a capsule or a liquid form for oral administration. Capsules are prepared by evaporating an alcoholic solution of NCA ¹³¹I-sodium iodide on the inner wall of a gelatin capsule. The activity remains firmly fixed, and capsules are convenient and safe to administer in both diagnostic and therapeutic dosages. ¹³¹I-NaI solutions or capsules are available from Jubilant DraxImage and Mallinckrodt Pharmaceuticals.

The ¹³¹I-NaI solution is clear and colorless and is made isotonic with physiologic saline. Air and radiolytic free radicals (e.g., HO_2^{\bullet}) oxidize I⁻ to volatile I₂, which is potentially hazardous. Air oxidation is minimized by adding sodium ascorbate or thiosulfate to the solution at alkaline pH, which is maintained between 7.5 and 9.0. Radiations (β -rays) may cause both the solution and the glass container to darken. The shelf-life of the ¹³¹I-NaI preparation is 4 weeks after calibration.

This agent is used mostly for the measurement of thyroid uptake and imaging after oral administration. Whether a capsule or a solution for oral administration is used is a matter of choice by the physician, although capsules are safer from radiation safety point. Another important use of ¹³¹I-NaI is in the treatment of thyroid diseases such as thyroid carcinoma and hyperthyroidism.

7.2.2 ¹²³I-Sodium lodide

Iodine-123 ($t_{1/2}$ = 13.2 h) is available in the form of NaI after separation from other radionuclides produced in the cyclotron. The commercial suppliers are Mallinckrodt Pharmaceuticals and Cardinal Health. It is supplied in capsule or solution for oral administration. The pH of the solution is maintained between 7.5 and 9.0. According to the *USP* 39, other chemical forms of radioactivity should not exceed 5% of the total radioactivity.

As mentioned in Chap. 4, ¹²³I may be contaminated with ¹²⁴I ($t_{1/2} = 4.2$ d) and ¹²⁵I ($t_{1/2} = 60$ d) depending on the types of target and irradiating particles used in the cyclotron. Iodine-124 is the most likely contaminant when the enriched ¹²⁴Te target is bombarded with protons resulting in the ¹²⁴Te(p, n)¹²⁴I reaction. At calibration time, the total amount of radiocontaminants is less than 6% of the ¹²³I activity. A 6% ¹²⁴I contamination at calibration time results in 18.3% contamination after 24 h of decay. Since ¹²⁴I emits high-energy photons that degrade scintigraphic image resolution, the ¹²³I capsule or solution should be used soon after receipt.

Iodine-125 is the primary contaminant in ¹²³I produced by the ¹²⁷I(p, 5n) ¹²³I reaction. At calibration, its concentration does not exceed 3% of the total activity, but increases with time. However, ¹²⁵I does not pose a serious problem in scintigraphic imaging because of its low-energy photons, except for a higher radiation dose to the patient. When ¹²³I is produced by using the ¹²⁴Xe gas target, there is no ¹²⁴I contamination.

 123 I-NaI is used most commonly for the measurement of thyroid uptake and imaging and is much better than 131 I-NaI because 123 I has a photon energy of 159 keV and a half-life of 13.2 h and does not emit any β^- -radiations. The shelf-life of 123 I-NaI capsule or solution is 30 h after calibration.

7.2.3 ¹²⁵I-Albumin

Although albumin can be labeled with any radioisotope of iodine, ¹²⁵I-radioiodinated serum albumin (RISA) is commonly used in clinical medicine. It is prepared by iodinating human serum albumin using the chloramine-T method at 10°C in an alkaline medium. It can also be iodinated by the iodogen method. Free iodide is removed by anion-exchange resin, and membrane filtration is employed to sterilize the product. Commercial preparations contain 0.9% benzyl alcohol as a preservative. The solution should be stored at 2–8°C to minimize degradation. The shelf-life after calibration is 60 days for ¹²⁵I-RISA. For dilution of RISA, one should use sterile isotonic saline containing a small quantity of human serum albumin. The latter is added to minimize adsorption of RISA on the walls of the container. Iso-Tex Diagnostics supplies RISA in multidosage vials or single-dosage syringes.

¹²⁵I-RISA appears as a clear, colorless to slightly yellow solution. Radiation may cause both the albumin solution and the container to darken with time. According to the *USP* 39, the pH of the solution should be between 7.0 and 8.5, and other forms of activity, including iodide and iodate, should not exceed 3% of the total radioactivity.

Blood volume and cardiac output are measured with ¹²⁵I-RISA.

7.2.4 ¹²³I-loflupane (DaTscan)

¹²³I-ioflupane (brand name DaTscan) is a cocaine analog and has the formula ¹²³I-N- ω -fluoropropyl-2β-carbomethoxy-3β-(4-iodophenyl)nortropane or (¹²I)-FP-CIT. Iodination of ioflupane is carried out by destannylation of stannalyted precursor Sn-FP-CIT with ¹²³I-sodium iodide in the presence of an oxidizing agent. The tributylstannyl precursor is prepared from cold FP-CIT in a palladiumcatalyzed reaction with bis(tributyl)distannane (Pimlott and Sutherland 2011).

Like other cocaine analogs, ¹²³I-ioflupane has avid affinity for dopamine transporters (DaT) present in the presynaptic nerve endings in the striatum of the brain and has been used for the detection of Parkinson's disease. It has been approved by the US FDA for this indication and is supplied by GE Healthcare.

7.2.5 ¹²³I- or ¹³¹I-Metaiodobenzylguanidine (AdreView)

The compound metaiodobenzylguanidine (MIBG) is labeled with ¹²³I or ¹³¹I by the isotope exchange method. A mixture of ¹³¹I-NaI and MIBG is refluxed for 72 h, cooled, and then passed through an anion-exchange column to remove unreacted iodide. ¹³¹I-MIBG is commercially available from AnazaoHealth, USA. Its recommended storage temperature is -200° C to -10° C, and the expiration time is 8 days after calibration.

¹²³I-MIBG, also known as ¹³¹I-iobenguane sulfate, is prepared by adding ¹²³I-NaI to a solution of *N*-chlorosuccinimide in trichloroacetic acid followed by the addition of 3-trimethyl-silylbenzylguanidine in trichloroacetic acid. GE Healthcare supplies this under the trade name AdreView.

Radioiodinated MIBG primarily localizes in the medulla of the adrenal gland. Its primary use is in the detection of pheochromocytoma. ¹²³I-MIBG is used to localize the myocardial regions depleted of catecholamine stores due to infarction. ¹³¹I-MIBG has also been used in the treatment of neuroblastoma.

7.2.6 ¹²⁵I-Sodium lothalamate (Glofil)

Sodium iothalamate (Glofil) is labeled with ¹²⁵I ($t_{1/2} = 60$ d) by the ion-exchange method in acidic medium and is available from Iso-Tex Diagnostics, Inc., USA. It is supplied in a concentration of approximately 1 mg/ml sodium iothalamate with a radioactivity concentration of 250–300 μ Ci/ml (9.25–11.1 MBq). It contains 0.9% benzyl alcohol as preservative. Its expiration period is 35–40 days, and it is stored at 2–8°C. It is used for the measurement of glomerular filtration rate (GFR) in humans and animals.

7.3 Miscellaneous Radiopharmaceuticals of Clinical Interest

7.3.1 ¹¹¹In-DTPA

¹¹¹In-DTPA is prepared by adding a dilute DTPA solution to a solution of ¹¹¹InCl₃ ($t_{1/2} = 2.8 \text{ d}$) in acetate buffer, pH 5, and then heating for 15 min at 100°C in a boiling

water bath. This product is supplied by GE Healthcare. This compound is primarily used for cisternography.

7.3.2 ¹³³Xe Gas

Xenon-133 ($t_{1/2} = 5.3$ d) is a noble gas and is chemically inert. Xenon-133 is produced by the fission of ²³⁵U in the reactor. After separation and purification, the ¹³³Xe radionuclide is supplied in gaseous form in vials with diluents such as CO₂, air, or carrier xenon gas. The storage temperature for the gas is 15–30°C, and the shelf-life of ¹³³Xe is 14 days after calibration. Caution should be exercised in handling radioxenon because of the potential radiation exposure, and preferably it should be handled in the fumehood. Nuclear medicine studies using ¹³³Xe should be performed in rooms that are at negative pressure relative to the surrounding areas. It is supplied by Mallinckrodt Pharmaceuticals and Lantheus Medical Imaging.

Xenon-133 is indicated primarily for ventilation studies of the lungs and also for the assessment of cerebral blood flow.

7.3.3 ²⁰¹TI-Thallous Chloride

Thallium-201 ($t_{1/2}$ = 73 h) is produced in the cyclotron and is supplied in the form of NCA thallous chloride in isotonic saline solution at pH 4.5–7.0 for intravenous administration. Mallinckrodt Pharmaceuticals, Lantheus Medical Imaging, and GE Healthcare are the primary vendors of ²⁰¹Tl. It contains sodium chloride for isotonicity and 0.9% benzyl alcohol as a bactericidal agent. At the time of calibration, the preparation contains no more than 1% ²⁰⁰Tl, no more than 1% ²⁰²Tl, no more than 0.25% ²⁰³Pb, and no less than 98% ²⁰¹Tl of total activity.

The shelf-life of ²⁰¹Tl is suggested as 5–6 days after calibration, depending on the manufacturer. This radionuclide should be stored at room temperature.

It is used for myocardial perfusion imaging in order to delineate between ischemic and infarcted myocardium. It is also indicated for the detection of hyperparathyroidism and brain tumors.

7.3.4 ⁶⁷Ga-Citrate

The ⁶⁷Ga-citrate complex is formed by adding a sufficient amount of sodium citrate to a ⁶⁷Ga chloride ($t_{1/2} = 78.2$ h) solution and raising the pH to 5–8 with sodium hydroxide. At higher pH, gallium hydroxide and gallate form at the loss of citrate. The preparation is stabilized with 0.9% benzyl alcohol. It should be stored at room temperature and used within 7 days after calibration. It is available from Mallinckrodt Pharmaceuticals and Lantheus Medical Imaging.

Gallium-67-citrate is used primarily for detecting malignant diseases such as Hodgkin's disease, lymphomas, and bronchogenic carcinoma. It is also used for localizing acute inflammatory diseases and infections.

7.3.5 ³²P-Sodium Orthophosphate

Phosphorus-32 ($t_{1/2} = 14.3$ d) is supplied as a solution of ³²P-disodium phosphate suitable for oral or intravenous administration. This is a clear and colorless solution with a pH of 5–6. It contains a 0.9% NaCl solution for isotonicity and a sodium acetate buffer. The primary use of ³²P includes the therapeutic treatment of polycy-themia vera, leukemia, and other neoplastic hematologic disorders. Sometimes, it is used as a diagnostic agent for certain ocular tumors.

7.3.6 ⁸⁹Sr-Strontium Chloride (Metastron)

Strontium-89 ($t_{1/2}$ = 50.6 d) is a reactor-produced radionuclide and supplied in the form of ⁸⁹SrCl₂ containing 4 mCi (148 MBq) in a vial or a syringe. Its pH is 4–7.5. It is supplied by GE Healthcare under the brand name Metastron. The product is stored at 15–25°C and should be used within 28 days after calibration. Since it is a β -particle emitter, it is contained in plastic syringes or vials.

Strontium-89 is indicated for the relief of pain in patients with skeletal metastases, which must be confirmed prior to therapy.

7.3.7 ¹⁵³Sm-Ethylenediaminetetramethylene Phosphonic Acid (Quadramet)

Samarium-153 ($t_{1/2} = 1.9$ d) is supplied in the form of the ¹⁵³Sm-EDTMP complex under the trade name Quadramet, and its USAN name is ¹⁵³Sm-lexidronam. As mentioned in Chap. 4, ¹⁵³Sm is produced in the reactor by ¹⁵²Sm (n, γ) ¹⁵³Sm reaction. ¹⁵³Sm-EDTMP is prepared by simply dissolving the target in an alkaline solution of EDTMP at pH 7–8.5 and heating the mixture at 75–80°C for 45–60 min (IAEA 2003). The final activity is adjusted to 30–35 mCi (1.1–1.3 GBq)/ml with water, and its radiochemical purity is 95%. The pH of the final product is 7.0–8.5 and the radiochemical purity is >99%. ¹⁵³Sm-EDTMP is stored at room temperature and retains its stability for >7 d.

It is marketed by Lantheus Medical Imaging in the USA and by CIS Bio International, a subsidiary of IBA Molecular (Curium), outside the USA. Because of its β -particle emission, it is used for the palliation of pain from metastatic bone cancer. Also, its 103-keV (28%) photons allow scintigraphic imaging of the whole body.

7.3.8 ⁵⁷Co- or ⁵⁸Co-Cyanocobalamin

Radiolabeled cyanocobalamin, or vitamin B_{12} , is prepared by biosynthesis: the organism *Streptomyces griseus* is grown in a medium containing ⁵⁷Co ($t_{1/2} = 271$ d) or ⁵⁸Co ($t_{1/2} = 71$ d), and the labeled cobalamins are then separated. The compound is supplied in a capsule for oral administration or in a solution for intravenous injection and is available from Covidien. The final pH of the solution should be 4–5. This compound is sensitive to light, heat, and high pH, and therefore it is stored at 5°C in the dark. Its shelf-life is 6 months. The absorption of vitamin B_{12} in anemic patients and in other vitamin B_{12} malabsorption syndromes is studied with labeled cyanocobalamins with and without intrinsic factor.

7.3.9 ⁵¹Cr-Labeled Red Blood Cells

To label red blood cells efficiently with ⁵¹Cr ($t_{1/2} = 27.7$ d), 50–100-µCi (1.85– 3.7 MBq) ⁵¹Cr-sodium chromate is added to 20–30 ml of human blood containing ACD solution, and the mixture is incubated in a water bath at 37°C for 20 min with occasional shaking. It is then cooled for 10 min at room temperature, and ascorbic acid is added to reduce untagged Cr⁶⁺ to Cr³⁺ and to stop the reaction. The reason for this is that two Cr⁶⁺ ions bind to the globin part of hemoglobin, whereas Cr³⁺ does not label RBCs. The cells are washed and finally suspended in saline for injection. The labeling yield is almost 80–90%. When ⁵¹Cr-labeled RBCs are used for the measurement of red cell survival, the labeling mixture is injected without washing off Cr³⁺. Cr³⁺ is excreted in the urine in several hours.

The ⁵¹Cr-labeled RBCs are commonly used for the measurement of red cell mass and its survival. These labeled cells can also be used for imaging the spleen.

7.3.10 Radiolabeled Leukocytes and Platelets

7.3.10.1 Leukocyte Separation

Leukocytes are separated from whole blood by sedimentation, centrifugation, and washing with isotonic saline. Heparin or ACD is added as anticoagulant. Hetastarch is added to enhance the sedimentation of RBCs. Leukocytes are then separated by centrifugation at 200 g and washed with isotonic saline. Leukocytes obtained by this technique are partially contaminated with RBCs and platelets, but such a level of contamination does not compromise significantly the labeling efficiency of leukocytes. Labeling is preferred in saline solution rather than in plasma, since ¹¹¹In binds to transferrin in the latter more avidly than to leukocytes.

7.3.10.2 Platelet Separation

Platelets are isolated by initial separation of platelet-rich plasma (PRP) after centrifugation of whole blood at 200 g to remove RBCs and leukocytes, followed

by centrifugation of the PRP at 1500 g. ACD is added at a blood-to-ACD ratio of 6:1 to keep a slightly acidic pH of 6.5 to prevent platelet aggregation. Platelet labeling is preferable in plasma (mixed with ACD) suspension, rather than in saline, to preserve the platelet function, although the labeling yield is somewhat compromised.

7.3.10.3 ¹¹¹In-Labeling

¹¹¹In-Oxine

¹¹¹In-oxine is used for labeling leukocytes and platelets. ¹¹¹In-oxine can be prepared by mixing ¹¹¹InCl₃ in acetate buffer, pH 5.0, with 8-hydroxyquinoline (oxine) in ethanol. The ¹¹¹In-oxine complex is extracted into chloroform or methylene chloride, which is then evaporated to dryness. The residue of ¹¹¹In-oxine is taken up into ethanol for use in labeling (Thakur et al. 1977).

GE Healthcare supplies ¹¹¹In-oxine in aqueous solution at pH 6.5–7.5, containing polysorbate 80 as the stabilizer. The radionuclide impurity is ^{114m}In, which should not exceed more than 0.25% of the total activity at expiration time of ¹¹¹In. ¹¹¹In-oxine tends to adhere to the plastic syringe and therefore should be drawn from the vial only immediately before labeling. It is stored at 15–30°C.

¹¹¹In-Labeling of Leukocytes and Platelets

The schematic diagrams showing sequential steps in ¹¹¹In-labeling are shown in Fig. 7.4 for leukocytes and Fig. 7.5 for platelets. It should be noted that leukocytes are labeled in saline suspension, while plasma mixed with ACD is used as the medium for



Fig. 7.4 Schematic method of ¹¹¹In-labeling of leukocytes (WBCs)



Fig. 7.5 Schematic method of ¹¹¹In-labeling of platelets

platelet suspension. The commercial preparation of ¹¹¹In-oxine in aqueous solution is preferable to ethanol solution because ethanol tends to damage the cells.

Both leukocytes and platelets may be damaged to varying degrees by the labeling technique, particularly by the carrier oxine, and thus lose proper functional activity. This may result in clumping of cells, which should be checked visually. Also, separated cells are mixed cells, for example, leukocytes mixed with RBCs and platelets and platelets mixed with RBCs and leukocytes. This leads to undesirable in vivo biodistribution of labeled cells. Chemotaxis of granulocytes deteriorates during storage, and this can lead to false-negative scans. For this reason, it is recommended that labeled leukocytes should be reinjected within 5 h after initial blood drawing or within 3 h after labeling.

Lymphocytes are very sensitive to radiations and exhibit chromosome aberrations consisting of gaps and breaks induced by radiations. At 150 μ Ci (5.55 MBq) per 100 million lymphocytes, 93% of cells are reported to become abnormal (ten Berge et al. 1983).

The labeling yield varies with the number of leukocytes or platelets and usually increases with the number of cells. The yield ranges between 75 and 90% for an average 100 million leukocytes, although it is somewhat lower for platelets. Metal ions such as Cu, Zn, Fe, Al, and Cd interfere with ¹¹¹In-labeling and should be avoided.

In vitro experiments elucidate the mechanism of ¹¹¹In-labeling that indium oxine is a neutral lipophilic complex that crosses the cell membrane into the cell. Since indium oxine is a relatively weak chelate, ¹¹¹In is transchelated to macromolecular proteins in cytoplasm due to higher binding affinity and remains there for a long period of time. The released oxine diffuses out of the cell. The primary use of ¹¹¹In-leukocytes is for the detection of inflammatory diseases, abscesses, or other infections. ¹¹¹In-platelets are used for detecting actively forming deep vein thrombi.

7.3.10.4 99mTc-Labeling of Leukocytes and Platelets

As mentioned previously, ^{99m}Tc-HMPAO is a neutral lipophilic complex and thus, like ¹¹¹In-oxine, can serve as a labeling agent for leukocytes. Normally, separated leukocytes are suspended in plasma/ACD mixture, and then ^{99m}Tc-HMPAO (freshly formulated) is added to the cell (Peters et al. 1986). The cells are incubated for 15 min at room temperature, then washed with plasma, and finally suspended in plasma for injection. The labeling yield is of the order of 50–60%. The cellular integrity appears to remain normal.

Several studies have shown that granulocytes can be labeled in vivo by first labeling antigranulocyte antibodies with ^{99m}Tc in vitro, and then injecting the labeled antibodies into the subject ^{99m}Tc-labeling of platelets has not yet been appreciated significantly, although some studies similar to those of leukocyte labeling have been made.

^{99m}Tc-leukocytes are used for the detection of inflammation, abscess, or other infections.

7.3.11 Radiolabeled Monoclonal Antibodies

Antibodies are immunoglobulins (Ig) produced in vivo in response to the administration of an antigen to animals and humans and bind specifically to that antigen, forming an antigen–antibody complex. Antibodies are produced by the differentiation of B lymphocytes. An antigen molecule may comprise many determinants that can produce a variety of antibodies upon antigenic challenge in animals or humans. Such antibodies are called polyclonal antibodies because they are heterogeneous and nonspecific in nature.

The structure of a typical antibody molecule is illustrated in Fig. 7.6. It is a Y-shaped molecule composed of two identical heavy and two identical light polypeptide chains that are covalently linked by disulfide bonds. The light chain has one variable region (V_L) and one constant region (C_L), whereas the heavy chain has one variable region (V_H) and three constant regions (C_{H1} , C_{H2} , C_{H3}). The combined region of V_L , C_L , V_H , and C_{H1} is called the Fab portion of the molecule. The C_{H2} and C_{H3} regions are collectively called the Fc portion. The variable regions of the molecule are responsible for binding to the antigen, whereas the Fc region binds to Fc receptors of phagocytic cells, activates the complement cascade, and metabolizes the Ig molecules.

By digestion of the antibody molecule with the proteolytic enzyme papain, two Fab' fragments and one Fc fragment are obtained, whereas digestion of antibody with pepsin results in the production of one $F(ab')_2$ fragment and one Fc fragment (Fig. 7.6).



Fig. 7.6 Molecular structure of antibody and fragments of antibody obtained after enzymatic digestion with papain and pepsin

7.3.11.1 Production of Monoclonal Antibody

The polyclonal antibodies labeled with ¹³¹I and ¹²⁵I were used originally to detect tumors, and success was limited because of the heterogeneity and nonspecific binding of the antibodies. Köhler and Milstein (1975) introduced the hybridoma technology to produce monoclonal antibodies (Mabs), which are homogeneous and highly specific for a particular antigen. A comprehensive review on monoclonal antibodies has been reported by Zuckier et al. (1990).

A basic scheme for the production of Mabs is illustrated in Fig. 7.7. The hybridoma technology involves the initial immunization of a mouse with a particular antigen. The spleen cells from the immunized mouse are then mixed with myeloma cells in the presence of polyethylene glycol (PEG) whereby some immune cells (B lymphocytes) fuse to the myeloma cells forming hybrid cells. The cell mixture is suspended in HAT (hypoxanthine–aminopterin–thymidine) selective media in which unfused B lymphocytes will die and unfused myeloma cells are killed. The hybrid cells are then cloned further and ultimately screened for hybrids, producing Mabs that react with the antigen used for immunizing the mouse. The hybridoma cells can be grown in tissue culture media or by administering the cells to mice intraperitoneally and obtaining their ascites fluid. Large quantities of Mabs are produced by the hybrid cells in the culture medium, hollow fiber matrix, and ascites fluid and are separated by chromatography.



Fig. 7.7 A basic scheme for the production of hybrid cells that are used to make monoclonal antibodies

An important advantage of the hybridoma technology is that the hybridoma cells can be safely stored by freezing and the production of antibody can be renewed as needed by growing the cells in tissue culture media or injecting them into mice.

There are several problems associated with the hybridoma technology that need attention in the production of Mabs. The efficiency of fusion between the immune cell and the myeloma cell is very low, and even in successful fusions, only 1 in 20,000 fused cells is ultimately converted into a viable hybridoma to produce specific Mab. This is largely due to weak antigens or small quantities of antigens used in the immunization process. This problem can be overcome by selective association and fusion of cells to produce highly specific Mabs.

A major difficulty exists in making human Mabs that are desirable for parenteral administration to patients. The use of murine Mabs in humans elicits human antimurine antibody (HAMA) response depending on the administered dosages and immune status of the patient and must be monitored carefully. The difficulty in making human Mabs also lies in the lack of appropriate fusion partner (myeloma cell) and in the problem of obtaining sensitized B lymphocytes. Fusion partners, called heteromyelomas, have been constructed by fusing human and mouse myeloma cells, giving only limited success in producing human hybridoma. It is generally impossible to immunize humans with an antigen of interest to produce immune B lymphocytes. However, in some instances, peripheral B lymphocytes from immunized patients have been used for generating hybridomas.

Recombinant DNA techniques have been developed in which the variable region (V) of the mouse monoclonal antibody is coupled to the constant region (C) of human monoclonal antibody, resulting in a chimeric molecule. These restructured molecules are then transfected into mouse myeloma cell lines that produce

antibodies that are less immunogenic in humans than murine antibodies. This method is used particularly for antibodies to be used for treatment in high dosages and repeated administrations.

7.3.11.2 Radiolabeling of Monoclonal Antibody

Radiolabeling of Mabs can be accomplished with several radionuclides, among which ¹³¹I, ¹²³I, ¹²⁵I, ¹¹¹In, and ^{99m}Tc are most commonly used in nuclear medicine. An excellent review on radiolabeling of antibodies has been reported by Hnatowich (1990). Following is a brief description of the techniques of labeling with iodine isotopes, ¹¹¹In and ^{99m}Tc.

Radioiodination of Antibody

Approximately 100–500 μ g of antibody is dissolved in 50–100 μ l phosphate buffered saline (PBS), pH 7, in a tube coated with iodogen (see Radioiodination in Chap. 6). An appropriate amount of iodine isotope [1–5-mCi (37–185 MBq)¹³¹I-NaI] in 50- μ l solution is added to the reaction tube. After 12–15 min of incubation at room temperature, the mixture is transferred to a separate tube. The iodinated antibody is separated from unreacted iodide by either dialysis against saline overnight at 2°C or by gel chromatography using a Sephadex G-25 gel. The yield is 60–80%. Other methods of iodination described previously can be adopted, although the labeling yield may vary and the protein may lose immunoreactivity.

¹¹¹In-Labeling of Antibody

Mabs are labeled with ¹¹¹In using bifunctional chelating agents (BFC) such as DTPA, GYK-DTPA, SCN-Bz-DTPA, and DOTA. Initially, the chelating agent is conjugated to the antibody, and then ¹¹¹In binds to the conjugated Mab via coordinate bonds with the chelating agent.

A typical ¹¹¹In-labeling method for Mab using DTPA anhydride as the chelator is briefly described here. The DTPA cyclic anhydride is dissolved in chloroform, and the solution is evaporated in a reaction tube with N_2 . Mab is then added so that the molar ratio of Mab to DTPA is 1:1. The antibody is dissolved in bicarbonate buffer, pH 8.2, in the tube. After incubation for 30 min at room temperature, the free DTPA is removed by either dialysis or gel chromatography. The resulting conjugated Mab is labeled by adding ¹¹¹InCl₃ in acetate buffer, pH 5.5, or in citrate buffer, pH 5.0. In many cases, incubation for 30 min at room temperature suffices for quantitative labeling, obviating the need for further purification by dialysis or gel chromatography.

Increasing the number of DTPA molecules coupled to the antibody molecule diminishes the immunoreactivity of Mab, and usually not more than one chelating molecule per Mab molecule is essential for optimal labeling. DTPA is linked to the antibody via amide bonds between an amino group of the lysine residue of the antibody and one carboxylate group of DTPA. In this instance, four carboxylate groups are available for chelation with ¹¹¹In. However, in the case of SCN-Bz-DTPA, the chelator is linked to the antibody via a thiourea bond formed between the isothiocyanate group and an amino group of the lysine residue. This leaves all its five

carboxylate groups available for chelation with ¹¹¹In for improved stability of the complex (Hnatowich 1990).

Antibodies labeled with ¹¹¹In via the macrocyclic chelator, DOTA, have shown high stability in vivo without any transchelation to other serum proteins. But all chelating agents have shown increased liver uptake, which is the major drawback with ¹¹¹In-labeled Mabs.

¹¹¹In-Capromab Pendetide (ProstaScint)

The single-dosage kit, ProstaScint, supplied by Jazz Pharmaceuticals, contains Mab 7E11.C5.3, a murine monoclonal antibody produced against prostate carcinoma and prostate hypertrophy. In the kit, the antibody is chelated to GYK-DTPA and lyophilized to give capromab pendetide. Labeling with ¹¹¹In is carried out by adding ¹¹¹InCl₃ to the vial and incubating for 30 min at room temperature. The mixture is then filtered through a 0.22- μ m Millex-GV filter to remove any particulate matter. The labeling yield should be more than 90%. ¹¹¹In-capromab pendetide should be stored at room temperature and dispensed within 8 h of labeling.

¹¹¹In-capromab pendetide is used for detecting primary and metastatic prostate cancer.

7.3.11.3 99mTc-Labeling of Antibody

There are three methods of ^{99m}Tc-labeling of antibodies or their fragments: (1) direct method; (2) indirect method by first preparing a preformed ^{99m}Tc-chelate, which is then attached to the antibody; and (3) the indirect labeling using a bifunctional chelating (BFC) agent that is attached to the antibody on one side and ^{99m}Tc to the other (Eckelman et al. 1996).

Direct Method

In the direct method, also called the pretinning method, the antibody and a solution of stannous chloride, potassium phthalate, and sodium potassium tartrate are incubated for 21 h at room temperature. The pretinned antibody can be stored frozen at -20° C for future use. To radiolabel the antibody, 99m TcO₄⁻ is added to the pretinned kit and incubated for 1 h at room temperature. 99m Tc remains firmly bound to immunoglobulin G (IgG) as confirmed by high-performance liquid chromatography (HPLC) following transchelation challenge with various agents.

In the pretinning process, sulfhydryl groups are freed by the reduction of disulfide bonds of the antibody by stannous ions. The use of high concentration of stannous ions often leads to the formation of 99m Tc-labeled Fab' and F(ab')₂ fragments due to the breakdown of the disulfide bonds in the region between C_{H1} and C_{H2} segments of the heavy chain (Hnatowich 1990). In this method, chromatographic separation of the 99m Tc-labeled antibody or fragment from free or reduced 99m Tc is essential to achieve maximum purity.

To prevent the breakdown of the antibody into smaller fragments, milder agents such as 2-mercaptoethanol and dithiothreitol have been used in place of stannous ions. In these cases, postlabeling purification may be avoided if proper conditions are applied to achieve maximum labeling.

Indirect Method Using Preformed 99mTc-Chelate

In this technique, initially a ^{99m}Tc-chelate is formed using a BFC such as diamidodithio or a cyclam derivative, and then the complex is allowed to react with the antibody to obtain the ^{99m}Tc-labeled antibody. The disadvantage of this method is that it requires several steps rather than one or two simple steps and the labeling yield is poor. For these reasons, this method is not widely favored.

Indirect Labeling Using Bifunctional Chelating Agent

In this approach, a BFC is conjugated to the antibody on one side of the BFC and a radiometal ion by chelation on the other side. In practice, the antibody is first reacted with the BFC to form a BFC–antibody complex that is then separated from the reaction mixture. ^{99m}Tc-labeling is carried out by adding ^{99m}TcO₄⁻ to the BFC– antibody complex in the presence of a reducing agent (e.g., Sn²⁺ ions) or by ligand exchange using a weak ^{99m}Tc-chelate such as ^{99m}Tc-gluceptate, ^{99m}Tc-tartrate, or ^{99m}Tc-citrate.

A number of BFCs have been utilized to label antibodies with 99m Tc, and of these, cyclic anhydride of DTPA is the most common one. Other chelating agents include metallothionein, dithiosemicarbazone, and diamine dimercaptide (N₂S₂), the latter being the very popular. However, nonspecific binding with the antibody leads to the in vivo breakdown of the 99m Tc-complex and thus reduces the clinical utility of the 99m Tc-labeled antibody.

Some newer BFCs have been introduced for use in ^{99m}Tc-labeling of different antibodies, antibody fragments, peptides, and other small molecules useful for imaging. Among them, 6-hydrazinopyridine-3-carboxylic acid or hydrazinonicotin-amide (HYNIC) has been very useful for this purpose. The active ester of HYNIC is used to derivatize the amino groups of lysine residues in proteins or peptides. Incubation of these conjugates with simple Tc⁵⁺ oxo core such as in ^{99m}Tc-gluceptate(GH) yields quantitative labeling of proteins or peptides.

In this method, an excess of freshly prepared HYNIC solution (3 to 4:1 molar ratio) is added dropwise to a stirred solution of a protein or peptide in phosphate buffer at slightly alkaline pH (~pH 7.8). After continuous stirring for 5 h in the dark at room temperature, the solution is dialyzed against citrate buffer. After dialysis, the solution is filtered to give HYNIC-conjugated protein or peptide. Approximately, three HYNIC molecules are present per protein or peptide molecule.

 99m Tc-labeling is accomplished by adding an appropriate amount of freshly prepared 99m Tc-GH that has the Tc⁵⁺ oxo group and incubating the mixture for 60 min at room temperature. The reaction involves ligand exchange. The labeling yield is more than 90%, as determined by ITLC-SG method using 0.1 M sodium citrate as the solvent (described in Chap. 8). The plasma incubation shows that the labeled product is stable.

Since HYNIC can occupy only two sites of the technetium coordination sphere, there may be other sites for binding additional ligands. Based on this hypothesis, investigators have used the so-called co-ligands for adding more stability to the ^{99m}Tc-labeled HYNIC conjugate of protein or peptide. Many

co-ligands, namely, tricine, ethylenediaminediacetic acid (EDTA), tricine plus trisodium triphenylphosphinetrisulfonate (TPPTS), tricine plus nicotinic acid (NIC), and tricine plus isonicotinic acid (ISONIC), have been evaluated to enhance the labeling yield; however, tricine has been the co-ligand of choice in many cases. The addition of a co-ligand in ^{99m}Tc-labeling enhances the elimination of the labeled product from the blood and thus improves the target-to-non-target activity ratio in organ imaging.

In co-ligand labeling, tricine in water is added to the HYNIC conjugate in ammonium acetate buffer at pH 5.2. The 99m TcO₄⁻ solution with appropriate activity is then added to the mixture, followed by the addition of the SnCl₂ solution in HCl. The mixture is incubated for 30–60 min at room temperature, and finally the labeled product is purified by dialysis or P4 column chromatography. The yield is almost 90% with added stability of the labeled product.

Radiolabeled antibodies are used for detecting a variety of pathophysiological conditions depending on the type and characteristics of the antibody. Many antibodies have been developed against various cancer antigens and used for their detection by the radiolabeling technique. The use of radioiodinated antibodies is limited, because ¹³¹I gives higher radiation dose to the patients, ¹²³I is expensive, and in vivo dehalogenation causes a high blood background. ¹¹¹In-labeled antibodies are useful for tumor imaging in that the half-life is reasonably long enough to localize in the tumor and the photon energy (171 keV and 245 keV) is optimally acceptable for imaging. However, the amount to be administered is limited due to higher radiation dose to the patient. In clinical situations, the half-life of ^{99m}Tc is somewhat short to allow for sufficient localization of ^{99m}Tc-labeled antibodies in tumors, although using higher activity, tumors have been successfully detected.

7.3.11.4 99mTc-Sulesomab (LeukoScan)

This single-dosage kit is manufactured by Immunomedics, Inc., New Jersey, under the brand name LeukoScan. It is approved for human use in Europe and other countries, but not in the USA. The kit vial contains the Fab' fragment, called sulesomab, obtained from the murine monoclonal antigranulocyte antibody, IMMU-MN3, along with Sn²⁺ ions plus potassium sodium tartrate, sodium acetate, sodium chloride, glacial acetic acid, and sucrose. The contents are lyophilized under nitrogen atmosphere. Reconstitution of the kit is carried out by adding 0.5 ml of saline to dissolve the lyophilized product, followed by the addition of approximately 30-mCi (1110 MBq) ^{99m}TeO₄⁻ in 1-ml volume. The reaction is allowed for 10 min and the labeling yield should be more than 90%. The kit should be stored at 2–8°C before and after reconstitution and should be used within 4 h of formulation.

^{99m}Tc-sulesomab targets the granulocytes and therefore is primarily used to detect infection and inflammation. Although repeated administration of LeukoScan can cause HAMA in vivo, no case has been reported to have HAMA from a single injection.

7.3.12 Radiolabeled Peptides

Imaging with radiolabeled antibodies encounters the difficulty of higher background due to slow plasma clearance and tumor uptake. This problem is somewhat mitigated by the use of peptides whose molecular size is smaller than those of proteins. The plasma clearance of the peptides is much faster. They exhibit rapid target tissue uptake and rapid excretion mainly due to the degradation of the peptides by peptidases. Based on these facts, various peptides have been introduced for targeting specific tumors and actively forming thrombi. Various derivatives of native peptides have also been synthesized to improve their biological characteristics and thus to enhance their binding to biological targets.

Peptides have been labeled with both ¹¹¹In and ^{99m}Tc. The basic principles of labeling of peptides are identical to those of antibodies described above and, therefore, are not discussed here. High specific activity of radiolabeled peptides can be achieved, particularly with ^{99m}Tc. However, due to the small size of the peptide molecules, ^{99m}Tc-labeling is likely to alter the regions of the peptide that interact with the biological target and consequently to result in the loss of their binding affinity. Direct labeling of peptides with ^{99m}Tc using Sn²⁺ as the reducing agent may cause damage to the molecule by breaking open the disulfide bonds. So the indirect labeling method using BFCs is preferable for ^{99m}Tc-labeling of peptides.

The radiolabeled peptides approved by the US FDA for clinical use are ^{99m}Tc-MAG3 (described earlier) and ¹¹¹In-pentetriotide (described below).

7.3.12.1 ¹¹¹In-Pentetreotide (OctreoScan)

The single-dosage kit, also known as OctreoScan, is supplied by Mallinckrodt Pharmaceuticals. It consists of a reaction vial containing a lyophilized mixture of octreotide conjugated to DTPA (pentetreotide), gentisic acid, trisodium citrate, citric acid, and inositol. Also included in the kit is a 3-mCi (111 MBq) ¹¹¹InCl₃ solution. Labeling is carried out by adding ¹¹¹InCl₃ to the reaction vial and incubating the mixture for 30 min at room temperature. The labeling yield should be more than 90%. ¹¹¹In-pentetreotide should be stored at a temperature below 25°C and be dispensed within 6 h after preparation.

Octreotide is a synthetic analog of the human hormone somatostatin, and therefore ¹¹¹In-pentetreotide binds to somatostatin receptors on body tissues. It is particularly useful in detecting primary and metastatic neuroendocrine tumors such as carcinoids, gastrinomas, neuroblastomas, pituitary adenomas, and medullary thyroid carcinomas.

7.3.13 Other Radiopharmaceuticals of Clinical Importance

The compound ¹¹¹In-indium chloride is supplied as a sterile solution in HCl at pH below 2.5; acidic pH is needed because it precipitates as hydroxide at pH above 5.5.

It is used for bone marrow imaging and for labeling different antibodies and peptides. The compound ⁵¹Cr-sodium chromate is supplied as a sterile solution at pH 7.5–8.5 and is used for labeling RBCs for use in the study of red cell survival and spleen imaging.

7.4 US FDA-Approved PET Radiopharmaceuticals

7.4.1 ¹⁸F-Sodium Fluoride

Fluorine-18 is produced by irradiation of ¹⁸O-water with protons in a cyclotron and recovered as ¹⁸F-sodium fluoride by passing the irradiated water target mixture through a carbonate-type anion-exchange resin column. The water passes through, whereas ¹⁸F⁻ is retained on the column, which is removed by elution with potassium carbonate solution. Its pH should be between 4.5 and 8.0. ¹⁸F is obtained as gas after irradiation for electrophilic substitution as in ¹⁸F-fluorodopa synthesis. While ¹⁸F-sodium fluoride is most commonly used for the synthesis of ¹⁸F-fluorodeoxyglucose, it is also used for other ¹⁸F-labeled PET radiopharmaceuticals. The US FDA has approved it for bone scintigraphy.

7.4.2 ¹⁸F-Fluorodeoxyglucose

¹⁸F-2-fluoro-2-deoxyglucose (2-FDG) is normally produced in places where a cyclotron is locally available. Deoxyglucose is labeled with ¹⁸F ($t_{1/2} = 110$ min) by nucleophilic displacement reaction of an acetylated sugar derivative followed by hydrolysis (Hamacher et al. 1986). A solution of 1,3,4,6-tetra-O-acetyl-2-Otrifluormethane-sulfonyl-\beta-d-mannopyranose in anhydrous acetonitrile is added to a dry residue of ¹⁸F-fluoride containing aminopolyether (Kryptofix 2.2.2) and potassium carbonate. The mixture is heated under reflux for about 5 min. The solution is then passed through a C-18 Sep-Pak column to elute acetylated carbohydrates with tetrahydrofuran (THF), which is then hydrolyzed by refluxing in hydrochloric acid at 130°C for 15 min. ¹⁸F-2-fluoro-2-deoxyglucose (2-FDG) is obtained by passing the hydrolysate through a C-18 Sep-Pak column. The yield can be as high as 60%, and the preparation time is approximately 50 min. ¹⁸F-2-FDG is routinely synthesized in an automated synthesis box in which ¹⁸F-fluoride is introduced and the sequence of reactions follows to yield ¹⁸F-2-FDG. The final solution diluted with saline has a pH of 7.0. The molecular structure of ¹⁸F-2-FDG is shown in Fig. 7.8a.

¹⁸F-2-FDG is used primarily for the study of metabolism in the brain and heart and for the detection of epilepsy and various tumors.



Fig. 7.8 Molecular structures of **a** 18 F-2-fluoro-2-deoxyglucose (18 F-FDG), **b** 18 F-florbetapir, **c** 18 F-flutemetamol, and **d** 18 F-florbetaben

7.4.3 ¹⁸F-Fluciclovine (Axumin)

The synthesis of ¹⁸F-fluciclovine is similar to that of ¹⁸F-FDG and rendered by nucleophilic reaction of ¹⁸F-fluoride with 1-tert-butyl carbamate-3-trifluromethane-sulfonoxy-1-cyclobutane-1-carboxylic acid methyl ester (FACBC precursor) (Shoup et al. 1999). The ¹⁸F-fluoride is mixed with a Kryptofix/potassium carbonate in dry acetonitrile in a reaction vial and then evaporated to dryness. A solution of FACBC precursor is added to the residue in the vial, and the solution is heated at 85°C for 5 min followed by dissolving it in methylene chloride. The solution is passed through a silica gel Sep-Pak to remove F⁻ ion. The ¹⁸F-labeled intermediate is eluted with methylene chloride followed by evaporation. The product is hydrolyzed with dilute HCl to give ¹⁸F-fluciclovine, which is further purified by passing through C-18 Sep-Pak and 0.22-µm filter. The radiochemical yield is ~12% at EOB, and the radiochemical purity as determined by TLC is 99%. Automated synthesis using a synthesis box takes about 60 min, and the yield is improved to ~24%. It is stored at room temperature (20 to 25°C).

It is marketed by Blue Earth Diagnostics Ltd. of the UK under the brand name Axumin for detection of recurrent prostate cancer in humans. It is approved by the US FDA and is marketed in the USA by Siemens' PETNET Solutions, Inc. It can be used for the detection of other cancers too.

7.4.4 ¹⁸F-Florbetapir (Amyvid)

¹⁸F-florbetapir (trade name Amyvid or AV-45) is prepared by nucleophilic reaction between ¹⁸F-fluorideion and precursor (E)-2-(2-(2-(2-((tert-butoxycarbonyl(methyl))))))

amino)styryl)pyridin-2-yloxy)ethoxy)ethoxy)ethyl4-methylbenzenesulfonate (AV-105) in an automated fluorination module (Yao et al. 2010). ¹⁸F-fluoride ion is taken up in a mixture of K₂CO₃ and Kryptofix 2.2.2 in acetonitrile solution, which is dried by successive heating at 140°C and 120°C for 4 and 12 min. The ¹⁸F-K/ Kryptofix compound is taken up in 0.5-ml anhydrous acetonitrile in a reaction vessel. AV-105 in acetonitrile/DMSO solution is added to the reaction vessel and heated at 130°C for 10 min resulting in fluorinated intermediate, N-Boc-[¹⁸F]AV-45. It is hydrolyzed with dilute HCl followed by neutralization with a solution of NaOH and ammonium acetate. The solution is loaded on a C-18 Sep-Pak column, and unreacted ¹⁸F⁻ ion is removed by washing with water, and ¹⁸F-florbetapir is eluted with acetonitrile. The fluorinated product is further purified by HPLC, in which it is eluted with ethanol for clinical use. The radiochemical yield is $\sim 25.4\%$, and the radiochemical purity is >95% with a high specific activity of 12,702 Ci (470 TBq)/mmol. ¹⁸F-Florbetapir injection is supplied in a 10-ml, 30-ml, and 50-ml multidose vial containing a clear, colorless solution at a strength of 13.5-51 mCi (500-1900 MBq)/ ml at the end of synthesis. The molecular structure of ¹⁸F-florbetapir is shown in Fig. 7.8b.

¹⁸F-florbetapir avidly binds to amyloid plaques and localizes other conditions of dementia and is indicated for the diagnosis of Alzheimer's disease (AD) by PET imaging. It is supplied by Eli Lilly.

7.4.5 ¹⁸F-Flutemetamol (Vizamyl)

¹⁸F-flutemetamol is an amyloid plaque imaging agent supplied by GE Healthcare under the trade name Vizamyl. It is obtained by labeling a cold precursor, AH111907, with ¹⁸F-fluoride by nucleophilic substitution similar to the method for ¹⁸F-florbetapir (Nelissen et al. 2009) and supplied in ethanol and polysorbate 80 in phosphate buffer. The radiochemical purity as determined by HPLC is around 98%. The upper limit of cold precursor is 10 μg per patient dosage. Its structure is shown in Fig. 7.8c. Vizamyl is used to detect amyloid plaques in AD patients.

7.4.6 ¹⁸F-Florbetaben (Neuraceq)

¹⁸F-florbetaben avidly binds to the amyloid plaques in neurodegenerative disorders including AD and therefore is used to detect AD in patients. It has the molecular structure shown in Fig.7.8d. It is synthesized by nucleophilic substitution of methanesulfonic acid in the precursor methanesulfonic acid 2-{2-[2-(4-{2-[4-(tertbutoxycarbonyl-methyl-amino)-phenyl]-vinyl}-phenoxy)-ethoxy]-ethoxy}-ethyl ester with activated ¹⁸F-fluoride, which is prepared by mixing ¹⁸F⁻ with K₂CO₃ and Kryptofix 2.2.2 in acetonitrile solution and drying the mixture by successive heating at 140°C and 120°C for 4 and 12 min (Wang et al. 2013). The dry residue is taken up in acetonitrile, to which the precursor is added and the solution is heated to 120°C for 6 min. The reaction mixture is subjected to HPLC, followed by further

purification by passing through a C-18 Sep-Pak cartridge. ¹⁸F-florbetaben is eluted from the cartridge with absolute ethanol. The entire process has been integrated into automatic synthesis, which takes about 50 min with 20%–25% radiochemical yield and 95% radiochemical purity. It is stored at room temperature (25°C). It is supplied under the brand name NeuraCeq by Piramal Imaging in a 30-ml multidose vial containing 1.4–135-mCi (50–5000 MBq) ¹⁸F-florbetaben.

7.4.7 ¹¹C-Choline

¹¹C-choline is a tracer specific for recurrent prostate cancer and is currently approved by the US FDA for this indication. It is prepared by a reaction between ¹¹C-methyl iodide (¹¹CH₃I) and 2-(dimethylamino)-ethanol (Hara et al. 1997). The reaction is carried out at 120°C for 5 min and the product is taken up in water. The aqueous solution is passed through a Sep-Pack column, and ¹¹C-choline is eluted with 0.9% NaCl solution. It is further purified by reverse-phase HPLC that results in a radiochemical purity of 98%, and radiochemical yield is 98% with a specific activity of 30 mCi (1.1GBq)/µg. Currently, it is prepared using commercially available automated synthesis boxes.

Besides prostate cancer, other cancers such as brain and breast cancers have been detected by this agent.

7.4.8 ¹³N-Ammonia

Nitrogen-13-labeled ammonia is produced by reduction of ¹³*N*-labeled nitrates and nitrites that are produced by proton irradiation of water in a cyclotron. The reduction is carried out with titanium chloride in alkaline medium. ¹³*N*-NH₃ is then distilled and finally trapped in acidic saline solution (Weiland et al. 1991). The radiochemical yield is ~95% as determined by HPLC. Its pH should be between 4.5 and 7.5. It is approved for measurement of myocardial and cerebral perfusion by PET imaging.

7.4.9 ⁸²Rb-Rubidium Chloride

⁸²Rb-rubidium chloride is available from the ⁸²Sr–⁸²Rb generator, which is manufactured and supplied by Bracco Diagnostics. ⁸²Rb is eluted with saline and must be checked for ⁸²Sr and ⁸⁵Sr breakthrough daily before the start of its use for patient studies. Since ⁸²Rb has a short half-life of 75 s, it is administered to the patient by an infusion pump described in Chap. 5. The administered activity is the integrated activity infused at a certain flow rate for a certain period of time set by the operator, and all data are printed out by a printer.

⁸²Rb is used for myocardial perfusion imaging using PET to delineate ischemia from infarction in patients.

7.4.10 ⁶⁸Ga- and ¹⁷⁷Lu-Labeled DOTATOC and DOTATATE

DOTA is macrocyclic bifunctional chelating agent, synthesis of 2-(p-nitrobenzyl)-1,4,7,10-tetraazacyclododecane-N,N',N",N"-tetraacetic acid. that binds to ⁶⁸Ga or ¹⁷⁷Lu on one side and a peptide like Tyr³-octreotide (TOC) and Tyr³-octreotate (TATE), which are somatostatin analogs, on the other. Initially DOTATATE or DOTATOC is obtained by chelation between the two entities and is available commercially. For radiolabeling DOTATOC and DOTATATE with ⁶⁸Ga, the chelate is first dissolved in 0.01M acetic acid in a reaction vial. The ⁶⁸Ga radioactivity is eluted as ⁶⁸GaCl₃ from the ⁶⁸Ge–⁶⁸Ga generator using dilute HCl. The radioactivity is added to the reaction vial followed by addition of the acetate buffer and NaOH. The mixture is heated at 80°C for 20 min in a heating block (Breeman et al. 2005). The reaction is optimal at pH 4–5. The mixture is passed through a C-18 cartridge for HPLC, and radiolabeled DOTATOC or DOTATATE is recovered by eluting the cartridge with 30% ethanol. The radiochemical yield is almost quantitative with a specific activity of 1 GBq/mmol. The structures of ⁶⁸Ga-DOTATOC and ⁶⁸Ga-DOTATATE are shown in Fig.7.9a and Fig.7.9b, respectively.

DOTATATE is supplied as a single-dose kit (brand name NetSpot) by Advanced Accelerator Applications, USA, Inc., for labeling with ⁶⁸Ga available from a ⁶⁸Ge–⁶⁸Ga generator. The kit consists of two vials – vial 1 containing DOTATATE and inactive ingredients, and vial 2 containing a buffer solution – and a cartridge containing 600-mg silica. Labeling is carried out by first eluting ⁶⁸GaCl₃ from the



Fig. 7.9 Structures of a ⁶⁸Ga-DOTATOC and b ⁶⁸Ga-DOTATATE (Reproduced from open access article by Velikyan 2015) and c ¹⁸F-fluorodopa

generator with dilute HCl through the cartridge to vial 1, followed by adding the buffer from vial 2. The mixture is heated at 95°C for 7 min and then cooled for 10 min at room temperature. The radiochemical yield determined by the instant thin layer chromatography method is 92%. It should be stored at 25°C and used within 4 h after labeling.

While ⁶⁸Ga-labeled octreotides are used primarily for the detection of neuroendocrine tumors (NET) by PET imaging because of its positron emission, ¹⁷⁷Lu is a β^- -emitter, and so ¹⁷⁷Lu-labeled octreotides are used for treatment of NETs. DOTATATE and DOTATOC are labeled with ¹⁷⁷Lu in the same way as with ⁶⁸Ga. The US FDA has approved ⁶⁸Ga-DOTATATE for this purpose, but ⁶⁸Ga-DOTATOC has been approved as an orphan drug by the US FDA. An orphan drug status is given to a drug to be used for a specific rare disease that affects less than 200,000 people or for limited clinical use. The US FDA approves it for routine clinical use based on the positive results of the orphan drug study.

In June 2016, ¹⁷⁷Lu-DOTATATE or ¹⁷⁷Lu-oxodotreotide (named Lutathera) has been granted priority review by the US FDA for human use and is expected to be approved soon for peptide receptor radionuclide therapy (PRRT). NetSpot and Lutathera would work in pair to detect and treat NETs, thus illustrating the use of theranostics in personalized medicine.

7.5 Non-US FDA-Approved PET Radiopharmaceuticals of Potential Use

7.5.1 ¹⁵O-Water

¹⁵O-oxygen is produced in the cyclotron by the ¹⁵N (p, n) ¹⁵O reaction, and the irradiated gas is transferred to a ¹⁵O-water generator in which it is mixed with hydrogen and passed over a palladium/charcoal catalyst at 170°C (Meyer et al. 1986). The H_2^{15} O vapor is trapped in saline, which is then passed through a radiation detector for radioassay and ultimately injected into the patient in a very short time.

H₂¹⁵O is commonly used for myocardial and cerebral perfusion studies.

7.5.2 ¹¹C-Sodium Acetate

¹¹C-labeled acetate is produced by the reaction of the Grignard reagent, methylmagnesium bromide, with cyclotron-produced ¹¹C-carbon dioxide. After reaction, the product is hydrolyzed with water or aqueous acid, followed by further purification using solvent extraction. ¹¹C-acetate has been found to be stable at pH between 4.5 and 8.5 for up to 2 h at room temperature. It is used for the measurement of oxygen consumption in the heart and brain.

7.5.3 ¹⁸F-Fluorodopa

There are several methods of synthesizing 6^{-18} F-fluoro-3, 4-dihydroxy-phenylalanine (6^{-18} F-fluorodopa), of which the method of fluorodemetallation using electrophilic fluorinating agents is most common. Of d- and l-isomers of dopa, only the *l*-isomer is selectively converted to dopamine by the enzymes and hence is used for labeling. Initially, a protected organomercury precursor of dopa is prepared. Other precursors using tin, silicon, selenium, and germanium have been reported. ¹⁸F-labeled acetylhypofluorite prepared in the gas phase is then allowed to react with the mercury precursor in chloroform or acetonitrile at room temperature. Acid hydrolysis with 47% HBr provides a relatively high yield (10–12%) of 1–6-¹⁸F-fluorodopa (Luxen et al. 1987) and high specific activity of nearly 100 mCi (3.7 GBq)/mmol. It is supplied at pH between 4.0 and 5.0. Normally EDTA and ascorbic acid are added to the final preparation for stability. The major impurity is mercury and its USP limit is 0.5 µg/ml of the preparation. Its structure is shown in Fig. 7.9c. 1–6-¹⁸F-fluorodopa is used for the assessment of the presynaptic dopaminergic function in the brain.

7.5.4 ¹⁸F-Fluorothymidine

¹⁸F-fluorothymidine (FLT) is prepared by nucleophilic reaction between ¹⁸F-fluoride and a precursor, 2, 3'-anhydro-5'-*o*-benzoyl-2'-deoxythymidine, which is prepared by standard organic synthesis (Machulla et al. 2000). ¹⁸F-fluoride is mixed with Kryptofix 2.2.2 and potassium carbonate in acetonitrile, and the mixture is dried to a residue by heating at 120°C for 5 min. The precursor in dimethyl sulfoxide (DMSO) is added to the dried residue and heated at 160°C for 10 min. The 5'-0protecting group is hydrolyzed with sodium hydroxide. ¹⁸F-FLT is isolated by passing through alumina Sep-Pak and further purified by using the HPLC. The overall yield is about 45% and the radiochemical purity is more than 95%. The synthesis time is about 60 min.

Since thymidine is incorporated into DNA and provides a measure of cell proliferation, ¹⁸F-FLT is commonly used for in vivo diagnosis and characterization of tumors in humans.

7.5.5 ¹⁸F-Flurpiridaz

¹⁸F-flurpiridaz was developed by Bristol–Myers Squibb with the product name of BMS-747158-02 and currently is supplied by Lantheus Medical Imaging for PET myocardial perfusion imaging. It is an analog of pyridaben, a known inhibitor of mitochondrial complex 1 (MC-1), and its chemical formula is 2-tert-Butyl-4-chloro-5-[4-(2-[¹⁸F]fluoroethoxymethyl)-benzyloxy]-2H-pyridazin-3-one. ¹⁸F-flurpiridaz is prepared by nucleophilic substitution reaction between ¹⁸F-fluoride ion and a toluene sulfonate ester. The product is purified by high-performance liquid chromatography (Leung 2007). The average radiochemical yield is ~25%, and the radiochemical purity is >95% with specific activities of 1550–5500 Ci (57–204 TBq)/ mmol at the end of synthesis.

7.6 Labeling of Therapeutic Radiopharmaceuticals

7.6.1 ¹¹¹In- and ⁹⁰Y-Ibritumomab Tiuxetan (Zevalin)

This single-dosage kit is supplied by Spectrum Pharmaceuticals, USA, under the brand name Zevalin. It consists of a murine monoclonal anti-CD20 antibody covalently conjugated to the metal chelator DTPA, which forms a stable complex with ¹¹¹In for imaging and with ⁹⁰Y for therapy.

The kit is supplied with four vials – a vial containing 3.2 mg of conjugated antibody in 2-ml saline, a vial containing 2ml 50mM sodium acetate, a vial containing phosphate buffer, and a fourth empty reaction vial. Prior to labeling, a volume of sodium acetate buffer equivalent to 1.2 times the volume of the tracer solution is transferred to the reaction vial. Then, 5.5mCi (203.5 MBq) ¹¹¹In or 40mCi (1.48 GBq) ⁹⁰Y as chloride is added to the reaction vial and mixed thoroughly without shaking. Next, 1.3 ml of conjugated antibody is added. The mixture is incubated for exactly 30 min for ¹¹¹In-labeling and for 5 min for ⁹⁰Y labeling, followed by the addition of enough phosphate buffer to make the final volume to 10 ml. The labeling yield is determined by instant thin-layer liquid chromatography using ITLC-SG strips and 0.9% NaCl solvent and should be greater than 95% for both radionuclides. The kit is stored at 2–8°C.

⁹⁰Y-ibritumomab tiuxetan is used for the treatment of relapsed or refractory low-grade, follicular, or CD20 transformed non-Hodgkin's lymphoma (NHL). ¹¹¹In-ibritumomab tiuxetan is used as an imaging agent to predict the distribution of the subsequent therapeutic dosage of ⁹⁰Y-ibritumomab within the body. An earlier version of anti-CD20 antibody, rituximab, has also been approved under the brand name Rituxan for treatment of NHL.

7.6.2 ⁹⁰Y-TheraSphere

⁹⁰Y-TheraSphere consists of glass microspheres having a mean size of 20–30 μ m. They are prepared by irradiating cold glass spheres containing stable ⁸⁹Y with neutrons in a reactor, whereby ⁸⁹Y is activated to ⁹⁰Y by neutron capture. These ⁹⁰Y-TheraSphere beads are insoluble in body fluid and nontoxic, and each milligram contains between 22,000 and 73,000 microspheres. The dosage is supplied in 0.6-ml volume of sterile and pyrogen-free water in a 1-ml cone-bottom vial contained in a clear acrylic vial. Depending on the dosage requirement for treatment, six sizes are available: 81 mCi (3 GBq), 135 mCi (5 GBq), 189 mCi (7 GBq), 270 mCi (10 GBq), 405 mCi (15 GBq), and 540 mCi (20 GBq). The product is supplied by

MDS Nordion, Canada, as a unit dosage along with an administration set and an accessory set containing an electronic dosimeter, Rados Rad-60R, which is reusable. It is stored at room temperature.

 90 Y-TheraSpheres are used for radiation treatment of hepatocellular carcinoma and are administered into the tumor through a catheter placed into the hepatic artery that supplies blood to the tumor. The β^- -radiations (0.936 MeV) from 90 Y-TheraSpheres lodged in the liver kill the tumor cells along with some normal tissues.

7.6.3 ⁹⁰Y-SIR-Sphere (SIRTeX)

 90 Y-SIR-Spheres (SIRTeX) are made of biocompatible microspheres with size between 20 and 60 µm in diameter. The microspheres are supplied in 5 cc sterile water in a glass vial contained in a lead pot. Each vial contains 81.1 mCi (3 GBq) of 90 Y and 40–80 million microspheres and is stored at room temperature (20–25°C). The shelf-life of SIR-Sphere is 24 h from the time of calibration. The product is supplied as a unit dosage by Sirtex Medical Limited, Australia, and Sirtex Medical Inc., USA.

Like ⁹⁰Y-TheraSpheres, ⁹⁰Y-SIR-Spheres are used for the treatment of unresectable metastatic liver tumors from primary colorectal cancer and are administered via a catheter placed in the hepatic artery.

7.6.4 ²²³Ra-Radium Chloride (Xofigo)

The production of ²²³Ra has been described in Chap. 4, and the α -particle emitting ²²³Ra-radium chloride is available from the ²²⁷Ac \rightarrow ²²⁷Th \rightarrow ²²³Ra generator (Chap. 5). For clinical use, the eluted ²²³Ra chloride is supplied by Bayer HealthCare Pharmaceutical Inc. under the brand name Xofigo. Initially, it was distributed as Alpharadin by a Norwegian company Algeta ASA, which was later acquired by Bayer. It is supplied in a single-use vial containing 178 µCi (6600 kBq) of ²²³Ra in 6 ml of 0.9% NaCl solution at pH 6–8 at a concentration of 29.7 µCi (1100 kBq)/ml on the reference date and stored at temperature below 40°C. The patient dosage is good for 96 h. It is US FDA-approved and used for the treatment of castration-resistant prostate cancer and symptomatic bone metastasis.

Questions

- 1. What is the difference between MAA and colloid particles?
- Twenty millicurie (740 MBq) ^{99m}Tc-MAA contains two million MAA particles. If a patient is injected with 3-mCi (111 MBq) ^{99m}Tc-MAA for lung imaging, how many particles did he receive?
- 3. What are the most useful phosphonate compounds for bone imaging? Describe the general methods of ^{99m}Tc-labeling of these compounds.
- 4. Describe the basic principle of ^{99m}Tc-sulfur colloid preparations. Why are gelatin and EDTA added to ^{99m}Tc-sulfur colloid?

- 5. Name the important radiopharmaceuticals used for the study of hepatobiliary function and describe the basic methods of their preparation.
- 6. What are the usual expiratory periods for (a) ¹³¹I-labeled compounds and (b) ^{99m}Tc-labeled compounds?
- 7. Describe the methods of labeling RBCs with ^{99m}Tc and ⁵¹Cr. Discuss the merits and disadvantages of each method.
- State the recommended temperatures of storage of the following compounds: (a) ^{99m}Tc-sulfur colloid and (b) ⁵⁷Co-cyanocobalamin.
- 9. Describe the methods of ¹¹¹In-labeling of platelets and leukocytes. What is the mechanism of labeling of platelets with ¹¹¹In?
- 10. Why is ¹¹¹In-indium chloride supplied at pH below 2.5?
- 11. Explain how the ^{99m}Tc-HMPAO kit is stabilized.
- 12. What is the charge of the following ^{99m}Tc-radiopharmaceuticals: (a) ^{99m}Tc-HMPAO, (b) ^{99m}Tc-MAG3, (c) ^{99m}Tc-sestamibi, and (d) ^{99m}Tc-tetrofosmin?
- 13. What is the amount of Sn²⁺ needed for optimum labeling of RBCs by the in vivo method?
- 14. Give three examples of ⁹⁹Tc-labeling by ligand exchange mechanism.
- 15. What are the restrictions on the quality of ${}^{99m}\text{Tc}\text{O}_4^-$ in the preparation of ${}^{99m}\text{Tc}\text{-HMPAO}$?
- 16. Why is hetastarch added to the whole blood for leukocyte separation?
- 17. Describe the methods of production of monoclonal antibody and its labeling with ¹¹¹In and ^{99m}Tc.
- 18. What are the difficulties in making human monoclonal antibodies?
- 19. Why is SCN-Bz-DTPA better than DTPA as a bifunctional chelating agent in labeling antibodies?
- 20. What are ¹¹¹In- and ⁹⁰Y-ibritumomab tiuxetan used?
- 21. What is the mechanism of 99mTc-labeling of antibodies by the direct method?
- 22. Discuss the method of labeling of antibodies with HYNIC and tricine.
- 23. Describe the methods of preparation of ¹⁸F-FDG and ¹⁸F-fluorodopa.
- 24. What are the two distinct features in fluorine labeling?
- 25. What are the agents used for detection of Alzheimer's disease?
- 26. ⁶⁸Ga-DOTATATE is used for detecting _____ tumor.
- 27. What are the ⁹⁰Y-TheraSpheres and ⁹⁰Y-SIR-Spheres used for?
- 28. What are the agents for palliation of pain due to bone metastasis, and why are they used?

References and Suggested Reading

- Abrams MJ, Davison A, Jones AG, et al. Synthesis and characterization of hexakis (alkyl isocyanide) and hexakis (aryl isocyanide) complexes of technetium (I). Inorg Chem. 1983;22: 2798.
- Breeman WA, de Jong M, de Blois E, et al. Radiolabeling DOTA- peptides with ⁶⁸Ga. Eur J Nucl Med Mol Imaging. 2005;32:478.
- Callahan RJ, Froelich JW, McKusick KA, et al. A modified method for the in vivo labeling of red blood cells with Tc-99m: concise communication. J Nucl Med. 1982;23:315.
- Dewanjee MK. The chemistry of 99mTc-labeled radiopharmaceuticals. Semin Nucl Med. 1990;20:5.

- Eckelman WC, Stiegman J, Paik CH. Radiopharmaceutical chemistry. In: Harpert J, Eckelman WC, Neumann RD, editors. Nuclear medicine: diagnosis and therapy. New York: Thieme Medical; 1996. p. 217.
- Edwards DS, Cheeseman EH, Watson MW, et al. Synthesis and characterization of technetium and rhenium complexes of N, N'-1, 2-diethylenediylbis-l-cysteine. Neurolites and its metabolites. In: Nicolini M, Bandoli G, Mazzi U, editors. Technetium and rhenium in chemistry and nuclear medicine. Verona: Cortina International; 1990. p. 433.
- Fritzberg AR, Kasina S, Eshima D, et al. Synthesis and biological evaluation of technetium-99m MAG3 as hippuran replacement. J Nucl Med. 1986;27:11.
- Hamacher K, Coenen HH, Stocklin G. Efficient stereospecific synthesis of NCA 2-[2¹⁸F]-fluoro-2-deoxy-d-glucose using aminopolyether supported nucleophilic substitution. J Nucl Med. 1986;27:235.
- Hara T, Noboru N, Shinoura N, Kondo T. PET imaging of brain tumor with [methyl-¹¹C]-choline. J Nucl Med. 1997;38:842.
- Hnatowich DJ. Recent developments in the radiolabeling of antibodies with iodine, indium and technetium. Semin Nucl Med. 1990;20:80.
- International Atomic Energy Agency. Manual for reactor produced radioisotopes. IAEA-TECDOC-1340; 2003.
- Kelly JD, Forster AM, Higley B, et al. Technetium-99m-tetrofosmin as a new radiopharmaceutical for myocardial perfusion imaging. J Nucl Med. 1993;34:222.
- Köhler G, Milstein C. Continuous cultures of fused cells secreting antibody of predefined specificity. Nature. 1975;256:495.
- Leung K. 2-tert-Butyl-4-chloro-5-[4-(2-[18F]fluoroethoxymethyl)-benzyloxy]-2H–pyridazin-3-one. 2007 Dec 15 [Updated 2012 Jan 24]. In: Molecular Imaging and Contrast Agent Database (MICAD) [Internet]. Bethesda (MD): National Center for Biotechnology Information (US); 2004–2013. Available from: http://www.ncbi.nlm.nih.gov/books/NBK23517/
- Loberg MD, Cooper M, Harvey E, et al. Development of new radiopharmaceuticals based on N-substitution of iminodiacetic acid. J Nucl Med. 1976;17:633.
- Luxen A, Bida GT, Phelps ME, et al. Synthesis of enantiomerically pure d and 1 6-[F-18] fluorodopa and in vivo metabolites via regioselective fluorodemercuration. J Nucl Med. 1987;28:624.
- Machulla HJ, Blocher A, Kuntzsch M, et al. Simplified labeling approach for synthesizing 3'-deoxy-3'-[¹⁸F] fluorothymidine ([¹⁸F] FLT). J Radioanal Nucl Chem. 2000;243:843.
- Meyer GJ, Ostercholz A, Hundeshagen H. ¹⁵O-water constant infusion system for clinical routine application. J Label Compd Radiopharm. 1986;23:1209.
- Nelissen N, Van Laere K, Thurfjell L, et al. Phase I study of the Pittsburgh compound B derivative 18F-flutemetamol in healthy volunteers and patients with probable Alzheimer disease. J Nucl Med. 2009;50:1251.
- Peters AM, Danpure HJ, Osman S, et al. Clinical experience with ^{99m}Tc-hexamethyl propylene amine oxime for labeling leukocytes and imaging inflammation. Lancet. 1986;2:946.
- Pimlott SL, Sutherland A. Molecular tracers for the PET and SPECT imaging of disease. Chem Soc Rev. 2011;40:149.
- Sodd VJ, Allen DR, Hoagland DR, et al., editors. Radiopharmaceuticals II. New York: Society of Nuclear Medicine; 1979.
- Shoup TM, Olson J, Hoffman JM, et al. Synthesis and evaluation of [18F]1-amino-3-fluorocyclobutane-1-carboxylic acid to image brain tumors. J Nucl Med. 1999;40:331.
- Stöcklin G, Pike VW, editors. Radiopharmaceuticals for positron emission tomography. Dordrecht: Kluwer; 1993.
- ten Berge RJM, Natarajan AT, Hardenman MR, et al. Labeling with indium-111 has detrimental effects on human lymphocytes. J Nucl Med. 1983;24:615.
- Thakur ML, Coleman RE, Welch MJ. Indium-111-labeled leukocytes for the localization of abscesses: preparation, analysis, tissue distribution and comparison with gallium-67 citrate in dogs. J Lab Clin Med. 1977;82:217.
- Troutner DR, Volkert WA, Hoffman TJ, et al. A neutral lipophilic complex of Tc-99m with a multidentate amine oxime. Int J Appl Radiat Isot. 1984;35:467.

- United States Pharmacopeial Convention. U.S. pharmacopeia 39 & National Formulary 34. United States Pharmacopeial Convention: Rockville; 2009.
- Velikyan I. ⁶⁸Ga-based radiopharmaceuticals: production and application relationship. Molecules. 2015;20:12913.
- Wang H, Guo X, Jiang S and Tang S. Automated synthesis of [18F] Florbetaben as Alzheimer's disease imaging agent based on a synthesis module system. Appl Radiat Isot. 2013;71:41.
- Weiland D, Bida G, Pagett H, et al. In-target preparation of [13N] ammonia via proton irradiation of dilute aqueous ethanol and acetic acid mixtures. Appl Radiat Isot. 1991;42:1095.
- Welch MJ, editor. Radiopharmaceuticals and other compounds labelled with short-lived radionuclides. New York: Pergamon Press; 1977.
- Welch MJ, Redvanly CS, editors. Handbook of radiopharmaceuticals. Radiochemistry and applications. Hoboken: Wiley; 2003.
- Yao CH, Lin KJ, Weng CC, et al. GMP-compliant automated synthesis of [¹⁸F]AV-45 (Florbetapir F-18) for imaging β-amyloid plaques in human brain. Appl Radiat Isot. 2010;68:2293.
- Zolle I, editor. Technetium-99m pharmaceuticals: preparation and quality control in nuclear medicine. New York: Springer; 2007.
- Zuckier LS, Rodriguez LD, Scharff MD. Immunologic and pharmacologic concepts of monoclonal antibodies. Semin Nucl Med. 1990;20:166.

Quality Control of Radiopharmaceuticals

8

Since radiopharmaceuticals are intended for administration to humans, it is imperative that they undergo strict quality control measures. Basically, quality control involves several specific tests and measurements that ensure the purity, potency, product identity, biologic safety, and efficacy of radiopharmaceuticals. All quality control procedures that are applied to nonradioactive pharmaceuticals are equally applicable to radiopharmaceuticals; in addition, tests for radionuclidic and radiochemical purity have to be carried out. Often these quality control tests are carried out by the manufacturers from the beginning of production all the way up to the finished product. However, the introduction of kits, the increasing use of short-lived radionuclides such as ^{99m}Tc and the on-site preparation of many radiopharmaceuticals require that most, if not all, quality control tests be performed on all in-house preparations before dispensing these products for human administration.

The quality control tests fall into two categories: physicochemical tests and biological tests. The physicochemical tests indicate the level of radionuclidic and radiochemical impurities and determine the pH, ionic strength, osmolality, and physical state of the sample, particularly if it is a colloid. The biological tests establish the sterility, apyrogenicity, and toxicity of the material. These methods are outlined in detail below.

8.1 Physicochemical Tests

Various in vitro physicochemical tests are essential for the determination of purity and integrity of a radiopharmaceutical. Some of these tests are unique for radiopharmaceuticals because they contain radionuclides.

8.1.1 Physical Characteristics

The physical appearance of a radiopharmaceutical is important both on receipt and subsequently. One should be familiar with the color and state of a radiopharmaceutical. A true solution should not contain any particulate matter. Any deviation from the original color and clarity should be viewed with concern because it may reflect changes in the radiopharmaceutical that would alter its biologic behavior.

Colloidal or aggregate preparations should have a proper size range of particles for a given purpose. For example, for visualization of the reticuloendothelial system, colloidal particles should have a mean size around 100 nm. In ^{99m}Tc-sulfur colloid preparations, the particle size $(0.1-1 \ \mu m)$ may vary considerably from batch to batch, which can be checked by means of a microscope. These observations should be corroborated further by tissue distribution studies in animals, in which colloids of proper size should localize in the liver, while larger aggregated particles would deposit in the lungs.

In aggregate preparations such as ^{99m}Tc-MAA, the particle size should vary between 10 μ m and 100 μ m. The size can be checked with a hemocytometer under a light microscope. Preparations containing particles larger than 150 μ m should be discarded because of the possibility of pulmonary arterial blockade by these large particles. The number of particles in a preparation is equally important and can be determined by counting the particles on a hemocytometer under a light microscope.

8.1.2 pH and Ionic Strength

All radiopharmaceuticals should have an appropriate hydrogen ion concentration or pH for their stability and integrity. The ideal pH of a radiopharmaceutical should be 7.4 (pH of the blood), although it can vary between 2 and 9 because of the high buffer capacity of the blood. The pH of a solution is accurately measured by a pH meter, whereas colorimetric evaluation with pH paper (litmus paper) is rather inaccurate. Any deviation from the desired pH must be treated with caution and should be remedied.

Radiopharmaceuticals must also have proper ionic strength, isotonicity, and osmolality in order to be suitable for human administration. Correct ionic strength can be achieved by adding a proper acid, alkali, or electrolyte and can be calculated from the concentrations of added electrolytes.

At this point a word of caution is in order. Since ionic strength and pH are important factors for the stability of a radiopharmaceutical, it is important to use the proper diluent, preferably the same solvent as used in the original preparation, when diluting a radiopharmaceutical.

8.1.3 Radionuclidic Purity

Radionuclidic purity is defined as the fraction of total radioactivity in the form of the desired radionuclide present in a radiopharmaceutical. Impurities arise from extraneous nuclear reactions due to isotopic impurities in the target material during cyclotron irradiation or from fission of heavy elements in the reactor. Some examples are ⁹⁹Mo in ^{99m}Tc-labeled preparations (this arises due to ⁹⁹Mo breakthrough from the Moly generator) and many iodine isotopes in ¹³¹I-labeled preparations. The undesirable radionuclides may belong to the same element as the desired radionuclide or to a different element. The presence of these extraneous radionuclides increases the undue radiation dose to the patient and may also degrade the scintigraphic images. These impurities should be removed by appropriate chemical methods, provided their chemical properties are distinctly different from those of the desired radionuclide.

Radionuclidic purity is determined by measuring the half-lives and characteristic radiations emitted by individual radionuclides. Since a given radiation may belong to a number of radionuclides, determination of radiation energy alone does not establish the identity of a radionuclide, and its half-life must be established by methods described in Chap. 2. Radionuclides that emit γ -rays are distinguished from one another by identification of their γ -ray energies on the spectra obtained on a NaI(T1) or lithium-drifted germanium [Ge(Li)] detector coupled to a multichannel analyzer (see Chap. 3). Pure β -emitters are not as easy to check as the γ -emitters because of the difficulty in counting in a well counter. They may be checked for purity with a β -spectrometer or a liquid scintillation counter.

Radionuclidic purity depends on the relative half-lives and the quantities of the desired radionuclide and other contaminants, and changes with time. The presence of small quantities of a long-lived contaminant radionuclide is difficult to detect in the presence of large quantities of a desired short-lived radionuclide. In these instances, the short-lived radionuclide is allowed to decay and then the long-lived activity is measured. Trace amounts of various radionuclidic impurities in the ^{99m}Tc-eluate from a Moly generator are usually measured by a Ge(Li) detector after allowing ^{99m}Tc to decay. The detection and determination of ⁹⁹Mo in the ^{99m}Tc-eluate have been described in Chap. 5.

8.1.4 Radiochemical Purity

The radiochemical purity of a radiopharmaceutical is the fraction of total radioactivity in the desired chemical form in the radiopharmaceutical. Radiochemical impurities arise from decomposition due to the action of solvent, change in temperature or pH, light, presence of oxidizing or reducing agents, incomplete reaction, and radiolysis. Examples of radiochemical impurity are free ^{99m}Tc O_4^- and hydrolyzed ^{99m}Tc in ^{99m}Tclabeled complexes, free ¹³¹I-iodide in ¹³¹I-labeled proteins, and ⁵¹Cr³⁺ in a solution of ⁵¹Cr-sodium chromate. The presence of radiochemical impurities in a radiopharmaceutical results in poor-quality images due to the high background from the surrounding tissues and the blood and gives unnecessary radiation dose to the patient.

Decomposition of labeled compounds by radiolysis depends on the specific activity of the radioactive material, the type and energy of the emitted radiation, and the half-life of the radionuclide. Absorption of radiations by labeled molecules results in the formation of free radicals with unpaired electrons, which in turn leads to further decomposition of other molecules. A secondary process due to radiolysis produces H_2O_2 or HO_2° from decomposition of water (solvent), which reacts with

and ultimately decomposes labeled molecules. Particles are more damaging than γ -rays due to their short range and complete local absorption in matter.

The stability of a compound is time dependent on exposure to light, change in temperature, and radiolysis. The longer a compound is exposed to these conditions, the more it will tend to break down. For this reason, most radiopharmaceuticals are assigned an expiratory date after which they are not guaranteed for their intended use. Substances such as sodium ascorbate, ascorbic acid, and sodium sulfite are often added to maintain the stability of radiopharmaceuticals. Some radiopharmaceuticals are stored in the dark under refrigeration to lessen the degradation of the material.

A number of analytical methods are used to detect and determine the radiochemical impurities in a given radiopharmaceutical. Particularly important are precipitation, paper, thin-layer, and gel chromatography, paper and gel electrophoresis, ion exchange, solvent extraction, high-performance liquid chromatography, and distillation. These methods are briefly outlined below.

Precipitation

This method involves the precipitation of one radiochemical entity from another with an appropriate chemical reagent. The precipitate is separated by centrifugation. For example, the amount of ${}^{51}Cr^{3+}$ present in a ${}^{51}Cr$ -sodium chromate solution may be measured by precipitating chromate as lead chromate and determining the supernatant radioactivity.

Paper and Instant Thin-Layer Chromatography

In paper and instant thin-layer chromatography, a small aliquot of the radiopharmaceutical preparation is spotted on a paper (Whatman paper strip) or an instant thin-layer chromatography (ITLC) strip [ITLC strips are made of glass fiber impregnated with silica gel (SG) or polysilicic acid (SA)], and then chromatography is carried out by dipping the spotted strip into an appropriate solvent contained in a jar or a chamber. The strip is dipped in such a way that the spot remains above the solvent. The commonly used solvents for chromatography of 99mTc-complexes are 85% methanol, acetone, methyl ethyl ketone (MEK), 0.9% NaCl solution, and water. During the chromatographic process, different components of the sample distribute themselves between the adsorbent (paper or silica gel) and the solvent, depending on their distribution coefficients. Here the adsorbent is the stationary phase and the solvent the mobile phase. Electrostatic forces of the stationary phase tend to retard various components, while the mobile phase carries them along. This effect and varying solubilities of different components in a solvent cause the individual components to move at different speeds and to appear at different distances along the paper or ITLC strip. Polarity of the solvent also affects the chromatographic separation of different components in a sample.

Paper or ITLC chromatography can be either ascending or descending type. In ascending chromatography, the mobile phase moves up, whereas in the descending type it moves down. Whereas some chromatography takes hours for the complete procedure, ITLC is relatively fast and takes only a few minutes.

In paper chromatography or ITLC, each component in a given sample is characterized by an R_f value, which is defined as the ratio of the distance traveled by the component to the distance traveled by the solvent front from the original point of application of the sample. These values are established with known components and may vary under different experimental conditions. The $R_{\rm f}$ values are used primarily for the identification of different components in a given sample.

When the solvent front moves to a desired distance, the strip is removed from the chamber, dried, and divided into several segments, usually ten, and the radioactivity of each segment is measured in an appropriate counter, particularly in a NaI(Tl) well counter. Histograms are obtained by plotting the radioactivity of each segment. Alternatively, the activity along the strip can be measured by a radiochromatographic scanner, which, with an automatic integrator device, plots the radioactivity versus the distance along the strip. Radiochemical impurity is calculated as the ratio (as a percentage) of the radioactivity of the undesirable component to the total activity applied at the origin.

As previously mentioned in Chap. 6, three ^{99m}Tc species may exist in any ^{99m}Tclabeled preparation: free, hydrolyzed, and bound ^{99m}Tc. The ITLC method is used routinely in nuclear pharmacy to estimate the amounts of these three components and hence the labeling yield. Because the chromatographic separation depends on the type of paper and solvent, different information can be obtained with different systems. For example, in the analysis of ^{99m}Tc-pyrophosphate, the ITLC method using 85% methanol or acetone and ITLC-SG paper gives only two peaks – bound and hydrolyzed ^{99m}Tc at the origin ($R_f = 0$) and free ^{99m}TcO₄⁻ at the solvent front ($R_f = 1.0$), as shown in Fig. 8.1. If, however, Whatman No. 1 paper and saline are used in ITLC chromatography, the three components can be separated: the bound ^{99m}Tc at the solvent front, the hydrolyzed ^{99m}Tc at the origin, and the free^{99m}TcO₄⁻ at $R_f = 0.7$. It is therefore obvious that an interpretation of chromatographic results should be made with caution depending on the system used. The R_f values of different ^{99m}Tc species observed with several chromatographic systems are shown in



Fig. 8.1 Typical chromatogram obtained with ITLC-SG paper and acetone, showing two peaks: one at the solvent front for free 99m Tc O_4^- and the other at the origin for both hydrolyzed and bound 99m Tc-labeled compounds

			$R_{ m f}$		
99mTc-labeled	Stationary			99mTc-	Hydrolyzed
radiopharmaceuticals	phase	Solvent	99mTcO4-	complex	^{99m} Tc
99mTc-PYP	ITLC-SG	Acetone	1.0	0.0	0.0
	ITLC-SG	Saline	1.0	1.0	0.0
^{99m} Tc-HDP	ITLC-SG	Acetone	1.0	0.0	0.0
	ITLC-SG	Saline	1.0	1.0	0.0
^{99m} Tc-MDP	ITLC-SG	Acetone	1.0	0.0	0.0
	ITLC-SG	Saline	1.0	1.0	0.0
99mTc-DTPA	ITLC-SG	Acetone	1.0	0.0	0.0
	ITLC-SG	Saline	1.0	1.0	0.0
^{99m} Tc-albumin colloid	ITLC-SG	Acetone	1.0	0.0	0.0
99mTc-SC	ITLC-SG	Acetone	1.0	0.0	0.0
^{99m} Tc-MAA	ITLC-SG	Acetone	1.0	0.0	0.0
99mTc-DISIDA	ITLC-SA	20% NaCl	1.0	0.0	0.0
99mTc-mebrofenin	ITLC-SG	Water	1.0	1.0	0.0
99mTc-DMSA	ITLC-SA	Acetone	1.0	0.0	0.0
99mTc-sestamibi	Al ₂ O ₃ -coated plastic plate	Ethanol	0.0	1.0	0.0
99mTc-HMPAO	ITLC-SG	Butanone (MEK)	1.0	1.0	0.0
				(Primary)	
	ITLC-SG	Saline	1.0	0.0	0.0
	Whatman 1	50% acetonitrile	1.0	1.0	0.0
^{99m} Tc-tetrofosmin	ITLC-SG	Acetone/ dichloromethane (35:65 v/v)	1.0	0.5	0.0
99mTc-MAG3	Whatman 3 MM	Acetone	1.0	0.0	0.0
	Whatman 3 MM	Water	1.0	1.0	0.0
99mTc-bicisate	Whatman 3 MM	Ethyl acetate	0.0	1.0	0.0
99m Tc-tilmanocept	Whatman 3 MM	Acetone	0.0	1.0	00

 Table 8.1
 Chromatographic data of ^{99m}Tc-labeled radiopharmaceuticals

Table 8.1. For radiopharmaceuticals other than 99m Tc-labeled products, the $R_{\rm f}$ values are presented in Table 8.2.

For the sake of brevity, in nuclear medicine, 5- to 6-cm long and 1-cm wide ITLC (SG or SA) or Whatman No. 1 or 3 strips are employed for the analysis of ^{99m}Tc-labeled radiopharmaceuticals. Chromatography is usually performed with acetone or saline in a small vial fitted with a screw cap (Fig. 8.2). The total time of chromatography is only a few minutes. Afterward, the chromatogram is cut in half and the activity in each half is measured. With SA and Whatman paper, the cut is made at 1:3 ratio resulting in different $R_{\rm f}$ values. As described in Fig. 8.3, the activities of free, hydrolyzed, and bound ^{99m}Tc can be determined and their percentages calculated.

For practical reasons, some ^{99m}Tc-labeled radiopharmaceuticals require only one solvent chromatography. For example, the thin-layer chromatography of ^{99m}Tc-DMSA is performed with only ITLC-SA and acetone, because DMSA does not move to the
			$R_{\rm f}$ Values	5
	Stationary		Labeled	
Radiopharmaceuticals	phase	Solvent	product	Impurities
¹²⁵ I-RISA	ITLC-SG	85% methanol	0.0	1.0 (I ⁻)
¹³¹ I-MIBG	Silica gel plated plastic	Ethyl acetate/ethanol (1:1)	0.0	0.6 (I ⁻)
¹³¹ I-NaI	ITLC-SG	85% methanol	1.0	0.2 (IO ₃ ⁻)
⁵¹ Cr-sodium chromate	ITLC-SG	<i>n</i> -Butanol saturated with 1 N HCl	0.9	0.2 (Cr ³⁺)
67Ga-citrate	ITLC-SG	CHCl ₃ /acetic acid (9:1)	0.1	1.0
⁶⁸ Ga-DOTATATE	ITLC-SA	1 M ammonium acetate/ methanol (1:1)	0.7	0.1
¹¹¹ In-DTPA	ITLC-SG	10% ammonium acetate/ methanol (1:1)	1.0	0.1 (In ³⁺)
¹¹¹ In-capromab pendetide ^a	ITLC-SG	Saline	0.0	1.0 (In ³⁺)
¹⁸ F-FDG ^a	Silica gel	CH ₃ CN/H ₂ O (95:5)	0.37	0.0
¹⁸ F-fluciclovine ^b	Chiraplates	CH ₃ CN/water/ methanol(20:5:5)	0.63	0.0
⁹⁰ Y-, ¹¹¹ In-ibritumomab tiuxetan ^a	ITLC-SG	0.9% NaCl sol	0.0	1.0

 Table 8.2
 Chromatographic data of radiopharmaceuticals other than ^{99m}Tc-complexes

Data are adapted from Procedure manual (1977) ^aData are from package insert ^bShoup et al. (1999)



Fig. 8.2 Chromatographic chamber type vials



Fig. 8.3 Method of determining radiochemical purity (bound fraction) of ^{99m}Tc-labeled radiopharmaceuticals from miniaturized ITLC system

solvent front in saline. Similarly, ^{99m}Tc-SC and ^{99m}Tc-MAA require only ITLC-SG and acetone, giving free ^{99m}TcO₄ and ^{99m}Tc-chelate because these radiopharmaceuticals do not dissolve in saline. ¹³¹I-MIBG is checked for radiochemical purity using silica gel plated plastic and a mixture of ethyl acetate and ethanol (1:1) as solvent, which gives for ¹³¹I-iodide $R_f = 0.6$ and for ¹³¹I-MIBG $R_f = 0.0$.

Some factors in thin-layer chromatography must be considered in order to avoid artifacts. The chromatographic paper should be dry. Caution should be exercised to avoid streaking of solvents along the edge of the paper strip. The sample spot should be small and long air drying should be avoided to prevent air oxidation of ^{99m}Tc-chelate.

Gel Chromatography

Gel chromatography is a useful method for separating different components of a radiopharmaceutical preparation. In this method, a sample is spotted on the top of a column of Sephadex gel or Bio-Rad gel, soaked in an appropriate solvent, and then eluted with the same solvent. Separation of the components of a sample depends on the molecular size of the species – the larger ones are eluted faster than the smaller ones. Sequential fractions of the eluate are collected by means of an automated fraction collector, and the radioactivity is measured in each fraction. The identity of different components is established by using known samples on the gel column. The radioactivity in each fraction is then plotted versus the fraction number, which gives the relative concentrations of different molecular size components in a given sample. The amount of a component is expressed as the ratio (as a percentage) of its radioactivity to the total radioactivity placed on the column.

Gel chromatography is useful in separating proteins of different molecular weights. This method is equally important in detecting impurities in 99m Tc-radiopharmaceuticals. Free, bound, and unbound hydrolyzed 99m Tc species can be separated and identified by this method using Sephadex gel and saline as the eluting solvent. In this case, the 99m Tc-chelate is eluted first, 99m TcO₄⁻ comes through next, and the hydrolyzed 99m Tc is retained by the column. In several 99m Tc-labeled preparations, the chelate binds to Sephadex gel, which causes problems in the separation of the impurities. Examples are 99m Tc-gluconate and 99m Tc-mannitol, which are adsorbed on the Sephadex column.

Paper or Polyacrylamide Gel Electrophoresis

Paper or polyacrylamide gel electrophoresis consists of applying a radioactive sample on a paper or polyacrylamide gel soaked in a suitable buffer, and then applying an appropriate voltage across the paper or gel for a certain period of time. The components of the sample move to different positions along the paper or gel medium, depending on their charge and ionic mobility. After electrophoresis, the distribution of activity along the strip or gel column is determined by a counter or a radiochromatographic scanner. The latter cannot be used, however, for the gel electrophoresis column because they are technically incompatible. Since protein molecules become charged in buffer solutions above or below their isoelectric pH, most proteins can be separated by this method with the use of appropriate buffers. If the amount of carrier is sufficient, color formation between the sample and a suitable reagent (e.g., ninhydrin in the case of proteins and amino acids) can be used advantageously in the development of an electrophoretogram. For example, a good separation of free iodide and radioiodinated proteins can be achieved by electrophoresis in buffer.

Ion Exchange

Ion exchange is performed by passing a sample of a radiopharmaceutical through a column of ionic resin and eluting the column with suitable solvents. Separation of different species in a sample is effected by the exchange of ions from the solution onto the resin and their relative affinity for this exchange under certain physico-chemical conditions.

Resins are polymerized, high molecular weight, insoluble electrolytes. They consist of two components: a large, heavy, polymeric ion and an oppositely charged small ion that is exchangeable with other ions in solution in contact with the resin. There are two kinds of ion-exchange resins: cation-exchange resins, which have small cations, and anion-exchange resins, which have small anions. Typical examples of cation exchange and anion exchange reactions are illustrated below:

Cation exchange : $R - H + Na^+ \rightarrow R - Na + H^+$ Anion exchange : $R - OH + Cl^- \rightarrow R - Cl + OH^-$

Cation-exchange resins contain carboxylates, silicates, and sulfonate groups. Dowex-50 is an example of this kind of resin. Anion-exchange resins include quaternary ammonium compounds, and Dowex-l is an example of this type. Pore size and cross-linkage of the resin affect the ion-exchange separation of different components in a sample. The ion-exchange method is useful in radiochemistry. In nuclear pharmacy, the presence of ${}^{99m}\text{TcO}_4^-$ in ${}^{99m}\text{Tc-labeled}$ protein can be definitely determined by this method. ${}^{99m}\text{TcO}_4^-$ is adsorbed on Dowex-l resin, and ${}^{99m}\text{Tc-labeled}$ protein and hydrolyzed ${}^{99m}\text{Tc}$ come through in the eluate when the column is washed with saline. Since the hydrolyzed ${}^{99m}\text{Tc}$ activity accompanies ${}^{99m}\text{Tc-labeled}$ protein in the elution, it remains undetected by this method. Another example of an application of the ion-exchange method is the removal of unreacted iodide from an iodination mixture. Iodide is retained by the anion-exchange resin, whereas iodinated protein is eluted with the solvent.

Solvent Extraction

In solvent extraction, a solution containing one or more chemical compounds is shaken with an immiscible liquid and separation of different compounds is effected by the preferential solubility of individual compounds in one solvent or another. Thus, different solutes distribute themselves between two immiscible liquid phases. The ratio of solubilities of a component in two phases is called the distribution or partition coefficient. The efficiency of solvent extraction of a compound from one solvent into another depends primarily on this partition coefficient.

Solvent extraction of ${}^{99m}\text{Tc}O_4^-$ with MEK from ${}^{99}\text{Mo}O_4^{2^-}$ has been a successful method of avoiding various radiocontaminants in the ${}^{99m}\text{Tc}$ -eluate. The use of the solvent extraction method is limited in nuclear pharmacy because ITLC methods are generally more convenient.

High-Performance Liquid Chromatography

High-performance liquid chromatography (HPLC) is an important technique in the analysis of radiopharmaceutical samples, because it provides separation of components with high resolution. High resolution, speed of separation, and high recovery of solutes are the important advantages of HPLC.

The HPLC columns are heavy-walled tubes of glass or stainless steel 2–5 mm in internal diameter and between 15 cm and 30 cm in length and are packed with appropriate packing materials. In a typical HPLC method, a sample is injected by an injection valve or by a syringe/septum arrangement, and then the eluent is pumped into the column under pressure (up to 6000 psi) at a precisely controlled rate using a an electrical pump. The eluate is passed on to a sensitive detector that monitors the concentration of different solutes in the sample. The detector response (proportional to the concentration of solutes) is plotted against time after injection of the sample, which is often called the retention time.

The packing material consists of very fine microparticles with mean diameters between 5 μ m and 10 μ m for analytical HPLC and greater than 20 μ m for preparative HPLC. The sample size should be optimally small (5–250 μ l) for a given size column, since larger volumes decrease the resolution of chromatographic separation. Two types of pumps are available: constant flow rate pump and constant pressure pump.

The HPLC methods are of two types: normal phase and reverse phase. In normalphase HPLC, the packing material is polar in nature and is prepared by reacting the –OH groups of the silica surface with various reagents to give highly stable R–Si–C, R–Si–N, or R–Si–O–C bonded materials. The standard bonded phase material is the siloxane (Si–O–Si–R) packing. By varying the nature of the polar functional group on the organic side chain, different selectivity can be imparted relative to the silica packing. The commonly used solvents in normal-phase HPLC are hexane, heptane, acetone, and other hydrocarbons, often mixed with small amounts of a more polar solvent. For a given application, solvent strength is varied by changing the concentration of the more polar solvent component. Samples of moderate to strong polarity are usually well separated by normal-phase HPLC.

In reverse-phase HPLC, the stationary phase consists of fully porous, silica microparticulates chemically bonded with alkyl chains and is relatively nonpolar in nature. The octyl-(C_8) and octadecyl-(C_{18}) hydrophobic phases bonded onto silica microparticulates have been the most widely used column packing materials. The latter is commonly noted as octadecylsilane (ODS or C_{18}) packing. The common mobile phases used in reverse-phase HPLC are polar solvents such as water, to which varying concentrations of miscible organics (e.g., methanol and acetonitrile) are added. Solvent strength is usually varied by changing the composition of the solvent mixture. Nonpolar to weakly polar compounds are well separated by reverse-phase HPLC.

Of various detectors used to monitor the concentration of various solutes in the eluate, the ultraviolet (UV) monitor and the radiation detector such as NaI(Tl) detector are most common. The UV monitor measures the absorbance of light in the eluate, which is proportional to the concentration of a solute present in the eluate. The radiation detector is used for measuring the concentration of radioactive components in the eluate. In the analysis of radiopharmaceuticals, both the UV monitor and radiation detector are often used for measuring the concentration of different components in a radiopharmaceutical.

A variety of compounds such as carbohydrates, drugs, proteins, fatty acids, and so on have been separated by HPLC methods. Reverse-phase HPLC has been a strong tool in the analysis of many radiopharmaceuticals.

Distillation

Two compounds with considerably different vapor pressure can be separated by simple distillation at a specific temperature. The compound with higher vapor pressure is distilled off first, leaving the other compound in the distilling flask. For example, iodide present as a contaminant in an iodination mixture can be oxidized to iodine and separated by distillation. Noble gases (¹³³Xe, ⁸¹Kr, etc.) are separated by distillation.

8.1.5 Chemical Purity

The chemical purity of a radiopharmaceutical is the fraction of the material in the desired chemical form, whether or not all of it is in the labeled form. Chemical impurities arise from the breakdown of the material either before or after labeling, their inadvertent addition during labeling, and their undue accompaniment in the

preparation of the compound. For example, aluminum is a chemical impurity in the ^{99m}Tc-eluate. The presence of a slight amount of globulins in the preparation of albumin is indicative of impurities in the latter. However, additives, acid, alkali, and buffers are not considered impurities.

The presence of chemical impurities before radiolabeling may result in undesirable labeled molecules that may interfere with the diagnostic test. Undue chemical impurities may also cause a toxic effect. Purification of radiopharmaceuticals from these impurities is often carried out by methods of chemical separation such as precipitation, solvent extraction, ion exchange, and distillation.

8.1.6 Radioassay

The amount of radioactivity of a radiopharmaceutical before dispensing, as well as that of each individual dosage before administration to patients, must be determined. These activity determinations are carried out by means of a radionuclide dose calibrator described in Chap. 3. The performance of the dose calibrator must be checked by carrying out several quality control tests.

Dose Calibrator Quality Control

Years ago, the NRC in 10CFR35 required timely quality control tests performed for calibration of the dose calibrator to validate its accurate operation and established criteria for these tests. However, current 10CFR35 requires only the dose calibrator to be calibrated according to the manufacturer's recommendations or nationally recognized standards. The following tests are essential for calibration of the dose calibrator.

- 1. Constancy (daily)
- 2. Accuracy (at installation, annually, and after repairs)
- 3. Linearity (at installation, quarterly, and after repairs)
- 4. Geometry (at installation and after repairs)

Constancy

The constancy test indicates the reproducibility of measurements by a dose calibrator, and is performed by measuring the activity of a sealed source of a long-lived radionuclide (²²⁶Ra, ¹³⁷Cs, or ⁵⁷Co) on frequently used settings in the dose calibrator. A deviation of the reading by more than $\pm 10\%$ of the calculated activity may indicate the malfunction of the dose calibrator and hence repair or replacement. The constancy test must be done daily and at other times, whenever the dose calibrator is used, using at least a $10 \,\mu$ Ci (370 kBq) or more ²²⁶Ra source, or a $50 \,\mu$ Ci (1.85 MBq) or more ¹³⁷Cs or ⁵⁷Co source.

Accuracy

The accuracy of a dose calibrator is determined by measuring the activities of at least two long-lived reference sources at their respective isotope settings and comparing the measured activity with the stated activity. The measured activity must agree with the stated activity within $\pm 10\%$. Otherwise, the dose calibrator needs repair or replacement.

The activity of the reference sources must be accurate within $\pm 5\%$, and one of them must have energy between 100 keV and 500 keV. These sources are available from the National Institute of Standards and Technology and other manufacturers whose standards are of equal accuracy. The typical reference sources are ⁵⁷Co, ¹³³Ba, and ¹³⁷Cs.

Linearity

The linearity test indicates the dose calibrator's ability to measure the activity accurately over a wide range of values. Normally, dose calibrators exhibit a linear response for activities up to 200 mCi (7.4 GBq) to 2 Ci (74 GBq), depending on the chamber geometry and the electronics of the dose calibrator, and tend to underestimate at higher activities. The linearity test must be carried out over the range of activities from the highest dosage administered to the patient down to 30 μ Ci (1.11 MBq). Two common methods for checking the linearity of the dose calibrator are described below:

Decay Method In this method of linearity check, a source of ^{99m}Tc is usually used, the activity of which is at least equal to the highest dosage normally administered to the patients in a given institution. The source is then assayed in the dose calibrator at 0 h and then every 6 h during the working hours daily until the activity decays down to 30 μ Ci (1.11 MBq). The measured activities are plotted against time intervals on semilog paper and the "best fit" straight line is drawn through the data points (Fig. 8.4). The deviation of the point farthest from the line is calculated. If this deviation is more



Fig. 8.4 Plot of ^{99m}Tc activity versus time for the linearity check of the dose calibrator

than $\pm 10\%$, the dose calibrator needs to be replaced or adjusted, or correction factors must be applied to activities when measured in nonlinear regions.

Shielding Method This method is less time-consuming and easy to perform using 99m Tc. A commercial calibration kit used in this method contains seven concentric cylindrical tubes or "sleeves". The innermost tube is not lead lined and therefore provides no attenuation of gamma radiations. The other six tubes are lead lined with increasing thickness to simulate the various periods of decay. All tubes are color-coded corresponding to certain decay of 99m Tc. When these tubes are placed over the 99m Tc source in the dose calibrator, seven activity measurements represent activities at different times of decay. From the first time measurements, calibration factors are established for each tube by dividing the innermost tube reading by each outer tube reading. For subsequent linearity tests, identical measurements are made by the kit using a 99m Tc source. Each tube measurement is then corrected by the corresponding calibration factor to give identical values for all tubes. The average of these values is calculated. If each individual tube measurement falls within ±10% of the average value, the dose calibrator is considered to be functioning linearly; otherwise it needs to be replaced or adjusted or to apply correction factors.

It should be pointed out that before the linearity test by the shielding method can be instituted, the dose calibrator linearity must be established first by the decay method.

Geometry

Variations in sample volumes or geometric configurations of the container can affect the accuracy of measurements in a dose calibrator because of the attenuation of radiations, particularly the weak gamma radiations such as those of ¹²⁵I and ²⁰¹Tl. Thus, the same activity in different volumes [1 mCi (37 MBq) in 1 ml or 1 mCi (37 MBq) in 30 ml], in different containers (3-cc syringe or 10-cc syringe or 10-ml vial) or in containers of different materials (glass or plastic) may give different readings in the dose calibrators. Correction factors must be established for changes in volume or container configuration while measuring the activity of the radionuclide in question and must be applied to similar measurements, if the difference exceeds $\pm 10\%$.

Measurement of Radioactivity

Radioactivity of a radiopharmaceutical is measured by placing the sample inside the dose calibrator with the appropriate isotope selector setting. The reading is displayed in appropriate units (curie or becquerel) on the dial. Corrections are applied, whenever necessary.

Radioactivity can also be measured in a well-type NaI(Tl) counter. However, high-activity samples must be diluted before counting so that there is no loss of counts due to dead time. Normally, the radioactivity should be 1 μ Ci (37 kBq) or less per sample. Furthermore, the well counter must be calibrated before measurement of radioactivity. Readers are referred to standard books on physics and instrumentation for details of calibration techniques.

8.2 Biological Tests

Biological tests are carried out essentially to examine the sterility, apyrogenicity, and toxicity of radiopharmaceuticals before human administration. These tests for radiopharmaceuticals are identical to those for conventional pharmaceuticals. It should be realized that it is quite possible for a particular radiopharmaceutical solution to be sterile but still be highly pyrogenic when injected into patients. While radiopharmaceuticals become asterile due to bacterial, fungal, and yeast growth, pyrogenicity arises from certain metabolic byproducts (endotoxin) of these microorganisms. The tests for sterility, pyrogenicity, and toxicity are discussed below in some detail.

8.2.1 Sterility

Sterility indicates the absence of any viable bacteria or microorganisms in a radiopharmaceutical preparation. As already mentioned, all preparations for human administration must be sterilized by suitable methods that depend on the nature of the product, the solvent, and various additives.

Methods of Sterilization

Autoclaving

In autoclaving, the radiopharmaceutical is sterilized by heating in steam at 121°C under a pressure of 18 pounds per square inch (psi) for 15–20 min. This type of terminal steam sterilization kills microorganisms present in radiopharmaceutical solutions. Autoclaving is suitable only for thermostable aqueous solutions, whereas oil-based preparations and heat-labile radiopharmaceuticals such as some ^{99m}Tc-labeled preparations and iodinated proteins cannot withstand autoclaving because the molecule is damaged by heat. Autoclaving is not suitable for short-lived radio-nuclides such as ¹³N and ¹⁸F because the method takes too long. Thermostable radio-pharmaceuticals include ^{99m}Tc-pertechnetate, ¹¹¹In-DTPA, ⁶⁷Ga-gallium citrate, and ¹¹¹In-indium chloride. These compounds may also be sterilized by dry-heat sterilization and sometimes by irradiation with γ -rays.

Various types of autoclaves are available commercially. For a nuclear pharmacy, autoclaving can be performed in pressure cooker-type autoclaves equipped with a thermometer and a pressure gauge.

Membrane Filtration

Membrane filtration consists of simply filtering the radiopharmaceutical through a membrane filter that removes various organisms by a sieving mechanism. Commercially available Millipore filters are membrane filters made of cellulose esters and are available in various pore sizes and disposable units. A typical Millipore filter is shown in Fig. 8.5. The most common membrane filter size is 0.45 μ m, but a smaller pore size of 0.22 μ m is necessary for the sterilization of blood products and preparations suspected of contamination with smaller microorganisms.



Fig. 8.5 Millipore filter unit for sterilization of various radiopharmaceuticals (Courtesy of Millipore Corporation, Bedford, Massachussetts)

This is the most common method of sterilization in nuclear pharmacy and is the method of choice for short-lived radionuclides and heat-labile radiopharmaceuticals. In actual practice, if the volume of the radiopharmaceutical is small, then the solution is drawn in a syringe, a membrane filter is attached to the tip of the syringe (Fig. 8.5), and the volume is discharged through the filter into an aseptic container. In the case of larger volumes of radiopharmaceuticals, a leak-proof cylindrical unit fitted with a membrane filter and a movable plunger are used.

Another type of filter, Nuclepore, is available and is used conveniently for the determination of particle size in colloidal preparations.

Sterility Testing

Sterility testing is performed to prove that radiopharmaceuticals are essentially free of viable microorganisms. These tests must be performed aseptically so that external bacteria are not added to the test samples during the procedure. A sterile laminar flow hood is preferable, and personnel performing these tests should be well trained.

According to the USP 39, sterility tests are performed by incubating the radiopharmaceutical sample in fluid thioglycollate medium at 30–35°C for 14 days. Another test uses soybean–casein digest medium for incubation at 20–25°C for 14 days. The sample volume for the test should be at least as great as that for a human dosage. If bacterial growth is observed in either test, the radiopharmaceutical is considered to be contaminated and not sterile.

Since sterility testing frequently takes longer than the half-lives of many common short-lived radionuclides such as ^{99m}Tc, these radiopharmaceutical preparations are tested for sterility on a post hoc basis. In these cases, the product in question is released for human use provided the manufacturer has already established its sterility and apyrogenicity at the production level.

Another in vitro sterility test uses the metabolism of ¹⁴C-glucose by microorganisms present in the material under test. The basic principle of the test involves the addition of the test sample to a trypticase soy broth culture medium containing ¹⁴C-glucose, then incubation, and, finally, collection and radioassay of ¹⁴CO₂ formed by the metabolism of microorganisms, if present, in the sample. Radioassay is done with a gas ionization chamber and both aerobic and anaerobic microorganisms can be detected by this method. Automated instruments using this principle are commercially available. This method is useful, particularly because it requires only a short time, about 3–24 h, compared to many days in other methods approved by the *USP*.

8.2.2 Apyrogenicity

All radiopharmaceuticals for human administration are required to be pyrogen free. Pyrogens are either polysaccharides or proteins produced by the metabolism of microorganisms. They are 0.05–1 μ m in size and, in general, are soluble and heat stable. Bacterial products, the so-called bacterial endotoxins (BE), are the prime examples of pyrogens, but various chemicals also can add pyrogens to a radiopharmaceutical solution. Following administration, pyrogens produce symptoms of fever, chills, malaise, leukopenia, pain in joints, flushing, sweating, headache, and dilation of the pupils. Pyrogenic reactions can develop in subjects within 30 min to 2 h after administration but usually subside in 10–12 h after onset. These reactions are rarely fatal.

As already mentioned, sterility of a solution does not guarantee its apyrogenicity nor does sterilization destroy the pyrogens in a radiopharmaceutical. There is no specific method for making a sample apyrogenic. Since pyrogens arise mainly from the metabolism of bacteria, the best recourse to prevent pyrogenic contamination is to use sterile glassware, solutions, and equipment under aseptic conditions in any preparation procedure. Glassware can be made pyrogen free by hot-air sterilization at 175°C for several hours. One must use high-quality chemicals, distilled water, and glassware to avoid pyrogens. If one uses all these materials conforming to USP specifications and is absolutely meticulous in carrying out chemical compounding, then pyrogen-free radiopharmaceuticals can be prepared without difficulty.

Pyrogenicity Testing

USP Rabbit Test

The USP 39 bases the pyrogen test on the febrile response in rabbits within 3 h after injection of the material. Three mature normal rabbits weighing not less than 1.5 kg are chosen for the test, and their temperatures are controlled by keeping them in an area of uniform temperature. The volume of the test sample must be an equivalent human dosage, on a weight basis, and often three to ten times the human dosage by volume is used to achieve a greater safety factor. The test sample is injected into the ear vein of each of the three rabbits. The rectal temperatures of the animals are measured 1, 2, and 3 h after injection of the test material. If the rise in temperature in individual animals is less than 0.6° C and if the sum of the test material apyrogenic. If any of the above conditions is not fulfilled, the test must be repeated with five more rabbits. If not more than three of the total eight animals show a temperature rises does not exceed 3.7° C, the material is considered pyrogen free.

Bacterial Endotoxin Test

A rapid method for bacterial endotoxin test (BET), also called the limulus amebocyte lysate (LAL) test, is employed for the detection and quantitation of endotoxintype pyrogens. This method uses the lysate of amebocytes from the blood of the horseshoe crab, *Limulus polyphemus*. The principle of the test is based on the formation of an opaque gel by pyrogens in the presence of Ca^{2+} upon incubating the sample with the LAL at 37°C. An assay mixture usually consists of 0.1 ml LAL and a test sample at pH 6–8. The reaction takes place within 15–60 min after mixing and depends on the concentration of pyrogens. The formation of a gel indicates the presence of pyrogens. The thicker the gel, the greater the concentration of pyrogens in the sample.

The LAL is commercially available in lyophilized form in a kit. It should be stored at 5°C. In the kit, in addition to LAL, *Escherichia coli* endotoxin and pure water are supplied as the standards that are used to check the sensitivity of the test. The sensitivity of the test is given in endotoxin units (EU). The BET test is conducted on unknown samples as well as on *E. coli* endotoxin and water samples. Usually 0.1 ml of each sample and LAL are mixed together, and the mixture is incubated at 37°C for 60 min. If the *E. coli* endotoxin sample shows gel formation (positive control) and the water sample shows no gel formation (negative control), then unknown samples are considered positive or negative depending on whether they form gel or not.

Two requirements must be met for acceptance of the test as official. First, a concentration limit (EU/ml or EU/mg) and a maximum dosage (ml/kg or mg/kg) of pyrogen to be administered to humans must be assigned to each parenteral drug including radiopharmaceuticals. Manufacturers must establish the concentration limit for a drug using proper BET tests before FDA approval. For all radiopharmaceuticals, the endotoxin concentration limit is 175/V USP EU per ml of injection per kg, where V is the maximum recommended total dosage in ml at the expiration date or time. Second, the LAL test must be validated against an FDA-approved reference standard of endotoxin. For validation, an inhibition and enhancement test must be included in the procedure to ascertain the effect of ingredients in the sample on the BET procedure. The maximum permissible dosage for parenteral administration (except intrathecal) is 5.0 EU/kg, whereas it is 0.2 EU/kg for intrathecal administration.

Alcoholic solvents cause precipitation of the lysate and therefore must be avoided. Several proteins at high concentrations tend to produce gel even without endotoxin and should be diluted to appropriate concentrations before the test. Calcium ions are essential for gel formation in the LAL test. When metal chelates such as chelates of ^{99m}Tc and ¹¹¹In are tested for pyrogens, the free chelating agents may remove calcium ions by complexation from the test sample leaving insufficient or no Ca²⁺ ions for gel formation. Thus, before LAL testing, additional amounts of Ca²⁺ ions may need to be added to samples of metal chelates to complex all unbound chelating agents. This will leave sufficient Ca²⁺ for gel formation in the test sample.

8.2.3 Toxicity

Before a radiopharmaceutical is approved for human use, as with any other drug, its toxic effect and safe dosage must be established. Toxic effects due to radiopharaceutical administration include alterations in the histology or physiologic functions of different organs in the body or even death. These tests for acute or chronic toxicity can be carried out in various animals such as mice, rats, rabbits, and dogs. Typically they involve the administration of the radiopharmaceutical in certain dosage to animals for 2–6 weeks. The animals are sacrificed at various time intervals, and then a detailed autopsy examination of different organs is performed to observe any pathologic changes.

A quantity, called the LD_{50/60}, describes the lethal effect of a radiopharmaceutical; it is the dosage required to produce 50% mortality in 60 days in a species after administration of the radiopharmaceutical. For determination of the LD_{50/60}, the test substance is injected in increasing dosages into a large group of animals. The dosage at which 50% mortality of the animals is observed in 60 days following administration is established as the LD_{50/60} for the material. The test must be carried out in at least two species of animals. From these studies, a safety factor is established, which should be as large as practicable for human use. It must be borne in mind that following the administration of drugs different animal species react differently from humans, and these species differences must be taken into consideration when the safety dosage of a radiopharmaceutical is determined for humans.

In most radiopharmaceuticals, toxicity arises from the pharmaceutical part of the radiopharmaceutical, not from the radionuclide part, because the latter in diagnostic dosages does not cause severe toxic effects. Since the quantity of radiopharmaceuticals used is usually small, the toxic effect is minimal. Because of strict regulations on the use of animals for research, nowadays toxicity is preferably studied using cell culture and computer modeling rather than in animals.

8.3 Record Keeping

In a radiopharmaceutical operation, record keeping is mandatory for legal reasons as well as for tracing any faulty preparation in the case of a poor-quality scan. These records help trace the history of a particular radiopharmaceutical should any untoward effect take place in a patient due to its administration. In some institutions, records are kept on separate sheets for each individual product, whereas in others a single logbook is used in which a separate section is reserved for each individual product. Details of record keeping are given in Chaps. 9 and 11.

Questions

- 1. What are quality control tests and why are they needed for a radiopharmaceutical?
- Define radionuclidic purity and give some examples. Is ⁹⁹Mo in a ^{99m}Tc-labeled compound a radionuclidic or radiochemical impurity? Describe how the radionuclidic impurity can be estimated.
- 3. Define the radiochemical purity of a radiopharmaceutical. How do radiochemical impurities originate? Describe various methods of determining the radiochemical impurity in a radiopharmaceutical.
- 4. What are the three radioactive species in a ^{99m}Tc-radiopharmaceutical? Explain their origin.
- 5. For ^{99m}Tc-radiopharmaceuticals. ITLC methods are routinely used to detect radiochemical impurities. Which solvent and solid phase system is most common for this purpose and why?
- 6. An ITLC of a ^{99m}Tc-MDP sample was made with ITLC-SG paper and acetone. The strip was cut in the middle; the activity in the solvent front portion was found to be 3500 cpm and in the origin portion 38,000 cpm. Calculate the yield and impurity in percent. What is this impurity? Is the sample at origin after chromatography pure ^{99m}Tc-MDP?
- 7. If the experiment in Question 6 were performed with saline, what would be the results?
- 8. Describe the methods of sterilization and sterility testing.
- 9. What are pyrogens and their reaction symptoms? Describe the rabbit test and LAL test for pyrogens.
- 10. Define the $LD_{50/60}$ of a radiopharmaceutical. How can you determine this quantity?

References and Suggested Reading

- Avis KE, Leuchuk JW. Parenteral preparations. In: Avis KE, Lieberman HA, Lachman L, editors. Remington: the science and practice of pharmacy. 21st ed. Baltimore: Lippincott, Williams and Wilkins; 2005.
- Bobinet DD, Williams GC, Cohen MB. Comparison of commercial pyrogen testing laboratories. Am J Hosp Pharm. 1976;33:801.
- Dewanjee MK. The chemistry of 99mTc-labeled radiopharmaceuticals. Semin Nucl Med. 1990;20:5.
- Eckelman WC, Levenson SM, Johnston GS. Radiochemical purity of ^{99m}Tc-radiopharmaceuticals. Appl Radiol. 1977;6:211.
- Centre for Drug Evaluation and Research (CDER). Guideline on validation of the limulus Amebocyte lysate test as an end-product endotoxin test for human and animal parenteral drugs, biological products, and medical devices. Rockville: U.S. FDA; 1987.
- Krogsgaard OW. Radiochemical purity of various ^{99m}Tc-labelled bone-scanning agents. Eur J Nucl Med. 1976;1:15.
- Pauwels EKJ, Feitsma RIJ. Radiochemical quality control of ^{99m}Tc-labeled radiopharmaceuticals. Eur J Nucl Med. 1977;2:97.
- Procedure manual radiochemical purity of radiopharmaceuticals using Gelman Seprachrom[™] (ITLC[™]) chromatography. Ann Arbor: Gelman Science, Inc.; 1977.

- Meyer GJ, Coenen HH, Waters SL, et al. Quality assurance and quality control of short-lived radiopharmaceuticals for PET. In: Stöcklin G, Pike VW, editors. Radiopharmaceuticals for positron emission tomography: methodical aspects. Dordrecht: Kluwer; 1993. p. 91.
- Robbins PJ. Chromatography of technetium ^{99m}Tc-radiopharmaceuticals a practical guide. New York: Society of Nuclear Medicine; 1984.
- Shoup TM, Olson J, Hoffman JM, et al. Synthesis and evaluation of [18F]1-amino-3-fluorocyclobutane-1-carboxylic acid to image brain tumors. J Nucl Med. 1999;40(2):331–8.
- United States Pharmacopeial Convention. U.S. pharmacopeia 39 & National formulary 34. Rockville: The United States Pharmacopeial Convention; 2016.

Nuclear Pharmacy

9.1 Concept

We generally come across two terms in the literature: *nuclear pharmacy* and *radio-pharmacy*. Is there any difference between the two? In my opinion, there is no difference between the two terms, and they can be used interchangeably. The use of one term or the other is a matter of individual choice. The term *nuclear pharmacy* will be used in this chapter.

In a nuclear pharmacy, radiopharmaceuticals are prepared, stored, and dispensed primarily for human use, just as regular drugs are in a pharmacy. Nuclear pharmacy is staffed with trained personnel such as nuclear pharmacists and radiochemists, that is, chemists or pharmacists with special training in radiopharmaceutical chemistry. The nuclear pharmacy may serve as a center for education and training of pharmacy and nuclear medicine technology students and engage in basic research in the design and development of new radiopharmaceuticals. Here the remedy for any adverse reaction in humans due to the administration of radiopharmaceuticals is sought and found. Nuclear pharmacists can provide education and consultation to the patients and healthcare personnel in this field.

9.2 Design of Nuclear Pharmacy Unit

Several issues should be kept in mind when designing a nuclear pharmacy unit. Clean air environment, appropriate airflow, and segregation of areas for compounding and dispensing of drugs are important issues to consider. In addition, protection of personnel from radiation exposure, prevention of contamination of work area and radiation detection instruments, and disposal of radioactive waste are the common concerns. The design of a nuclear pharmacy should take into account daily operational protocols, proper utilization of available space, and provisions for future growth.



A nuclear pharmacy should be located within or near the nuclear medicine department because there is a close relationship between the two units. The nuclear pharmacy area can be as small as a 12 ft. \times 12 ft. (4 m \times 4 m) room, depending on the volume of the operation. For a larger operation, the unit may consist of several rooms. Ideally, it should have enough space for accommodating offices, a counting room, and a health physics laboratory on one side of a corridor and a high-radiation (hot lab) laboratory, a compounding room, a storeroom, and a dispensing area on the other side. A conceptual design of a nuclear pharmacy unit is presented in Fig. 9.1. The whole area should have minimal access to the public and the patient in order to avoid radiation hazard. Many institutions have a designated area for storage and disposal of radioactive waste away from departments, and the nuclear pharmacy can share this facility for its own storage and waste disposal. The daily transfer of radioactive waste to a central area for storage and disposal eliminates high levels of radiation within the nuclear pharmacy.

The laboratory area where compounding and dispensing are done should be equipped with workbenches made of stainless steel or wood covered with laminated plastic. The floor should be made of removable tiles or be covered with rubber mat; in the event of spillage, the contaminated tiles or rubber mat can be readily replaced with new ones. In each laboratory there should be an appropriate number of stainless steel sinks deep enough to prevent splashing and fitted with foot control. Each laboratory should have exhaust fumehoods fitted with filters to absorb gaseous and particulate radioactive materials, particularly radioiodine and radioxenon. A laminar flow hood should be installed in the dispensing area for a sterile environment. The storage area should be well built with thick concrete walls, and the walls of the storage safes should be lined with lead for radiation shielding. A safety shower and an eye wash should be installed for use in the case of major body contamination.

Various pieces of equipment and accessories are essential for efficient operation of nuclear pharmacy. Examples are (1) a dose calibrator capable of measuring various types and levels of radioactivity, (2) chromatography equipment, (3) radiation survey meters, (4) an area monitor, (5) a pH meter, (6) a light microscope for particle size determination, (7) a NaI(Tl) or Ge(Li) detector coupled to a multichannel analyzer to identify contaminants in radiopharmaceuticals, (8) lead-lined refrigerators and freezers to store cold kits and radiopharmaceuticals under refrigeration, (9) a hot water bath, (10) a dry heat oven, and (11) a well-type NaI(Tl) counter equipped with an automatic sample changer for counting multiple samples. In addition, lead



barrier shields (L-Blocks) (Fig. 9.2) are essential for handling radioactive materials behind them to minimize radiation exposure. A sufficient number of lead containers of various designs to hold syringes containing radioactivity are important for transporting radioactive materials (Fig. 9.3). Syringe shields are essential for injection for radiation protection unless contraindicated (Fig. 9.4a). Vial shields (Fig. 9.4b) are needed to hold the kit vials containing formulated radiopharmaceuticals. A unit dosage wall rack is utilized to hold all unit dosage syringe holders containing precalibrated dosages (Fig. 9.5). Used needles are disposed of in the sharp containers (Fig. 9.6a), and radioactive waste is disposed of in lead-lined waste bin (Fig. 9.6b). Lead-lined or leaded gloves, aprons, and eyeglasses are essential pieces of radiation safety equipment in a nuclear pharmacy operation. An autoclave is needed to sterilize certain materials in nuclear pharmacy, and a freeze dryer would serve to lyophilize liquid radiopharmaceuticals, if needed. An incubator is useful for incubation for sterility testing of radiopharmaceuticals. Certain basic equipment such as a balance, a centrifuge, pipetters, and a calculator should be available in nuclear pharmacy.

Various software packages designed to manage the operation of nuclear pharmacies are available from several vendors. These programs are primarily used for record keeping of data related to nuclear pharmacy. Data such as logging of shipments, preparation of radiopharmaceuticals, dispensing of radiopharmaceuticals,



Fig. 9.3 Different kinds of lead syringe holders for transporting syringes containing radioactive material (Courtesy of Biodex and Pinestar Technology Inc., Greenville, PA)



Fig. 9.4 (a) Lead syringe shield; (b) vial shield (Courtesy of Biodex and Pinestar Technology Inc., Greenville, PA)



Fig. 9.6 (a) Sharp container; (b) lead-lined waste container (Courtesy of Biodex and Pinestar Technology Inc., Greenville, PA)

and waste disposal can be stored in these programs. Survey and wipe test results and patient data also can be saved in these programs. All nuclear pharmacies should have these programs available for management of nuclear pharmacies.

9.3 USP General Chapter <797>: Pharmaceutical Compounding – Sterile Preparations

In order to protect the patients from undue harm, including death, due to microbial and pyrogen contamination, inappropriate quality, and variations in strength of ingredients in a drug, the US Pharmacopeial Convention (USP), in concurrence with the FDA, introduced in 2004 the first version of USP General Chapter <797>, "Pharmaceutical Compounding – Sterile Preparations," which sets standards for compounding sterile preparations. Following a review of the practical applications of the standards in subsequent years, a revision of Chapter <797> was introduced in 2008 to clarify old standards and to add new standards. These standards detail the procedures and requirements including environmental conditions for the preparation of compounded sterile preparations (CSPs). A CSP is a sterile preparation made by combining, diluting, pooling, or altering a drug product and differs from drugs prepared by reconstituting a conventional drug according to the manufacturer's instruction.

Again in 2015, the USP has proposed a draft revision of Chapter <797> with significant changes in standards for compounding CSPs. At the time of this writing, it is going through the comments period from stakeholders, after which it will be published. In the following, only salient points of the chapter are highlighted, with occasional allusion to the proposed updates. Readers are referred to USP 39 for a detailed description.

CSPs include biologics, diagnostics, drugs, nutrients, and radiopharmaceuticals and have been grouped into the following categories: low-risk level, medium-risk level, and high-risk level. As the names imply, the risk levels are based on the level of acceptable microbial contamination allowed during compounding and are assigned depending on where in the facility the CSPs are compounded. The details of the standards and requirements for these different categories of risk are given in the Chapter <797> publication. The proposed updates change three groups of CSPs to two groups, namely, Category 1 and Category 2, based on several factors of periodic checks, namely, among others, hand hygiene, garb, media fill testing, building facilities, environmental monitoring, and release testing. A parameter, *Beyond Use Date* (BUD), is defined as the date or time from the date of compounding, beyond which CSP cannot be used and must be discarded. Category 1 CSPs are assigned a BUD of 12 h or less at controlled temperature or 24 h or less at temperature of refrigeration, whereas Category 2 CSPs are assigned a BUD of greater than 12 h at controlled room temperature or greater than 24 h at temperature of refrigeration.

Several factors differentiate between standards for sterile and non-sterile compounding, namely, ISO-classified air environments, personnel garbing, gloving, and personnel experience and training in aseptic techniques. Environmental monitoring

Table 9.	ISO Classification	
of partice	late matter in room air	1

ISO ^b Class	Particle count ^a /m ³
3	35.2
4	352
5	3520
6	35,200
7	352,000
8	3,520,000

^aLimits are given in particles of 0.5 μ m and larger per cubic meter (ISO)

^bISO - International Organization for Standardization

is primarily performed by air particle measurement. International Organization for Standardization (ISO) offers different classifications of environment based on the number of particles per cubic meter in an area (Table 9.1). Sterility and pyrogen testings are also important factors to consider. Compounding personnel must be well trained in techniques and all standards of compounding. Standard operating procedures, master formulations, and compounding records must be maintained. Compounding areas must be cleaned and disinfected on a regular basis.

According to USP Chapter <797>, radiopharmaceuticals are considered low-risk CSPs and shall be compounded from sterile components in closed sterile containers and with a volume of 100 ml or less for a single-dose injection or not more than 30 ml taken from a multiple-dose container. The compounding shall be carried out in shielded vials and syringes in ISO Class 5 environment located in an ISO Class 8 or cleaner environment.

Multidose vials containing ^{99m}Tc compounds prepared in ISO Class 5 environment and punctured by needles with no direct contact contamination may be used up to the time recommended by the manufacturer. Properly shielded vials of radiopharmaceutical CSPs may be stored and transported in ambient environment without specific ISO class. Cell labeling (red blood labeling and white blood cell labeling) must be carried out in ISO Class 7 area.

⁹⁹Mo–^{99m}Tc, ⁸²Sr–⁸²Rb, and ⁶⁸Ge–⁶⁸Ga generators shall be stored and eluted as recommended by the manufacturers, following state and federal regulations. These generators shall be eluted in ISO Class 8 or cleaner environment. For short-lived radionuclides with half-life shorter than 15 min (e.g., ⁸²Sr–⁸²Rb generator), they can be handled according to manufacturer's instructions (e.g., near the patient in the scanning room). The ALARA principle must be adopted in handling the generator.

Category 1 radiopharmaceuticals shall be prepared in a compounding area segregated by a line of demarcation. Materials and garb used in a patient care and treatment area shall not cross the line of demarcation into the segregated compounding area.

Positron emission tomography (PET) radiopharmaceuticals are treated separately because of the nature of compounding, and their standards are addressed in USP Chapter <823> Radiopharmaceuticals for Positron Emission Tomography-Compounding.

9.4 Operation of Nuclear Pharmacy

The daily operation of a nuclear pharmacy involves the following steps: (1) receiving of radioactive materials, (2) preparation of radiopharmaceuticals, (3) quality control tests of radiopharmaceuticals, (4) storage, (5) dispensing, (6) radioactive waste disposal, and (7) infectious waste disposal.

Before the day's operation is begun, the nuclear pharmacist must ensure that all equipment in nuclear pharmacy such as the dose calibrator, survey meter, and NaI(Tl) well counter are in good operating condition. This is accomplished by proper calibration of each device with standard radioactive sources (e.g., ¹³⁷Cs, ²²⁶Ra, ⁵⁷Co, etc.). If a malfunction is noted in any instrument, it must be remedied before a measurement is made. All personnel in nuclear pharmacy must wear a laboratory coat and gloves while handling radioactive materials. A pair of long tongs should be used in the handling of high activity, preferably behind a lead barrier shield.

9.4.1 Receiving and Monitoring of Radioactive Packages

Individual users or institutions are authorized to possess and use radioactive materials upon issuance of a radioactive material license by the NRC or the Agreement State Agency (see Chap. 11). Prior to shipping, the suppliers require documentation of licensing of the user as to the types and limits of quantities of radioactive material. Normally, delivery of radioactive shipments is made directly to the nuclear medicine department or nuclear pharmacy because of the short half-lives of various radionuclides. In some institutions, radioactive shipments are delivered to the Radiation Safety Office, which then disburses to the respective user after the proper monitoring of the package for external exposure and contamination.

Monitoring of packages is required according to 10CFR20 if the packages are labeled as containing radioactive material, and is described in detail in Chap. 11. Briefly, the packages should be monitored within 3 h if delivered during normal hours or within 3 h from the beginning of the next working day if delivered after working hours. The survey must be done on the surface of the package and at 1 m, using a GM survey meter, and the readings should not exceed the limits of 200 mR/h and 10 mR/h, respectively. The wipe test of the package surface must be done according to 10CFR20 (see Chap. 11), and the limit for the test is 0.003 μ Ci (6600 dpm or 111 Bq) per 300 cm². All data must be entered in the receipt book (Fig. 9.7).

9.4.2 Preparation of Radiopharmaceuticals

All formulating should be carried out in a laminar flow hood and under aseptic conditions. Work should be done behind the lead barrier shields, and gloves should be worn for handling radioactivity. To satisfy the criteria of clean environment

		-+		_	-	-	_	_		_	_	 _	_	_		_	_	_	_	_	_	_	_
Received	Dy																						
Wipe Test	() or ()																						
*Survey at Surface	at 1 meter																						
ivity	Measured																						
Acti	Calibrated																						
Date of	Calib.																						
Date	Received																						
Total	Vol. (ml)																						
No. of	Vials																						
-	LOT NO.																						
	MITC.																						
	Isotope-unemical																						

RADIOISOTOPE RECEIPT FORM

Fig. 9.7 Typical radioisotope receipt form

Γ



Fig. 9.8 <797> compliant dose dispensing hood (Courtesy of Biodex and Pinestar Technology Inc., Greenville, PA)

recommended by USP General Chapter <797>, vendors have developed small dose dispensing hoods for formulating and dispensing radiopharmaceuticals (Fig. 9.8). These hoods are made of stainless steel with polycarbonate sides, through which hands are inserted inside to manipulate, and an L-Block in the front. Electric motors blow air through HEPA filters to provide an environment of ISO Class 5. These hoods are useful and financially beneficial for smaller nuclear pharmacies.

Many radiopharmaceuticals, particularly ^{99m}Tc-labeled radiopharmaceuticals, are prepared daily for nuclear medicine tests. Several long-lived radiopharmaceuticals including ¹²³I-MIBG are normally available from the commercial firm. For ^{99m}Tc-labeled radiopharmaceuticals, the ^{99m}Tc activity is eluted from the Moly generator daily early in the morning. After assaying in the dose calibrator and performing the tests for molybdenum breakthrough, aluminum breakthrough, pH, and radiochemical purity by chromatography, the ^{99m}Tc vial is identified with a label containing the information as to the total activity, concentration, time of calibration, and a nuclear pharmacy control number. This information should be recorded on the generator control sheet (Fig. 9.9).

^{99m}Tc-labeled radiopharmaceuticals are prepared using kits from various manufacturers. The total ^{99m}Tc activity to be added to the kit vial depends on the number of patients and their scheduled time for the study, of course, within the limit recommended by the manufacturer. Sufficient activity must be added to allow for decay over the period of use. Sometimes, the ^{99m}Tc-eluate needs to be diluted because of the high concentration, and it should be done with isotonic saline without preservative. Caution should be exercised not to introduce air in the vial to prevent oxidation of reduced ^{99m}Tc. Most ^{99m}Tc-labeled preparations are made by simply mixing the Date of Calibration: Activity: Manuf. Lot No:

99mTc-eluate from Moly generator

DAY	DATE	TIME	ACTIVITY (mCi)	VOLUME (ml)	MO-99 (μCi)	MO-99/Tc-99m (µCi/mCi) A.L. ≥ 0.0425	AI ³⁺	Tc-99m LOT NO.	TECH. NAME
×									
ONDA									
Σ									
AΥ									
UESD									
SDAY									
/EDNE									
5									
SDAY									
THUF									
RIDAY									
Ë									
۲ ۲									
LURDA									
SAT									
×									
SUNDA									
0									

Fig. 9.9 Typical log sheet for ^{99m}Tc-eluate from ⁹⁹Mo-^{99m}Tc generator

kit contents with ^{99m}Tc activity. In some formulations, sequential addition of different ingredients is needed, and in others, heating of the contents is required. After reconstitution, a control number is assigned to the kit vial. A label with information such as control number, product name, concentration, date and time of calibration, and expiration is pasted on the lead container. A radiation label is also placed on the container. The above information as well as other items such as manufacturer's control number for the kits, saline if used for dilution, the volume of saline, and so forth are also recorded in a logbook (Fig. 9.10).

Œ
0
~
0
ш
~
-
1
~
0
ш
\overline{a}
2
4
5
~
Ш,
◄
÷
÷
Δ.
0
—
7
\geq
LL L
~
_ ≿_
ົ
ő
1
U.
-

	Prep'd By								
	Conc. (mCi/ml)								
Total	Vol. (ml)								
	Vol. (ml)								
Saline	Lot No.								
	Mfr.								
	Lot No.								
Data	Vol. (ml)								
Kit I	Mfr.								
	Type								
	Vol. (ml)								
technetate	Activity (mCi)								
Tc-99m Per	Lot No.								
	Mfr.								
	NP No								
	Time								
	Date								

Fig. 9.10 ^{99m}Tc-labeled radiopharmaceutical preparation record sheet

9.4.3 Quality Control of Radiopharmaceuticals

As already mentioned, each radiopharmaceutical must pass several quality control tests before dispensing for human administration. Regular checks should be made for the sterility, apyrogenicity, and radiochemical purity of all labeled products. Commercial vendors often guarantee the quality and efficacy of labeled compounds, and in those situations, rigorous quality control tests are not needed at the receiving institutions. However, ^{99m}Tc-labeled radiopharmaceuticals are prepared daily, and the labeling efficiency must be determined by thin-layer or paper chromatography (see Chap. 8). Preparations with poor labeling should be discarded. Colloidal and macroaggregated preparations must be checked for particle size, and preparations with inappropriate particle size must be discarded. New radiopharmaceuticals and investigational drugs require sterility and pyrogen testing besides radiochemical purity. For short-lived radionuclides, the sterility and pyrogen tests can be conducted on an "after-the-fact" basis. Such radiopharmaceuticals are administered to humans, while the biological tests are continued until the final results are obtained. If the results are positive, the subject is then followed up for any symptoms for which remedial medications are instituted.

9.4.4 Storage

All radiopharmaceuticals should be properly stored so that they are not degraded by light or temperature. For example, ^{99m}Tc-labeled macroaggregated albumin should be stored at 2–4°C to prevent any bacterial growth and denaturation of proteins, whereas ^{99m}Tc-sulfur colloid can be stored at room temperature without any adverse effect.

Since radiation exposure is a serious problem in nuclear pharmacy, vials or syringes containing radiopharmaceuticals must be stored in lead containers or behind lead shields. In many institutions, lead safes are built into the walls of the room for storage of radioactive materials. To prevent the production of bremsstrahlung by β^- in high-Z materials such as lead, ³²P-labeled compounds and ⁸⁹Sr-SrCl₂ are stored in low-Z material containers such as plastic or Lucite containers.

9.4.5 Dispensing

Dispensing starts with a prescription or a hospital requisition made in writing by a physician for a nuclear medicine study for a patient. In the case of a centralized nuclear pharmacy (see later), a verbal order by telephone can replace a written prescription. Each prescription or requisition should contain patient's name and identification number (clinic or hospital number), age, the date, the type of study, the type and dosage of radiopharmaceutical, and the signature of the authorized user physician.

In many institutions, the dosages for many routine nuclear medicine studies are standardized, such as 20-mCi (740 MBq) ^{99m}Tc-MDP for whole-body bone imaging

and 4-mCi (148 MBq) ^{99m}Tc-MAA for lung perfusion imaging and, therefore, may be omitted in a prescription. A list of these standardized dosages should be readily available in nuclear pharmacy. Before a dosage is drawn, the volume to be drawn is calculated from the knowledge of the concentration and the date and time of calibration by means of a decay table for the radionuclide in question. The required volume is then drawn in a syringe aseptically behind the lead barrier shield, and the final dosage is assayed in the dose calibrator. Often, radiopharmaceutical dosages are drawn precalibrated and placed in the rack (Fig. 9.5) for later use.. As a matter of policy, the dosages drawn should not deviate by more than $\pm 20\%$ from the prescribed dosages at the time of administration. The syringe containing the dosage is labeled as to its content and quantity and then placed in a lead syringe holder. If the syringe label is not visible from outside, the holder must be labeled. If the dosage is to be transported to a distant facility, it should be assayed again in the dose calibrator on arrival. Proper decay correction must be made for the time between the first and second measurements.

Each time a radiopharmaceutical dosage is dispensed, the date and time of dispensing, the patient's name and identification number, the name, quantity, and control number of the radiopharmaceutical, and the name of the individual dispensing the dosage must be entered in the radiopharmaceutical dispensing record book (Fig. 9.11).

In a centralized nuclear pharmacy, the patient's name, the physician's name, and a prescription number are given to each dosage of a radiopharmaceutical dispensed. The receiving facility must enter all pertinent information in the record book.

9.4.6 Radioactive Waste Disposal

Radioactive waste generated in nuclear medicine and nuclear pharmacy (e.g., syringes, vials, needles, contaminated papers, tissues, etc.) is disposed of according to the methods outlined in 10CFR20 and 10CFR35 (see Chap. 8). These methods include decay-in-storage, release into sewerage system, incineration, and burial in a landfill. Because of the use of radionuclides with short half-lives, most of the radioactive waste in nuclear medicine is disposed of by the decay-in-storage method. In institutions where unit dosages are purchased from a central nuclear pharmacy, the syringes and vials with residual activities can be returned to the vendor who then disposes of them by following specific methods.

Although the columns of the ⁹⁹Mo-^{99m}Tc generators may be decayed to background for disposal to normal trash, a convenient method of disposing of these generators is to return them to the vendors who let them decay and later dispose of them. The out-of-use generators are packaged into the original shipping container, which is then properly labeled according to the instructions of the vendor and the Department of Transportation. Normally, the old generator is picked up by the authorized carrier when a new one is delivered.

Records must be maintained as to the date of storage, the amount stored and disposed, the date of disposal, the meter used to monitor, and the name of the individual who is disposing.

		<u> </u>	_	 	 _	_	_	_	 	 	 	 	-
Name of	Disperser												
Time of	Injection												
Activity	(Dispensed)												
Calib.	Time.												
SRD Calib.	Dose.												
L RECO	Study												
HARMACEUTICA	Clinic No.												
RADIOP	Patient's Name												
SAGES	Product												
UNIT DO	NP No.												
	Date												

All residual activity is disposed of according to NRC or Agreement State regulations.

Fig. 9.11 Radiopharmaceutical dispensing record sheet

9.4.7 Infectious Waste Disposal

In general, the states regulate the disposal of infectious waste containing body fluids, tissue, and other potentially infectious materials generated in healthcare institutions. Infectious waste may be incinerated, chemically treated, steam or dry sterilized, or sterilized with ionizing radiation. Blood, blood products, body fluids, and excreta can be discharged into the sanitary disposal system, if not otherwise prohibited. Infectious waste and items should be stored in puncture-resistant, leakresistant bags or containers and conspicuously labeled with the international biohazard symbol. Local regulations may limit the amount of infectious waste that can be stored on-site and the storage time. If radioactive infectious waste is stored for a lengthy period, appropriate precautions such as spraying with disinfectants, freezing, and tightly sealing the container must be taken to prevent putrefaction.

9.5 Nuclear Pharmacist

Nuclear pharmacists are individuals who are formally trained in all aspects of nuclear pharmacy operation described above and, as required, are certified and licensed by appropriate authorities to practice it. The formal education involves courses on anatomy, physiology, pharmacology, drug formulation, radioactive decay, radionuclide generator kinetics, radiation protection, regulations, quality control, etc. The NRC approves "authorized" nuclear pharmacists in two ways: those who are certified by nuclear pharmacy specialty board and those who have had 700 h of organized courses that include a combination of supervised practical experience under a preceptor (10CFR35.55 and 10CFR35.59) (see Chap. 11) and a minimum of 200 h of didactic and training courses. This experience must be attested by the preceptor. Such authorization allows nuclear pharmacists a wide latitude of freedom in their practice.

Pharmacy graduates who are licensed, have 4000 h of training and experience in nuclear pharmacy, and have passed a nuclear pharmacy board examination are also approved as authorized nuclear pharmacist by the NRC. Individuals who are not authorized by the NRC must practice in a nuclear pharmacy under the supervision of an authorized nuclear pharmacist or an authorized user. Authorized nuclear pharmacists can also serve as radiation safety officers with the approval of the NRC.

In the USA, there are several institutions, which offer baccalaureate (Bachelor of Nuclear Pharmacy – BNP), master's, and PharmD degrees in nuclear pharmacy, and duration of the degree course runs for varying periods for different degrees at different institutions. Also online courses in nuclear pharmacy are available to qualify for a nuclear pharmacist.

9.6 Centralized Nuclear Pharmacy

Since radiopharmaceuticals play an important role in nuclear medicine, it is essential to evaluate the cost-effectiveness of the preparation, distribution, and dispensing of various radiopharmaceuticals. It is rather expensive to operate a separate nuclear pharmacy within a small nuclear medicine department. On the other hand, a large nuclear medicine department should be able to run a nuclear pharmacy unit of its own with economic and operational benefit.

A centralized nuclear pharmacy in any region having reasonable transportation facilities can lead to significant savings of money and personnel time. It must be shared by many, if not all, hospitals and private practices in a given region; otherwise it may not be feasible to run it economically.

A centralized nuclear pharmacy would have the following advantages: radiopharmaceuticals could be available in a unit dosage form; the time the technologist spends in radiopharmaceutical preparation and dispensing could be used for clinical procedures; because a centralized nuclear pharmacy serves many institutions, the number of workers directly involved in the operation of nuclear pharmacy is reduced, and radiation exposure to the workers in general is minimized; and there is also less possibility of radioactive contamination of the nuclear medicine facilities than when radiopharmaceuticals are prepared in individual institutions.

The primary advantage of a centralized nuclear pharmacy is an economic one. The preparation of radiopharmaceuticals from the basic ingredients in a centralized nuclear pharmacy would minimize the cost, if permissible by nuclear pharmacy guidelines approved by the FDA (see Chap. 11 as to when a registration is required in various situations of nuclear pharmacy practice). Even the kits purchased in bulk quantities from the manufacturers could offer significant economic benefits. Although the kits are guaranteed for sterility and apyrogenicity by the manufacturers, the in-house radiopharmaceutical preparation from basic ingredients requires these tests and thus adds to the total cost of manufacturing. In smaller institutions, where the patient load is not heavy, obviously the use of kits is not economical because relatively few studies are performed with the radiopharmaceutical from a kit and the bulk of it is wasted. A centralized nuclear pharmacy could provide an appreciable economic advantage to these institutions by dispensing unit dosages, as needed.

Ideally, a centralized nuclear pharmacy should be located at the center of a geographic region and supply all radiopharmaceuticals in multidosages or unit dosages, as needed, to the participating hospitals. An authorized nuclear pharmacist should be in charge of the unit. The nuclear pharmacist, or other personnel under his supervision, should prepare radiopharmaceuticals daily under aseptic conditions; test for radiochemical purity, sterility, and apyrogenicity; and finally dispense them, as required, to all institutions. The assay of the unit dosage or multidosage preparation should be doubly made by both the nuclear pharmacist in the central nuclear pharmacy and the technologist in the nuclear medicine department of the participating institution. The basic operation of a centralized nuclear pharmacy is similar to that of a regular nuclear pharmacy. The only difference lies in the organizational aspects of the operation. Since the centralized nuclear pharmacy serves a number of institutions in different locations, a precisely timed protocol is needed for procuring all the requisitions and then preparing and shipping radiopharmaceuticals to different customers at specified times. All requisitions from participating institutions should be received well before shipping. The shipping can be done via airplane, taxi, or car, depending on the distance and the transportation facilities available. If the shipping is to be done via an airline, the departure and arrival times should be chosen to match the time of examination requested by the ordering facility. Centralized nuclear pharmacies must be operated under an authorized nuclear pharmacist.

Questions

- 1. Suppose you received a shipment of radiopharmaceuticals in your nuclear pharmacy. As a nuclear pharmacist, what are the steps you would take until it is dispensed?
- 2. What are the specific conditions of monitoring the radioactive shipments?
- 3. What are the limits of survey readings on radioactive shipments that, if exceeded, require notifying the NRC or the Agreement State?
- 4. Give a general description of a nuclear pharmacy operation in a hospital.
- 5. How do you justify a centralized nuclear pharmacy in a large community having several hospitals? What are the salient advantages of a centralized nuclear pharmacy?
- 6. What information should be included in the record of the reconstituted ^{99m}Tc-labeled radiopharmaceutical?
- 7. What are the important features of USP General Chapter <797> for compounding radiopharmaceuticals?
- 8. Describe the ISO classification.

References and Suggested Reading

- Callahan RJ. The role of commercial nuclear pharmacy in the future practice of nuclear medicine. Semin Nucl Med. 1996;26:85.
- Cox PH, Coenen HH, Deckart H, et al. Report and recommendations on the requirements of postgraduate training in radiopharmacy and radiopharmaceutical chemistry 1989. Eur J Nucl Med. 1990;17:203.
- Elliot AT, Hilditch TE, Murray T, McNulty H. The design and construction of a central radiopharmacy. Nucl Med Commun. 1993;14:328.
- Guidelines for the preparation of radiopharmaceuticals in hospitals Special report no. 11. London: British Institute of Radiology; 1979.
- Kawada TK, Tubis M, Ebenkamp T, Wolf W. Review of nuclear pharmacy practice in hospitals. Am J Hosp Pharm. 1982;39:266.
- Ponto JA, Hung SC. Nuclear pharmacy part II: nuclear pharmacy practice today. J Nucl Med Technol. 2000;28:76.
- Rhodes BA, Hladik WB III, Norenberg JP. Clinical radiopharmacy: principles and practices. Semin Nucl Med. 1996;26:77.
- Shaw SM, Ice RD. Nuclear pharmacy. Part I, emergence of the specialty of nuclear pharmacy. J Nucl Med Technol. 2000;28:8.
- The United States Pharmacopeial Convention. United States Pharmacopeia 39 and National Formulary 34. Chapter <797> pharmaceutical compounding sterile preparations. Rockville: The United States Pharmacopeial Convention; 2016.

Internal Radiation Dosimetry

10

10.1 Radiation Units

There are three basic units related to radiation: the roentgen (R) for exposure, the rad (radiation absorbed dose) for absorbed dose, and the rem (roentgen equivalent man) for dose equivalent.

The *roentgen* is the amount of x- or γ -radiation that produces ionization of one electrostatic unit of either positive or negative charge per cubic centimeter of air at 0°C and 760 mmHg (STP). Since 1 cm³ air weighs 0.001293 g at STP and a charge of either sign carries 1.6×10^{-19} Coulomb (C) or 4.8×10^{-10} electrostatic units, it can be shown that

$$1R = 2.58 \times 10^{-4} \,\mathrm{C/kg} \tag{10.1}$$

It should be noted that the roentgen applies only to air and to x- or γ -radiations. Due to practical limitations of the measuring instruments, the R unit is applicable only to photons of less than 3 MeV energy.

The *rad* is a more universal unit. It is a measure of the energy deposited in unit mass of any material by any type of radiation. The rad is defined as

$$1 \operatorname{rad} = 100 \operatorname{ergs} / \operatorname{g} \operatorname{absorber}$$
 (10.2)

Since 1 joule (J) $=10^7$ ergs,

$$1 \operatorname{rad} = 10^{-2} \operatorname{J/kg}$$
 (10.3)

In SI units, the gray (Gy) is the unit of radiation absorbed dose and is given by

$$1 \operatorname{gray}(\mathrm{Gy}) = 100 \operatorname{rad} \tag{10.4}$$

$$= 1 J / kg absorber$$
 (10.5)

By Eq. (10.4), one rad is one hundredth of a gray and also termed one centigray (cGy).

[©] Springer International Publishing AG 2018

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3_10

It can be shown that the energy absorbed per kilogram of air due to an exposure of 1 R is

 $1R = 86.9 \times 10^{-4} \text{ J / kg in air}$ Therefore, 1 R = 0.869 rad in air or 1 R = 0.00869 Gy in air

The rad is the absorbed dose in any matter or a person at the location of the exposure and is not limited by the type of radiation or absorber nor by the intensity of radiation. It should be understood that the rad is independent of the weight of material. This means that a radiation dose of 1 rad (0.01 Gy) is always 1 rad (0.01 Gy) in 1, 2, or 10 g of the material. However, the integral absorbed dose is given in units of gram-rads (g.rad or g.Gy) and calculated by multiplying the rad (Gy) by the mass of material. For example, if the radiation dose to a mass of 45 g is 10 rad (0.1 Gy), then the integral radiation dose to the material is 450 g.rad (or 4.5 g.Gy); however, the radiation dose is still 10 rad (0.1 Gy).

The dose equivalent unit, H_r , in *rem*, has been developed to account for the differences in effectiveness of different radiations in causing biological damage in tissues or organs. In radiobiology, the dose equivalent H_r for a particular radiation is defined as

$$H_{\rm r}(\rm rem) = \rm rad \times (\rm RBE)_{\rm r}$$
(10.6)

where $(RBE)_r$ is the *relative biological effectiveness* of the radiation. It is defined as the ratio of the dose of a standard radiation to produce a particular biological response to the dose of the radiation in question to produce the same biological response. The standard radiation may be any suitable radiation such as 250-kV x-radiation or ⁶⁰Co radiations, and, therefore, the RBE of a radiation depends on the choice of the standard radiation.

In radiation protection, however, the dose equivalent (H_r) is defined as

$$H_{\rm r}(\rm rem) = \rm rad \times W_{\rm r} \tag{10.7}$$

where W_r is the radiation weighting factor for a given type of radiation. W_r is related to the linear energy transfer¹ of the radiation and reflects the effectiveness of the radiation to cause biological or chemical damage in tissues or organs. It is useful in the design of shielding and in the calculation of radiation dose to radiation workers. In the past, the W_r values were called *quality factors* (QFs), which are somewhat different, but still are adopted by the Nuclear Regulatory Commission (NRC). The QF values of various radiations are listed in Table 10.1.

In SI units, the dose equivalent H_r is expressed in *sievert* (Sv), which is defined as

$$1 \operatorname{sievert}(Sv) = 100 \operatorname{rem}$$
(10.8)

In practical situations, all these radiation units are often expressed in milliroentgens (mR), millirad (mrad), and millirem (mrem), which are 10^{-3} times the units,

¹The linear energy transfer (LET) of a radiation is defined as the amount of energy deposited per unit length of the path by the radiation and is measured in kiloelectron volts per micrometer.

Table 10.1	Quality f	factors for	different	radiations	from	10CFR20
-------------------	-----------	-------------	-----------	------------	------	---------

Type of radiation	QF
X-rays, γ -rays, β -particles	1.0
High-energy rotons and neutrons of unknown energy	10.0
<i>α</i> -Particles	20.0
Heavy ions	20.0

roentgen, rad, and rem, respectively. In SI units, the equivalent quantities are milligrays (mGy) and millisieverts (mSv). A rad is also expressed as centigray (cGy).

10.2 Radiation Dosimetry

Radiation can cause deleterious effects in living systems. It is therefore essential to assess these effects in humans for a nuclear medicine procedure involving the administration of a radiopharmaceutical. The damaging effects arise from the absorption of energy in tissues and depend on a number of factors: (1) the activity of the administered radiopharmaceutical, (2) the physical and biological half-lives of the radiopharmaceutical, (3) the distribution and metabolic fate of the radiopharmaceutical in the body, (4) the fraction of energy released per disintegration from a source region that is absorbed in the particular target volume, and (5) the shape, composition, and location of the source and target organs. The physical characteristics of a radiopharmaceutical are well established. Information concerning the biological handling of a radiopharmaceutical can be obtained from various experimental studies in humans and animals. Because there are variations from one individual to another in physiologic functions and in the shape, size, density, and relative location of different organs, the factors 3–5 listed above are approximated for a "reference" 70-kg man.

If the amount of energy in ergs absorbed in a mass of material is known, then the absorbed dose D in rad is obtained by dividing the absorbed energy by 100 and the mass of the material. However, D can be calculated from the radiation dose rate R and the duration of exposure from the source of radiation. The dose rate is defined as the amount of radiation energy absorbed per unit time per gram of material. The calculation of radiation dose due to internally absorbed radionuclides is detailed below.

10.2.1 Calculation of Radiation Absorbed Dose

Radiopharmaceuticals administered to patients are distributed in various regions of the body. These regions can be considered points, lines, surfaces, or volumes. In internal dosimetry calculations, a region of interest for which the absorbed dose is to be calculated is considered the "target," whereas all other regions contributing to the radiation dose to the target are considered "source" regions. The source and target regions become the same when the radiation dose due to radioactivity in the target itself is calculated. Suppose a source volume *r* contains $A \mu$ Ci of a radiopharmaceutical emitting several radiations. If the *i*th radiation has energy E_i and a fractional abundance N_i per disintegration, then the energy absorbed per hour by a target
of mass m and volume v from the ith radiation emitted by the source volume r (dose rate) is given by

$$R_{i} (rad / h) = A / m(\mu Ci / g) N_{i}E_{i} (MeV / disintegration)$$

$$\times (3.7 \times 10^{4} \text{ disintegrations } / s.\mu Ci)$$

$$\times (1.6 \times 10^{-6} \text{ erg } / \text{ MeV})$$

$$\times (0.01g.rad / \text{ erg})$$

$$\times (3600 \text{ s } / h)$$

$$= 2.13(A / m) N_{i}E_{i}$$

If the target and the source are not the same, then a factor must be introduced to account for the partial absorption, if any, of the radiation energy. Thus,

$$R_i \left(\operatorname{rad} / \mathbf{h} \right) = 2.13 \left(A / m \right) N_i E_i \phi_i \left(v \leftarrow r \right)$$
(10.9)

Here, $\phi_i(v \leftarrow r)$ is called the *absorbed fraction* and is defined as the ratio of the energy absorbed by the target volume v from the *i*th radiation to the energy emitted by the *i*th radiation from the source volume *r*. This is a very critical factor that is difficult to evaluate because the absorbed fraction ϕ_i depends on the type and energy of the radiation, the shape and size of the source volume, and the shape, composition, and distance of the target volume. However, in the case of β -particles, conversion electrons, α -particles, and χ - and γ -rays of energies less than 11 keV, all of the energy emitted by a radionuclide is absorbed in the volume *r* larger than 1 cm. Then, ϕ_i becomes zero, unless v and r are the same; in which case $\phi_i=1$. For X- and γ -rays with energies greater than 11 keV, the value of ϕ_i decreases with increasing energy and varies between 0 and 1, depending on the energy. The values of ϕ_i are calculated by statistical methods on the basis of fundamental mechanisms of interaction of radiations with matter and are available in many standard textbooks on radiation dosimetry, particularly the medical internal radiation dose (MIRD) pamphlets published by the Society of Nuclear Medicine.

The quantity $2.13N_iE_i$ is a constant for the *i*th radiation and is often denoted by Δ_i . Thus,

$$\Delta_i = 2.13 N_i E_i \tag{10.10}$$

The quantity Δ_i is called the *equilibrium dose constant* and has the unit g.rad/ μ Ci.h based on the units chosen in Eq. (10.9). It should be pointed out that for γ -rays and α -particles, E_i is the maximum energy of these radiations. However, since β -particles are emitted with a distribution of energy, the average energy \overline{E}_{β} of β -particles is used in the calculation of Δ_i . Now Eq. (10.9) becomes

$$R_i \left(\operatorname{rad} / \mathbf{h} \right) = \left(A / m \right) \Delta_i \phi_i \left(v \leftarrow r \right)$$
(10.11)

The activity A changes in vivo due to the physical decay and biological elimination of the radiopharmaceutical, and therefore the dose rate also changes. Assuming an effective exponential change in A, Eq. (10.11) can be written:

$$R_{i}\left(\operatorname{rad}/\operatorname{h}\right) = \left(A_{0}/m\right)\Delta_{i}e^{-\lambda_{e}t}\phi_{i}\left(v\leftarrow r\right)$$
(10.12)

Here, λ_e is the effective decay constant of the radiopharmaceutical, and *t* is the time over which the original activity A_0 has decayed.

The cumulative radiation dose D_i due to the *i*th radiation during the period t = 0 to *t* can be obtained by integrating Eq. (10.12). Thus,

$$D_{i}(\operatorname{rad}) = \frac{A_{0}}{m} \Delta_{i} \phi_{i} \left(v \leftarrow r \right) \int_{0}^{t} e^{-\lambda_{v} t} dt$$

$$= \frac{A_{0}}{m} \Delta_{i} \phi_{i} \left(v \leftarrow r \right) \frac{1}{\lambda_{e}} \left(1 - e^{-\lambda_{v} t} \right)$$

$$= 1.44 \frac{A_{0}}{m} \Delta_{i} T_{e} \left(1 - e^{-\lambda_{v} t} \right) \phi_{i} \left(v \leftarrow r \right)$$

(10.13)

Here, T_e is the effective half-life of the radiopharmaceutical in hours (discussed in Chap. 6). If $t = \infty$, that is, the radiopharmaceutical is completely eliminated, then the exponential term $e^{-\lambda_e t}$ approaches zero, and the absorbed dose in Eq. (10.13) may be written

$$D_i(\operatorname{rad}) = 1.44(A_0 / m)\Delta_i T_e \phi_i(v \leftarrow r)$$
(10.14)

If the radionuclide has *n* radiations with energies $E_1, E_2, ..., E_n$ and fractional abundances $N_1, N_2, ..., N_n$, per disintegration, then the total dose *D* can be obtained by summing Eq. (10.14) over all radiations. Thus,

$$D(\operatorname{rad}) = 1.44 \frac{A_0}{m} T_e \sum_{i=1}^n \Delta_i \phi_i \left(v \leftarrow r \right)$$
(10.15)

This summation can also be applied to Eq. (10.12) for the dose rate R_i . The total dose to the target from other source regions can be calculated by summing Eq. (10.15) over all regions. Equation (10.15) assumes that the uptake in the organ is instantaneous and the radioactivity is eliminated by both physical decay and biological excretion. Modifications must be made if either physical decay or biological excretion only occurs and if the uptake is not instantaneous. The reader is referred to standard radiobiology or physics textbooks for further details.

In the MIRD pamphlets, the values of Δ_i have been compiled on the basis of various nuclear characteristics of the radionuclide in question. The ϕ_i values have been calculated on the basis of different sizes and masses of the organ or tissues receiving the radiation dose and the radiation characteristics of the radionuclide. The calculation is made on the assumption of a 70-kg standard man. In MIRD pamphlet No. 11, \tilde{A} has been substituted for the quantity $1.44 \times A_0 \times T_e$ and *S* for the quantity $\left(\sum_{i=1}^{n} \Delta_i \phi_i\right) / m$. \tilde{A} is called the cumulated activity and *S* is called the mean absorbed dose per unit cumulated activity.

$$D = \tilde{A} \cdot S \tag{10.16}$$

The values of *S* are tabulated in MIRD pamphlet No. 11. MIRD dose estimate reports are available for several radiopharmaceuticals and periodically updated and published by the Society of Nuclear Medicine and Molecular Imaging.

Problem 10.1

Calculate the absorbed dose to the liver of an adult patient who receives 3 mCi (111 MBq) ^{99m}Tc-sulfur colloid for a liver scan, assuming 85% liver uptake with no excretion.

Answer

Mass of the liver =1700 g (for a standard man) A_0 in the liver =3000 × 0.85 = 2550 µCi (86.7 MBq) $T_e = 6$ h [using Eq. (6.3) and assuming $T_b = \infty$]

The major radiations of ^{99m}Tc are 140-keV photons, X-rays, and Auger and conversion electrons. The Δ and ϕ values for these radiations are obtained from MIRD pamphlets (assuming uniform distribution) and given below.

Radiation	Δ_i	ϕ_i	$\Delta_i \phi_i$
140-keV photon	0.2640	0.160	0.0422
X-rays (20 keV)	0.0031	0.784	0.0024
Electrons	0.0360	1.000	0.0360
Total			0.0806

From Eq. (10.15), the total dose to the liver is

 $D = 1.44 \times (2550 / 1700) \times 6 \times 0.0806 = 1.04 \operatorname{rad}(0.0104 \operatorname{Gy})$

10.2.2 Radiation Dose in System International (SI) Units

The radiation dose in SI units due to the administration of a radiopharmaceutical can be calculated by assuming a source volume r containing A MBq of the radiopharmaceutical that emits several radiations. If the *i*th radiation has energy E_i and a fractional abundance N_i per disintegration, then the energy absorbed per hour by a target of mass m and volume v from the *i*th radiation emitted by the source volume r (dose rate) is given by

$$R_{i} (Gy/h) = A / m (MBq/g) N_{i} E_{i} (MeV / disintegration)$$

$$\times 10^{6} disintegrations / (s \bullet MBq)$$

$$\times (1.6 \times 10^{-6} erg / MeV)$$

$$\times (1 \times 10^{-4} g Gy / erg)$$

$$\times (3600 s / h)$$

$$= 0.576 (A / m) N E_{i}$$

When the target and the source are not the same, the absorbed fraction $\phi(v \leftarrow r)$ must be taken into account. Thus,

$$R_{i} \left(\text{Gy} / \text{h} \right) = 0.576 \left(A / m \right) N_{i} E_{i} \phi_{i} \left(v \leftarrow r \right)$$
(10.17)

The quantity $0.576N_iE_i$ is a constant and can be denoted by Δ_i as in Eq. (10.10). Thus,

$$\Delta_i = 0.576 N_i E_i \tag{10.18}$$

With this value of D_i , Eqs. (10.11)–(10.16) are equally applicable to radiation doses in SI units. It should be understood that the equations in SI units contain a constant $\Delta_i = 0.576N_iE_i$ and activities expressed in MBq, whereas the equations in rad units contain the equilibrium constant $\Delta_i = 2.13N_iE_i$ and activities expressed in microcuries.

Table 10.2 presents radiation absorbed doses in different organs in adults from various radiopharmaceuticals. The doses have been adapted from package inserts of individual products, except ¹⁸F-FDG and ⁹⁰Y-Zevalin.

		Dose	
Radiopharmaceutical	Organ	rad/mCi	mGy/GBq
^{99m} Tc-pertechnetate	Thyroid	0.130	35.1
-	Upper large intestine	0.120	32.4
	Lower large intestine	0.110	30.0
	Stomach	0.051	13.8
	Ovaries	0.030	8.1
	Testes	0.009	2.4
^{99m} Tc-sulfur colloid	Liver	0.335	91.2
	Spleen	0.213	57.4.
	Marrow	0.028	7.4
	Ovaries	0.056	15.2
^{99m} Tc-diethylenetriaminepentaacetic	Bladder (2-h void)	0.115	31.1
acid (DTPA)	Kidneys	0.090	24.3
	Gonads	0.011	3.0
^{99m} Tc-gluceptate	Kidneys	0.170	45.9
•	Bladder (2-h void)	0.120	32.4
	Ovaries	0.080	21.6
^{99m} Tc-tetrofosmin (Myoview) at rest	Gallbladder	0.180	48.7
	Upper large intestine	0.113	30.5
	Lower large intestine	0.082	22.2
	Heart (wall)	0.015	4.1
	Kidneys	0.046	12.4
	Ovaries	0.035	9.5
	Bladder (wall)	0.071	19.2
^{99m} Tc-macroaggregated albumin	Lungs	0.22	59.5
(MAA)	Kidneys	0.011	3.0
	Liver	0.018	4.9
	Ovaries	0.008	2.2
	Testes	0.006	1.6
^{99m} Tc-stannous pyrophosphate	Bladder	0.034	9.2
(blood pool imaging)	Red marrow	0.019	5.1
	Ovaries	0.023	6.2
	Testes	0.013	3.5
	Blood	0.051	13.8

Table 10.2 Radiation absorbed doses in adults for various radiopharmaceuticals

(continued)

		Dose	
Radiopharmaceutical	Organ	rad/mCi	mGy/GBq
^{99m} Tc-methylenediphosphonate	Bone	0.035	9.5
(MDP)	Bladder wall (2-h void)	0.130	35.1
	Kidneys	0.040	10.8
	Marrow	0.026	7.0
	Ovaries	0.012	3.2
	Testes	0.008	2.1
^{99m} Tc-mebrofenin (Choletec)	Liver	0.047	12.7
	Lower large intestine	0.474	128.1
	Upper large intestine	0.364	98.4
	Gallbladder	0.137	37.0
	Bladder	0.029	7.8
	Red marrow	0.034	9.1
	Ovaries	0.101	27.3
^{99m} Tc-mercapto	Bladder wall	0.480	129.7
acetylglycylglycylglycine (MAG3)	Gallbladder	0.016	4.3
	Kidneys	0.014	3.8
	Lower large intestine	0.033	8.9
	Ovaries	0.026	7.0
^{99m} Tc-hexamethylpropylene amine	Brain	0.026	7.0
oxime (Ceretec)	Thyroid	0.100	27.0
	Kidneys	0.130	35.1
	Ovaries	0.023	6.2
	Gallbladder	0.190	51.4
	Lachrymal gland	0.258	69.7
^{99m} Tc-dimercaptosuccinic acid	Bladder wall	0.070	18.9
(DMSA)	Kidneys	0.630	170.3
	Liver	0.031	8.6
	Bone marrow	0.022	5.9
	Ovaries	0.013	3.6
	Testes	0.007	1.8
99mTc-ethyl cysteinate dimer	Brain	0.020	5.4
(Neurolite)	Gallbladder wall	0.092	24.9
	Upper large intestine	0.063	17.0
	Kidneys	0.027	7.3
	Liver	0.020	5.4
	Ovaries	0.030	8.1
	Bladder wall	0.270	72.9
99mTc-sestamibi (Cardiolite) at rest	Gallbladder	0.067	18.1
	Upper large intestine	0.180	48.6
	Lower large intestine	0.13	35.1
	Heart wall	0.017	4.6
	Kidneys	0.067	18.1
	Ovaries	0.050	13.5
	Bladder wall	0.067	18.1

		Dose	
Radiopharmaceutical	Organ	rad/mCi	mGy/GBq
¹³¹ I-sodium iodide (25% uptake)	Thyroid	1300.00	3.50×10^{5}
	Ovaries	0.14	37.8
	Liver	0.48	129.7
¹²³ I-ioflupane (DaTscan) ^c	Brain	0.066	17.8
	Striata	0.85	230.0
	Liver	0.10	27.9
	Lungs	0.15	41.2
	Bladder wall	0.20	53.1
	Lower large intestinal wall	0.16	42.0
¹²³ I-sodium iodide (25% uptake)	Thyroid	12.75	3445.9
· · · ·	Bladder	0.30	81.1
	Ovaries	0.05	13.5
¹²³ I-metaiodobenzylguanidine	Adrenals	0.059	16.0
(MIBG)	Brain	0.018	4.8
	Gallbladder	0.080	22.0
	Heart	0.067	18.0
	Kidneys	0.039	11.0
	Liver	0.270	73.0
	Red marrow	0.026	7.1
	Testes	0.260	7.1
¹³¹ I-metaiodobenzylguanidine	Bladder (wall)	2.96	800.0
(MIBG)	Liver	2.92	789.2
	Spleen	2.18	589.2
	Heart (wall)	1.41	381.1
	Adrenal medulla	0.78	210.8
	Kidneys	0.33	89.2
	Ovaries	0.27	73.0
¹¹¹ In-white blood cell (WBC)	Spleen	26.0	7027.0
	Liver	38.0	10,270.0
	Red marrow	26.0	7027.0
	Skeleton	7.28	1967.6
	Ovaries	3.80	1027.0
¹¹¹ In-pentetreotide (OctreoScan)	Kidneys	1.81	488.4
	Liver	0.41	110.0
	Spleen	2.46	664.9
	Bladder wall	1.007	272.2
	Ovaries	0.16	44.1
¹¹¹ In-capromab pendetide	Liver	3.70	1000.0
(ProstaScint)	Spleen	3.26	881.1
	Kidneys	2.48	670.3
	Marrow	0.86	232.4
	Testes	1.12	339.0
	Prostate	1.64	443.2

(continued)

		Dose	
Radiopharmaceutical	Organ	rad/mCi	mGy/GBq
¹⁸ F-fluciclovine (Axumin)	Heart wall	0.19	52
	Liver	0.12	33
	Lungs	0.13	34
	Pancreas	0.38	102
	Marrow	0.09	25
	Bladder wall	0.09	25
	Uterus	0.17	45
¹⁸ F-sodium fluoride	Bone surface	0.15	40.0
	Bladder wall	0.81	220.0
	Red marrow	0.15	40.0
¹⁸ F-florbetapir (Amyvid)	Upper large intestine wall	0.27	74.0
1 () /	Small intestine	0.24	66.0
	Osteogenic cells	0.104	28.0
	Brain	0.037	10.0
	Gallbladder wall	0.53	143.0
	Liver	0.24	64.0
	Bladder wall	0.10	27.0
¹⁸ F-florbetaben (Neuracea)	Brain	0.05	13.0
r heroetaben (realabed)	Kidneys	0.09	24.0
	Liver	0.14	39.0
	Lower large intestinal wall	0.13	35.0
	Small intestine	0.13	31.0
	Upper large intestinal wall	0.14	38.0
	Urinary bladder wall	0.26	70.0
¹⁸ F-flutemetamol (Vizamyl)	Gallbladder wall	1.06	287.0
	Brain	0.041	11.0
	Upper large intestinal wall	0.433	117.0
	Bladder wall	0.537	145.0
	Liver	0.211	57.0
	Small intestinal wall	0.377	102.0
¹⁸ F-fluorodeoxyglucose (FDG) ^a	Brain	0.07	18.9
	Heart	0.22	59.5
	Bladder	0.70	189.2
	Spleen	0.14	37.8
	Ovaries	0.063	17.0
	Uterus	0.085	23.0
⁸² Rb-rubidium chloride	Kidnevs	0.032	8.6
	Heart (wall)	0.007	1.9
²⁰¹ Tl-thallous chloride	Heart	0.50	135.1
	Kidneys	1.20	324.3
	Liver	0.55	148.6
	Thyroid	0.65	175.7
	Testes	0.50	135.1

	Dose		
Radiopharmaceutical	Organ	rad/mCi	mGy/GBq
⁶⁸ Ga-DOTATATE	Adrenals	0.31	86.0
	Kidneys	0.34	93.0
	Liver	0.19	50.0
	Spleen	0.40	109.0
	Bladder wall	0.36	98.0
⁶⁷ Ga-gallium citrate	Liver	0.46	124.3
	Marrow	0.58	156.7
	Kidneys	0.41	110.8
	Spleen	0.53	143.2
	Upper large intestine	0.56	151.4
	Lower large intestine	0.90	243.2
	Gonads	0.26	70.0
¹⁵³ Sm-lexidronam (Quadramet)	Bone surfaces	25.000	6756.8
	Red marrow	5.700	1540.0
	Bladder wall	3.600	973.0
	Kidneys	0.065	17.6
	Ovaries	0.032	8.6
	Liver	0.019	5.1
⁸⁹ Sr-strontium chloride (Metastron)	Bone surfaces	63.0	17,000.0
	Red bone marrow	40.7	11,000.0
	Lower bowel	17.4	4700.0
	Bladder wall	4.8	1300.0
	Ovaries	2.9	800.0
	Kidneys	2.9	800.0
⁹⁰ Y-ibritumomab tiuxetan (Zevalin) ^b	Spleen	27.2	7350.0
	Liver	16.0	4320.0
	Lungs	7.6	2050.0
	Bladder wall	3.3	890.0
	Red marrow	2.2	590.0
	Kidneys	0.8	220.0
	Other organs	1.5	400.0
¹³³ Xe-xenon	Lungs	0.008	2.2
²²³ Ra-radium chloride (Xofigo)	Osteogenic cells	4262.6	1.15×10^{6}
	Red marrow	513.5	1.4×10^{5}
	Bladder wall	14.9	4030.0
	Lower intestine wall	171.9	4.6×10^{4}
	Liver	11.0	2980.0
	Kidneys	11.9	3200.0

^aFrom Stabin et al. (1996)

^bFrom Wiseman et al. (2003)

10.2.3 Effective Dose Equivalent and Effective Dose

The concept of *effective dose equivalent* has been introduced by the International Commission on Radiation Protection (ICRP) because the stochastic damaging effects of radiations vary in different tissues. While the dose equivalent (H_r) is related to the variations of damage caused by types of radiations, the effective dose equivalent (H_T) relates to the damage caused by the radiosensitivity of different tissues. Dimensionless weighting factors (W_T) have been assigned to different organs based on their relative radiosensitivities that were assessed from the expression of cancer and genetic defects in various populations exposed to radiation. The tissue-weighted dose equivalent (H_T) to an organ or tissue is given by the product of the dose equivalent (H_r) to the organ or tissue and the W_T applicable to that organ or tissue. Thus,

$$H_{\mathrm{T,r}} = W_{\mathrm{T}} \times H_{\mathrm{r}} \tag{10.19}$$

The effective dose equivalent $H_{\rm E}$ is the sum of tissue-weighted dose equivalents in different tissues and organs for different radiations and is calculated as

$$H_{\rm E} = \sum_{\rm T,r} H_{\rm T,r}$$
$$= \sum_{\rm T,r} W_{\rm T} \times H_{\rm r}$$
(10.20)

The values of W_T were first published in ICRP 26 in 1977, which have been adopted by the NRC and included in 10CFR20, and they are listed in Table 10.3. In 1990 the ICRP updated these values and incorporated them in ICRP 60, in which effective dose equivalent has been renamed simply effective dose, although the NRC still uses the former term. Yet in 2007, the ICRP revised the W_T values again replacing the values in ICRP 60, and updated values were published in ICRP 103 (ICRP 2007).These values are listed in Table 10.4.

The effective dose gives an estimate of possible risk of stochastic effects due to total body irradiation by external sources (e.g., diagnostic X-ray procedures) or internal sources (e.g., intravenous administration of radiopharmaceuticals). These values are not applicable to radiation therapy because the effective dose is calculated for an "average" man. Table 10.5 lists the effective doses (H_E) from different radiopharmaceuticals for adults. The radiosensitivity of different organs is age dependent, but only adult values are given.

Table 10.3 Tissue weighting factors, $W_{\rm T}$ from 10CFR20

Tissue	W_{T}
Gonads	0.25
Breast	0.15
Red bone marrow	0.12
Lungs	0.12
Thyroid	0.03
Bone surfaces	0.03
Remainder	0.30
Total body	1.00

	Number of		
Organ/tissue	tissues	W_{T}	Total contribution
Lung, stomach, colon, bone marrow, breast,	6	0.12	0.72
remainder			
Gonads	1	0.08	0.08
Thyroid, esophagus, bladder, liver	4	0.04	0.16
Bone surface, skin, brain, salivary glands	4	0.01	0.04

Table 10.4 Tissue weighting factors, $W_{\rm T}$, in the 2007 Recommendations^a

^aReproduced with permission from Table B.2 in ICRP (2007)

1. The $W_{\rm T}$ for gonads is applied to the mean of the doses to testes and ovaries

2. The dose to the colon is taken to be the mass-weighted mean of ULI and LLI doses, as in the Publication 60 formulation. The specified remainder tissues (14 in total, 13 in each sex) are adrenals, extrathoracic tissue (ET), gallbladder, heart, kidneys, lymphatic nodes, muscle, oral mucosa, pancreas, prostate (male), small intestine (SI), spleen, thymus, and uterus/cervix (female)

Table 10.5	Effective	doses	from	various	radiopha	rmaceuticals	in	nuclear	medicine
------------	-----------	-------	------	---------	----------	--------------	----	---------	----------

	Effective dose ^a	
Radiopharmaceuticals	rem/mCi	mSv/MBq
^{99m} Tc-pertechnetate	0.048	0.013
^{99m} Tc-sestamibi (exercise)	0.030	0.008
^{99m} Tc-macroaggregated albumin (MAA)	0.04	0.011
^{99m} Tc-tetrofosmin (exercise)	0.026	0.007
^{99m} Tc-DTPA aerosol	0.022	0.006
^{99m} Tc-methylene diphosphonate (MDP)	0.022	0.006
^{99m} Tc-red blood cell	0.026	0.007
^{99m} Tc-iminodiacetic acid (IDA) derivatives	0.063	0.017
^{99m} Tc-diethylenetriaminepentaacetic acid (DTPA)	0.019	0.005
^{99m} Tc-dimercaptosuccinic acid (DMSA)	0.033	0.009
^{99m} Tc-sulfur colloid	0.033	0.009
^{99m} Tc-white blood cell	0.041	0.011
^{99m} Tc-hexamethylpropylene amine oxime (Ceretec)	0.033	0.009
^{99m} Tc-mercaptoacetylglycylglycylglycine (MAG3)	0.026	0.007
¹¹¹ In-white blood cell (WBC)	1.33	0.360
¹¹¹ In-diethylenetriaminepentaacetic acid (DTPA)	0.078	0.021
¹¹¹ In-pentetreotide (Octreoscan)	0.200	0.054
¹²³ I–NaI (35% uptake)	0.814	0.220
¹³¹ I–NaI (35% uptake)	88.80	24.00
¹²³ I–ioflupane (DaTscan)	0.078	0.021
²⁰¹ Tl-thallium chloride	0.814	0.220
¹⁸ F–fluciclovine (Axumin) ^b	0.814	0.220
¹⁸ F–florbetaben (Neuraceq) ^b	0.070	0.019
¹⁸ F–florbetapir (Amyvid) ^b	0.070	0.019
¹⁸ F–sodium fluoride	0.078	0.021
¹⁸ F–flutemetamol (Vizamyl) ^b	0.118	0.032
¹⁸ F-fluorodeoxyglucose	0.070	0.019
⁶⁸ Ga-DOTATATE (NetSpot) ^b	0.078	0.021
⁶⁷ Ga-citrate	0.370	0.100
¹²³ I-metaiodobenzylguanidine (MIBG)	0.048	0.013
¹³¹ I- metaiodobenzylguanidine (MIBG)	0.520	0.140
⁸² Rb-rubidium chloride	0.011	0.003

^aReproduced with permission from ICRP publication 80 (1999)

^bFrom package insert

10.3 North American Consensus Guidelines for Pediatric Administered Radiopharmaceutical Activities

The metabolism, biodistribution, and excretion of drugs varies with body weight and body surface and are different in children from those in adults, so radiopharmaceutical dosages for children must be adjusted. Several methods and formulas have been reported on pediatric dosage calculations based on body weight, body surface area, combination of weight and area, and simple ratios of adult dosages. The calculation based on body surface area is more accurate for pediatric dosages. The body surface area of an average adult is 1.73 m² and proportional to the 0.7 power of the body weight. The North American Consensus group of pediatric nuclear physicians, technologists, and physicists in North America, representing the Society of Nuclear Medicine, the Pediatric Radiology, and the American College of Radiology, has established consensus guidelines for pediatric administered dosages for commonly used radiopharmaceuticals in terms of activity/kg based on body weight (Gelfand et al. 2011). Based on a number of factors such as body weight, adult dosage, and type of radiopharmaceutical, the European Association of Nuclear Medicine (EANM) also has established pediatric dosages in the form of a card (Lassmann et al. 2009). There are similarities and differences in these two guidelines, and both groups have harmonized the two guidelines for universal application. For several nuclear studies, a minimum dosage is required for a meaningful scan, and for some radiopharmaceuticals, a maximum dosage is allowed because of the high radiation dose to the pediatric patient.

The recent North American Consensus Guidelines for Pediatric Radiopharmaceutical Activities are presented in Table 10.6.

	Administered	Minimum administered	Maximum administered
	activity, MBq/kg	activity, MBq	activity, MBq
Radiopharmaceutical	(mCi/kg)	(mCi)	(mCi)
¹²³ I–MIBG	5.2 (0.14)	37.0 (1.0)	370 (10.0)
^{99m} Tc-MDP	9.3 (0.25)	37.0 (1.0)	
¹⁸ F-FDG	Body: 3.7–5.2	26.0 (0.7)	
	(0.10 - 0.14)		
	Brain: 3.7 (0.10)		
^{99m} Tc-DMSA	1.85 (0.05)	18.5 (0.5)	100 (2.7)
^{99m} Tc-MAG3	Without flow	37.0 (1.0)	148 (4.0)
	study: 3.7 (0.10)		
	With flow study:		
	5.55 (0.15)		
^{99m} Tc-IDA	1.85 (0.05)	18.5 (0.5)	
^{99m} Tc-MAA	If 99mTc is used	14.8 (0.4)	
	for ventilation,		
	2.59 (0.07)		
	No ^{99m} Tc		
	ventilation		
	study:1.1 (0.03)		

 Table 10.6
 2016 Update of the North American Consensus Guidelines for Pediatric Administered

 Radiopharmaceutical Activities
 \$\$\$

Radiopharmaceutical	Administered activity, MBq/kg (mCi/kg)	Minimum administered activity, MBq (mCi)	Maximum administered activity, MBq (mCi)
^{99m} Tc pertechnetate (Meckel	1.85 (0.05)	9.25 (0.25)	()
diverticulum imaging)	1.05 (0.05)	9.23 (0.23)	
¹⁸ E sodium fluorida	2 22 (0.06)	14.0 (0.38)	
^{99m} Te portechastate (systegraphy)	2.22 (0.00)	14.0 (0.36) No more then 27	No more then 27
re-pertechnictate (cystography)	dosage	(1.0) for each bladder filling cycle	(1.0) for bladder-filling cycle
99mTc-sulfur colloid(for oral liquid	No weight-based	9.25 (0.25)	37 (1.0)
gastric emptying)	dosage		
^{99m} Tc-sulfur colloid (for solid gastric	No weight-based	9.25 (0.25)	18.5 (0.5)
99mTc HMPAO (Ceretec)/99mTc ECD	11.1(0.3)	185 (5.0)	740 (20)
(Neurolite) for brain perfusion	11.1 (0.5)	105 (5.0)	740 (20)
^{99m} Tc sestamibi (Cardiolite)/ ^{99m} Tc	5 55 (0 15)	74(2)	370 (10)
tetrofosmin (Myoview) for	5.55 (0.15)	74(2)	570 (10)
myocardial perfusion (single scap or			
first of two scape, same day)			
^{99m} Tc sectamibi (Cardiolite)/ ^{99m} Tc	167(0.45)	222 (6.0)	1110 (30)
tetrofosmin (Myoview) for	10.7 (0.45)	222 (0.0)	1110 (50)
myocardial perfusion (second of 2			
scons, some day)			
Na ¹²³ I for thyroid imaging	0.28 (0.0075)	1.0(0.027)	11 (0 3)
^{99m} Te portechaetate for thuroid	1.1(0.02)	7.0(0.027)	11(0.5) 02(2.5)
imaging	1.1 (0.03)	7.0 (0.19)	95 (2.5)
^{99m} Te DBC for blood pool Imaging	11.8 (0.22)	74 (2.0)	740 (20)
^{99m} Te WPC for infection Imaging	74(0.2)	74(2.0)	740 (20)
⁶⁸ Ca DOTATOC ar	7.4(0.2)	14(2)	195 (5)
68Ga-DOTATATE	2.7 (0.074)	14 (0.38)	165 (5)

Adapted from Treves et al. (2016) (Copyright permission not needed for guidelines per verbal communication with the Society of Nuclear Medicine)

Questions

- 1. Define roentgen, rad, rem, gray, and sievert.
- 2. Calculate the absorbed dose to the lungs of an adult patient who received 3 mCi (111 MBq) ^{99m}Tc-MAA, assuming 99% uptake and uniform distribution of the radioactivity in the lungs. Pertinent data are $T_{\rm b} = 1.5$ h and $S = 5.25 \times 10^{-5}$ rad/ µCi.h or 0.0142 Gy/GBq.h.
- 3. If the radiation dose to 1 g of an absorbing medium is 25 rad (0.25 Gy), what is the radiation dose to 2 g of the absorbing medium?
- 4. Calculate the dose in rem and sievert to a tumor that received 20 rad (0.2 Gy) from neutron therapy (QF = 10 for neutrons).
- 5. What is the difference between $W_{\rm T}$ and Wr?
- 6. What is the approximate average whole-body dose from common ^{99m}Tc-radiopharmaceuticals?

- 7. What is the difference between effective dose equivalent and effective dose?
- 8. North American Guidelines for pediatric radiopharmaceutical dosages are based on (a) body surface or (b) body weight.

References and Suggested Reading

- Fourth International Radiopharmaceutical Dosimetry Symposium, Oak Ridge, November, 1985, CONF-851113.
- Gelfand MJ, Parisi MT, Treves ST. Pediatric radiopharmaceutical administered doses. 2010 North American consensus guidelines. J Nucl Med. 2011;52:318.
- Howell RW, Wessels BW, Loevinger R. The MIRD perspective. J Nucl Med. 1999;40:3S-10S.
- ICRP. Radiation dose to patients from radiopharmaceuticals. New York: Elsevier, ICRP Publications 80; 1999.
- ICRP. The 2007 Recommendations of the International Commission on Radiological Protection. New York: Elsevier, ICRP Publication 103; 2007, p. 261.
- ICRP. 1990 Recommendations of the international commission on radiological protection. New York: Elsevier, ICRP Publications 60; 1991.
- Lassmann M, Biassoni L, Monsieurs M, et al. The new EANM paediatric dosage card. Eur J Nucl Med Mol Imaging. 2009;36:540.
- Loevinger R, Budinger T, Watson E. MIRD primer for absorbed dose calculations. New York: Society of Nuclear Medicine; 1991.
- National Council on Radiation Protection and Measurements. General concepts for the dosimetry of internally deposited radionuclides (NCRP 84). Bethesda: NCRP Publications; 1985.
- Reports of Medical Internal Radiation Dose (MIRD) Committee. Pamphlet Nos. 1–11. Society of Nuclear Medicine, New York; 1968–1977.
- Stabin MG. Fundamentals of nuclear medicine Dosimetry. New York: Springer; 2008.
- Stabin MG, Stubbs JB, Toohey RE. Radiation dose estimates for radiopharmaceuticals. Radiation Internal Dose Information Center, Oak Ridge Institute for Science and Foundation; Oak Ridge: Tennessee; 1996.
- Treves ST, Gelfand MJ, Fahey FH, et al. 2016 update of the North Amrican consensus guidelines for pediatric Administered radiopharmaceutical Activities. J Nucl Med. 2016;57:15N.
- U.S. Food and Drug Administration. Radioactive drugs and radioactive biological products. Fed Register. 1975;40:144.
- Wiseman GA, Kornmehl E, Leigh B, et al. Radiation dosimetry results and safety correlations from ⁹⁰Y-Ibritumomab tiuxetan radioimmunotherapy for relapsed or refractory non-Hodgkin's lymphoma: combined data from 4 clinical trials. J Nucl Med. 2003;44:465.
- Zanzonico PB. Internal radiation dosimetry: a review of basic concepts and recent developments. J Nucl Med. 2000;41:297.

Radiation Regulations, Protection, and Uses

11

The use of radiations and radiolabeled products for any purpose is governed by regulatory agencies in different countries all over the world. This chapter focuses on regulations that pertain only to the USA, and only a brief summary of European regulations is given at the end.

The use of radiopharmaceuticals in humans was almost unregulated until the late 1950s. Since then, a progression of regulations has been imposed on the use of radiations in humans. Until 1963, all reactor-produced radiopharmaceuticals were under the control of the Atomic Energy Commission [(AEC), now the Nuclear Regulatory Commission (NRC)] only for the control of their radiation hazards. The therapeutic or diagnostic efficacy and the pharmaceutical quality of radiopharmaceuticals were not regulated by the AEC nor by the US Food and Drug Administration (FDA) until the early 1960s. In 1963 the FDA introduced rules that the clinical efficacy of all radiopharmaceuticals, for that matter, all drugs, must be reported. However, under an agreement between the AEC and the FDA, all investigational new radioactive drugs were exempted from these regulations. In July 1975, the exemption of all new investigational drugs was revoked by the FDA, and all radiopharmaceuticals came under its regulations. Thus, the FDA regulates the safety and efficacy of radiopharmaceuticals in humans, whereas the NRC controls the radiation safety of the worker, the patient, and the public. For approved radiopharmaceuticals, the state boards of pharmacies regulate the pharmacy aspect of nuclear pharmacy operations. Also, state agencies regulated the man-made radiations, such as X-rays.

11.1 Food and Drug Administration

The use of all drugs in humans is normally regulated by the FDA in two ways – either by submission of Notice of Claimed Investigational Exemption for a New Drug (IND) by an investigator or by submission of a New Drug Application (NDA) by a manufacturer. There are three categories of INDs: (1) physician-sponsored

[©] Springer International Publishing AG 2018

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3_11

IND for an unapproved drug or a drug for a new indication; (2) emergency use IND for an experimental drug for use in an emergency situation, where there is no time for submitting an IND application and no approved protocol exists; and (3) treatment IND for experimental drugs showing promise for serious or immediately life-threatening conditions during final clinical work and the FDA review.

The following is a brief outline of the two pathways of drug approval, and one must consult corresponding Federal Registers for full detail (21CFR312 for IND and 21CFR314 for NDA).

11.1.1 Investigational New Drug

Approval for the use of investigational radiopharmaceuticals in humans must be obtained from the FDA by submitting an IND on Forms FDA 1571 and FDA 1572. The IND must include the names and credentials of the investigators, purpose of the project, manufacturing and toxicologic data of the radiopharmaceutical, the technical details of the project, and the clinical protocol.

In all human investigations, the FDA requires that investigators obtain written consent from patients or their relatives for the proposed study. In the consent form, details of the safety and hazard of the radiopharmaceutical, the benefit from the study, financial compensation, if any, and a brief outline of the procedure are spelled out.

In almost all institutions, an institutional review board (IRB) is established to supervise and regulate the use of radiopharmaceuticals in humans. This committee is approved by the FDA. The IRB is composed of scientists, laymen, lawyers, clergymen, and others and is responsible for the close monitoring of clinical protocols in humans in the institution. This committee approves the contents of the consent form to be presented to the patient.

An IND is sponsored by a physician or a drug company. The drug company sponsors a group of investigators who conduct the clinical protocol of a new drug on behalf of the company. In contrast, the physician-sponsored IND is carried out under his own protocol for a specific radiopharmaceutical. Following submission of the IND, the sponsor has to wait for 30 days to start investigation to allow the FDA to review the application for any deficiency. By this period or earlier, the FDA notifies the sponsor for correction or to start the project. The IND is run for a limited period, and a specific number of patients are undertaken in the protocol. An annual report must be submitted stating the progress and various findings of the study. Any serious adverse reactions must be reported to the FDA immediately. Identical INDs may be submitted by several individual sponsors for the same product. The FDA collects all data on the safety and efficacy of the product to decide on its approval.

The IND investigation of a new drug is carried out in three phases. After completion of a phase, data has to be submitted to the FDA approval, and, if approved, application for the next phase study is made. When all three phase studies are completed, the sponsor (normally a drug company) submits all pertinent supporting data from all investigators in an NDA to the FDA for approval for marketing the product for clinical use.

- Phase I: In this phase, only a limited number of patients or volunteers (generally 20–80) are included to determine the pharmacologic distribution, metabolism, excretion, toxicity, optimum dosage, and any adverse reactions.
- Phase II: In this phase, controlled clinical studies are conducted in a limited number of patients (usually several hundreds) for a specific disease.
- Phase III: A large number of patients with the specific disease are involved in Phase III clinical trial to assess the drug's safety, efficacy, and dosage necessary in diagnosing or treating the disease. This phase of the study is normally conducted in several hundreds to thousands patients by several investigators for improved statistical data.

11.1.2 New Drug Application

Usually the drug companies apply to the FDA for approval of an NDA for marketing a new radiopharmaceutical for one or more clinical uses. According to requirements of the Food and Drug Administration Modernization Act (FDAMA) passed by Congress in 1997, the FDA introduced the final rule for approval of radiopharmaceuticals used in vivo for diagnosis and monitoring of human diseases (21CFR315). This section addresses the issues related to pharmacologic and toxicologic effects, clinical effectiveness, adverse reactions, indications for use, and estimated absorbed dose from the use of the radiopharmaceutical. These data are collected in abovementioned three phases of IND studies and are included in the NDA application to the FDA for approval for marketing (21CFR314).

When the FDA is convinced of the efficacy and safety of the radiopharmaceutical for human use supported by the data, it approves an NDA to the sponsor for marketing the drug product. In its approval, the FDA specifies the indications and contraindications of the radiopharmaceutical, its dosimetry, clinical pharmacological information, method of formulation, route of administration, and any precaution to be taken. All the information must be included in the package insert.

11.1.3 Expanded Access IND

Expanded access, sometimes called compassionate use, is an FDA pathway for a patient to receive a radioactive drug outside of an IND for the diagnosis, monitoring, or treatment of a serious disease or condition, when the patient cannot be enrolled in a clinical trial (e.g., a patient is not eligible for any ongoing clinical trials, or there are no ongoing clinical trials). Expanded access IND (eaIND) may be applied for single patient or multiple patients. The sponsor (the commercial vendor or the physician) must submit a protocol to the FDA on Form FDA 3926 for the expanded access IND with all pertinent information available from and required by the FDA. The FDA must determine the safety and effectiveness of the drug as opposed to the potential risk, prior to approval of the protocol for expanded access use. IRB approval and patient-informed consent are mandatory. Direct charges can be made

to single patients, whereas both direct and indirect costs can be charged in case of multiple patients. The sponsor must wait for 30 days from submission to receive authorization from the FDA to start the protocol.

Expanded access use of a commercial company's IND drug must be authorized by the company. In case of emergency use of a drug for a single patient, the physician makes the submission to the FDA on the phone or electronically explaining the protocol and must submit the expanded access IND in writing within 15 working days from initial authorization.

11.1.4 Exploratory IND

Traditional INDs for a new drug involve the determination of the safe dose for humans; assessment of pharmacologic, pharmacokinetic parameters; and toxicity of the drug. These tests require a vast amount of resources for product synthesis, animal use, laboratory experiments, and time. In order to minimize the use of potential resources in 2006, the FDA implemented what is called an exploratory IND (eIND), in which a drug product is evaluated in only a limited number of subjects with a limited range of doses for a limited period of time. Unlike in traditional INDs, eINDs can be initiated with less preclinical support because of low doses of the drug used causing less toxicity. The eIND is meant for a clinical trial conducted in early Phase I prior to traditional IND with limited human exposure and no diagnostic or therapeutic intent. Through eIND, an investigator can assess (a) the mechanism of action of the drug, (b) pharmacokinetics, (c) a drug candidate from a group with therapeutic potential based on pharmacodynamic properties, and (d) a product's biodistribution using imaging technology.

An eIND is intended to prove a concept or idea that distinguishes a promising product from a not-so-promising product. This speeds up development and lowers the cost in the drug development for clinical use. Submission of an eIND to the FDA must include the following:

- Clinical protocol: It must indicate the rationale for selecting a compound of interest, all facts about the product, and if it is a single-dose or multidose study in a small group of subjects for a limited time (e.g., 7 days). Single doses (microdoses) are used for pharmacokinetics or imaging studies, while multidose studies are used for establishing pharmacologic end points but not limits of tolerability.
- 2. Chemistry, manufacturing, and controls: It includes a description of the physicochemical and biological properties; dosage to be administered; route of administration; grade and quality of all ingredients used in the manufacture of the drug; name and address of the manufacturer (if different from the sponsor); method of manufacture of the drug; composition of the drug; tests employed to ensure the identity, strength, quality, purity, and potency of the drug; and results of sterility and pyrogen tests. Also, the impurity profile in the drug should be included in the application. At the outset of the application, the sponsor must state if there is any potential human risk with the drug and, if so, how it is planned to monitor them.

3. Pharmacokinetics, pharmacology, and toxicology information: This information is obtained from animal studies using increasing dosages of the drug. While smaller dosages are used for studying pharmacokinetics, larger dosages are used for limited time of exposure (e.g., 7 days) to determine the pharmacologic effects but not maximally tolerated dosages.

In clinical trials the aim of the study is to establish safe starting and maximum dosage for the clinical trial. For pharmacokinetics or imaging studies, microdoses are used, which are defined as less than 1/100th of dosage of the test substance that yields a pharmacologic effect with a maximum dosage of 100 g. These single-dosage animal data are acceptable to the FDA to support human studies under eINDs. For assessment of pharmacologic effects, clinical trials are normally conducted using repeat dosages in sensitive rodents over 7 days but can be extended for a 2-week repeat studies. Evaluation of changes in central nervous, respiratory, and cardiovascular system should be part of the pharmacologic parameters. The human dosages in the clinical protocol must be scaled down by a large factor for adequate safety.

Clinical trials can also be conducted to evaluate the mechanism of action of the test drug. Various parameters studied in animals including dosage and dosage regimen can be applied to explain the mechanism of action, and they can be extrapolated to clinical investigations to humans

4. Any previous human experience, if any, should be included in the eIND.

The eIND must be withdrawn after completion of the proposed protocol. Readers are referred to "Guidance for Industry, Investigators and Reviewers: Exploratory IND Studies at http://www.fda.gov/cder/guidance for further information. In essence, eIND eliminates nonpotential drugs early in the investigation thus saving valuable resources for other important uses. The odds for drug failure in late clinical investigations is minimized, and many safe and effective drugs will be available to oncology patients.

11.1.5 Radioactive Drug Research Committee

To expedite investigations of new radiopharmaceuticals, the FDA allows institutions to form the so-called Radioactive Drug Research Committee (RDRC) (21CFR361.1), which functions like a mini-FDA. The committee is composed of at least five members – an authorized user, a radiochemist or radiopharmacist competent to formulate radioactive drugs, a person with experience in radiation safety and dosimetry, and at least two other individuals of other disciplines. Additional members of diverse disciplines are recommended. The committee can be formed under a medical institution, or a joint RDRC can be established with more than one institution to achieve a high level of experience and diversity. The committee membership with a designated chairman is submitted to the FDA for approval and, upon satisfactory review, is approved by the FDA. The committee approves and monitors protocols of investigators involving the use of radiopharmaceuticals to study the kinetics, distribution, localization, biochemistry, physiology, etc. in humans but not for any immediate therapeutic or diagnostic intent nor to determine the safety and efficacy of the drug as in a clinical trial.

There are several limitations in RDRC protocols. The radiation dose to the critical organs (effective dose, dose to the lens, and blood-forming organs) cannot exceed 3 rem (0.03 Sv) from a single dosage of the drug and a sum of greater than 5 rem (0.05 Sv) per year during the study. Only 30 patients over the age of 18 are normally permitted in the protocol. If the number exceeds 30 or if the age of any subject is less than 18, then a special summary report with justification must be submitted. Pregnant women are not allowed to participate in the RDRC protocol.

An investigator formally submits to the RDRC a research protocol to use a new radiopharmaceutical with detailed description of the study, and it must be approved by the institutional review board. The RDRC meets at least quarterly with at least 50% membership present. Members with conflict of interest in the research protocol must recuse from voting on the protocol. If the protocol is approved on its merit, the RDRC regularly monitors its progress. Any adverse effect encountered during the study must be immediately reported to the FDA. The chairman of the committee keeps the minutes of all meetings, signs the approval or rejection of the protocols, and finally submits an annual report of all activities to the FDA. Also, any change in the membership must be reported to and approved by the FDA.

11.1.6 Difference Between RDRC and Exploratory IND

The following major differences between the two processes are noted:

- While an RDRC protocol investigates the pharmacokinetics, pharmacology, biodistribution, etc. of a radioactive drug typically in 30 patients, an eIND is a clinical protocol to study the safety and efficacy of a drug using small dosages with minimal pharmacologic effects.
- 2. The FDA directly approves and monitors the eINDs, whereas it monitors the RDRC protocols only indirectly.
- 3. In RDRC, if subjects of age less than 18 are included in the study and the number of patients is more than 30, a special summary report must be submitted to the FDA. No such restrictions exist in eINDs.
- 4. The RDRC limits the radiation exposure to human subjects, whereas there is no such limit in eIND.

11.1.7 PET Radiopharmaceuticals

According to Section 121 of FDAMA, the FDA has established appropriate approval procedures and Current Good Manufacturing Practice (CGMP) requirements for positron emission tomography (PET) radiopharmaceuticals. Accordingly, the FDA has published a guidance on CGMP that addresses the issues of meticulous validation,

calibration, and documentation for the production of PET radiopharmaceuticals. It outlines the standards to adopt in manufacturing PET radiopharmaceuticals to meet the requirements of safety, identity, strength, quality, and purity of the product. The FDA also requires a PET center to employ a sufficient number of personnel with essential training and experience to perform the required CGMP.

Since methods of production of PET radiopharmaceuticals vary considerably among manufacturing centers, the FDA considers PET radiopharmaceuticals as new drugs, and therefore, each facility is required to have an NDA or abbreviated NDA (ANDA) of the PET drug approved by the FDA, based on the safety and effectiveness data. The FDA has approved ¹⁸F-fluorodeoxyglucose (FDG), ¹³N-ammonia, ⁸²Rb-rubidium chloride, and ¹⁸F-sodium fluoride for clinical use in humans based on literature review and input from the medical community. One can apply for an NDA for these products referring to an already approved NDA, provided their ingredients, route of administration, dosage form, and strength are identical. However, the FDA considers an ANDA to be a more appropriate application, rather than a full NDA, for an already approved drug for a particular indication.

The FDA mandated that beginning December 12, 2015, investigational use of a PET drug must be covered by a traditional IND unless it is exempted from all of the IND requirements. The research use of a PET drug is covered by the RDRC, provided the administered dosage does not cause detectable pharmacologic effect without compromising the benefit of the study and the protocol maintains all elements of RDRC requirements. Expanded access IND (eaIND) is applied for clinical use of PET drugs that are not covered by NDA or ANDA. eaIND is applicable when (1) a patient or patients have a serious life-threatening disease; (2) there is no comparable or satisfactory alternative therapy to diagnose, monitor, or treat the disease; and (3) the potential patient benefit justifies the potential risks of the treatment use.

11.1.8 FDA Regulations for Compounding in Nuclear Pharmacies

Section 503A of the FDAMA specifies the criteria and requirements for pharmacy compounding. Under this section, drug products that are compounded by a licensed pharmacist or physician on a customized basis for an individual patient on the basis of a valid prescription may be entitled to exemptions from three provisions of the Act: (1) the adulteration provision of Section 501(a)(2)(B) (concerning the good manufacturing practice requirements); (2) the misbranding provision of Section 502(f)(1) (concerning the labeling of drugs with adequate directions for use; and (3) the new drug provision of Section 505 (concerning the approval of drugs under NDA or ANDA).

For this exemption, the drug compounded in bulk or small quantities must meet the requirements of the US Pharmacopeia (USP) or National Formulary (NF) monograph and has components approved by the FDA and manufactured by a registered manufacturer. The compounded drug cannot be a product that has been withdrawn from the market because of the unsafe and ineffective characteristics or a copy of the commercial drug in inordinate amounts or routinely produced. However, Section 503A does not apply to PET drugs and other radiopharmaceuticals, even though the radiopharmaceuticals are compounded by a nuclear pharmacist or physician under a valid prescription. Thus, these drug products are not exempted from the requirements of Sections 501(a)(2)(B), 502 (f)(1), and 505. Although compounding of radiopharmaceuticals is identical to that of conventional drugs, radiopharmaceutical handling is distinctly different because of radiation. In 1984 the FDA set guidelines for nuclear pharmacy practice and for requirements for registering as a manufacturer. The FDA is considering various guidelines and corresponding compliance guides to be implemented in the future. In 2001 the American Pharmaceutical Association (APhA) published a treatise on nuclear pharmacy guidelines based on the principles of the 1984 Nuclear Pharmacy Guideline. It is hoped that the forthcoming FDA guidelines and compliance guides will follow those of the APhA.

There are centralized nuclear pharmacies that supply radiopharmaceuticals to many local and distant hospitals. Nuclear pharmacies may operate as standalone units or within a pharmacy or nuclear medicine department and supply all radiopharmaceuticals to the department of nuclear medicine in different hospitals. All these organizations must possess licenses from the NRC or the Agreement State Agency (see later) for the use of radioactive materials. The state boards of pharmacy in the USA have set specific guidelines regarding the practice of nuclear pharmacies, but the guidelines vary from state to state. Nuclear pharmacies at times may perform some activities that are considered "manufacturing." In 1984 the FDA set guidelines for nuclear pharmacies as to when they are required to register with the FDA as a manufacturer. Here are some examples (Table 11.1):

11.1.9 Drug Quality and Security Act

Until recently, drug compounding on physician's or pharmacist's order was outside the control of the US FDA, and as a result, drugs formulated by compounding facilities were of suboptimal quality and caused adverse effects including deaths. So Congress recently passed a law (Drug Quality and Security Act) authorizing the FDA to monitor and keep track of the activities of these compounding facilities. Under the law, compounding facilities are considered as "outsourcing" facilities and must comply with the Current Good Manufacturing Practice (CGMP) in compounding drugs. Also they must provide information on the compounded drugs and biannually report the adverse effects of the drug to the FDA. The FDA will have the authority to inspect these facilities on a risk-based schedule. The FDA recommends that all compounding facilities register their facility and drugs with the FDA, although it is not mandatory. However, the FDA urges all healthcare providers to use only registered compounding pharmacies for their provision of compounded drugs. If a compounding facility does not register with the FDA, it will be considered a manufacturer and is required to follow CGMP to produce drugs.

		Registration
Source of drug	Activities of the nuclear pharmacy	required
Radioactive drug is supplied by a manufacturer (product	Dispenses the drug under a prescription in the manufacturer's original container	No
is subject to an approved NDA or IND)	After storing the drug, ships the drug in the manufacturer's original container to another nuclear pharmacy or to a physician with or without having received a prescription	No
	Fills the drug into single- or multiple-dosage containers in anticipation of a future need and its subsequent dispensing under a prescription	No
	Dispenses a drug that was diluted or filled into single- or multiple-dosage containers upon receipt of a prescription	No
	Dilutes or fills the drug into single- or multiple-dosage containers and dispenses the drugs without a prescription but upon receipt of an appropriate order, for use within the same institution.	No
	Dilutes or fills the drug into single- or multiple-dosage containers and ships it without a prescription to another nuclear pharmacy or institution that, irrespective of its location or ownership, is recognized as a separate entity by the FDA.	Yes
	Upon a request from a physician, routinely dilutes or fills the drug into single- or multiple- dosage containers and ships the drug to the physician for his/her own professional use	No
	Upon receipt of a prescription, prepares a radioactive drug and dispenses it	No
Radioactive drug (not involving the use of a nonradioactive kit) prepared by the nuclear pharmacy	Prepares a radioactive drug in anticipation of a future need and its subsequent dispensing under a prescription	No
	Prepares a radioactive drug and dispenses it without a prescription but upon receipt of an appropriate order for use within the same institution	No
	Prepares a radioactive drug and ships it without a prescription to another pharmacy or institution that, irrespective of its location or ownership, is recognized as a separate entity by the FDA	Yes
	Operates an accelerator or nuclear reactor to produce radionuclides and radiochemicals to manufacture radioactive drugs to be dispensed under a prescription	No
	Prepares radiochemicals and ships them to other nuclear pharmacies or institutions as drug components	Yes
	Upon a request from a physician, routinely prepares a drug in single- or multiple-dosage containers and ships the drug to the physician for his/her own professional use	No

Table 11.1 Requirements for registration as a manufacturer

(continued)

		Registration
Source of drug	Activities of the nuclear pharmacy	required
A reagent kit and generator are supplied by a manufacturer (the kit and	Radiolabels the reagent kit according to the manufacturer's directions and dispenses the drug under a prescription	No
generator are subject to an approved NDA and IND)	Radiolabels a reagent kit in anticipation of a future need and its subsequent dispensing under a prescription	No
	Radiolabels a reagent kit and ships it without a prescription to another pharmacy that, irrespective of its location or ownership, is recognized as a separate entity by the FDA	Yes
	Upon request from a physician, routinely radiolabels a reagent kit and ships the drug to the physician for own use in his/her professional practice	No
A reagent kit is prepared by the nuclear pharmacy	Upon receipt of a prescription, prepares and radiolabels the reagent kit and dispenses it	No
	Prepares a reagent kit in anticipation of a future need; upon receipt of a prescription, radiolabels and dispenses it	No
	Prepares a reagent kit and ships it without a prescription, either before or after radiolabeling, to another pharmacy that, irrespective of its location or ownership, is recognized as a separate entity by the FDA	Yes
	Prepares a reagent kit and ships it without a prescription, either before or after radiolabeling, to another institution	Yes
	Upon a request from a physician, routinely prepares reagent kits and ships them either before or after radiolabeling, to the physician (or his/her own professional use)	No
Radioactive drug or reagent kit obtained from another nuclear pharmacy, institution, or practitioner	Uses the radioactive drug or reagent kit to perform one or more steps in the manufacture of a radioactive drug as a service for the nuclear pharmacy or institution that supplied the radioactive drug or kit, i.e., custom manufacturing	Yes

11.1.10 State Boards of Pharmacy

The practice of nuclear pharmacy is regulated by the board of pharmacy in each state. The National Association of Nuclear Pharmacies (NANP) has introduced Model Nuclear Pharmacy Regulations that are available to state boards of pharmacies for implementation. These regulations include training requirements, requirements for space, equipment quality control, and other related aspects of pharmacy practice. There may be variations in implementation of these regulations from state to state.

11.2 Nuclear Regulatory Commission

The Nuclear Regulatory Commission (NRC) regulates all reactor-produced byproduct materials with regard to their use and disposal and the radiation safety of all personnel using them as well as the public. Until 2005, naturally occurring and accelerator-produced radioactive materials (NARM) were regulated by the state regulatory agencies such as health department, environmental agency, and so on, while the NRC controlled the byproduct material produced in the reactor. On August 8, 2005, Congress passed the Energy Policy Act expanding the definition of byproduct materials to include NARM products and thereby transferring their control to the NRC. Now the NRC regulates all reactor-produced, accelerator-produced, and naturally occurring radioactive materials, and the Agreement States (see below) must adopt the NRC regulations for radiation control.

11.2.1 Agreement States

As stated above, the accelerator-produced and naturally occurring radionuclides had been regulated by state agencies until August 8, 2005, when these were included in the definition of byproduct material and brought under the regulatory control of the NRC. For convenience of operation, at present, 37 states have entered into agreement with the NRC to implement all regulations concerning the use of all byproduct materials including naturally occurring, accelerator-produced, and reactor-produced radionuclides. These states are called the Agreement States. The rules and regulations of these states controlling the use of byproduct materials must be as strict as, if not stricter than, those of the NRC. Like the NRC, they issue licenses to applicants (authorized users), upon submission of the intended use of radionuclides, and strictly monitor the appropriate use and disposal of byproducts by the users.

11.2.2 Licenses

Authorization for the use of byproduct material is granted by issuance of a license by the NRC or the Agreement State. There are two categories of licenses:

1. General domestic license: Although the general domestic license is given for the use of byproduct material in various devices according to 10CFR31, only the provisions of 10CFR31.11 are applicable for general license for the use of byproduct material in certain in vitro clinical laboratory tests in the amount of 10 μ Ci (370 kBq) each of ¹²⁵I, ¹³¹I, ¹⁴C, and ⁷⁵Se, 20 μ Ci (740 kBq) of ⁵⁹Fe, and 50 μ Ci (1.85 MBq) of ³H. Such general licenses are given to physicians, veterinarians, clinical laboratories, and hospitals only for in vitro tests, not for the use of byproduct material in humans or animals. An application must be filed with the NRC using the Form NRC-483 "Registration Certificate – In vitro Testing

with Byproduct Material under General License" and a validated copy must be obtained prior to the use of byproduct material. The total amount to be possessed at any one time should not exceed 200 μ Ci (7.4 MBq) of ¹²⁵I, ¹³¹I, ⁷⁵Se, and/or ⁵⁹Fe. The products must be supplied in prepackaged units. Appropriate records of possession, use, and storage of byproduct materials must be maintained.

2. Specific domestic licenses: The specific licenses are given in two categories – one to manufacture or transfer for commercial distribution certain items containing byproduct material (10CFR32) and the other to possess, use, and transfer byproduct material in any chemical or physical form with the limitations of the maximum activity specified (10CFR33). The former types of specific licenses are typically given to commercial manufacturers. The latter type is called the specific license of broad scope or "broad license" and has three categories based on the maximum activity allowed for the receipt, acquisition, ownership, possession, use, and transfer of any chemical or physical form of byproduct material (10CFR33.11). The Type A broad license allows specified quantities of activities, usually in multicuries; the Type B broad license allows maximum activities of byproduct material specified in 10CFR33.100, Schedule A, Column I; and the Type C license permits maximum activities of byproduct material specified in 10CFR33.100, Schedule A, Column II, which are two orders of magnitude less than those in the Type B license.

The Type A licenses are mainly issued to large medical institutions with previous experience that are engaged in medical research and in diagnostic and therapeutic uses of byproduct material. Individual users in the institution are authorized by licensee's management to conduct specific protocols using byproduct materials. Establishment of a Radiation Safety Committee and appointment of a radiation safety officer are required. The Type B licenses are normally issued to physicians in private practice or group practice and smaller medical institutions where the use of byproduct material is limited and the names of all authorized users are indicated on the license. A radiation safety officer is required. The Type C licenses are issued to physicians in practice using only a limited quantity of byproduct material. The licensee must have a bachelor degree in physical or biological science or engineering with 40 h of training and experience in handling radioactivity. The licensee provides a statement that the byproduct material will be used by him or persons under his supervision who satisfy the training requirement in 10CFR33.15.

In all cases of specific licenses, an application must be signed by the licensee's management and filed with the NRC using the NRC Form 313. All information related to the possession, use, and disposal of byproduct material must be provided on the application.

11.2.3 Accreditation of Nuclear Medicine Facilities

For improved quality assurance of the clinical procedures in the nuclear medicine facilities, the US Congress has passed a law requiring these facilities, institutional or stand-alone, to be accredited by qualified accreditation agencies. In the same

context, the Centers for Medicare and Medicaid Services (CMS) and private health insurers such as UnitedHealthcare and Blue Cross Blue Shield also require accreditation of these facilities for reimbursement for patient studies. Two organizations, the American College of Radiology (ACR) and the Intersocietal Commission for the Accreditation of Nuclear Medicine Laboratories (ICANL), have set specific criteria for accreditation of nuclear medicine facilities. The focus of these programs is perpetual quality improvement of the facilities through peer reviews and continuing education and training. For accreditation, the interested nuclear medicine facility needs to apply to any of these organizations along with a payment of appropriate fees. The entire department or, if desired, a section of it such as nuclear cardiology, PET center, etc. separately can apply for accreditation. ACR or ICANL grants accreditation based on the fulfillment of requirements for eligibility.

Although the purpose of both ACR and IACNL programs are the same, there are some subtle differences in the concept and focus of review process. The ICANL emphasizes on the specifics of an examination involving a particular organ, critically reviewing the procedural, technical, and interpretative quality of patient studies. It requires at least two representative case studies per organ type (e.g., cardiac, genitourinary, gastrointestinal, tumor, thyroids, therapy, etc.), and most studies should be interpreted as abnormal by as many physicians as possible. In all, as many as 20 patient studies must be submitted for comprehensive review. In the case of PET studies, three cases are required to be submitted.

In contrast, ACR emphasizes on the quality control, calibration of equipment, and technical details of the patient studies and accordingly has developed three modules – module 1 for planar imaging (whole body (required), spot bone, liver, MUGA, lung perfusion, thyroid, and so on), module 2 for SPECT studies (bone (required), brain, myocardial perfusion gallium), and module 3 for the heart (myocardial perfusion and MUGA). The facility must submit two different examination types for each module/submodule. For accreditation, ACR requires the facilities to submit approved phantom data on the acceptance test and subsequent annual performance test of all equipment using National Electrical Manufacturers Association (NEMA) protocol, data collection, reporting, radiopharmaceutical procedures, and laboratory safety, along with clinical images. Both ACR and ICANL have set requirements for qualifications of professionals for the purpose of accreditation.

For ICANL accreditation, physicians need to be board certified in nuclear medicine or radiology with special competency in nuclear medicine, whereas special competency is not required by ACR. Both agencies require quality control tests to be performed daily, weekly, monthly, or annually depending on the nature of the test. However, ACR mandates the presence of a certified medical physicist for monitoring the performance tests, but ACANL only recommends for such an individual. Technologists need to be certified by the American Registry of Radiologic Technologists in nuclear medicine (ARRT(N)) or Nuclear Medicine Technology Certification Board (NMTCB) or eligible by training and experience approved by ACR. Continued accreditation is granted based on the evidence of continuing education of specified hours for each professional at the facility. Detailed information is available from http://www.acr.org and http://www.icanl.org.

11.2.4 Radiation Protection

Because radiation can cause damage in living systems, international and national organizations have been established to set guidelines for the safe handling of radioactive materials. The International Commission on Radiological Protection (ICRP) and the National Council on Radiation Protection and Measurement (NCRP) are two such organizations. They set guidelines for all radiation workers to follow in handling radiations. The NRC adopts these recommendations into regulations for implementing radiation protection programs in the USA. At present, the 10CFR20 contains all major radiation protection regulations applicable in the USA. Since it is beyond the scope of this book to include the entire 10CFR20, only the relevant highlights are presented here.

Definitions

Several terms relate to absorbed doses and radiation areas as defined in the revised 10CFR20:

- *Committed dose equivalent* $(H_{T,50})$ is the dose equivalent to organs or tissues of reference (T) that will be received from an intake of radioactive material by an individual during the 50-year period following the intake.
- Committed effective dose equivalent $(H_{E,50})$ is the sum of the products of the weighting factors applicable to each of the body organs or tissues that are irradiated and the committed dose equivalent to these organs or tissues $(H_{E,50} = \Sigma W_T \times H_{T.50})$. This is given by Eq. (10.20) in Chap. 10.
- Controlled area means an area, beyond a restricted area but inside the site boundary, access to which can be limited the licensee for any reason.
- *Deep-dose equivalent* (H_d), which applies to the external whole-body exposure, is the dose equivalent at a tissue depth of 1 cm (1000 mg/cm²).
- *Dose equivalent* (H_r) is the product of absorbed dose in tissue, quality factor, and all other modifying factors at the location of interest. It is expressed in rem (Sv) and given by Eq. (10.7) in Chap. 10.
- Shallow-dose equivalent (H_s), which applies to the external exposure of the skin or an extremity, is the dose equivalent at a tissue depth of 0.007 cm (7 mg/cm²) averaged over an area of 1 cm².
- Effective dose equivalent (H_E) is the sum of the products of the weighting factor applicable to each of the body organs or tissues that are irradiated and the dose equivalent to the corresponding organ or tissue ($H_E = \sum W_T \times \sum H_r$). The values of W_T are given in Table 10.3 in Chap. 10. ICRP terms this simply effective dose.
- Annual limit on intake (ALI) is the derived limit on the amount of radioactive material taken into the body of an adult worker by inhalation or ingestion in a year. These values are given in Table 1, Appendix B, in 10CFR20.
- Derived air concentration (DAC) is the concentration of a given radionuclide in air that, if breathed by the reference man for a working year of 2000 h under conditions of light work, results in an intake of ALI. DAC values are given in Table 1, column 3 of Appendix B in 10CFR20.

- Total effective dose equivalent (TEDE) is the sum of the effective deep-dose equivalent (for external exposure) and the committed effective dose equivalent (for internal exposure) for all organs.
- Radiation area is an area in which an individual could receive from a radiation source a dose equivalent in excess of 5 mrem (0.05 mSv) in 1 h at 30 cm from the source.
- High radiation area is an area in which an individual could receive from a radiation source a dose equivalent in excess of 100 mrem (1 mSv) in 1 h at 30 cm from the source.
- Very high radiation area is an area in which an individual could receive from radiation sources an absorbed dose in excess of 500 rad (5 Gy) in 1 h at 1 m from the source.
- Restricted area is an area of limited access that the licensee establishes for the purpose of protecting individuals against undue risks from exposure to radiation and radioactive materials.
- Unrestricted area is an area in which an individual could receive from an external source a maximum dose of 2 mrem ($20 \ \mu Sv$)/h, and access to the area is neither limited nor controlled by the licensee.

Caution Signs and Labels

The NRC requires that specific signs, symbols, and labels be used to warn people of possible danger from the presence of radiations. These signs use magenta, purple, and black colors on a yellow background, and some typical signs are shown in Fig. 11.1.

- Caution: Radiation Area This sign must be posted in radiation areas.
- Caution: High Radiation Area or Danger, High Radiation Area This sign must be posted in high radiation areas.
- Caution: Radioactive Material or Danger, Radioactive Material This sign is posted in areas or rooms in which ten times the quantity or more of any licensed material specified in Appendix C of 10CFR20 are used or stored. All containers with quantities of licensed materials exceeding those specified in Appendix C of 10CFR20 should be labeled with this sign. These labels must be removed or defaced prior to disposal of the container in the unrestricted areas.

Caution signs are not required in rooms storing the sealed sources, provided the radiation exposure at 1 foot (30 cm) from the surface of the source reads less than 5 mrem (0.05 mSv) per h. Caution signs are not needed in rooms where radioactive materials are handled for less than 8 h, during which time the materials are constantly attended.

Occupational Dose Limits

The annual limit of the occupational dose to an individual adult is the more limiting of (a) TEDE of 5 rem (0.05 Sv) or (b) the sum of the deep-dose equivalent and the committed dose equivalent to any individual organ or tissue other than the lens of the eye being equal to 50 rem (0.5 Sv). It should be noted that there is no lifetime cumulative dose limit in the revised 10CFR20, although the NCRP recommends a lifetime cumulative dose of 1 rem (0.01 Sv) × age in years.



Fig. 11.1 Radiation caution signs

The annual limit on the occupational dose to the lens of the eye is 15 rem (0.15 Sv).

The annual limit on the occupational dose to the skin and other extremities is the shallow-dose equivalent of 50 rem (0.5 Sv).

Depending on the license conditions, both internal and external doses have to be summed to comply with the limits. A licensee may authorize under planned special procedures an adult worker to receive additional dose in excess of the prescribed annual limits, provided no alternative procedure is available. The total dose from all planned procedures plus all doses in excess of the limits must not exceed the dose limit (5 rem or 0.05 Sv) in a given year, nor must it exceed five times the annual dose limits in the individual's lifetime.

Doses received in excess of the annual limits, including doses received during accidents, emergencies, and planned special exposures, must be subtracted from the limits for planned special exposures that the individual may receive during the current year and during the individual's lifetime.

The licensee shall reduce the dose that an individual may receive in the current year by the amount of occupational dose already received while employed by another person.

The annual occupational dose limits for minors are 10% of the annual dose limits for the adults. The dose limit to the fetus/embryo during the entire pregnancy (gestation period) due to occupational exposure of a declared pregnant woman is 0.5 rem (0.005 Sv).

The total effective dose equivalent to individual members of the public is 0.1 rem (0.001 Sv) per year. However, this limit can be increased to 0.5 rem (0.005 Sv) provided the need for such a higher limit is demonstrated.

The dose in an unrestricted area from an external source is 2 mrem (0.02 mSv) in an hour.

ALARA Program

The dose limits are the upper limits for radiation exposure to individuals. The NRC has instituted the ALARA (as low as reasonably achievable) concept to reduce radiation exposure to individuals. The ALARA concept calls for a reasonable effort to maintain individual and collective doses as low as possible. Under this concept, techniques, equipment, and procedures are all critically evaluated. According to Regulatory Guide NUREG-1556, volume 9, Appendix L, under the ALARA concept, when the exposure to a radiation worker exceeds 10% of the occupational exposure in a quarter (Action level I), an investigation by the RSO takes place, and the report is reviewed by the Radiation Safety Committee (RSC). When the occupational exposure exceeds 30% of the occupational exposure (Action level II), corrective actions are taken, or the institution must justify a higher dose level for ALARA in that particular situation.

Principles of Radiation Protection

Of the various types of radiation, the α -particle is most damaging due to its great charge and mass, followed by the β -particle and the γ -ray. Heavier particles have shorter ranges and therefore deposit more energy per *unit* path length in the absorber, causing more damage. These are called *nonpenetrating* radiations. On the other hand, γ - and X-rays have no charge and mass and therefore have a much longer range in matter. These electromagnetic radiations are called *penetrating* radiations. Knowledge of the type and energy of radiations is essential in understanding the principles of radiation protection.

The cardinal principles of radiation protection from external sources are based on four factors: time, distance, shielding, and activity.

Time

The total radiation exposure to an individual is directly proportional to the time the person is exposed to the radiation source. The longer the exposure, the higher the radiation dose. Therefore, it is wise to spend no more time than necessary near radiation sources.

Distance

The intensity of a radiation source, and hence the radiation exposure, varies inversely as the square of the distance. It is recommended that an individual remains as far away as practically possible from the radiation source. Procedures and radiation areas should be designed such that only minimum exposure occurs to individuals doing the procedures or staying in or near the radiation areas.

The radiation exposure level from γ - and X-ray emitters can be estimated from the *exposure rate constant*, Γ , which is defined as the exposure due to γ - and X-rays in R/h from 1 mCi (37 MBq) of a radionuclide at a distance of 1 cm. Each γ - and X-ray emitter has a specific value for Γ^1 , and it has the unit of R-cm²/mCi-h at 1 cm or, in SI units,

¹The Γ value of photon-emitting radionuclides can be calculated from the expression $\Gamma = 199\Sigma N_i E_i \mu_i$, where N_i is the fractional abundance of photons of energy E_i in MeV and μ_i is the mass absorption coefficient (cm²/g) of air for photons of energy E_i .

Radionuclides	Γ^{20} (R-cm ² /mCi-h at 1 cm)	$\Gamma^{20} (\mu Gy-m^2/GBq-h \text{ at }1\text{ m})^a$	HVL, Pb (cm)
¹³⁷ Cs	3.26	88.11	0.65
^{99m} Tc	0.59	15.95	0.03
²⁰¹ Tl	0.45	12.16	0.02
⁹⁹ Mo	1.46	39.46	0.70
⁶⁷ Ga	0.76	20.54	0.10
^{123}I	1.55	41.89	0.04
¹¹¹ In	2.05	55.41	0.10
¹²⁵ I	1.37	37.03	0.003
⁵⁷ Co	0.56	15.16	0.02
^{131}I	2.17	58.65	0.30
${}^{18}F^{b}$	5.7	154.05	0.39

 Table 11.2
 Exposure rate constants and half-value layer values in lead of commonly used radionuclides

Adapted from Goodwin (1984)

^aR-cm²/mCi-h is equal to 27.027 µGy-m²/GBq-h

^bPersonal communication with Dr. M. Stabin, Oak Ridge Associated Universities, Inc., Oak Ridge, Tennessee

 μ Gy-m²/GBq-h at 1 m. Since γ - or X-rays below some 10 or 20 keV are absorbed by the container and thus do not contribute to radiation exposure, often γ - and X-rays above these energies only are included in the calculation of Γ . In these instances, they are denoted by Γ^{10} or Γ^{20} . The values of Γ^{20} for different radionuclides are given in Table 11.2.

The exposure rate *X* from an n (mCi) radionuclide source at a distance d (cm) is given by

$$X = \frac{n\Gamma}{d^2} \tag{11.1}$$

where Γ is the exposure rate constant of the radionuclide.

Problem 11.1

What is the exposure rate at 30 cm from a vial containing 20 mCi (740 MBq) of ¹³¹I?

Answer

The exposure rate constant Γ^{20} for ¹³¹I is 2.17 R-cm²/mCi-h at 1 cm from Table 11.1. Therefore, using Eq. (11.1), at 30 cm

$$X = \frac{20 \times 2.17}{30^2} = 0.048 \text{ R / h}$$

Since Γ^{20} for ¹³¹I in SI units is 58.65 µGy-m²/GBq-h at 1 m, X for 740 MBq ¹³¹I at 30 cm (0.3 m) is

$$X = \frac{0.74 \times 58.65}{(0.3)^2} = 482.2\,\mu Gy \,/\,h$$

Shielding

Various high atomic number (Z) materials that absorb radiations can be used to provide radiation protection. Since the ranges of α - and β -particles are short in matter, the containers themselves act as shields for these radiations. However, γ -radiations are highly penetrating, and therefore highly absorbing material must be used for shielding of γ -emitting sources. For economic reasons, lead is most commonly used for this purpose. The concept of half-value layer (HVL) of an absorbing material for penetrating radiations is important in the design of shielding for radiation protection. It is defined as the thickness of shielding that reduces the exposure from a radiation source by one half. Thus, an HVL of an absorber placed around a source of radiation with an exposure rate of 100 mR/h will reduce the exposure rate to 50 mR/h. The HVL is dependent on both the energy of the radiation and the atomic number of the absorbing material. The HVL value is higher for high-energy radiations and lower for high-Z materials. The higher the HVL of any material for a radiation, the larger the amount of material necessary to shield the radiation. The HVLs in lead of different radionuclides are given in Table 11.2.

Obviously, shielding is an important means of protection from radiation. Radionuclides should be stored in a shielded area. The dosages for patients should be transported in lead containers and injected using syringe shield. Radionuclides emitting β -particles should be stored in containers of low-Z material such as aluminum and plastic because in high-Z material such as lead, they produce highly penetrating bremsstrahlung radiation. For example, ³²P should be stored in plastic containers instead of lead containers.

Activity

It should be obvious that the radiation hazard increases with the intensity of the radioactive source. The higher the source strength, the more the radiation exposure. Therefore, one should not work unnecessarily with high quantities of radioactivity.

Receiving and Monitoring of Radioactive Packages

According to 10CFR20, all packages carrying radioactive labels must be monitored for radioactive contamination. Monitoring should be done within 3 h after delivery if the package is delivered during the normal working hours or no later than 3 h from the beginning of the next working day if it is received after working hours. Two types of monitoring are performed: survey for external exposure and wipe test for removable contamination on the surface of the package due to leakage of the radioactive material. The external survey is made by using a GM survey meter at the surface and at 1 m from the package. The wipe test for removable contamination is carried out by swabbing 300 cm² areas on the package surface using absorbent paper and counting the swab in a NaI(TI) scintillation counter. The NRC limits of these measurements are:

Tests	Limits
Survey at the surface	<200 mR/h
Survey at 1 m	<10 mR/h
Wipe test	6600 dpm/300 cm ²

If any of the readings exceeds the limit, a report of investigation and remedy has to be made, and the NRC and the final delivery carrier must be notified by telephone and telegram, mailgram, or facsimile.

After the completion of the survey, all information as to the date of receipt, the manufacturer, the lot number, name and quantity of the product, date and time of calibration, the survey readings, and the name of the individual performing the tests are required to be entered into a record book.

Radioactive Waste Disposal

Radioactive waste generated in nuclear medicine or pharmacy (e.g., syringes, needles, vials containing residual activities, liquid waste, gas, and contaminated papers, tissues, and liners) is disposed of by the following methods according to the guidelines set forth in 10CFR20:

- 1. Decay-in-storage
- 2. Release into a sewerage system
- 3. Transfer to an authorized recipient (commercial land disposal facilities)
- 4. Other disposal methods approved by the NRC (e.g., incineration and atmospheric release of radioactive gases)

The following is a brief description of the different methods of radioactive waste disposal, but one should consult 10CFR20 and 10CFR35 for further details.

Decay-in-Storage

Although 10CFR20 does not spell out the conditions of the decay-in-storage method, 10CFR35.92 describes this method in detail. Radionuclides with half-lives less than 120 days usually are disposed of by this method. The waste is allowed to decay for a period of time and then surveyed. If the radioactivity of the waste cannot be distinguished from background, it can be disposed of in the normal trash after removal of all radiation labels. This method is most appropriate for short-lived radionuclides such as ^{99m}Tc, ¹²³I, ²⁰¹Tl, ¹¹¹In, and ⁶⁷Ga, and therefore it is routinely employed in nuclear medicine. Radioactive waste should be stored separately according to the similar half-lives of radionuclides for convenience of timely disposal of each radionuclide.

Release into a Sewerage System

The NRC permits radioactive waste disposal into a sewerage system provided the radioactive material is soluble (or dispersible biological material) in water and the quantity disposed of monthly does not exceed the limits of the maximum permissible concentrations (MPCs) set in 10CFR20. When more than one radionuclide is released, the fraction of each radionuclide is calculated from the limit given in 10CFR20, and the sum of the fractions of all radionuclides should not exceed unity. Disposal depends on the flow rate of water but is limited to 1 Ci (37 GBq) of ¹⁴C, 5 Ci (185 GBq) of ³H, and 1 Ci (37 GBq) for all other radionuclides annually.

Excreta from humans undergoing medical diagnosis or treatment with radioactive material are exempted from these limitations. However, items contaminated with excreta (such as linens and diapers contaminated with urine or feces) are not exempted from these limitations. To follow this method of radioactive disposal in an institution, one has to determine the average daily flow of sewer water in the institution from the water usage bill and the number of users of a radionuclide, so that for each individual user a limit can be set for sewer disposal of the radionuclide in question.

Transfer to an Authorized Recipient

A transfer to an authorized recipient method is adopted for long-lived radionuclides and usually involves transfer of radioactive waste to authorized commercial firms that bury or incinerate at approved sites or facilities.

Each shipment of radioactive waste must be accompanied by a shipment manifest that contains the names, addresses, and telephone numbers of the waste generator and waste collector and the identity, volume, and total radioactivity of the radionuclide. The manifest shall include a certification that the shipment is properly classified, packaged, marked, and labeled according to the regulations of the Department of Transportation.

Other Disposal Methods

A licensee may adopt separate methods of radioactive waste disposal other than those mentioned above, provided approval is obtained from the regulatory agency. The impact of such disposal methods on the environment, nearby facilities, and the population is heavily weighed before approval is granted. Incineration of carcasses of research animals containing radioactive materials is allowed by this method up to the limit of MPCs. Radioactive gas such as ¹³³Xe is also released by this method as long as the radioactive effluent into the atmosphere does not exceed the NRC limits of MPCs. Radioactive waste containing 0.05 μ Ci (1.85 kBq) or less of ³H or ¹⁴C per gram of medium used for liquid scintillation counting or of animal tissue may be disposed of in the regular nonradioactive trash. The disposed tissue must not be used for human or animal consumption.

Records must be maintained of the date of storage and the amount and kind of activity in a waste disposal logbook. The stored packages must be labeled with pertinent information. The date of disposal, the amount of disposed activity, and the name of the individual who is disposing must also be recorded in the logbook.

Radioactive Spill

Accidental spillage of radioactivity can cause unnecessary radiation exposure to personnel and must be treated cautiously and expeditiously. There are two types of spills: major and minor. No definitive distinction exists between a major and a minor spill. A major spill usually occurs when the spilled activity cannot be contained in a normal way and can cause undue exposure to personnel around. In the case of a major spill, the radiation safety office should be notified immediately. In either case, the access to the area should be restricted. Appropriate procedures must be

established for decontamination. Areas, personnel, and equipment have to be decontaminated, keeping in mind the principle of containment of radioactivity. Survey and wipe test have to be carried out after decontamination. The RSO investigates the accident and recommends corrective action if a major spill occurs.

Personnel Monitoring

Personnel monitoring is required under the following conditions:

- 1. Occupational workers including minors and pregnant women likely to receive in 1 year a dose in excess of 10% of the annual limit from the external radiation source
- 2. Individuals entering high or very high radiation areas

Monitoring for occupational intake of radioactive material is also required if the annual intake by an individual is likely to exceed 10% of the ALls in Table 1, Appendix B of 10CFR20, and if the minors and pregnant women are likely to receive a committed effective dose equivalent in excess of 0.05 rem (0.5 mSv) in 1 year.

Three common devices are used to measure the exposure of ionizing radiations received by an individual: the pocket dosimeter, the film badge, and the thermoluminescent dosimeter. The pocket dosimeter works on the principle of a charged electroscope (Fig. 11.2) provided with a scale inside. The scale is so designed that when the dosimeter is fully charged, it reads zero, and as the charge is reduced by radiation, the reading on the viewable scale increases. The dosimeter is initially charged to read zero. Ionizing radiation discharges the dosimeter by ionization in the sensitive volume of the chamber, and the amount of exposure can be read from the scale. The dosimeter has the advantage of giving an immediate reading, but it requires frequent charging for reuse. Because the charge leaks over time, the cumulative reading over a long period of time can be erroneous. These dosimeters are available in full-scale readings of 200 mR, 500 mR, and 1 R.

The film badge is most popular and cost-effective for personnel monitoring and gives reasonably accurate readings of exposures from β -, γ -, and X-radiations. The film badge consists of a radiation-sensitive film held in a plastic holder (Fig. 11.2). Filters of different materials (aluminum, copper, and cadmium) are attached to the holder in front of the film to differentiate exposures from radiations of different types and energies. The optical density of the developed film after exposure is measured by a densitometer and compared with that of a calibrated film exposed to known radiations. Film badges are usually changed by radiation workers on a monthly basis and give an integrated dose for each individual for a month. The main disadvantage of the film badge is the long waiting period before the exposed personnel know about their exposure. The film badge also tends to develop fog due to heat and humidity, particularly when in storage for a long time, and this may obscure the actual exposure reading.

In many institutions the film badges of all workers are sent to a commercial firm approved by National Voluntary Laboratory Accreditation Program (NVLAP) of the



Fig. 11.2 Devices to measure personnel radiation exposure. (**a**) Pocket dosimeter (Courtesy of Nuclear Associates, Division of Victoreen, Inc., 100 Voice Rd., Carle Place, New York.). (**b**) Film badge holder. (**c**) Film badge. (**d**) Thermoluminescent chip in finger badge

National Institute of Standards and Technology that develops and reads the density of the films and sends the report of exposure to the institution. When an individual is employed at a radiation facility, a record of his accumulated dose must be retrieved from previous employers and added to his present dose account.

A thermoluminescent dosimeter (TLD) consists of inorganic crystals (chips) such as lithium fluoride (LiF) and manganese-activated calcium fluoride (CaF₂:Mn) held in holders like the film badges or finger rings. When these crystals are exposed to radiations, electrons from the valence band are excited and trapped by the impurities in the forbidden band. If the radiation-exposed crystal is heated to $300-400^{\circ}$ C, the trapped electrons are raised to the conduction band, wherefrom they fall back into the valence band, emitting light. The amount of light emitted is proportional to the amount of radiation energy absorbed in the TLD. The light is measured and read as the amount of radiation exposure by a TLD reader, a device that heats the crystal and reads the exposure as well. The TLD gives an accurate exposure reading and can be reused after proper heating (annealing).

It should be noted that exposures to radiation due to medical procedures and background radiation are not included in occupational dose limits. Therefore, radiation workers should wear film badges or dosimeters only at work. These devices should be taken off during any medical procedures involving radiation such as radiographic procedures and dental examinations and also when leaving after the day's work.
Bioassay

NRC Regulatory Guide 8.20 gives the details of bioassay requirements for ¹³¹I and ¹²⁵I radionuclides. Bioassays are required when the level of radioiodine activity handled (volatile or dispersible) exceeds the following values:

Open bench : 1mCi(37MBq) Fumehood : 10mCi(370MBq) Glovebox : 100mCi(3.7GBq)

When the radioiodinated material is nonvolatile, the limits of activity are higher by a factor of 10. ¹³¹I-capsules (e.g., diagnostic capsules) may be considered with iodine in nonvolatile form, and bioassay may not be necessary unless they are inadvertently opened (e.g., dropped or crushed).

For iodine radionuclides, bioassay is performed by the thyroid uptake test within 72 h to 14 days, depending on the frequency of handling radioiodine but at least 6 h after the exposure or intake. Sometimes urine analysis may also be required. Bioassays may be required for other radionuclides depending on the amount and type of the radionuclide.

Dos and Don'ts in Radiation Protection Practice

- Do post radiation signs in radiation areas.
- Do wear laboratory coats and gloves when working with radioactive materials.
- Do handle radioactivity behind the lead barrier shield.
- Do work in a ventilated fumehood when working with radioactive gases.
- Do cover the trays and workbench with absorbent paper.
- Do store and transport radioactive material in lead containers.
- Do wear a film badge while working in the radiation laboratory.
- Do identify all radionuclides and dates of assay on the containers.
- Do survey work areas for any contamination as frequently as possible.
- Do clean up spills promptly, and survey the area after cleaning.
- Do not eat, drink, or smoke in the radiation laboratory.
- Do not pipette any radioactive material by mouth.
- Do monitor hands and feet before leaving the radiation work area.
- Do notify the RSO in case of any major spill or other emergencies related to radiation.

11.2.5 Medical Uses of Radioactive Materials

The NRC or an Agreement State regulates the medical use of all byproduct materials by enforcing 10CFR35. There are six major categories of medical uses of radioactive materials according to 10CFR35:

- 1. Radiopharmaceuticals for uptake, dilution, and excretion (10CFR35.100)
- Radiopharmaceuticals for imaging and localization including generators and kits (10CFR35.200)

- 3. Radiopharmaceuticals for therapy (10CFR35.300)
- 4. Sealed sources for brachytherapy (10CFR35.400)
- Sealed sources for diagnosis such as sources of ¹²⁵I and ¹⁵³Gd for bone mineral analysis (10CFR35.500)
- 6. Sealed sources for teletherapy such as sources of ⁶⁰Co and ¹³⁷Cs in teletherapy units (10CFR35.600)

The regulations for the medical use of all radioactive materials are given in 10CFR35, but radiopharmaceuticals under categories 1, 2, and 3 only are relevant in nuclear medicine. These radiopharmaceuticals must be approved for human clinical use by the FDA under an IND or NDA. The ^{99m}Tc activity is eluted from the ⁹⁹Mo–^{99m}Tc generator, and reagent kits are used to prepare ^{99m}Tc-labeled radiopharmaceuticals according to instructions given in the package inserts. Only reagent kits that are approved by the FDA under an IND or NDA may be used for radiopharmaceutical preparation.

Applications, Amendments, and Notifications

As already mentioned, applications for a license and its renewals must be made by the licensee's management for the medical uses of byproduct materials. Amendments to the license must be made by the licensee's management for the following:

- 1. Appointment or discontinuation of an authorized user, radiation safety officer, authorized medical physicist, or authorized nuclear pharmacist
- 2. Change of name or address of the licensee
- 3. Change or addition of the use areas
- 4. The use of excess or new byproduct materials not permitted before in the license

Notification of the above must be made within 30 days of occurrence. Change or addition of areas of use for uptake and dilution (10CFR35.100) and for localization and imaging (10CFR35.200) need not be amended. The Type A specific licenses of broad scope are exempted from these requirements, because the Radiation Safety Committee is authorized to make most of these amendments.

Authority and Responsibilities of the License

According to 10CFR35.24, the licensee's management is responsible for the overall implementation of a radiation safety program in the medical uses of byproduct material. The licensee's management shall approve in writing all new authorized users, an RSO, or a nuclear pharmacist, and ministerial changes in the radiation safety program that do not require license amendment (10CFR35.26).

The licensee's management shall appoint an RSO, who accepts in writing responsibilities to implement a radiation protection program. Management may appoint one or more temporary RSOs for 60 days in a year, if all conditions of an RSO are met.

The licensee's management also must appoint an RSC, if the licensee is authorized for two or more different types of uses of byproduct material. Examples are the use of therapeutic quantities of unsealed byproduct material (10CFR35.300) and manual brachytherapy (10CFR35.400), manual brachytherapy and low-dose-rate therapy units (10CFR35.600), or teletherapy units (10CFR35.600) and gamma knife units (10CFR35.600). The RSC must include in its membership as a minimum an authorized user of each type of use permitted in the license, the RSO, a representative of the nursing service, a representative of management, and other members, if appropriate. The NRC does not prescribe any definite frequencies of the RSC meetings nor record keeping of the minutes, but quarterly meetings and record keeping are advised. The use of byproduct materials for uptake and dilution (10CFR35.100) and imaging and localization (10CFR35.200) does not require an RSC in small institutions and private practices.

Supervision

According to 10CFR35.27, a licensee that permits an individual to work under an authorized user or authorized nuclear pharmacist using byproduct material must instruct the supervised individual to strictly follow all regulations and conditions of the license and all procedures involving byproduct material. There is no requirement for periodic review of the supervised individual's work and records. The licensee is responsible for the acts and omissions of the supervised individuals.

Mobile Nuclear Medicine Service

According to 10CFR35.80, a licensee providing mobile nuclear medicine service to a client must:

- 1. Have a letter signed by the licensee and the management of each client spelling out the details of the responsibility and authority of the client and the licensee.
- 2. Calibrate and daily check the instruments for measuring dosages and surveying.
- 3. Measure dosages and perform surveys of the area of uses at the client address.
- 4. The client must have a license for receiving and using byproduct material.

Written Directives

According to 10CFR35.40, a written directive is required when a dosage greater than 30 μ Ci (1.11 MBq) of ¹³¹I-NaI or a therapeutic dosage of an unsealed byproduct material other than ¹³¹I-NaI is administered to a patient or human research subject. The written directive must be dated and signed by an authorized user and must contain the patient's name, the dosage, the name of the drug, and the route of administration. A revision of the written directive can be made, if necessary, provided it is signed and dated by the authorized user prior to administration. In case of an emergency, an oral revision to an existing written directive is acceptable, which must be followed by a written directive within 48 h.

According to 10CFR35.41, the licensee shall develop and maintain a copy of the written procedures for the written directive that includes specific verifications of the identity of the patient before each administration and that the administration is in accordance with the written directive. The identity of the patient may be verified by the name, driver's license, birthday, any hospital's ID, number, etc.

Measurement of Dosages

According to 10CFR35.63, all dosages for patient administration must be measured in an instrument (dose calibrator) that is calibrated with nationally recognized standards or the manufacturer's instructions (10CFR35.60). Although the methods of calibration are not specifically prescribed in 10CFR35, the constancy, accuracy, linearity, and geometry of the dose calibrator must be checked as described in Chap. 8.

For unit dosages, the activity can be determined by direct measurement or by the decay correction of the activity provided by the licensed manufacturer. For dosages other than unit dosages, the activity must be determined by direct measurement, a combination of measurement of radioactivity and mathematical calculations, or a combination of volumetric measurements and mathematical calculations based on the activity provided by the manufacturer.

Unless otherwise directed by the authorized user, the licensee may not use a dosage if it does not fall within the prescribed dosage range, or if it differs from the prescribed dosage by more than 20%. The licensees who use only unit dosages supplied by the manufacturer may not need to have a dose calibrator to measure the dosages.

Calibration, Transmission, and Reference Sources

The following sources of byproduct material are permitted for check, calibration, transmission, and reference use (10CFR35.65):

- 1. Sealed sources not exceeding 30 mCi (1.11 GBq) manufactured and supplied by a licensed manufacturer or a licensee authorized to redistribute such sources
- Any byproduct material with a half-life not longer than 120 days in individual amounts not exceeding 15 mCi (0.56 GBq)
- 3. Any byproduct material with a half-life longer than 120 days in individual amounts not to exceed the smaller of 200 μ Ci (7.4 MBq) or 1000 times the quantities in Appendix B of 10CFR30
- 4. 99mTc in amounts needed

A licensee may only use sealed sources for medical use, manufactured by a licensed manufacturer (10CFR.49).

Requirement for Possession of Sealed Sources

According to 10CFR35.67, sealed sources of radionuclides with a half-life greater than 30 d and containing more than 100 μ Ci (3.7 MBq) of γ -emitting material or more than 10 μ Ci (370 kBq) α -emitting material must be leak tested and inventoried semiannually. If a source shows a leak of 0.005 μ Ci (185 Bq) or more of removable contamination, it must be immediately removed from use and stored, disposed of, or repaired according to regulations, and a report must be filed with the NRC within 5 d of the leak test describing the source involved, the test results, and the action taken.

Labeling of Vials and Syringes

Each syringe and vial containing radioactivity must be labeled to identify the radioactive drug (10CFR35.69). Each syringe or vial shield also must be labeled, unless the label on the syringe or vial is visible through the shield. Although syringe shields are not required by the NRC regulations for administration of radiopharmaceuticals, they should be used to maintain ALARA exposures.

Surveys of Ambient Radiation Exposure Rate

In addition to requirements of 10CFR20.1501 for survey for radiation exposure, According to 10CFR35.70, the NRC requires that the licensee shall survey all areas including those where unsealed byproduct material requiring a written directive is prepared for use or administered. The survey must be performed at the end of each day of use with a radiation detection instrument.

Calibration of Survey Instruments

According to 10CFR35.61, the survey meter must be calibrated before its first use, annually, and after repairs that affect calibration. Calibration must be made in all scales with readings up to 1000 mrem (10 mSv) per hour with a radiation source, and two separated readings must be calibrated on each scale or decade (digital) that is used to show compliance. The date of calibration must be noted on the instrument. The licensee may not use the survey instruments if the difference between the indicated exposure rate and the calculated exposure rate is more than 20%. Requirement for wipe testing of various areas of use for removable contamination has been eliminated in the current 10CFR35 regulations. However, it is advisable to adopt wipe testing for removable contamination for better radiation protection.

Training and Experience Requirements for Medical Uses of Byproduct Materials

Authorized users, RSOs, and nuclear pharmacists are required to have appropriate training and experience for medical uses of byproduct materials. Normally there are two methods of approval: (1) certification by a specific medical specialty board and (2) training and work experience in radionuclide handling techniques applicable to specific medical use of byproduct material.

The specialty boards approved by the NRC are listed on the NRC website. However, each board must meet all requirements of the training and work experience in a specific category described below and be approved by the NRC.

The training part includes a specified period of classroom and laboratory instruction in the areas of (1) radiation physics and instrumentation, (2) radiation protection, (3) mathematics pertinent to radioactivity, (4) chemistry of byproduct material, and (5) radiation biology and radiation dosimetry (for RSO).

The work experience must be under an authorized user, RSO, or nuclear pharmacist and must include:

- 1. Ordering, receiving, and unpacking radioactive materials and surveying
- 2. Calibration of dose calibrators and survey meters
- 3. Calculating, measuring, and preparing dosages for patients
- 4. Procedures for spill management

- 5. Safely administering dosages to patients (for authorized users only)
- 6. Elution of radioactive generators (for localization and imaging studies)

In addition, approval by training and experience method requires a written certification by a preceptor that the individual has acquired competence in the techniques to function independently for a specified use of byproduct material.

According to 10CFR35.59, the training and experience must have been obtained within 7 years previous to the date of application, or the applicant must have related continuing education and experience since the required training and experience were completed.

The required hours of training and experience vary for different types of uses of byproduct materials:

Radiation safety officer (10CFR35.50)	200 h of didactic training plus 1 year of work experience under a radiation safety officer
Authorized nuclear pharmacist (10CFR35.55)	700 h of combined training and work experience, including 200 h of classroom and laboratory training
Authorized user (uptake, dilution, and excretion) (10CFR35.190)	60 h of combined training and work experience, including 8 h of classroom and laboratory training
Authorized user (localization and imaging) (10CFR35.290)	700 h of combined training and work experience, including 80 h of classroom and laboratory training
Authorized user (therapeutic use requiring written directive) (10CFR35.390)	700 h of combined training and work experience, including 200 h of classroom and laboratory training, plus three cases in each therapeutic use of byproduct material
Authorized user [hyperthyroidism using less than 33 mCi (1.22 GBq) ¹³¹ I-NaI] (10CFR35.392)	80 h of combined training and work experience, plus three cases of hyperthyroid treatments
Authorized user [thyroid cancer using greater than 33 mCi (1.22 GBq) ¹³¹ I-NaI] (10CFR35.394)	80 h of combined training and experience, plus three cases of thyroid cancer treatments

11.2.6 Report and Notification of Medical Event

A medical event occurs when a dose exceeds 5 rem (0.05 Sv) effective dose equivalent or 50 rem (0.5 Sv) to an organ or tissue or skin from any of the following situations:

- 1. The total dosage delivered differs from the prescribed dosage by 20% or more or falls outside the prescribed dosage range.
- 2. Administration of a wrong radioactive drug containing byproduct material.
- 3. Administration by a wrong route.
- 4. Administration to a wrong individual.

The licensee must notify a medical event by telephone to the NRC Operations Center no later than 1 calendar day after the discovery of the event, followed by a written report to the NRC Regional Office within 15 days. The report must include the licensee's name; prescribing physician's name; brief description of the event; cause of the event; effect of the event, if any, on the individual; corrective action taken, if any; and whether the affected individual or his or her relative or guardian has been notified. The individual's name or identification number shall not be included in the report. The licensee shall notify the individual and the referring physician of the event no later than 24 h after the discovery, unless the referring physician personally takes the responsibility of informing or not informing the individual based on medical judgment. If a verbal notification is made, the licensee shall inform the individual of the availability of a written description of the event, which the licensee will provide upon request.

In addition, the licensee shall annotate a copy of the report filed with the NRC with the name and social security number or other identification number of the affected individual and provide a copy of the annotated report to the referring physician, if other than the licensee, within 15 days of occurrence of the event. Record keeping of medical events is not required since the reports are provided to the NRC.

11.2.7 Report and Notification of Dose to Embryo/Fetus or Nursing Child

The licensee shall report to the NRC an event in which an embryo/fetus receives more than 5 rem (50 mSv) dose equivalent due to the administration of byproduct material to a pregnant individual, unless such a dose was specifically approved in advance by the authorized user. Also, a report must be made to the NRC if the dose to a nursing child, from the administration of byproduct material to a breast-feeding individual, exceeds total effective dose equivalent 5 rem (50 mSv) or has resulted in unintended permanent functional damage to an organ or a physiological system of the child.

The conditions, timing, and descriptions of the report are identical to those of the medical events described above.

11.2.8 Release of Patients Administered with Radiopharmaceuticals

According to 10CFR35.75, a licensee can release a patient administered with a radiopharmaceutical or a permanent radioactive implant, provided the TEDE to any other individual from exposure to the released patient is not likely to exceed 500 mrem (5 mSv).

Practically in nuclear medicine, patients treated with ¹³¹I-NaI are commonly considered under these regulations. In these cases, if the activity in the patient is less than 33 mCi (1.2 GBq) or the measured exposure rate is less than 7 mrem/h (0.07 mSv/h) at 1 m, then the patient can be released. However, patients administered with higher ¹³¹I-activities, 200 mCi (7.4 GBq) or somewhat more, may be released provided the dose calculations using patient-specific parameters show that the potential TEDE to any individual would be no greater than 0.5 rem (5 mSv) (NUREG-1556, vol 9, Rev. 2). The patient-specific calculations depend on the choice of the occupancy factor and the physical or effective half-life. An occupancy factor of 0.75 at 1 m is chosen for $t_{1/2}$ of less than 1 day and a value of 0.25 at 1 m for $t_{1/2}$ greater than 1 day. A value of 0.25 for the occupancy factor would be valid if the patient follows the instructions, such as for the first 2 days: (1) maintain the distances from others; (2) sleep alone or, better yet, live alone; (3) do not travel by airplane or mass transportation; (4) do not travel in automobiles with others; (5) have the sole use of the bathroom; (6) drink plenty of water; and (7) limit visits by others. These instructions must be given in writing to the patient to follow after release.

The released patient must be given instructions, including written instructions, to maintain the dose as low as reasonably achievable if the TEDE to any other individual is likely to exceed 100 mrem (1 mSv). In the case of ¹³¹I treatment, instructions must be given to the patient when the activity in the patient is more than 7 mCi (259 MBq) or when the measured exposure rate exceeds 2 mrem/h (0.02 mSv/h) at 1 m from the patient. If the dose to a breast-fed infant or child could exceed 100 mrem (1 mSv) assuming continuous breast-feeding by a patient administered with radiopharmaceutical, then instructions on interruption for a period of time or discontinuation of breast-feeding and consequences of failure to follow the guidance must also be given. Table 11.3 lists the activity limits for giving instructions to the breast-feeding patients, activity limits for record keeping, and activity limits for cessation of breast-feeding.

Records of release of patients are required if the TEDE is calculated by using the retained activity rather than the administered activity, using an occupancy factor less than 0.25 at 1 m, using a biological or effective $t_{1/2}$, or considering the shielding by tissue. Records are also required if instructions are given to a breast-feeding woman who may give a TEDE exceeding 500 mrem (5 mSv) to the infant from continuous breast-feeding (10CFR35.2075). Table 11.3 gives the activity limits that require record keeping in case of breast-feeding.

	Activity above which instructions are needed [mCi	Activity above which record is needed [mCi	Recommended duration of
Radiopharmaceutical	(MBq)]	(MBq)]	cessation of breast-feeding
¹³¹ I-NaI	0.004 (0.01)	0.002 (0.07)	Complete cessation
¹²³ I-NaI	0.5 (20)	3 (100)	
¹²³ I-MIBG	2 (70)	10 (400)	12 h (4 mCi/150 MBq)
^{99m} Tc-DTPA	30 (1000)	150 (6000)	
^{99m} Tc-MAA	1.3 (50)	6.5 (200)	12.6 h (4 mCi/150 MBq)
^{99m} Tc-pertechnetate	3 (100)	15 (600)	12 h (12 mCi/440 MBq)
99mTc-DISIDA	30 (1000)	150 (6000)	
^{99m} Tc-sestamibi	30 (1000)	150 (6000)	
^{99m} Tc-MDP	30 (1000)	150 (6000)	
^{99m} Tc-PYP	25 (900)	120 (4000)	
^{99m} Tc-RBC in vivo	10 (400)	50 (2000)	6 h (20 mCi/740 MBq)
^{99m} Tc-RBC in vitro	30 (1000)	150 (6000)	
^{99m} Tc-sulfur colloid	7 (300)	35 (1000)	6 h (12 mCi/440 MBq)
^{99m} Tc-MAG3	30 (1000)	150 (6000)	
^{99m} Tc-WBC	4 (100)	15 (600)	12 h (12 mCi/440 MBq)
⁶⁷ Ga-citrate	0.04 (1)	0.2 (7)	1 month (4 mCi/150 MBq)
¹¹¹ In-WBC	0.2 (10)	1 (40)	1 week (0.5 mCi/20 MBq)
²⁰¹ Tl	1 (40)	5 (200)	2 weeks (3 mCi/110 MBq)

 Table 11.3
 Limits of activities that require instructions to breast-feeding patients and record keeping

NUREG-1556, vol. 9, Rev. 2

11.2.9 Verification Card for Radioactive Patients

Ever since the 9/11/2001 attack by terrorists on the US landmarks, the US government and the public have become extremely concerned about the security and safety of the nation. The Department of Homeland Security has been established to implement and monitor different aspects of public security. Some of these measures include airline passengers check, background checks of many visitors, etc. One of the major concerns has been the use of explosives containing radioactive materials by miscreants to disrupt the human life and society. In view of this, the Homeland Security has set monitoring devices (radiation detectors) at various locations such as airports, tunnels, bridges, border crossing points, historical monuments, landmarks, and the like. One pitfall of this measure is that patients who receive radioactive drugs for diagnostic and therapeutic purposes are likely to trigger these detectors while passing through these checkpoints and undergo unnecessary hassle with authorities to prove that the radioactivity was from the medical tests. Based on numerous such reports, the NRC has recommended providing patients having radioactivity a card with information such as the name of the patient, type of radionuclide administered, date of examination, and a contact number to verify the information on the card. How long the patient needs to carry the information card depends on the half-life of the radionuclide, the type of radiation, and the biological elimination of the radiopharmaceutical. The time periods for different radionuclides suggested by Zuckier et al. (2004) are given in Table 11.4.

Table 11.4	Time for radioactive patients to carry
verification	cards for different radionuclides

¹⁸ F	1 day
99mTc and 123I	3 days
¹¹¹ In	14-17 days
67Ga and 201Tl	30 days
^{131}I	95 days

11.2.10 Record Keeping

Records must be maintained for the receipt, storage, and disposal of radioactive materials and for various activities performed in the radiation laboratories. According to the NRC regulations, these records must contain specific information and be kept for certain period of time. Table 11.5 lists the records that are required by the NRC and the period of time to be kept.

11.3 Department of Transportation

The transportation of radioactive materials is governed by the US Department of Transportation (DOT), which sets the guidelines for packaging, types of packaging material, limits of radioactivity in a package, and exposure limits. Title 49 of the Code of Federal Regulations (49CFR) contains all these regulations related to packaging and transportation of radioactive materials.

		Time to maintain
Type of operation	Information needed	the records
Written directives (10CFR35.2040)	Copy of the written directives	3 years
Procedures requiring written directives (10CFR35.2041)	Copy of the procedures	Duration of the license
Dosage of radiopharmaceuticals dispensed (10CFR35.2063)	Name, lot number, expiration date, patient's name or identification number, prescribed dosage and dispensed dosage, date and time of administration, and name of the individual	3 years
Calibration of dose calibrator (10CFR35.2060)	Model, serial number of the dose calibrator, date and results of test, and name of the individual	3 years
Calibration of survey meters (10CFR35.2061)	Model and serial number of the instrument, date and results of calibration, and name of the individual	3 years
Semiannual leak tests and inventory of sealed sources (10CFR35.2067)	Model and serial number of each source and its radionuclide, estimated activity, measured activity in μ Ci (Bq), date of test, location of source (inventory), and name of the individual	3 years
⁹⁹ Mo, ⁸² SR, and ⁸⁵ Sr breakthrough (10CFR35.2204)	μCi (MBq) of ⁹⁹ Mo or ⁸² Sr and ⁸⁵ Sr per mCi (MBq) of ^{99m} Tc or ⁸² Rb, date and time of measurement, name of the individual	3 years
Thyroid bioassay and whole-body counting (10CFR20.2106)	Name of the individual having the bioassay, date of reading, and the individual taking the measurement	Until the NRC terminates the license
Personnel exposure monitoring records (10CFR20.2106)	Must be on Form NRC-5 according to items described in the form	Until the NRC terminates the license
Radioactive waste disposal by decay-in-storage (10CFR35.2092)	Date of disposal, instrument used, background reading and surface reading of the waste container, and the name of the individual	3 years
Planned special procedures (10CFR20.2105)	Circumstances, name of authorizing individual, doses expected	Until the NRC terminates the license
Surveys (10CFR35.2070)	Date, area, trigger level (mR/h), survey data, instrument used, and name of the individual	3 years
Release of patients with unsealed byproduct material (10CFR35.2075)	Basis of calculation to release the patient, such as retained activity, occupancy factor less than 0.25 at 1 m, using T_p or T_e or considering shielding by tissue	3 years
Instruction given to breast-feeding female (10CFR35.2075)	Instruction given if dose to the infant exceeds 0.5 rem (5 mSv)	3 years

Table 11.5	Time limit for record	keeping of various	activities related	to radioactive materials
------------	-----------------------	--------------------	--------------------	--------------------------



Fig. 11.3 Three types of Department of Transportation (DOT) labels required for transportation of radioactive materials

Table 11.6	Labeling categories for
packages con	ntaining radioactive materials

	Exposure (mR/h)	
Type of label	At surface	At 1 m
White - I	< 0.5	-
Yellow - II	$> 0.5 \le 50$	<1
Yellow - III	$> 50 \le 200$	$> 1 \le 10$

Note: No package shall exceed 200 mR/h at the surface of the package or 10 mR/h at 1 m. Transport index is the reading in mR/h at 1 m from the package surface

There are two types of packaging:

- Type A: This type of packaging is primarily used for most radiopharmaceuticals. Packaging is sufficient to prevent loss of radioactive material with proper shielding to maintain the prescribed exposure during normal transportation. The limits of radioactivities of various radionuclides under this category are specified in 49CFR.
- Type B: When the radioactivity exceeds the limits specified in Type A, Type B packaging must be utilized. Such packaging is considerably more accident resistant and is required for very large quantities of radioactive material.

The packages must pass certain tests such as the drop test, corner drop test, compression test, and 30-min water spray test.

The radioactive packages must be labeled properly prior to transportation. There are three types of labels (Fig. 11.3) according to the exposure reading at 1 m (transport index, TI). The TI criteria for three labels are given in Table 11.6. The TI must be indicated on the label, and the sign "RADIOACTIVE" must be placed on the package. The maximum permissible TI value is 10, although it is limited to 3 for passenger-carrying aircrafts. For liquids, the label "THIS SIDE UP" must be placed on the package. Each package must be labeled on opposite sides with the appropriate warning label (one of the labels in Fig. 11.3). The label must identify the contents and amounts of

	Quantity			Quantity	
Radionuclide	(mCi)	(MBq)	Radionuclide	(mCi)	(MBq)
⁵⁷ Co	22	800	¹¹¹ In	5	200
⁶⁷ Ga	16	600	^{32}P	0.8	30
^{123}I	16	600	^{99m} Tc	22	800
¹²⁵ I	5.4	200	²⁰¹ Tl	27	1000
¹³¹ I	1.4	50	¹³³ Xe gas	541	20,000

 Table 11.7
 Limited quantities of several radionuclides that are exempted from shipping and labeling requirements, according to 49CFR I73.425

radionuclide in curies or becquerels. The package must contain shipping document inside bearing the identity, amount, and chemical form of the radioactive material and the TI (Table 11.7).

Placards are necessary on the transport vehicles carrying yellow-III-labeled packages and must be put on all four sides of the vehicle.

According to 49CFR173.421, radionuclides are exempted from the packaging and labeling requirements if only a limited quantity is shipped. The surface exposure readings should not exceed 0.5 mR/h at all points of the package surface, and the wipe test indicates no removable contamination in excess of 6600 dpm/300 cm². A notice or a label displaying "Radioactive – Limited Quantity" must be enclosed inside or pasted outside or forwarded with the package. The notice must include the name of the shipper and the consignee, and the following statement must be in or on the package: "This package conforms to the conditions and limitations specified in 49CFR173.421 for radioactive material, excepted package – limited quantity of material, UN2910." The limited quantities for some important radionuclides are given in Table 11.7, based on $10^{-4} A_2$ as stated in 49CFR173.425. The values of A_2 are obtained from 49CFR173.435.

Employees who ship hazardous material (hazmat) including radioactive material must have hazmat training to be able to recognize and identify hazardous material, to conduct their specific function, and to enforce safety procedures in shipping to protect the public. The training must be given to new employees within 90 days of employment and then repeated every 3 years. The training is provided by the hazmat employer or other public or private sources, and a record of training must be made.

11.4 European Regulations Governing Radiopharmaceuticals

Regulations governing the use of radioactive drugs in humans were at variance in different European countries until 1989 when the European Union (EU, a union of currently 28 European countries) adopted the European Union Directives involving radiopharmaceuticals. As implied in the charter of the European Union, medicinal products, among others, are transported and distributed free of regulatory

constraints of individual countries. The European regulatory organizations have three main instruments: directives, guidelines, and European regulations. Directives are mandatory rules to be translated into national legislation and implemented in each member country. Guidelines are recommendations (not mandatory) for effective implementation of directives by the member countries. European regulations are mandatory for all member countries without adoption into national legislation. The following is a brief description of different regulations governing the use, marketing, and disposal of radiopharmaceuticals.

11.4.1 Drug Registration

Directive 65/65/EEC amended later by 83/570/EEC and 87/21/EEC defines medicinal products and details the requirements for registration for commercialization of medicinal products by each member state. Directives 75/318/EEC and 75/319/EEC required each member state to register medicinal products with pharmaceutical data and pharmacological and toxicological data and clinical effectiveness of each product, for marketing within all EU member states. Until 1989, radiopharmaceuticals were exempt from these requirements, but then 89/343/EEC was introduced requiring the registration of all radiopharmaceuticals for human use in all EU member states.

Directive 2001/83/EC was introduced in 2001 replacing 1989 directives for the use of medicinal products in humans. It dealt with the disparities between certain national provisions, in particular between provisions relating to medicinal products, which directly affected the functioning of the internal market of the EU. It gives details of product registration and the information thereof, which were required for uniform implementation throughout the EU, and all member states must abide by these rules. This directive established criteria for preparing medicinal products in pharmacy in accordance with a prescription for a patient or in accordance with the prescription of a pharmacopeia and products for research and development trials. According to the directive, a marketing authorization (MA) must be issued by a member state in the EU to market the medicinal product in the state, except for radiopharmaceuticals if prepared by authorized institutions from authorized ingredients following manufacturer's instructions. Different components in the application for MA include, among others, composition of the medicinal product, description of the production method, adverse effects of the product, all preclinical toxicological and pharmacological tests results, and labeling requirements.

A drug can be registered for commercialization by a centralized or decentralized registration procedure. In the centralized procedure, a pharmaceutical company submits an application termed *marketing authorization application* (MAA) to the European Medicines Agency (EMA), which is roughly parallel to the US FDA, for approval, which is approved or rejected based on the proof of quality, safety, and efficacy of the product. There are several timely steps in submitting the application, namely, eligibility request for a drug of interest under centralized procedure 7–18 months prior to submission when reviewers are appointed and a pre-submission meeting is held and finally electronic submission of the MAA with required fee to the Committee for Medicinal Products for Human Use (CHMP). The CHMP normally makes a decision within 210

days, and the MAA, if approved, is then sent to European Commission to publish in Community Register within 67 days. The approved MAA is valid for all EU states. While companies have the option of having a centralized MAA from the EMA for a medicine of significant importance, the centralized registration procedure is mandatory for certain drugs, such as monoclonal antibodies, drugs for HIV and diabetes, genetically engineered drugs, or orphan drugs. The Directive 2001/83/EC was further amended by 2003/63/EC and 2004/27/EC to cover more medicinal products under centralized procedure, to allow compassionate use of medicinal products for treatment of patients in the absence of alternatives, to put time limit on MAA for 5 years, and to revoke MAA if the product is not marketed for 3 years.

In the decentralized procedure, also called the *national authorization procedure*, an application is made by a company to an authority of one member state which approves/disapproves an MAA for a medicinal product after review. The applicant state then presents the authorization to other member states for registration. Alternatively, companies may apply simultaneously to several member states for MAA of a medicinal product that has not been authorized yet in any EU state.

11.4.2 Good Manufacturing Practice

Directive 91/356/EEC introduced in 1991 provides the principles of good manufacturing practice (GMP), which apply to drug manufacturing at the industrial level as well as to compounding in hospitals. This directive has been revoked and replaced by Directive 2003/94/EC in 2003. According to this directive, the manufacturers must have sufficiently competent and qualified personnel to follow strict GMP guidelines for the production of medicinal products, who will receive continuing training in the practice. The manufacturer must implement good quality control procedures for each medicinal product, and samples of each batch must be retained for 1 year after the expiry date. For an approved radiopharmaceutical for marketing, a summary of the product characteristics (SPC), equivalent to package inserts in the USA, must be accompanied, which entails relevant information, such as chemical form, approved clinical indication, internal dosimetry, instructions for labeling kits, method to verify radiochemical purity, shelf life, storage temperature, etc. Such information must also be obtained for excipients of medical products. Records of the medicinal product must be maintained for at least 1 year after the expiration date of the batch or at least 5 years after the certification, whichever is longer.

11.4.3 European Pharmacopoeia

The *European Pharmacopoeia*, 9th edition, 2017, published by the European Directorate for the Quality of Medicines (EDQM), which is equivalent to the *US Pharmacopeia*, specifies the characteristics of all radiopharmaceuticals in monograph forms, regarding radionuclidic and radiochemical purity, pH, sterility, pyrogenicity, etc. It is mandatory to adopt these guidelines in the manufacturing of medicinal products in the entire EU. Further, it is the responsibility of the radiopharmacist to ensure

the quality, safety, and efficacy of a radiopharmaceutical if it is intended for human administration. Similarly, the nuclear physician is responsible for administration of the radiopharmaceutical to the patient and the clinical care of the patient for any adverse reactions thereof. Claims may be made against any adverse reaction for up to 10 years after the event; therefore, the patient's and preparation's records must be maintained for this length of time.

Clinical trials are conducted by qualified clinicians based on protocols approved by an Ethics Committee in each institution. Data are collected on pharmacokinetic characteristics, clinical efficacy, safety, etc. for a particular indication of a disease, which are then submitted for MA. Any modification in production or administration of a medicinal product to humans requires a new clinical trial.

11.4.4 Guidelines for Small-Scale Radiopharmaceutical Preparation

Although the directives and regulations of European Union provide guidelines as to the preparation and human use of radiopharmaceuticals for marketing by commercial firms, there are a lot of variations in their acceptance and implementation in different states of the union. Also they have not adequately addressed the issue of small-scale preparations of radiopharmaceuticals in hospitals and small clinical departments, which prepare them in-house because of their short half-life. The European Association of Nuclear Medicine (EANM) has established the Radiopharmaceuticals following the current good radiopharmacy practice (cGRPP). The guidelines developed by the committee provide detailed description of all aspects of operations in a hospital pharmacy and the like (Elsinga et al. 2010). The following are the highlights of guidelines.

There should be sufficient number of trained personnel to carry out the radiopharmacy operation based on the size and complexity of the facility. A responsible person (RPR) experienced in handling radioactivity should supervise all activities in the operation. Personnel profile and credentials must be maintained on all personnel in radiopharmacy. Responsibilities may be carried out by RPR himself or delegated to other trained workers. Standards of operation (SOP) must be in place for every segment of small-scale production. While RPR is responsible for overall operation, persons designated for quality assurance, quality control, and production of radiopharmaceuticals must be responsible for their respective operation. The quality assurance must entail all principles of cGRPP in small-scale radiopharmaceutical preparations.

Work area in a facility for radiopharmaceutical preparation may be in one room or a couple of rooms. Extreme care should be taken to avoid mix-up and unintended use. An area or room should be designated as aseptic workstation for aseptic procedure with unidirectional flow of filtered air. Particle size and microbial contamination must be monitored in these workstations, which also require cleaning at regular intervals.

Equipment used for synthesis, counting, preparation, and dispensing must be clean and calibrated as required. The maintenance record must be kept in a logbook.

If an automated synthesis box and a radiopharmaceutical dispensing unit are used, their accurate functionality must be established by checking the integrity of different components of the respective unit.

Quality control equipment such as the HPLC system, dose calibrator, etc. must be calibrated and well maintained for accurate performance. Solutions, glassware, and all accessories should be sterile. The master preparation and control records include chronological order of how small-scale radiopharmaceuticals are to be prepared, namely, radiosynthesis, purification steps, QC of the product, etc., by following the SOPs of each step. The master preparation serves as a template for the batch records and must be approved by RPR. Laboratory equipment should be calibrated regularly according to established procedures, and the data should be recorded. The identity, purity, and quality of the materials used in the synthesis should be optimal.

Materials should be purchased from qualified and reliable vendors who attest to their integrity, purity, and quality. A process needs to be validated by batch records which meet predetermined acceptance criteria. A new process or changes to the existing process should undergo the same validation process. The acceptance criteria for small-scale radiopharmaceuticals should be those of European Pharmacopoeia.

The stability of radiopharmaceuticals is defined by parameters such as identity, pH, chemical purity, and radiochemical purity which are determined by various technical methods. Microbial tests for sterility and bacterial endotoxin test (BET) for endotoxin are performed using the standards of European Pharmacopoeia.

Finished radiopharmaceuticals must be labeled with either computer-generated or handwritten labels containing information such as the name, amount, and expiration time of the radiopharmaceuticals.

All information must be recorded and maintained for at least 1 year.

11.4.5 Radiation Protection

The European Atomic Energy Community (EURATOM) establishes the basic radiation protection standards to protect the health of the radiation workers and the public from radiation hazards. The initial Directive 84/466/EURATOM published in 1984 followed the principles of radiation protection established by the ICRP. This directive has been replaced by several directives, 89/618/EURATOM, 90/641/ EURATOM, 96/29/EURATOM, 97/43/EURATOM, and 2003/122/EURATOM, in subsequent years, and the current Directive 2013/59/EURATOM is the basis of primary radiation protection standards applicable to all European Union member nations. Much of the regulations in this directive are similar to those of the NRC given in 10CFR20 in the USA. The dose limits from radiation exposure set by the ICRP for the public and radiation workers have been accepted for regulations by the EURATOM. Table 11.8 shows the dose limits from radiation exposure to the radiation workers and the public, which are somewhat different from those of the NRC dose limits in the USA.

All diagnostic and therapeutic procedures in nuclear medicine must be documented and strictly followed. All member states of EU must have uniform standard

Limits	Exposed radiation workers (aged over 18)	Apprentices and students (aged between 16 and 18)	Public	Pregnant and breast-feeding women
Effective dose	20 mSv (2 rem) per year and 100 mSv (10 rem) in a consecutive 5-year period, subject to a maximum of 50 mSv (5 rem) in a single year	6 mSv (600mrem)	1 mSv(100 mrem)	<1 mSv (100mrem)
Equivalent dose for eye lens	150 mSv (15 rem)	50 mSv (5 rem)	15 mSv (1.5 rem)	
Equivalent dose for the skin, hands, forearms, feet, ankle	500 mSv (50 rem)	150 mSv (15 rem)	50 mSv (5 rem)	

Table 11.8 Dose limits from 2013/29/EURATOM for different groups of individuals

for training, certification, continuing education, and licensing for the practice of radiological procedures. The optimization principle (similar to ALARA principle of the NRC in the USA) for dose reduction applies to all radiation workers in EU. Personnel monitoring is mandatory for all radiation workers using specific monitoring devices, and personnel dose record must be maintained until an individual has or would have attained the age of 75 years but in any case not less than 30 years after termination of the work involving radiation exposure. The use of radiation is approved by the issuance of a license to a qualified person with experience in handling radiation. All activities in the radiation area must be recorded and maintained.

In the 2013/59/EUROATOM directive, two experts are recognized – radiation protection expert and medical physics expert. While radiation protection expert gives advice to an undertaking (an institution or a facility) on legal matters related to occupational and public exposure, medical physics expert assumes responsibilities or provides advice on dosimetry, medical equipment, quality assurance, and training of personnel in radiation handling. Similar to a radiation safety officer (RSO) in the USA, an undertaking may employ a radiation protection officer (RPO) to implement and supervise the radiation protection program in the industries and institutions using radionuclides for diagnosis and treatment. For details refer to 2013/59/EUROATOM.

Although all EU regulations and directives are equally applicable to all member states, the actual situation is quite different from country to country because of the lack of effective implementation in many states. So in some member states, these directives are effectively applied, while in others, these are loosely applied, and, in some cases, there may be a breach of the community law.

Questions

- 1. What are the occupational dose limits for the following parts of the body of a radiation worker: (a) whole body, gonads, and eye lens; (b) hands; and (c) skin? How many rem can a radiation worker receive per week?
- 2. What is the occupational dose limit for pregnant women during the gestation period?
- 3. What are the features of planned special procedures?
- 4. What are the cardinal rules of protection from external sources of radiation?
- 5. If a source of radioactivity shows an exposure rate of 50 mR/h at 4 m from the source, calculate the exposure rate at (a) 3 m from the source and (b) 6 m from the source.
- 6. What will be the exposure rate in percent of a radioactive sample surrounded by an HVL of absorbing material? Calculate the exposure rate if the source exposure rate is 75 mR/h.
- 7. Describe the principles of personnel monitoring by film badges and thermoluminescent dosimeters. What are the merits and disadvantages of these two methods?
- 8. What are the steps you would take in the event of a spill of a liquid radioactive sample on the floor of a radioisotope laboratory?
- 9. What are the dose limits to (a) individual members of the public and (b) an unrestricted area?
- 10. A patient has been treated with 200 mCi (7.4 GBq) ¹³¹I for thyroid cancer. What are the factors you would take into consideration for the release of the patient from the hospital?
- 11. At what limits of activity and exposure would you give instructions to the patients and breast-feeding women who are released after treatment with ¹³¹I?
- 12. What is the maximum value of transport index that is allowed for transportation of radioactive material?
- 13. When do you need a bioassay if handling ¹³¹I-NaI?
- 14. Describe the situations in which a medical event will occur.
- 15. What are the requirements for a physician to become authorized?
- 16. What is an eIND? What is the difference between eIND and IND?
- 17. What is the difference between eIND and RDRC?
- 18. When does an expanded access IND apply?

References and Suggested Reading

Cox PH. European legislation and its effects on the production of radiopharmaceuticals. In: Sampson CB, editor. Textbook of radiopharmacy. Amsterdam: Gordon and Breach Science Publishers; 1999.

Directive 2004/27/EC, 2004.

Directive 2001/83/EC, 2001. Directive 2003/63/EC, 2003.

Directive 2003/94/EC, 2003.

Directive 89/343/EEC, 1989

- Directive 2013/59/EURATOM, 2013.
- Elsinga P, Todde S, Penuelas I, et al. Guidance on current good radiopharmacy practice (cGRPP) for the small-scale preparation of radiopharmaceuticals. Eur J Nucl Med Mol Imaging. 2010;37:1049.
- European Atomic Energy Community (EURATOM).
- Gollnick DA. Basic radiation protection technology. 4th ed. Altadena: Pacific Radiation Corporation; 2000.
- Goodwin PN. Radiation safety for patients and personnel. In: Freeman and Johnson's clinical radionuclide imaging. 3rd ed. Philadelphia: WB Saunders; 1984. p. 320.
- http://www.acr.org and http://www.icanl.org.
- International Commission on Radiological Protection. General principles for the radiation protection of workers. ICRP 75. New York: Elsevier; 1997.
- International Commission on Radiological Protection. 1990 recommendations of the ICRP. ICRP 60. New York: Elsevier; 1990.
- National Council on Radiation Protection and Measurements. Limitation of exposure to ionizing radiation (NCRP 116). Bethesda: NCRP Publications; 1993.
- National Council on Radiation Protection and Measurements. Maintaining radiation protection records (NCRP 114). Bethesda: NCRP Publications; 1992.
- National Council on Radiation Protection and Measurements. Radiation protection and allied health personnel (NCRP 105). Bethesda: NCRP Publications; 1989.
- National Council on Radiation Protection and Measurements. Nuclear medicine factors influencing the choice and use of radionuclides in diagnosis and therapy (NCRP 70). Bethesda: NCRP Publications; 1982.
- Nuclear Regulatory Commission. Medical use of byproduct material. 10CFR Part 35. Washington, DC: NRC; 2007.
- Nuclear Regulatory Commission. Consolidated guidance about material licenses: program specific guidance about medical license. NUREg-1556, vol. 9, Rev. 2. Washington, DC: NRC; 2002.
- Nuclear Regulatory Commission. Standards for protection against radiation. 10CFR Part 20. Washington, DC: NRC; 1995.
- Shapiro J. Radiation protection. 4th ed. Cambridge, MA: Harvard University Press; 2002.
- U.S. Food and Drug Administration. Regulations for in vivo radiopharmaceuticals for diagnosing and monitoring. 21CFR Part 315. Rockville: U.S. Food and Drug Administration; 1999.
- U.S. Food and Drug Administration. Food and drug administration modernization act of 1997. Rockville: U.S. Food and Drug Administration; 1997.
- U.S. Food and Drug Administration. Nuclear pharmacy guideline: criteria for determining when to register as a drug establishment. Washington, DC: U.S. Food and Drug Administration; 1984.
- U.S. Food and Drug Administration. Radioactive drugs and radioactive biological products. Federal Register, vol 40, p 144. Washington: U.S. Govt. Print. Off.; 1975.
- U.S. Food and Drug Administration. https://www.fda.gov/Drugs/GuidanceComplianceRegulatory Information/Guidances/default.htm.
- Zuckier L, Stabin M, Garetano G, et al. Sensitivity of personal homeland security radiation detectors to medical radionuclides and implications for counseling of nuclear medicine patients. RSNA Ann Meet. 2004; Abstract SSJ 19–01.

In Vitro and In Vivo Nonimaging Tests

12

12.1 Radioimmunoassay

The radioimmunoassay (RIA) method was first developed by S.A. Berson and R.S. Yalow in the late 1950s for the determination of insulin in human serum. The method is employed to determine numerous hormones, enzymes, antigens, and drugs in minute quantities $(10^{-9}-10^{-12} M)$ in human plasma in order to assess various disease conditions.

12.1.1 Principle

The RIA method is based on the formation of an antigen–antibody complex and utilizes the principles of the isotope dilution technique. An antigen (Ag) is a substance (e.g., protein) that is able to induce the production of an antibody in the body and binds to that antibody very specifically. Conversely, an antibody (Ab) is usually a protein that is produced in immunologic response to an antigen and forms a specific complex with the antigen. In an RIA method, a mixture of radiolabeled antigen (Ag*) and unlabeled antigen is added to a quantity of its antibody that is *insufficient* to form the antigen–antibody complex with all antigen (both labeled and unlabeled). In the formation of this complex, both types of antigen will be competing for the limited binding sites on the antibody, and both labeled and unlabeled complexes will be formed in proportion to the amounts of respective antigen. Thus, in an RIA mixture, the following reactions take place:

$$Ab + Ag \rightleftharpoons Ab - Ag + Ag$$
$$Ab + Ag^* \rightleftharpoons Ab - Ag^* + Ag^*$$

Here the antibody is present in an *insufficient* amount to bind all the labeled and unlabeled antigen. Most often, in an RIA mixture, the unreacted labeled antigen is

[©] Springer International Publishing AG 2018 G.B. Saha, *Fundamentals of Nuclear Pharmacy*, https://doi.org/10.1007/978-3-319-57580-3_12

referred to as free antigen and its concentration is denoted by F, and labeled antigen– antibody complex (Ab–Ag*) is referred to as bound antigen and its concentration is denoted by B. For constant amounts of antibody and labeled antigen (with antibody insufficient to form complexes with all of the labeled and unlabeled antigen), the amount of bound antigen will be inversely proportional to the quantity of unlabeled antigen; that is, if the amount of unlabeled antigen is increased, the amount of bound antigen will decrease with a concomitant increase in the amount of free antigen left in the mixture and vice versa. Thus, the ratio of bound to free antigen (B/F) is a function of the concentration of unlabeled antigen in the RIA mixture and can be used in the determination of an unknown concentration of antigen in a sample by using the so-called standard or dose–response curve as described below.

12.1.2 Methodology

A series of standard samples are prepared with increasing but known concentrations of unlabeled antigen, including one sample without any unlabeled antigen; the latter is referred to as the zero standard. To each of these samples, a known amount of labeled antigen and a constant quantity of antibody (remember, insufficient antibody to bind to all labeled and unlabeled antigen) are added, and the mixture is incubated. The period of incubation and the temperature vary with the type of antigen to be assayed.

After incubation, the bound and free antigens of each sample are separated by an appropriate chemical method. Some of the common methods of separation are (1) precipitation with reagents such as ethanol, polyethylene glycol, and ammonium sulfate; (2) adsorption of antigen on a solid surface such as talc, charcoal, cellulose, and silica; (3) adsorption of antibody on a solid phase such as glass or plastic; (4) gel filtration using Sephadex and Bio-Rad Gel; and (5) a double antibody method in which a second antibody is added to the RIA mixture to precipitate bound antigen. The reader is referred to any standard book on RIA for details of these methods.

After separation, the amounts of bound and free antigens are determined by measuring the activity in a counter, and the B/F ratio or percent bound is calculated for each sample. These values are then plotted against the logarithms of the unlabeled antigen concentration of each sample. The plot is the standard curve for the RIA of the antigen in question. A typical standard curve for digoxin RIA is shown in Fig. 12.1. For a sample with an unknown amount of antigen, an identical procedure is followed, B/F or percent bound is calculated, and the corresponding level of antigen is read from the standard curve.

Instead of B/F, sometimes F/B and B/B_0 are plotted in constructing the standard curve. Here B_0 is the concentration of bound antigen in the zero standard sample. These curves are not linear as seen in Fig. 12.1. However, a linear standard curve can be obtained by using the logit function, which is defined as

$$\operatorname{logit}(Y) = \log_{e}\left(\frac{Y}{1-Y}\right) \tag{12.1}$$



where $Y = B/B_0$. A plot of logit (*Y*) against log [Ag] gives a linear standard curve on which it is easier to read the data for an unknown sample.

12.1.3 Sensitivity and Specificity

The RIA method is highly sensitive due to the presence of radioactivity that can be detected in tracer quantities. In RIA, the immunologic reaction between the antigen and the antibody is highly specific, and hence the method has high specificity. Peptides, hormones, drugs, and so on can be detected in the range of $10^{-9}-10^{-12} M$. The accuracy of the method depends on various experimental factors and the specificity of the antigen–antibody reaction. The precision of RIA is affected by experimental errors in pipetting of reagents, chemical separation of the complex, and counting.

12.1.4 Application

The RIA method is useful in the assay of various hormones, enzymes, steroids, and peptides in plasma. These measurements yield information on the normal and abnormal states of patients. Some examples of substances that are assayed by RIA are T_3 , gastrin, angiotensin, and aldosterone.

Another area of application of RIA is in the determination of the serum level of a drug that has been administered to a patient.

Kits are marketed by commercial manufacturers for the RIA of the abovementioned substances. In a given kit, the following materials are included: (1) a series of standard samples containing increasing amounts of unlabeled antigen, (2) a vial of labeled antigen, and (3) a vial of antibody solution.

Depending on the type of the RIA method, other supplementary materials may be provided. Mostly ¹²⁵I antigens are used.

At present, the use of RIA has been curtailed considerably, because of the applications of the other nonradioactive methods such as enzyme-linked immunosorbent assay (ELISA), chemiluminescence immunoassay, enzyme immunoassay, and immunofluorescence assay.

12.2 Schilling Test

The Schilling test indicates normal or abnormal absorption of vitamin B_{12} (cyanocobalamin), as in pernicious anemia. Vitamin B_{12} labeled with ⁵⁷Co is administered to fasting patients, and the 24-h urinary excretion of the tracer is measured and used as an index of the disease state.

In the actual procedure, the patient is asked to fast overnight; $0.5 \ \mu g^{57}$ Co-vitamin B_{12} containing $0.5 \ \mu$ Ci (18.5 kBq) radioactivity is then given orally, followed by intramuscular administration of a large dosage (~1000 μ g) of cold vitamin B_{12} . The latter is given to promote urinary excretion of vitamin B_{12} and to saturate the liver and other tissues. A radioactive standard is prepared with an aliquot or identical amount of the administered dosage. Urine is collected over a period of 24 h. The activities in the 24-h urine and the standard are measured, and the percent excreted in 24 h is calculated. The normal values of urinary excretion of vitamin B_{12} are in the range of 10–40% (mean 18%). Values lower than this limit indicate malabsorption of vitamin B_{12} .

If the values are lower than normal (<7%), pernicious anemia may be suspected and can be distinguished from other related diseases. The procedure is repeated several days later with 30 mg intrinsic factor given orally along with radioactive vitamin B₁₂. In the case of pernicious anemia or total gastrectomy, the 24-h urinary excretion becomes normal (10–40%). In syndromes not affected by intrinsic factor, the value still remains low.

Alternatively, a dual-isotope method may be applied, and repetition of the Schilling test in the case of pernicious anemia is avoided. In this method, a capsule containing both ⁵⁷Co-vitamin B_{12} and intrinsic factor and another capsule containing only ⁵⁸Co-vitamin B_{12} are administered orally simultaneously. Both isotopes in the 24-h urine sample are counted in a well counter on two energy windows. In the case of pernicious anemia, the 24-h urinary excretion should be normal for ⁵⁷Co and low for ⁵⁸Co.

12.3 Blood Volume

The two common methods of measuring blood volume are the ¹²⁵I-labeled serum albumin method and the ⁵¹Cr-labeled red blood cell method.

12.3.1 ¹²⁵I-Labeled Serum Albumin Method

The principle of the ¹²⁵I-labeled serum albumin method is that after ¹²⁵I-RISA is administered, it is thoroughly mixed with the circulating blood, and therefore blood volume can be determined from the activity of a blood sample and the total administered activity.

In this procedure, $10 \ \mu$ Ci (0.37 MBq)¹²⁵I-RISA is injected intravenously, and a 5- to 10-ml blood sample is collected in a tube containing heparin 10–20 min after injection. A standard is prepared using the same amount as the injected dosage. If a fraction of the injected dosage is used for the standard, a correction factor must be considered in the final calculation. The hematocrit is determined, and the plasma is separated by centrifugation of the remaining blood. Then 1 ml plasma and 1 ml standard are counted in a NaI(Tl) well counter. From the measured activities, the blood volume is calculated as follows:

Plasma volume =
$$\frac{C_{\rm s} \times V_{\rm s}}{C_{\rm p}}$$
 (12.2)

where C_s is the radioactivity (cpm) in 1 ml of the standard, V_s is the volume (ml) of the standard corrected for fraction of the injected dosage, and C_p is the radioactivity (cpm) in 1 ml plasma

Blood volume =
$$\frac{\text{Plasma volume}}{1 - (\text{Hematocrit} \times 0.92)}$$
(12.3)

where 0.92 is the correction factor for the trapped plasma in the red blood cells and for the difference between the venous and whole-body hematocrits.

12.3.2 ⁵¹Cr-Labeled Red Blood Cell Method

The blood volume can be measured with ⁵¹Cr-labeled red blood cells using the same principle as in the ¹²⁵I-RISA method.

About 50–100 μ Ci (1.85–3.7 MBq) ⁵¹Cr-labeled red blood cell suspension is injected intravenously into the patient, and a separate aliquot of the suspension is used as a standard. A blood sample is collected 15–20 min after the injection, and a hematocrit is determined. The plasma sample, the whole blood sample, and the standard are counted in a NaI(Tl) well counter, and the blood volume is calculated from the measured counts.

12.3.3 Application

The normal blood volume for humans is 4000–5500 ml. Determination of blood volume is most useful in pre- and postoperative patient care. From both these methods, the red cell volume can be easily calculated as

Red cell volume = Blood volume × Hematocrit × 0.92
$$(12.4)$$



Determination of red cell volume is particularly useful in patients with polycythemia vera, specifically in the evaluation of their response to treatment.

12.4 Red Blood Cell Survival

The lifetime of a red blood cell is approximately 120 days. However, red cells of different ages are present in blood, and one can measure only the average survival half-time of these cells, which is done by means of ⁵¹Cr-labeled red cells. About 50 μ Ci (1.85 MBq) of labeled red blood cells is injected into the patient, and a 24-h blood sample is collected and considered as the 100% sample. Serial blood samples of 6–10 ml are then obtained every 48 h until the activity in the last sample is less than half of the 100% sample. An aliquot of each blood sample is taken and hemolyzed. All samples are counted in a well counter on the same day to avoid decay correction. The activities are then plotted against time after injection, and the red cell survival half-time is determined from the curve. The normal values range between 25 and 33 days with a mean value of 28 days (Fig. 12.2). In hemolytic anemia patients, the red cell survival half-time is much shorter (Fig. 12.2).

Questions

- 1. Describe the general principles of the RIA method.
- 2. Why is the RIA method so highly sensitive and specific? What is a logit function?
- 3. What is a standard curve in RIA? How do you construct it?
- 4. In the Schilling test, why is a large dosage of nonradioactive vitamin B₁₂ injected intramuscularly following the oral administration of ⁵⁷Co-vitamin B₁₂? What are the normal values of urinary excretion of ⁵⁷Co-vitamin B₁₂? What additional test do you do in cases of suspected pernicious anemia?

- 5. In a blood volume measurement, 2 ml plasma and 1 ml of the standard measured 6020 cpm and 13,590 cpm, respectively. If the volume of the standard was 500 ml, calculate the blood volume of the patient whose hematocrit was 45%.
- 6. In a red blood cell survival study, the following data were obtained after injection of ⁵¹Cr-labeled red blood cells:

Time (d)	Blood (cpm/ml)
1	3010
2	2810
3	2683
6	2235
8	2001
10	1789
12	1601
14	1412

Plot these activities versus time and find the red cell survival half-time. Is it normal or abnormal?

Suggested Reading

- Chase GC, Rabinowitz JL. Principles of radioisotope methodology. 3rd ed. Minneapolis: Burgess; 1970.
- Moss AJ Jr, Dalrymple GV, Boyd CM, editors. Practical radioimmunoassay. St Louis: Mosby; 1976.
- Odell WD, Daughaday WH, editors. Principles of competitive protein-binding assays. Philadelphia: Lippincott; 1974.

Rothfeld B, editor. Nuclear medicine in vitro. Philadelphia: Lippincott; 1974.

Thorell JI, Larson SM. Radioimmunoassay and related techniques. St Louis: Mosby; 1978.

Diagnostic Uses of Radiopharmaceuticals in Nuclear Medicine

13

In previous chapters, we described various characteristics and production of radionuclides, preparation of different radiopharmaceuticals using various radionuclides, and their quality control. In the present chapter, we shall describe clinical uses of these radiopharmaceuticals in the diagnosis of various diseases in humans. The discussion is primarily divided into sections on different organs. In each section, the anatomic structure and physiologic function of the organ are briefly described, and appropriate nuclear medicine tests are discussed along with their clinical usefulness, particularly with respect to the radiopharmaceuticals used, their pharmacologic aspect, the mechanism of their localization, and diagnosis of various diseases in humans.

13.1 Central Nervous System

13.1.1 Anatomy and Physiology

The central nervous system (CNS) consists of two parts – the brain in the skull and the spinal cord in the vertebral column. The brain consists of two symmetric cerebral hemispheres (left and right) separated by longitudinal fissures. Each hemisphere has four lobes – the frontal, parietal, temporal, and occipital – and these lobes are separated by fissures (Fig. 13.1). Both the cerebellum and the pons are dorsally located behind the cerebral hemispheres in the posterior fossa of the skull. The cerebellum is responsible for motor coordination and space orientation of the body, while the pons forms the bridge between the connecting links. The medulla oblongata is a region of passage for nerve fiber tracts that extend between the spinal cord and the higher regions of the brain, and it contains reflex centers and cranial nerves. The thalamus and hypothalamus are situated inside the interbrain, and their function involves general sensations (pain, temperature, pleasant feelings, and feeding reflexes). The pituitary gland is suspended underneath the hypothalamus. Between the left and right halves of the interbrain lies the third ventricle as a



Fig. 13.1 Sagittal section of a normal brain

continuation of the cerebral aqueduct. The third ventricle communicates with the first and second lateral ventricles via an interventricular foramen. The fourth ventricle exists as an expansion of the neural canal above the medulla. The ventricles are fluid-filled spaces within the brain. The choroid plexus is a mass of blood vessels lying in the lateral ventricles.

The outer layer of the cerebral hemispheres is composed of gray matter and is known as the cerebral cortex. Beneath this lie tracts of fiber comprising the white matter along with clumps of gray matter. It has been estimated that the human cortex contains about 10–14 billion neurons, which are nerve cells with afferent and efferent nerve fibers. All of these cells are formed before birth and none of them, if injured, is ever replaced. The brain and spinal cord are covered with meninges, through which the cerebrospinal fluid (CSF) circulates. The CSF is a colorless fluid containing a few lymphocytes and is similar in composition to plasma. Most of the components of CSF are secreted by vascular plexuses (e.g., choroid plexus) lining the ventricles. The CSF is secreted at a rate of 50–400 ml/d into the cisterns (opening in the subarachnoid space) and the subarachnoid space (a space between two layers of meninges in the CNS) and is finally reabsorbed into the venous blood leaving the cranium. This fluid acts as a shock absorber for the brain.

Nerve cells need a constant supply of oxygen for survival; this supply is maintained by the blood vessels. The brain receives nearly 20% of the total cardiac output and consumes about 20% of total oxygen used by the whole body at rest. The two internal carotid and the two vertebral arteries supply blood to the brain, and a single anterior and two spinal arteries supply blood to the spinal cord. All of the venous blood from the CNS eventually drains into the superior vena cava.

13.1.2 Radiopharmaceuticals and Imaging Techniques

Brain Imaging

The principle of brain imaging is governed by a mechanism called the blood-brain barrier (BBB), which excludes many substances from entering the brain from the blood. The BBB is probably a functional mixture of anatomic, physiologic, and metabolic phenomena, and which of these are effective in a particular instance depends on the physicochemical properties of the substance in question. The barrier perhaps results from a tight intracellular junction of endothelial cells in the brain capillaries, lack of extracellular fluid space, lack of pinocytosis, and limited transport mechanism. The barrier is selective: some substances, such as water, glucose, sodium chloride, and so on, readily enter the brain, whereas compounds such as sodium nitrite, sodium iodide, sucrose, bile pigments, and many commonly used radiopharmaceuticals do so with difficulty or not at all. The breakdown of the BBB, as in the case of tumors or other diseases, results in the penetration of the latter compounds into the brain.

Based on the principle of BBB, radiopharmaceuticals for brain imaging can be broadly grouped into two categories: diffusible and nondiffusible. Diffusible tracers are typically lipophilic and readily cross the BBB. Examples are ^{99m}Tchexamethylpropylene amine oxime (^{99m}Tc-HMPAO), ^{99m}Tc-ethyl cysteinate dimer (^{99m}Tc-ECD), and ¹⁸F-fluorodeoxyglucose (¹⁸F-FDG). Nondiffusible tracers are hydrophilic and polar and cannot cross the BBB except in abnormal tissues where the BBB is broken. Examples are ^{99m}TcO₄⁻, ²⁰¹Tl, and ^{99m}Tc-DTPA.

Decades ago, in the absence of diffusible radiopharmaceuticals, nondiffusible tracers were the agents of choice for brain imaging. However, with the introduction of diffusible tracers, nondiffusible tracers are rarely used for brain imaging, except ^{99m}Tc-DTPA for assessment of brain death. Among the diffusible tracers, ^{99m}Tc-HMPAO and ^{99m}Tc-ECD are used for brain perfusion imaging, and ¹⁸F-FDG is commonly used for brain metabolic imaging. ¹⁸F-fluorodopa is used to detect cerebral diseases related to dopamine receptors, such as Parkinson disease, whereas ¹⁸F-florbetapir and ¹⁸F-flutemetamol are used in amyloid plaque imaging in Alzheimer's disease. The characteristics of the commonly used radiopharmaceuticals for brain imaging are summarized in Table 13.1.

^{99m}Tc-Ethyl Cysteinate Dimer (Neurolite)

^{99m}Tc-ECD is a neutral lipophilic complex that localizes in the brain by crossing the BBB via passive diffusion and is used as a brain perfusion agent. However, in the brain, an enzyme-catalyzed hydrolysis of one of the ester groups to carboxylic acid results in the formation of an anionic complex, which cannot diffuse across the

	,
	-
imaging	
ticals for brain	
ı radiopharmaceu	^{99m} Tc-
Common	
Table 13.1	
100	

$ \begin{array}{c c c c c c c c c c c c c c c c c c c $								
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $		¹⁸ F-flutemetamol	110 min	511	5	185	1.5	
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $		¹⁸ F-florbetaben	110 min	511	8.1	300	0.75-2.2	
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $		¹⁸ F-florbetapir	110 min	511	10	370	0.5-0.8	
		¹⁸ F-fluorodopa	110 min	511	5-10	185-370	0.3-0.5	
$^{90m}Tc^ ^{90m}Tc^ ^{90m}Tc^ ^{1}Tc^ ^{1}Tc^-$ <th< td=""><td></td><td>¹⁸F-FDG</td><td>10 min</td><td>511</td><td>10-15</td><td>370-555</td><td>0.6</td><td></td></th<>		¹⁸ F-FDG	10 min	511	10-15	370-555	0.6	
$^{90mTc-}$ $^{90mTc-}$ CharacteristicsHMPAO $^{90mTc-}ECD$ $t_{1/2}$ (physical)6 h6 hPhoton energy (keV)140140Usual dosage (mCi)10-2010-20Usual dosage(MBq)370-740370-740Usual wait time for0.3-20.5-1imaging (h) p.i.0.5-1		²³ I-ioflupane	13.2 h	159	3-5	111-185	3–6	
$9^{9m}Tc$ - Characteristics $9^{9m}Tc$ - HMPAO $t_{1/2}$ (physical)6 hPhoton energy (keV)140Usual dosage (mCi)10-20Usual dosage (MBq)370-740Usual wait time for imaging (h) p.i.0.3-2		^{99m} Tc-ECD	6 h	140	10-20	370-740	0.5 - 1	
Characteristics 1 _{1,2} (physical) Photon energy (keV) Usual dosage (mCi) Usual dosage(MBq) Usual wait time for imaging (h) p.i.	-2T ^{m99}	HMPAO	6 h	140	10-20	370-740	0.3–2	
		Characteristics	$t_{1/2}$ (physical)	Photon energy (keV)	Usual dosage (mCi)	Usual dosage(MBq)	Usual wait time for	imaging (h) p.i.

BBB, thus preventing the washout from the brain. After intravenous administration, the blood clearance of ^{99m}Tc-ECD is very rapid, and the blood activity is less than 10% after 5 min. The brain uptake is very rapid and amounts to 5–6% of the injected dosage (ID) with very slow washout. The ratio of gray to white matter uptake is greater than 2:1. The lung uptake is negligible and the hepatobiliary excretion is about 11% ID. The urinary excretion is $55 \pm 10\%$ in 2 h and about 78 ± 14% in 24 h after injection (Leveille et al. 1989; Vallabhajosula et al. 1989).

Approximately 10–20 mCi (370–740 MBq)^{99m}Tc-ECD is injected intravenously into the patient. Both planar and SPECT imaging can be performed using a gamma camera equipped with a parallel hole collimator in either dynamic or static mode. However, currently SPECT/CT is the choice of method for imaging, in which CT images are utilized for attenuation correction of and coregistration with SPECT images. Initially noncontrast CT images are obtained, and SPECT images are taken 20–40 min after injection at 3–10° intervals over 180° or 360° using a scintillation camera equipped with a low-energy high-resolution (LEHR) parallel hole collimator. Data are acquired in a 128 × 128 matrix. SPECT data are corrected for attenuation and then transverse (short axis) CT and SPECT images are reconstructed and fused together. Sagittal (vertical long axis) and coronal (horizontal long axis) images are generated from the transverse images by using appropriate algorithm. Perfusion abnormalities due to infarction, stroke, tumor, and so forth show decreased uptake of ^{99m}Tc-ECD.

Seizure foci in epilepsy patients can be identified by ^{99m}Tc ECD SPECT study. Initially an interictal or baseline scan is obtained by SPECT imaging at 10–15 min after injection of 25–30 mCi (875–1110 MBq) ^{99m}Tc-ECD. Ictal or periictal imaging is obtained by administering the tracer at the point of seizure followed by SPECT imaging 10–15 min later. Because of the hypermetabolism at the epileptic foci during seizure, ictal images show a focal increase in tracer uptake relative to the decreased or no uptake in interictal images. Typical CT attenuation-corrected SPECT images in ictal and interictal states of an epileptic patient are shown in Fig. 13.2.

^{99m}Tc-Hexamethylpropylene Amine Oxime (Ceretec)

As stated in Chap. 7, the primary complex d, 1 isomer of 99m Tc-HMPAO, not the meso isomer, is a lipophilic moiety, which diffuses into the brain by crossing the BBB. In the brain, it is converted to a secondary complex, most likely due to a reaction with glutathione, which is hydrophilic and is unable to back out of the brain. The blood clearance is rapid after intravenous injection resulting in a blood level of 12% ID at 1 h postinjection (Sharp, et al. 1986). The maximum brain uptake of ~4% ID occurs within 1 min of injection. Only 15% of the brain activity washes out within 2 min postinjection, after which the brain activity remains at a plateau over a period of 24 h. The urinary excretion is about 35% ID in 24 h after injection. The soft tissue, liver, and gastrointestinal uptakes are high (~10%).

Approximately 10–20 mCi (370–740 MBq) ^{99m}Tc-HMPAO is administered intravenously to patients with altered cerebral perfusion as in stroke. As in case of ^{99m}Tc-ECD, SPECT/CT is commonly employed to image the patient's brain using a



Fig. 13.2 Baseline and ictal images of an epilepsy patient obtained by ^{99m}Tc-ECD SPECT imaging in transverse, coronal and sagittal projections. Seizure focus is indicated by *white arrows* at right lateral and dorsal lateral anterior parietal regions. *Red arrows* indicate the prior surgical scar

scintillation camera equipped with a LEHR collimator. Perfusion abnormalities such as infarction, stroke, tumor, and so on show decreased uptake of ^{99m}Tc-HMPAO. A typical SPECT image obtained with ^{99m}Tc-HMPAO is shown in Fig. 13.3.

123I-Ioflupane

Ioflupane binds reversely to dopamine transporter (DAT) proteins present on presynaptic terminals of dopaminergic neurons, and so ¹²³I-ioflupane, also called ¹²³I-FP-CIT or DaTscan, is used to detect pathogenesis of several neurodegenerative diseases such as Parkinson syndromes (PS) by SPECT imaging. Following IV administration to humans, the blood activity disappears fast and is found to be about 53% of the dosage at 1 h and slowly decreases thereafter (Booij et al. 1998). Most of the activity is distributed in the lungs, liver, brain, bladder, and intestine. At 48 h postinjection, the urinary excretion is ~60% and fecal excretion is approximately 14%. The brain uptake is ~7% at 10 min after injection and falls to 3% at 5 h, with almost 30% of the activity in the striatum.

The recommended dosage for ¹²³I-ioflupane is 3–5 mCi (111–185 MBq) for IV administration to humans. Since ¹²³I-ioflupane contains some free ¹²³I-iodide, at least 1 h prior to its administration of radioactivity, 100 mg of iodide as potassium iodide or 400 mg of potassium perchlorate is administered to block the thyroid

Fig. 13.3 A SPECT image (midtransverse slice) obtained with 20 mCi (740 MBq) ^{99m}Tc-HMPAO demonstrating decreased uptake in the left hemisphere in a patient with stroke



uptake of the patient. SPECT imaging is carried out 3–6 h after the administration of radioactivity using a multi-headed camera. Images are acquired at 3° intervals over 360°, and CT transmission images are obtained for attenuation correction and coregistration. After attenuation correction, SPECT images are reconstructed and displayed for interpretation.

As a cocaine analog, ¹²³I-ioflupane localizes in normal striatum by binding to the dopamine transporters, and normal images are characterized by symmetric uptake of the activity in the caudate–putamen area of the two hemispheres (Fig. 13.4a), whereas decreased or absent activity is observed in abnormal images (Fig. 13.4b). It is used as compliment to other diagnostic evaluations in patients with Parkinson's syndromes to differentiate essential tremor from tremor due to idiopathic Parkinson's syndromes, multiple system atrophy, and progressive supranuclear palsy.

¹⁸F-Fluorodeoxyglucose

Since the brain derives its energy from the metabolism of glucose, ¹⁸F-FDG is a good candidate for metabolic imaging of the brain. After intravenous administration, ¹⁸F-FDG diffuses from blood into the brain by crossing the BBB and is metabolized in the brain cells wherein FDG is phosphorylated to FDG-6-phosphate mediated by hexokinase. Since FDG lacks a hydroxyl group at the 2-position, its first metabolite, FDG-6-phosphate, is not a substrate for glycolysis and does not undergo further metabolism. Because of its negative charge, FDG-6-phosphate remains trapped in the brain for several hours, thus facilitating imaging of the brain at convenience. However, several studies have reported suggesting that a significant fraction of ¹⁴C-DG-6-phosphate undergoes further metabolism and is incorporated into glycogen (Virkamaki et al. 1997). Dienel et al. (1993) reported that almost 20%



Fig. 13.4 a Normal image of ¹²³I-ioflupane in human patient showing symmetrical uptake of activity in striata of both hemispheres of the brain. **b** An abnormal image of ¹²³I-ioflupane in a patient with suspected Parkinson's syndromes showing overall decreased uptake in both hemispheres except in the putamen area of right hemisphere

of ¹⁴C-deoxyglucose-6-phosphate is further metabolized in the brain, which diffuses into the blood pool. It is expected that ¹⁸F-FDG-6-phosphate would metabolize similar to ¹⁴C-DG-6-phosphate, and failure to account for further metabolism would underestimate the rate of tissue uptake of ¹⁸F-FDG.

Following intravenous administration of ¹⁸F-FDG to human subjects, its brain uptake in humans is 6.9% ID at 2 h postinjection. The uptake values for other organs at 1 h postinjection are as follows (Mejia et al. 1991): heart, 3.3%; kidneys, 1.3%; liver, 4.4%; red marrow, 1.7%; and bladder content, 6.3%. The urinary excretion is $19.6 \pm 10.9\%$ at 1 h and $21.2 \pm 5.0\%$ at 2 h.

PET/CT is commonly employed for brain imaging after ¹⁸F-FDG administration. The patient is normally asked to fast for 6 h and, if diabetic, is checked for blood sugar not to exceed 250 mg/dl. Prior to FDG administration, a blank CT scan is acquired followed by a CT transmission scan of the patient for attenuation correction. PET data are collected in 3D mode 45–60 min after administration of 10–15 mCi (370–555 MBq) ¹⁸F-FDG intravenously. Data are acquired in a 128 × 128 matrix and corrected for attenuation using CT data. The corrected data are then applied to reconstruct the images in short (transverse) axis, which are then utilized to construct the sagittal and coronal images. While fusion of PET and CT images is common, some nuclear physicians prefer to have MR images for fusion with PET images. ¹⁸F-FDG PET studies are useful to detect epileptic foci, tumor, dementia, and Alzheimer's and to differentiate between recurrent tumor and radiation necrosis.

During focal seizures (ictal state) in epileptic patients, brain metabolism and blood flow are increased at the focus, and therefore increased ¹⁸F-FDG uptake is seen. In the periods between seizures (the interictal state), both metabolism and blood flow are reduced at the focus and hence the decreased ¹⁸F-FDG uptake. However, ¹⁸F-FDG PET imaging during the interictal state is more useful than in the ictal state in localizing the epileptogenic focus in epilepsy patients for surgical ablation. An ¹⁸F-FDG PET image indicating the hypometabolism in the brain of an epileptic patient is shown in Fig. 13.5.



Fig. 13.5 Transverse and coronal images of an ¹⁸F-FDG PET study showing hypometabolic area in both temporal lobes in the interictal state of an epilepsy patient

¹⁸F-FDG PET imaging is useful in differentiating the recurrent brain tumors from necrotic brain tissue such as in radiation necrosis. Recurrent brain tumors exhibit high glucose metabolism, whereas necrotic brain tissue does not metabolize glucose. Thus, ¹⁸F-FDG PET shows increased uptake in brain tumors, whereas decreased uptake is seen in necrotic brain tissue. Brain tumor imaging with ¹⁸F-FDG is discussed in detail under tumor imaging in this chapter.

¹⁸F-FDG has also been used in the metabolic study of the brain in demented patients and Alzheimer's patients.

¹⁸F-Fluorodopa

As a neurotransmitting agent, ¹⁸F-fluorodopa crosses the BBB and accumulates in the brain with the highest uptake in the striatum (caudate nucleus and putamen) and lowest in the cerebellum. Since movement disorder (Parkinson disease or other neurodegenerative diseases) originates in the striatum, ¹⁸F-fluorodopa is used to detect these disorders. After intravenous administration, the plasma concentration of ¹⁸F-fluorodopa peaks quickly and then decreases to approximately 10% ID at 5 min after injection. The maximum brain uptake occurs in 20 min postinjection (Barrio et al. 1990). It is largely metabolized in circulation by dopa decarboxylase (DDC) ¹⁸F-fluorodopamine and by catechol-O-methyl-transferase to 18F-3-Oto methylfluorodopa (3-OMFD) before crossing the BBB. This complicates the uptake of ¹⁸F-fluorodopa. Inhibitors of DDC such as carbidopa and nitecapone are injected prior to administration of 18F-fluorodopa to improve brain uptake of the tracer. Since ¹⁸F-3-OMFD also enters the brain along with ¹⁸F-fluorodopa, L-phenylalanine has been used to prevent the entry of ¹⁸F-OMFD.

Approximately 5–10 mCi (185–370 MBq) ¹⁸F-fluorodopa is administered intravenously to patients with Parkinson's disease or other neurodegenerative diseases. Images are obtained after injection using a PET/CT scanner. Attenuation correction is made using the CT scans. In Parkinson's disease, the accumulation of the tracer is markedly reduced in the striatum of the brain. Also, low-grade, high-grade, and recurrent tumors have been detected with ¹⁸F-fluorodopa.

¹⁸F-Florbetapir (Amyvid)

¹⁸F-Florbetapir binds to amyloid plaques (composed of aggregated amyloid β -peptide, A β) that are considered responsible for cognitive impairment including Alzheimer's disease (AD) in patients and thus is used to detect these disorders, particularly AD. Following intravenous administration, the activity distributes throughout the body, and only <5% ID of the activity at 20 min and <2% ID at 45 min postinjection remain in the blood. The tracer is primarily excreted via the hepatobiliary system, and the initial liver uptake is ~19.8% clearing slowly to ~11% at 2.5 h postinjection (Lin et al. 2010). The initial peak uptake of the tracer in the brain is 5.1% that decreases to ~2.5% ID at 2.5 h postinjection. The total urinary excretion is 6% ID over 3 h, indicating little excretion via kidneys.

For PET/CT or PET/MR imaging, initially a CT or MR transmission scan is obtained for attenuation correction and coregistration of images. Next 10 mCi (370 MBq) of ¹⁸F-florbetapir in 10 ml solution is administered via a short catheter
to the patient suspected of having AD. PET images are obtained for 10 min at 30 to 50 min postinjection in 2D or 3D mode and are reconstructed after attenuation correction. Images are primarily displayed in transverse orientation for interpretation. Images are interpreted as positive when one or more areas of cortical gray matter have more activity relative to the adjacent white matter indicating the possibility of AD (Fig. 13.6a). A negative scan shows activity in white matter more than in gray matter (Fig. 13.6b). ¹⁸F-florbetapir imaging is not a definitive modality for AD, but it complements other clinical evaluations of AD.

¹⁸F-Flutemetamol (Vizamyl)

¹⁸F-flutemetamol binds avidly to the amyloid plaques in the brain striatum and is indicated for the detection of AD in patients. Following IV administration of the tracer in humans, approximately 7% of administered ¹⁸F-flutemetamol distributes to the brain, and ~25% of the tracer remains in the blood 20 minutes postinjection and ~10% at 3 h (EMA 2014). The clearance of brain activity is slow. The liver uptake



Fig. 13.6 PET images of amyloid uptake in AD patients using ¹⁸F-florbetapir (Amyvid). **a** A negative scan showing decreased uptake in cortical gray matter in a healthy patient. **b** A positive scan showing increased uptake in the gray matter in an AD patient



Fig. 13.7 The abnormal image (*right*) shows ¹⁸F-flutemetamol uptake levels in the gray matter which are similar to or greater than the adjacent white matter intensities. The gray matter uptake in the normal image (*left*) is sparse and at approximately the same level of intensity as the cerebellum (Reproduced from European Medicines Agency. Vizamyl; flutemetamol (¹⁸F); Procedure No. EMEA/H/C/002553; 2014)

is the highest at 20–25% ID. The tracer is mainly excreted via GI tract amounting to 52% ID, while the urinary excretion is about 37% ID. The biological half-life of the tracer is 4.5 h. Minor quantities of ¹⁸F-flutemetanol are metabolized and excreted via urine.

PET/CT or PET/MR imaging using ¹⁸F-flutemetamol has been successfully utilized to detect various cognitive disorders including AD. Approximately 5 mCi (185 MBq) of ¹⁸F-flutemetamol is administered IV followed by a flush of 5 to 15 ml of 0.9% NaCl solution. Initially a CT or MR image is acquired for attenuation correction and image coregistration. A 20-min PET image is obtained at 90 min postinjection, which is corrected for attenuation with CT or MR data and coregistered with the CT or MR image, followed by reconstruction. The reconstructed images are displayed in different anatomic orientations for interpretation. The amyloid plaques are seen with increased uptake in gray matter suggesting AD, whereas absent or sparse activity in the striatal area indicate the absence of AD. Uptake in cerebellum is minimal and appears equal in both normal and abnormal images. Normal and abnormal PET images with ¹⁸F-flutemetamol are shown in Fig. 13.7. This test is, however, an adjunct to other clinical methods of AD diagnosis.

¹⁸F-Florbetaben (Neuraceq)

¹⁸F-florbetaben is useful in the detection of amyloid plaques in the brain of AD patients. Following IV administration, ¹⁸F-florbetaben highly binds to plasma proteins (unbound fraction, 1.6%) and is metabolized by several CYP enzymes (Sabri et al. 2015a, b). The plasma activity is found to be 10–20% ID at 10 min declining to 90% at 50 min postinjection. Brain uptake is rapid, reaching a maximum of ~6% ID at 10 min postinjection. It is primarily excreted via hepatobiliary route with a biological half-life of 1 h. At 12 h postinjection, the urinary excretion is 30%. ID.

PET/CT or PET/MR imaging is carried out following IV administration of 8.1 mCi (300 MBq) and subsequent flush of 10 ml saline to patients suspected of having AD. First, CT or MR images are acquired for attenuation correction and coregistration with the PET image. After a wait of 45–130 min postinjection, PET images are acquired for a period of 15–20 min. The reconstructed image is obtained after applying attenuation correction to the PET image, which is then displayed in different orientations. Clinical interpretation is made by comparing the gray matter uptake relative to the adjacent white matter uptake of the radioactive tracer. A positive scan is demonstrated by an increased uptake in the gray matter compared to the white matter. However, a positive scan may indicate AD as well as other neurodegenerative diseases, and it is imperative that a definitive diagnosis of AD must be complemented by other clinical tests.

Note: A new theory explains how AD develops in aged people disputing the current concept that amyloid plaques composed of A β peptides destroy the brain cells causing AD. Now it is thought that tau proteins present in the brain cells, whose function is to help clear toxic proteins, are responsible for the brain cells death, not the plaques (Lonskaya et al. 2014). When tau is abnormal, which may be caused by errant genes; or aging, the proteins including A β proteins accumulate inside the neurons and exerts toxic effect, so the cells tend to spit out the proteins into the extracellular space, where A β proteins, being sticky, clump together to form amyloid plaques. The proteins that could not be spit out and remain in the neurons, kill them – not the amyloid plaques outside the cells. It explains why some older individuals having documented amyloid plaque buildup clinically do not have AD or other dementias. This discovery should lead to new probes to target tau proteins for better detection of AD.

Other Radiopharmaceuticals

¹⁵O–O₂ has been used to measure the oxygen consumption by the brain tissue, which measures the metabolic status of the brain. ¹⁵O–H₂O, n-¹⁵O-butanol, and ¹³³Xe have been used to measure the blood flow in the brain. ¹¹C-labeled ligands such as ¹¹C-*N*-methylspiperone have been used to image the D2 dopamine receptor density in schizophrenic patients in whom D2 dopamine receptors increase in number in the caudate nucleus and putamen. The highly mu-selective opiate agonist ¹¹C-carfentanil

has been used to quantify mu opiate receptors in patients with idiopathic unilateral temporal lobe epilepsy. In other instances, benzodiazepine receptors are imaged with ¹¹C-flumazenil and ¹²³I-iomazenil to detect areas of seizure foci in epilepsy patients.

Brain Interventional Study

Brain interventional study using acetazolamide (ACZ, Diamox) are performed to assess the cerebrovascular reserve capacity of the brain because ACZ causes vasodilation of cerebrovascular arteries to the extent of 20–40%, causing increased blood flow. The action of ACZ begins within 10 min of injection, reaches maximum at 25 min, and fades within 1 h.

In a typical interventional study, the patient is injected with 15 mCi (555 MBq) ^{99m}Tc-ECD, and pre-ACZ scan is started 15 min after injection and SPECT images taken for about 30 min. Fifteen minutes into the scan, the patient is administered with reconstituted ACZ containing 1 g. Soon after the pre-ACZ scan is finished, 25 mCi (850 MBq) ^{99m}Tc-ECD is injected and post-ACZ images are obtained after 15 min postinjection. A similar protocol is also used for ^{99m}Tc-HMPAO. SPECT images are collected with a dual-head camera using a high-resolution collimator. Comparison of the pre- and post-ACZ images shows only a slightly increased blood flow in the abnormal areas (ischemic) compared to the normal areas that show significantly increased blood flow. This technique identifies the areas at highest risk of ischemia and lateralization of the severity of the disease in the brain.

Cisternography

Cisternography is employed in the investigation of the rate of formation, flow, and resorption of CSF. Any obstruction in the cerebral ventricular system results in abnormal circulation of CSF. These abnormalities are manifested in hydrocephalus, CSF leakage, and other similar conditions.

¹¹¹In-DTPA

The radiopharmaceutical most commonly used in cisternography is ¹¹¹In-DTPA, although ^{99m}Tc-DTPA also can be used. Approximately 0.5 mCi (18.5 MBq) ¹¹¹In-DTPA is injected into the patient by lumbar puncture (subarachnoid space). Imaging with a gamma camera fitted with a medium-energy collimator is performed 4 h and 24–48 h after injection, and anterior, posterior, and lateral views are obtained. SPECT images also can be obtained, if needed. Under normal conditions, at 24 h, the radioactivity appears in the basal cisterns, convexities, and parasagittal locations. In the case of normal pressure hydrocephalus (NPH), the radioactivity is refluxed into the lateral ventricles and is still seen in them at 24–48 h with no activity found in the convexities.

In patients with CSF leakage, cotton pledgets are placed in the nostrils for a period of 24 h after lumbar puncture administration of ¹¹¹In-DTPA and then removed at the end of the study. The activities in the pledgets and the blood are measured in a well counter and compared. If the pledget activity is greater than the blood activity by a factor of 1.5 or more, CSF leakage (rhinorrhea) is suspected. If the patient is

actively leaking, the actual site of CSF leakage can be detected by gamma camera scintigraphy using a larger dosage of ¹¹¹In-DTPA (2–3 mCi or 74–111 MBq).

¹¹¹In-DTPA is also used to assess the shunt patency in patients with obstructive hydrocephalus who have been implanted with ventriculoatrial or ventriculoperitoneal shunts. The radiotracer (0.5 mCi or 18.5 MBq) is usually injected into the reservoir or the tubing under aseptic condition, and the passage of the tracer is observed by gamma camera scintigraphy. In the case of shunt patency, the rapid passage of radioactivity through the shunt should be seen within 30 min to 1 h after administration.

13.1.3 Diagnosis

Various diseases of the brain diagnosed by radionuclidic procedures are primary tumors such as gliomas and meningiomas, metastatic tumors, cerebrovascular infarcts, intracranial abscess, subdural hematoma, metabolic defects, epileptogenic focus, blood flow abnormalities as in stroke, alterations in the receptor density distribution as in schizophrenia, Parkinson's syndromes, and various other related diseases. Neurodegenerative disorders including AD can be detected by PET imaging. Normal pressure hydrocephalus (communicating and noncommunicating), CSF rhinorrhea (leakage), and CSF shunt patency can be detected by cisternography.

13.2 Thyroid

13.2.1 Anatomy and Physiology

The thyroid gland is composed of two lobes situated below the larynx, one on either side of the trachea (Fig. 13.8). The two lobes are connected by an isthmus lying near the surface of the neck. The normal weight of a thyroid gland is approximately 15–30 g. The thyroid gland is primarily composed of numerous spherical acini, each of which contains a variable amount of a homogeneous colloid material. These acini cells are responsible for the formation of thyroid hormones utilizing iodine obtained from dietary sources.

The primary function of the thyroid gland is to regulate the basal metabolic rate by controlling the synthesis and secretion of two important thyroid hormones, triiodothyronine (T3) and thyroxine (T4). These hormones act as stimulants to all metabolic processes, which are reflected by increased oxygen consumption and heat production. These hormones are essential for growth and sexual maturation.

There are five major steps in the synthesis of thyroid hormones:

- 1. Trapping of iodide from blood by the thyroid gland.
- 2. Oxidation of iodide to I° or I⁺ by peroxidase enzyme.
- 3. Organification, whereby monoiodotyrosine (MIT) and diiodotyrosine (DIT) are formed by iodination of tyrosine with iodine produced in step 2; tyrosine



molecules are bound by peptide linkage in thyroglobulin, which is stored in the lumen of the acinus.

- 4. Condensation or coupling in which one DIT molecule combines with either an MIT molecule or another DIT molecule to form T3 or T4, respectively.
- 5. Release of T3 and T4 into the circulation by enzymatic hydrolysis of thyroglobulin; in the blood approximately 90% of T4 is bound to T4-binding globulin (TBG) (the biological $t_{1/2}$ of T3 and T4 are 2 days and 7 days, respectively).

Control of the synthesis and secretion of thyroid hormones is maintained by a feedback mechanism with the thyrotropin or thyroid-stimulating hormone (TSH) secreted by the pituitary gland. TSH acts on the thyroid to increase trapping, organification, and release of thyroid hormones, primarily by stimulating the activity of the proteolytic enzyme responsible for the breakdown of thyroglobulin. Excessive amounts of T3 and T4 in the blood inhibit the release of TSH from the pituitary gland, thus maintaining thyroid function at an optimum level. TSH is in turn regulated by the action of TSH-releasing hormone (TRH) produced in the hypothalamus.

Thyroid diseases are primarily associated with the iodine uptake and functional status of the thyroid glands. When the thyroid produces excessive amounts of T4, the condition is called hyperthyroidism, which is manifested by symptoms such as increased appetite, restlessness, and hyperactivity. Endemic goiter results from an iodine-deficient diet, particularly in areas where the dietary intake of iodine is very low. This condition can be rectified by the addition of an adequate amount of iodide

to the food. Severe hyperfunctioning of the thyroid is called thyrotoxicosis, Graves' disease, or exophthalmic goiter.

Underfunctioning of the thyroid gland leads to the condition called hypothyroidism, which is manifested by lethargy, a tendency to gain weight, and cold intolerance. The level of circulating thyroid hormones remains low. Severe hypothyroidism is called myxedema, which is manifested by infiltration of the skin.

13.2.2 Radiopharmaceuticals and Imaging Techniques

¹³¹I- or ¹²³I-Sodium lodide

Since iodine is an essential element for the function of the thyroid gland, ¹³¹I- or ¹²³I-NaI has been the agent of choice for assessing its functional and structural status.

After oral administration of ¹³¹I-NaI or ¹²³I-NaI, iodide is absorbed through the intestine, and its level in the blood reaches a maximum within 3 h. Up to 90% of the administered dosage is excreted by the kidneys, and only a small fraction is excreted in feces and sweat. Urinary excretion is almost 50% in 24 h after administration. Two tests are performed – the radioiodide uptake and the imaging of the thyroid glands.

In the iodide uptake test, approximately $10-15 \ \mu$ Ci (0.37–0.56 MBq) ¹³¹I-NaI or 100 μ Ci (3.7 MBq) ¹²³I-NaI in capsule form is placed in a thyroid phantom, and the activity in counts is measured with a thyroid probe of NaI(Tl) crystal fitted with a long-bore collimator of lead, placed at the same distance as the patient would be seated for the uptake measurement. A room background count is taken and subtracted from the phantom counts, which gives the net standard count. The capsule or capsules are then administered orally to the patient, and the uptake is normally determined at 6 and 24 h after administration. The patient is seated at the same distance as the phantom, and the thyroid count is obtained using the thyroid probe. A thigh count is taken and subtracted from the thyroid count to correct for extrathyroidal activity. The thyroid uptake as a percentage of the administered dosage is calculated as follows:

$$\text{\%Uptake} = \frac{A - B}{C - D} \times 100 \tag{13.1}$$

where A is the total cpm of the thyroid, B is the total cpm of the thigh, C is the total cpm of the thyroid phantom corrected for decay to the time of counting, and D is the total cpm of the room background corrected for decay to the time of counting.

The normal values for thyroid uptake of 131 I-NaI or 123 I-NaI are 10–35% for 24 h and 7–20% for 6 h, but the values vary from institution to institution.

Thyroid scans are obtained at 24 h after oral administration of 100 μ Ci (3.7 MBq)¹³¹I-NaI or 300 μ Ci (11.1 MBq)¹²³I-NaI. A gamma camera equipped with a pinhole collimator is used to image the thyroid glands. Some laboratories use a parallel hole collimator instead of a pinhole collimator. Imaging is useful in the assessment of the thyroidal structure, position, and function in cases of thyroid carcinoma and hyperthyroid. A normal image with ¹³¹I at 24 h is shown in Fig. 13.9.



Fig. 13.9 Normal thyroid image obtained with ¹³¹I-iodide 24 h after administration of the dosage showing uniform distribution of activity in both lobes

Table 13.2	Inhibitory effec	t of drugs or chemic	cals on thyroid	uptake of iodine
------------	------------------	----------------------	-----------------	------------------

	Duration of
Drugs or chemicals	effect
T3, thiouracil (PTU, etc.), sulfonamides, cobaltous ions, penicillin,	1 week
adrenocorticotropic hormone(ACTH), isoniazid, steroids, bromides, perchlorate,	
pentothal, nitrates, butazolidin, thiocyanate	
Iodides, some vitamin mixtures, some cough medicine, seaweed, dinitrophenol	2-3 weeks
Thyroid extract, T4	4-6 weeks
Radiographic contrast media (e.g., Conray), oral contrast media (e.g.,	8 weeks
Cholografin)	
Contrast media used in bronchography, myelography and arthography (e.g., Lipiodol)	>1 year

Various drugs and chemicals in blood influence the thyroid uptake of iodine and are listed in Table 13.2. Iodine uptake should not be performed during the period of the effects of these drugs and chemicals.

^{99m}Tc-Sodium Pertechnetate

Due to their common ionic characteristics, iodide and ${}^{99m}\text{TcO}_4^-$ behave similarly following intravenous administration. Like iodide, ${}^{99m}\text{TcO}_4^-$ localizes in the thyroid, salivary glands, gastric mucosa, and choroid plexus of the brain. Following intravenous administration, ${}^{99m}\text{TcO}_4^-$ partly becomes protein-bound in plasma. The plasma clearance is rapid and it is secreted by gastric mucosa in the stomach and the intestine. It is trapped but not organified in the thyroid gland and is primarily used for assessing the structure of the thyroid gland. Approximately 30% of the injected activity is excreted in the urine in the first 24 h; fecal excretion becomes important after 24 h. The total urinary and fecal excretion of ${}^{99m}\text{Tc}$ is about 50% in 3 days and nearly 70% in 8 days. In contrast, reduced ${}^{99m}\text{Tc}$ and ${}^{99m}\text{Tc}$ -chelates are promptly cleared by the kidneys and do not accumulate in the thyroid and the choroid plexus. The thyroid uptake is $\sim 2\%$.

Approximately 10 mCi (370 MBq) 99m TcO₄⁻ is administered intravenously, and images are taken 10–30 min after injection using a gamma camera equipped with a pinhole collimator or a parallel hole collimator. The images demonstrate the trapping phenomenon indicating the structure of the thyroid like 123 I⁻ images.

Other Radiopharmaceuticals

Among other radiopharmaceuticals, ²⁰¹Tl-thallous chloride and ^{99m}Tc-sestamibi provide a good sensitivity in detecting the metastasis of thyroid cancer. ^{99m}Tc⁵⁺-DMSA has proved to be an excellent tracer for the detection of both primary and metastatic medullary carcinoma of the thyroid. Thyroid medullary carcinoma is also detected by using ¹¹¹In-pentetreotide, because of the presence of somatostatin receptors on these cancer cells. Although these radiopharmaceuticals (except Tc⁵⁺-DMSA) are approved for clinical use in other indications by the FDA, their routine use for thyroid cancer detection is limited. Recently ¹⁸F-FDG PET has been approved for reimbursement in staging thyroid follicular cancer.

13.2.3 Diagnosis

Common diseases that are diagnosed by the thyroid iodine uptake test include hypothyroidism and hyperthyroidism. Thyroid imaging is useful in detecting any palpable mass (nodule). Clinically, thyroid nodules can be classified into various categories – solitary or multiple, firm or soft, tender or nontender, and benign or malignant. Hyperfunctioning nodules accumulate relatively higher amounts of radioactivity and are termed "toxic", "hot", or "autonomous" nodules. Hypofunctioning nodules behave in opposite manner. Thyroid carcinoma does not concentrate radioiodine well and therefore is seen as a cold spot on the image. Figure 13.10 shows thyroid images with ^{99m}Tc and ¹³¹I indicating a hot nodule in the upper right lobe of the thyroid.

13.3 Lungs

13.3.1 Anatomy and Physiology

The airway of the respiratory tract starts at the nostrils and passes through the pharynx and then through the trachea in the neck. The upper end of the trachea is the larynx. The trachea branches at the lower end into two main bronchi, one going to each of the two lungs. The bronchi branch into bronchioles that in turn terminate into alveolar sacs. There are approximately 700 million alveoli in an adult man, providing a surface area of almost 80 m². A schematic diagram of the respiratory system is shown in Fig. 13.11.



Fig. 13.10 Thyroid images obtained with ¹³¹I (24 h after oral administration) and ^{99m}Tc (1 h after injection) and showing a "hot" nodule in the upper right lobe. Both images are similar in the distribution of radioactivity except that there is slightly more uptake of ¹³¹I in the left lobe



Fig. 13.11 Anatomic structure of the respiratory tract

The lungs are covered by a connecting tissue membrane called the visceral pleura. The pleural cavity between the visceral pleura and the thoracic lining (parietal pleura) is filled with serous fluid, which lubricates the two surfaces as they slide over one another during breathing.

Blood circulation is maintained by the pulmonary artery carrying deoxygenated blood from the right ventricle of the heart to the lungs and the pulmonary veins returning oxygenated blood from the lungs to the left atrium of the heart. The pulmonary arterial distribution is similar to airway segmental distribution. The pulmonary artery branches into distribution arteries ranging in diameter from 60 to 100 μ m. These arteries branch into precapillary arterioles with diameters of 25–35 μ m, which in turn terminate in capillary units whose average diameter is approximately 8 μ m. The capillaries are just large enough for the 7- μ m red cells to pass through without any deformation. There are about 280 billion arterial capillaries that connect to venules at the other end and ultimately to the veins. About 500–1000 capillaries surround each alveolus.

Deoxygenated blood carried by arterial capillaries comes in contact with the inhaled air in the alveolus, where oxygen almost instantaneously diffuses into the blood; venous carbon dioxide is released into the alveolus, wherefrom it is exhaled. Blood flow through the pulmonary arterial system is called pulmonary perfusion, and airflow through the bronchial system is called ventilation. Both proper ventilation and perfusion are essential for normal respiration. Overall, the lungs receive 106% of the cardiac output, 100% through the pulmonary artery and about 5–6% through the bronchial artery.

In the lungs there is a network of lymphatic vessels lined mainly by phagocytic cells, called macrophages. Dust particles on the walls of the alveoli are phagocytosed by these macrophages. Particles that are not removed by the macrophages enter the lymphatics and are deposited at the roots of the lung; for example, the deposits of coal dust in coal miners are seen as "black lungs".

13.3.2 Radiopharmaceuticals and Imaging Techniques

The characteristics of the radiopharmaceuticals used in lung imaging are listed in Table 13.3.

Perfusion Imaging

Lung perfusion imaging is based on the trapping of large particles in the capillary bed of the lungs. Particles larger than $10 \,\mu\text{m}$ are lodged in the capillaries in the first pass of circulation through the pulmonary artery following intravenous administration.

^{99m}Tc-Labeled Macroaggregated Albumin

Approximately 2–4 mCi (74–148 MBq) 99m Tc-MAA (size 10–90 μ m) is injected intravenously into patients lying in a supine position. Approximately 100,000–400,000 particles of MAA are administered per injection to adults and a lesser

Characteristics	99mTc-MAA	¹³³ Xe	99mTc-aerosol	67Ga-citrate
$t_{1/2}$ (physical)	6 h	5.3 days	6 h	67 h
$t_{1/2}$ (effective)	2–3 h	-	0.67	-
Photon energy (keV)	140	80	140	93, 180, 300
Usual dosage (mCi)	2–4	10-15	30	5-10
Usual dosage (MBq)	74–148	370–555	1110	185-370
Time to start imaging p.i.	Immediately	Immediately	Immediately	48–72 h
Uses	Perfusion	Ventilation	Ventilation	Inflammation,
	study	study	study	infection, cancer

Table 13.3 Radiopharmaceuticals for lungs imaging

number to children. The number of capillaries occluded (compared to a total of 280 billion) is almost negligible, whereas less than 1% of the precapillary arterioles and distribution arteries may be occluded. Larger particles (>150 μ m) may occlude the larger arteries, thus causing regional pulmonary embolism. Almost 95% of the administered activity is trapped in the lungs. The effective half-life of the macroaggregates in the lung is approximately 2–3 h. The particles are broken down into smaller ones by mechanical movement of the lungs and some enzymatic action (proteolysis) and then released into the circulation; these particles are then removed by phagocytes in the reticuloendothelial system.

Since occluded particles can cause a rise in pulmonary arterial pressure, not more than 100,000 particles are recommended in patients with pulmonary hypertension. In patients with right-to-left cardiac shunt, MAA particles may induce cerebral microembolization and, therefore, the number of particles should be reduced in these patients.

Images of the lungs are obtained immediately after injection by means of a large field-of-view gamma camera fitted with a low-energy, all-purpose, parallel hole collimator and placed over the lung field. The position of the patient must be supine for a uniform distribution of particles throughout the lung field; in a sitting position, a greater fraction of particles localize in the lower part of the lungs due to gravity, resulting in an uneven distribution of radioactivity in the lung field. A lung image obtained with ^{99m}Tc-MAA showing normal perfusion is shown in Fig. 13.12, and another demonstrating pulmonary embolism is presented in Fig. 13.13. Detection of lung tumors is discussed under Tumor Imaging, later.

Ventilation Study

In addition to perfusion, the lung has another physiologic parameter, that is, ventilation, to maintain the respiratory function. Radionuclidic ventilation studies of the lung indicate the presence of any obstruction in its airways.

¹³³Xe Gas

The radionuclide ¹³³Xe, available in gas form, is used for ventilation studies. In ¹³³Xe ventilation studies, the patient is asked to inhale ¹³³Xe (10–15 mCi or 370–555 MBq) gas mixed with air in a closed system in a xenon machine and to hold breath for 15–35 s, at which time all parts of the lungs are maximally ventilated and an image is obtained with a gamma camera fitted with a low-energy parallel hole collimator.



Fig. 13.12 Normal lung images obtained with ^{99m}Tc-MAA in different projections. The distribution of radioactivity is uniform in both lungs. *RL* right lateral, *LPO* left posterior oblique, *RPO* right posterior oblique, *LL* left lateral, *ANT* anterior, *POST* posterior



Fig. 13.13 Lung images obtained with ^{99m}Tc-MAA in different projections indicating multiple pulmonary emboli in both lobes of the lungs (see Fig. 13.12 for abbreviations)

The patient is then asked to breathe while equilibrium is reached and images are taken. The patient then inhales fresh air and exhales ¹³³Xe into a collecting bag or the xenon machine containing a charcoal trap. This period is called the "washout" period, during which all radioactivity should clear out of the lungs in about 3–5 min in normal men. Any obstruction in the airways should appear as a hot spot on the images obtained during the washout period. The relatively low-energy photons (80 keV) of ¹³³Xe are not suitable for good resolution images with a scintillation camera, and ^{99m}Tc-DTPA aerosols have replaced it for lung ventilation studies.

99mTc-Labeled Aerosol

^{99m}Tc-labeled aerosols, 0.5–3 μ m in size, are used routinely for lung ventilation studies. Radiolabeled aerosols are produced by nebulizing ^{99m}Tc-DTPA (or other appropriate ^{99m}Tc-products) in commercially available nebulizers. These commercial aerosol units are disposable. Approximately 30 mCi (1.11 GBq) ^{99m}Tc-DTPA in 3 ml is placed in the nebulizer. Air or oxygen is forced through the nebulizer at 30–50 psi to produce aerosol droplets that are then inhaled by the patient through a mouthpiece. Exhaled air from the patient is trapped in the filter attached to the aerosol unit, thus preventing any contamination of the surrounding area. About 10% of the activity is deposited in the lungs of a normal patient, and the remainder remains airborne and is exhaled. This deposition depends on size, shape, density, and electrical charge of the aerosol particles. The larger particles tend to settle in the central area, while the smaller particles deposit in the peripheral areas. The biological *t*_{1/2} of ^{99m}Tc-DTPA aerosol is about 0.75 h in normal subjects and is much shorter in smokers due to increased alveolar permeability.

After 5–10 min of inhalation by the patient, the aerosol unit is disconnected and stored for decay of ^{99m}Tc prior to disposal. The patient is then imaged in different projections with a gamma camera equipped with a low-energy, parallel hole collimator. Images show the distribution of the aerosol in bronchial spaces. Images are comparable to those obtained with ¹³³Xe. Normal and abnormal lung ventilation images obtained with ^{99m}Tc-aerosol are shown in Figs. 13.14 and 13.15, respectively.

99mTc-Technegas

Although ^{99m}Tc-technegas is not approved for clinical use in the USA, it is used clinically in other countries for the ventilation studies. The preparation of ^{99m}Tc-technegas has been described in Chap. 7. The technegas is administered to the patient through closed, single-use circuit breathing tubes until a counting rate of 2000 counts/s is attained. Standard views are obtained in different projections using a gamma camera with a low-energy parallel hole collimator. The ventilation defects are indicative of airway obstruction.

Nonembolic Lung Diseases

67Ga-Citrate

⁶⁷Ga-citrate is used in the evaluation of the presence and extent of many nonembolic lung diseases such as tumors, asbestosis, etc. After intravenous administration, gallium is bound to transferrin in plasma, and hence its plasma clearance is slow.



Fig. 13.14 Normal lung ventilation images obtained with ^{99m}Tc-DTPA aerosol (see Fig. 13.12 for abbreviations)



Fig. 13.15 Lung ventilation images obtained with ^{99m}Tc-DTPA aerosol indicating multiple defects in a patient with chronic obstructive pulmonary disease (see Fig. 13.12 for abbreviations)

It is nonspecific in biodistribution, and at 48-72 h it is seen in the liver (~5%), kidneys (~2%), and bone and bone marrow (~25%). It is secreted by the large intestine, and the appearance of increased bowel activity on the scan often poses a problem in lung image interpretation. For this reason, patients are often given laxatives before scanning for effective cleansing of the bowel.

Several hypotheses have been put forward to explain the mechanism of localization of ⁶⁷Ga (Weiner 1996). A large fraction of ⁶⁷Ga is found to be bound to lysosome like organelles in the cytoplasm. The ⁶⁷Ga uptake in tumor cells is influenced by vascularity, increased permeability of the cells, and a decrease in pH in the cytoplasm due to increased glycolytic activity in the cell. In the latter case, the lower pH dissociates ⁶⁷Ga-citrate, and then gallium ions bind to the intracellular proteins in the tumor cell. A plausible theory explains that gallium binds to lactoferrin released by polymorphonuclear leukocytes in areas of infections, and so ⁶⁷Ga-bound lactoferrin is responsible for gallium localization in inflammatory diseases and abscesses. Yet another theory supports that the ⁶⁷Ga uptake is mediated by transferrin-specific receptors present on the cell membrane. The ⁶⁷Ga uptake is suppressed by chemotherapeutic and radiation treatment.

Approximately 5–10 mCi (185–370 MBq) ⁶⁷Ga-citrate is injected intravenously, and the whole-body scan is obtained 48–72 h after injection using a large field-of-view scintillation camera equipped with a medium-energy parallel hole collimator. There is only a minimal ⁶⁷Ga uptake in normal lungs, female breasts, and thymic areas, whereas increased uptake is seen in areas of infection, inflammation, and carcinoma.

13.3.3 Diagnosis

Perfusion imaging of the lungs is effective in diagnosing pulmonary embolism, tumor, tuberculosis, fibrosis, infection, and other related diseases. Ventilation studies of the lungs indicate airway patency, airway obstruction, emphysema, and bronchitis. A combined study of lung perfusion (Q) and ventilation (V) often provides useful information. In the case of pulmonary embolism, a mismatch V/Q of normal ventilation and poor perfusion is typically observed. In the case of emphysema, asthma, and pulmonary fibrosis, both ventilation and perfusion are poor, giving a matched V/Q scan.

⁶⁷Ga scans are useful in evaluating nonembolic lung disorders such as inflammatory diseases, infections, sarcoidosis, lung cancers, pulmonary fibrosis, asbestosis, silicosis, and tissue damage by drugs such as amiodarone, bleomycin, methotrexate, and vincristine.

13.4 Liver

13.4.1 Anatomy and Physiology

The liver is the largest organ in the body, weighing about 1.5–1.7 kg in normal adults. It is located under the right side of the rib cage and attached to the interior surface of the diaphragm (Fig. 13.16). Its size and shape vary from individual to



Fig. 13.16 Anatomy of the liver in the body

individual. The liver consists of several lobes, each of which is subdivided into lobules. The lobes are delineated from one another by fissures.

The lobules possess sinusoids whose walls consist of two types of cells: hepatocytes or polygonal cells and Kupffer or reticuloendothelial cells (phagocytes); 70% of the total liver mass consists of hepatocytes, and the remaining 30% is made up of phagocytes. Hepatocytes maintain many metabolic processes, whereas phagocytes are responsible for the removal of any foreign particle from the circulation. The liver receives almost 70% of its blood supply from the portal vein and 30% from the hepatic arteries. The hepatic arteries carry oxygenated blood to the liver, whereas the portal vein carries blood rich in products of digestion (e.g., simple sugars and amino acids) from the gastrointestinal tract for further metabolism in the liver.

The major functions of the liver include metabolism, storage, and synthesis of fibrinogen, albumin, heparin, and some globulins; detoxification by conjugation and methylation; formation and excretion of bile into the intestine; and removal of foreign particles by phagocytes. Bile is excreted into the hepatic duct, concentrated in the gallbladder, and finally discharged through the cystic duct into the common bile duct, which delivers it into the duodenum. Bile contains pigments, bile salts, cholesterol, biliverdin, and bilirubin produced from red blood cell destruction in the spleen and the liver. An excess of bilirubin in the plasma and tissue fluids gives a yellow color to the skin, a condition known as jaundice. Excess bilirubin can result from obstruction of the bile duct, damage to the liver, or excessive breakdown of red blood cells.

13.4.2 Radiopharmaceuticals and Imaging Techniques

The radiopharmaceuticals used for liver imaging are divided into two groups based on the physiologic functions of the liver they are designed to evaluate. One group is

Characteristics	99mTc-IDA derivatives	99mTc-sulfur colloid
$t_{1/2}$ (physical)	6 h	6 h
Photon energy (keV)	140	140
Usual dosage (mCi)	5-10	2-15
Usual dosage (MBq)	185–370	74–555
Usual time to start imaging (min) p.i.	5	5-10
Uses	Liver function	Liver morphology
	Gallbladder	

Table 13.4 Radiopharmaceuticals for liver imaging

used to evaluate the functional status of the hepatocytes and the patency of the biliary duct and the other group the phagocytic function of the Kupffer cells. Lipophilic compounds labeled with radionuclides form the first group, and labeled colloids form the second. The characteristics of these radiopharmaceuticals are discussed below and summarized in Table 13.4.

^{99m}Tc-Labeled IDA Derivatives

^{99m}Tc-labeled IDA derivatives (^{99m}Tc-DISIDA, ^{99m}Tc-mebrofenin) are commonly used for hepatobiliary imaging. These tracers are extracted by the hepatocytes, excreted into the bile duct and the gallbladder and ultimately into the intestine. Only a small fraction of the injected dosage is eliminated in the urine. Lengthening the alkyl chain on the benzene ring of the IDA molecule results in increased hepatobiliary extraction and decreased renal excretion. Bilirubin competes with IDA derivatives, which leads to poor-quality images when bilirubin level is high (greater than 20–30 mg/100 ml). Of all IDA derivatives, ^{99m}Tc-DISIDA (Hepatolite) and ^{99m}Tc-mebrofenin (Choletec) are the agents of choice for hepatobiliary imaging.

Following intravenous injection of ^{99m}Tc-DISIDA or ^{99m}Tc-mebrofenin, about 8–17% of the injected activity remains in the circulation 30 min after injection. Approximately 1–9% of the administered activity is excreted in the urine in the first 2 h after injection. In fasting individuals, the maximum liver uptake occurs by 10 min postinjection and the peak gallbladder activity by 30–60 min after injection.

Approximately 3–5 mCi (111–185 MBq) ^{99m}Tc-IDA derivative is injected intravenously into patients who have fasted for 4–6 h prior to administration. Serial images are obtained with a scintillation camera fitted with a low-energy parallel hole collimator every 5 min for 30 min followed by 45- and 60-min images. This procedure is called cholescintigraphy. Each view includes the liver, gallbladder, common bile duct, duodenum, and jejunum. The gallbladder is easily visible by 30 min in normal subjects, because the activity is cleared rapidly from the liver. If any part of the above is not seen in 1–1.5 h, then delayed pictures are taken for up to 4 h.

The mechanism for the clearance of ^{99m}Tc-IDA derivatives involves hepatic extraction, hepatocyte binding and storage, and excretion into biliary canaliculi by an active transport mechanism. There are a number of receptor binding sites on the hepatocytes that are responsible for hepatic uptake. Bilirubin competes for these binding sites more avidly than ^{99m}Tc-IDA derivatives, and therefore at high bilirubin levels, the ^{99m}Tc-IDA derivative uptake is compromised. ^{99m}Tc-IDA derivatives are neither conjugated nor metabolized by the liver.

Cholescintigraphy with ^{99m}Tc-IDA derivatives is useful in differentiating between acute and chronic cholecystitis. In acute cholecystitis, which is mainly caused by cystic duct obstruction, the gallbladder is not visualized for as long as 4 h after administration of the tracer as opposed to the normal visualization of the liver, the common bile duct, and the duodenum. Prolonged fasting, acute pancreatitis, and severe liver disease also can lead to nonvisualization of the gallbladder. In chronic cholecystitis, the gallbladder may not be seen in the first hour, but is visualized on delayed images at 4 h.

Cholecystokinin (CCK) is a polypeptide hormone, endogenously released by the duodenal mucosa that causes the gallbladder to contract and the sphincter of Oddi to relax, and increases gastrointestinal motility and the secretion of bile. Synthetic CCK is available commercially under the name sincalide (Kinevac) and is administered in conjunction with ^{99m}Tc-IDA imaging to delineate different states of the gallbladder and biliary tract diseases. In acute cholecystitis, the gallbladder does not clear upon stimulation with CCK because CCK does not have any effect on cystic duct obstruction, whereas in chronic cholecystitis the gallbladder does clear with CCK stimulation. Some investigators administer CCK prior to imaging particularly to patients fasting more than 24–48 h, in which case the gallbladder is visualized ruling out acute cholecystitis. At times, investigators have substituted fatty meal for CCK.

Post-CCK cholescintigraphy is useful in determining the gallbladder ejection fraction to differentiate subjects with a partially obstructed, chronically inflamed, or functionally impaired gallbladder from those with normal gallbladder. Following the ^{99m}Tc-IDA image, CCK is injected at the time when the gallbladder is maximally filled, and images are obtained at 5, 10, 15, and 20 min post-CCK. Using appropriate regions of interest on both pre-CCK and post-CCK images and with the proper choice of background at different time intervals, the gallbladder ejection fraction is calculated as the difference between background corrected pre-CCK and post-CCK counts divided by the pre-CCK counts (expressed as percentage). A gallbladder ejection fraction.

Morphine enhances the sphincter of Oddi tone and increases intraluminal common bile duct pressure by 50–60%. Based on this, investigators administer morphine intravenously by slow administration, when the gallbladder is not seen up to 60 min after ^{99m}Tc-IDA derivative administration. The gallbladder is clearly seen on post-morphine images.

A normal cholescintigram and an abnormal cholescintigram without CCK are shown in Figs. 13.17 and 13.18, respectively.

99mTc-Sulfur Colloid

The low radiation dose and other favorable characteristics have made ^{99m}Tc-sulfur colloid the agent of choice for liver imaging. Following IV administration of either radiopharmaceutical, its plasma clearance half-time is approximately 2–5 min. Colloids are removed by phagocytes and the maximum hepatic uptake takes place within 20 min. Approximately 80–85% of the colloidal particles accumulate in the liver, 5–10% in the spleen, and the remainder in the bone marrow. Because it is



permanently trapped by the phagocytes in the liver, the effective half-life of ^{99m}Tc-colloid is almost equal to the physical half-life of ^{99m}Tc.

The size of the colloid particles is important in imaging the reticuloendothelial system. Whereas larger particles (>100 nm) accumulate preferentially in the liver and spleen, smaller particles (<20 nm) tend to accumulate in relatively higher concentrations in the bone marrow.

Images of the liver are obtained 5–10 min following intravenous injection of 2–4 mCi (74–148 MBq) ^{99m}Tc-sulfur colloid into the patient. Anterior, posterior, left lateral, and right lateral images are obtained at 15–20 min postinjection by the use of a scintillation camera fitted with a low-energy all-purpose parallel hole collimator. SPECT/CT also can be employed to collect the images of the liver. Sometimes, liver flow studies are performed to assess the vascularity of focal lesions such as tumors and abscesses. In these studies, a bolus injection of 10–15 mCi (370–555 MBq) ^{99m}Tc-sulfur colloid is given, and rapid sequential images are taken at 2-s to 4-s intervals. Normal liver images obtained with ^{99m}Tc-sulfur colloid are shown in Fig. 13.19.

Phagocytosis of colloids is governed by a number of factors, namely, blood flow to the organ, reticuloendothelial cell integrity, and the size, charge, and number of particles administered. Phagocytes have receptors on their surface, which attract foreign particles such as bacteria and colloidal particles. The phagocyte then



Fig. 13.18 Abnormal hepatobiliary images obtained with ^{99m}Tc-DISIDA in different projections showing common bile duct obstruction. The gallbladder is not visualized on the 30-min images. The activity is not cleared well into the gut even at 2 h after administration, even though the gallbladder can be seen (see Fig. 13.12 for abbreviations) (Courtesy of late Dr. Robert A. Johnson, Albuquerque, NM)





Right lateral





stretches itself around the foreign particle (Tc-colloid) and engulfs it. Bacteria in circulation face the same fate and are killed by phagocytosis. Phagocytes become inactive after the event of phagocytosis. Phagocytes have another receptors, called opsonin receptors, on their surface. It has also been postulated that after administration, the colloid particles are immediately coated with the serum protein, opsonin, and the opsonized colloid particles are recognized by phagocytes for ingestion.

Other Radiopharmaceuticals

The compound ⁶⁷Ga-gallium citrate is used in liver imaging, particularly for the detection of abscesses and tumors. Both tumors and abscesses are seen as hot spots due to increased accumulation of ⁶⁷Ga. Because the ⁶⁷Ga accumulation in these lesions is nonspecific and there is also a considerable uptake in normal liver tissue, the value of ⁶⁷Ga imaging is limited in these cases.

13.4.3 Diagnosis

Various diseases related to liver function, such as jaundice and biliary obstruction, are diagnosed by the use of ^{99m}Tc-labeled IDA derivatives. Chronic and acute cholecystitis can be differentiated with ^{99m}Tc-IDA derivatives.

Diseases involving the morphology of the liver are diagnosed with high accuracy by the use of ^{99m}Tc-sulfur colloid and ^{99m}Tc-albumin colloid. Among these are cirrhosis, abscess, tumor, metastatic lesion, hepatomegaly, hepatitis, and other diffuse and focal lesions. Liver images obtained with ^{99m}Tc-sulfur colloid demonstrating cirrhosis in a patient are shown in Fig. 13.20. Tumors and abscesses in the liver are detected with limited success by imaging with ⁶⁷Ga-gallium citrate.



Fig. 13.20 Liver images showing cirrhosis in a patient. Images were obtained with ^{99m}Tc-sulfur colloid in different projections. Diffuse, patchy, and decreased uptake of the tracer in the liver is indicative of cirrhosis

13.5 Spleen

13.5.1 Anatomy and Physiology

The spleen is the largest lymphoid organ and is located under the left side of the rib cage. In adults, its weight varies from 50 to 400 g. It is not normally palpable and is covered by visceral peritoneum. As a result of certain diseases, such as leukemia, lymphoma, typhoid, and so on, the spleen may become very enlarged – a condition called splenomegaly – in which case it can be palpated below the rib cage. The spleen is very fragile and can be ruptured easily by trauma.

Although it is not essential for life, it performs certain important functions. It contains reticuloendothelial or phagocytic cells that remove foreign particles from the circulation, produces lymphocytes and antibodies, and removes damaged and aged red blood cells. It splits hemoglobin from the red blood cells and stores the iron, while it releases bilirubin into the circulation for removal in the bile by the liver.

13.5.2 Radiopharmaceuticals and Imaging Techniques

99mTc-Sulfur Colloid

Imaging of the spleen is usually performed with colloids less than 1 μ m in size. Approximately 2–3 mCi (74–111 MBq) ^{99m}Tc-sulfur colloid is injected intravenously and imaging is begun about 15–30 min after injection. Images are obtained in the anterior, posterior, and left lateral projections with a scintillation camera. SPECT/CT also can be utilized for imaging the spleen.

99mTc-Labeled Red Blood Cells

A dosage of 2–3 mCi (74–111 MBq) heat-denatured ^{99m}Tc-labeled red blood cells is injected, and imaging can be performed 30–60 min after injection to demonstrate the structure of the spleen and any abnormality therein.

13.5.3 Diagnosis

Splenomegaly due to tumors, cysts, infarcts, abscesses, and ruptures can be diagnosed by ^{99m}Tc-sulfur colloid or ^{99m}Tc-albumin colloid imaging. Images of the spleen with ^{99m}Tc-sulfur colloid demonstrating splenomegaly are shown in Fig. 13.21.



Fig. 13.21 Images of the spleen obtained with ^{99m}Tc-sulfur colloid demonstrating splenomegaly. *Left*, anterior; *right*, posterior

13.6 Kidneys

13.6.1 Anatomy and Physiology

The urinary system consists of the two kidneys, the ureters, the bladder, and the urethra. Urine is formed by the kidneys, stored in the bladder, and finally discharged through the urethra. The kidneys lie against the posterior wall of the abdominal cavity, one on either side of the vertebral column. Morphologically, each kidney has an outer zone called the cortex, an inner zone called the medulla, and a pelvis (Fig. 13.22). The basic functional unit of the kidney is the nephron, which consists of a glomerulus and a renal tubule (Fig. 13.23). There are about two million nephrons in both kidneys. The renal tubule has three segments: the proximal tubule, the loop of Henle, and the distal tubule. The distal tubule empties into the collecting duct, which in turn merges into the renal pelvis.

The nephron performs three functions in the formation of urine: filtration of blood plasma by the glomeruli, selective absorption by the tubules of materials required in the body, and secretion of certain materials by the tubules for addition to the urine.

The blood supply is maintained by the renal artery, and in normal adults the kidneys receive nearly 25% of the cardiac output. The total blood volume passes through the kidneys in approximately 3–5 min. Glomeruli filter about 180 l of plasma per day, of which 2 l appear as urine in normal adults. Proteins and organic



Fig. 13.22 Internal structure of the kidney, vertical median section

compounds are not filtered, whereas water and electrolytes are filtered by glomeruli into renal tubules, where almost 95–98% of the filtrate is reabsorbed. Certain materials are not filtered by glomeruli but are secreted by renal tubules. The three segments of the renal tubule carry out uniquely coordinated functions of absorption and secretion of materials from and into the filtrate to balance the electrolyte concentration and the pH in the urine.

13.6.2 Radiopharmaceuticals and Imaging Techniques

The characteristics of various radiopharmaceuticals used in renal imaging are summarized in Table 13.5.



Fig. 13.23 Structure of a nephron

Table 13.5	Radiopharmaceuticals for rena	l imaging
		··· 0 C

Characteristics	99mTc-MAG3	99mTc-DTPA	99mTc-DMSA
$t_{1/2}$ (physical)	6 h	6 h	6 h
$t_{1/2}$ (effective)	-	1 h	-
Photon energy (keV)	140	140	140
Usual dosage (mCi)	5-10	10-15	2-5
Usual dosage (MBq)	185-370	370-555	74–185
Time to start imaging p.i.	Serial imaging	Serial imaging	3–5 h

99mTc-Mercaptoacetylglycylglycylglycine

^{99M}Tc-mercaptoacetylglycylglycylglycine (^{99m}Tc-MAG3) is commonly used for renal function assessments. After intravenous administration, the blood clearance of ^{99m}Tc-MAG3 is rapid and biphasic with a $t_{1/2}$ of 3.18 min for the first component and 16.9 min for the second component (Taylor et al. 1986, 1988). The renal extraction is close to 54%. The protein binding is almost 90%. It is primarily secreted by the tubules to the extent of greater than 90%. The urinary excretion is about 73% in 30 min and about 94.4% in 3 h after injection. At 3 h postinjection, only 2% of the activity remains in the blood pool and 2% in the liver, gallbladder, and gut.

^{99m}Tc-MAG3 is used for both flow and function studies of the kidneys. Approximately 5–10 mCi (185–370 MBq) of the agent is injected intravenously, and dynamic images are obtained initially, followed by delayed static images using a gamma camera with a low-energy parallel hole collimator. Visual interpretation of the images provides diagnosis of unilateral or bilateral obstructive or functional abnormalities of the kidneys.

The renograms are generated by choosing appropriate regions of interest in serial images of each kidney and plotting their activities versus time. A schematic normal renogram is shown in Fig. 13.24. As can be seen in the figure, the renogram has three segments: segment A represents the arrival of the tracer (vascular phase) and lasts for only approximately 30 s; segment B represents the renal accumulation of the tracer before its excretion; and segment C indicates the excretion of the tracer into the urine. The second and third phases of the renogram are important in the diagnosis of obstructive diseases of the kidneys. The period between injection and peak renal activity is called the renal transit time, the normal value of which is about 3–5 min for adults.

If the transit time is prolonged, the second phase of the renogram is less steep. Renal arterial stenosis, dehydration, or any pooling in the renal pelvis lengthens the transit time. The excretory phase depends on the state of dehydration, capacity of the renal pelvis, or any obstructive tubular abnormality. Various obstructive diseases, such as acute tubular necrosis and ureteral obstruction due to stenosis, may result in delayed excretion of the tracer and thus flatten the third segment of the renogram. Figure 13.25 shows serial images and the renogram of a patient with right kidney arterial occlusion and normal left kidney function.





Fig. 13.25 Renogram with ^{99m}Tc-MAG3. Serial images and renogram of a female patient with right renal arterial occlusion and normal left kidney function (Courtesy of Andrew Taylor, Jr., M.D., of Emory University School of Medicine, Atlanta, GA)

If the obstruction is noted in the excretory phase, often the diuretic, furosemide (Lasix), is administered intravenously a few minutes after peak renal activity is reached in order to differentiate between functional and mechanical obstructions. Furosemide as a diuretic alleviates functional obstruction, whereby the renogram showing excretory obstruction becomes normal. On the other hand, if the obstruction is mechanical (e.g., calculus), little change in the renogram occurs after furosemide administration.

Effective Renal Plasma Flow

The effective renal plasma flow (ERPF) or plasma clearance of a radiotracer is the rate of plasma flow through the kidneys, irrespective of whether it is filtered or secreted, and it refers to the volume of plasma that would account for measured quantity of a reagent excreted per minute in the urine. ^{99m}Tc-MAG3 is commonly used for the measurement of ERPF. There are two methods of measuring ERPF: the constant infusion technique and the single injection technique.

In the constant infusion technique, a continuous intravenous infusion of 99m Tc-MAG3 is maintained at a certain flow rate to keep a constant level of plasma radioactivity. An equilibrium is established when the rate of infusion is equal to the rate of excretion of the radiotracer in urine. At equilibrium, the plasma concentration (*P*) in counts per milliliter, urine concentration (*U*) in counts per milliliter, and urine flow rate (*V*) in milliliters per minute are measured. The ERPF is then calculated from

$$\text{ERPF} = \frac{UV}{P} \tag{13.2}$$

The value of ERPF is about 340 ml/min for ^{99m}Tc-MAG3 in normal adults, which is lower than the actual ERPF. In obstructive diseases, the value is smaller due to the decreased urine flow.

In the single injection technique, a bolus injection of ^{99m}Tc-MAG3 is given, and the plasma disappearance of the tracer is followed over a period of several hours. The plasma disappearance curve usually has two components. The ERPF is calculated from the administered dosage *I*, the slopes λ_1 and λ_2 , and intercepts A_1 and A_2 of the two components as follows (Sapirstein et al. 1955):

$$\text{ERPF} = \frac{I\lambda_1\lambda_2}{\lambda_1A_2 + \lambda_2A_1}$$
(13.3)

The reader is referred to other books on nephrology for more details on this subject.

99mTc-DTPA

^{99m}Tc-DTPA is a useful agent for renal imaging. Following intravenous administration, it is entirely filtered by glomeruli in the kidneys. For this reason, it can be used for the measurement of glomerular filtration rate (GFR) using the techniques employed in measuring ERPF. Both the constant infusion and single injection techniques can be employed, and Eqs. (13.2) and (13.3) can be used to calculate the renal clearance or GFR of the kidneys. The normal value of renal clearance is about 125 ml/min for a 70-kg man, but it varies with the weight of the body.

The plasma clearance of 99m Tc-DTPA is rapid and its half-time is about 70 min. Its biological half-life is about 1–2 h. Urinary excretion amounts to about 90% in 24 h, and its plasma protein binding is 5–10% in 1 h (Hauser et al. 1970). The renal uptake is about 7% in 1 h after injection, but it clears rapidly.

Approximately 10–15 mCi (370–555 MBq) ^{99m}Tc-DTPA is injected intravenously in a bolus form, and flow pictures (posterior views) are taken with a scintillation camera using a low-energy parallel hole collimator at 1- to 2-s intervals for up to 1–2 min. The flow study provides information about blood perfusion in the kidneys. Then the dynamic pictures are acquired every 30–120 s for the next 30 min. Renograms are generated from these dynamic data, which provide information about the renal function. A static image, taken 30–60 min later, demonstrates the structure of the kidneys. Serial images obtained with ^{99m}Tc-DTPA are shown in Fig. 13.26.



Fig. 13.26 Posterior images of the kidneys with ^{99m}Tc-DTPA indicating mildly impaired renal uptake in both kidneys, the left kidney being somewhat more impaired than the right kidney

99mTc-DMSA

^{99m}Tc-DMSA is another ^{99m}Tc-labeled complex frequently used as a renal imaging agent. Following intravenous injection, it is excreted in the urine via glomerular filtration and tubular secretion. The plasma clearance half-time is about 10 min. Plasma protein binding of ^{99m}Tc-DMSA is about 75% in 6 h, and its urinary excretion is about 37% in 24 h. It localizes in the renal cortex, and renal retention of ^{99m}Tc-DMSA in both kidneys amounts to nearly 24% of the administered dosage 1 h after injection (Arnold et al. 1975).

The usual dosage for intravenous administration is 2–5 mCi (74–185 MBq) ^{99m}Tc-DMSA for humans, although a lower dosage offers a good image. Images in different projections (posterior, lateral, and oblique) are obtained 3–4 h after injection using a gamma camera with a low-energy parallel hole collimator. A normal image of the kidneys at 1 h after administration of ^{99m}Tc-DMSA is shown in Fig. 13.27.

Captopril Renography

In renal artery stenosis, angiotensin II induces efferent arteriolar vasoconstriction by increasing efferent arteriolar resistance so that the GFR is maintained normal. However, if an angiotensin-converting enzyme (ACE) inhibitor such as captopril is administered, it blocks the formation of angiotensin II and thus removes the postglomerular efferent resistance, so that the GFR of the affected kidney falls, and tubular tracers accumulate in the tubular lumen without normal excretion. Therefore,



Fig. 13.27 Normal image of the kidneys (*posterior view*) obtained with ^{99m}Tc-DMSA at 1 h after administration

a decrease in the uptake of GFR agents such as ^{99m}Tc-DTPA and an accumulation of tubular agents such as ^{99m}Tc-MAG3 are seen after administration of captopril, with prolonged transit time for both GFR and tubular agents.

Based on these principles, captopril renography is performed to show the presence of renal artery stenosis responsible for renovascular hypertension in patients. Captopril renograms are obtained using ^{99m}Tc-DTPA, or ^{99m}Tc-MAG3. The study is performed using either a 1-day protocol or a 2-day protocol with variations in details from institution to institution.

Initially the patient is asked to withhold any antihypertensive drug at least overnight, diuretics for at least 1 day, and any ACE inhibitor for at least 4 days. Some investigators do not suggest hydration, while others hydrate the patient 60 min prior to renography to induce gentle diuresis. In a 1-day protocol, a baseline renogram is obtained using 1–3 mCi (37–111 MBq) ^{99m}Tc-DTPA or ^{99m}Tc-MAG3. The patient is asked to void the bladder and is given orally 25 mg captopril in crushed form suspended in water. One hour later, another renogram is obtained with 5–10 mCi (185–370 MBq) of the corresponding tracer. In a 2-d protocol, the postcaptopril renogram is obtained on a separate day, in which case, higher activities may be used.

In the absence of renovascular hypertension, both pre- and post-captopril renograms are similar, and the renal transit time remains the same. Patients with renal artery stenosis show reduced uptake of ^{99m}Tc-DTPA or increased accumulation of ^{99m}Tc-MAG3 in the post-captopril renograms and prolonged renal transit time in the affected kidney.

13.6.3 Diagnosis

Renography provides information about the functional status of the kidneys. Abnormal renograms are obtained in cases of ureteral obstruction, acute tubular necrosis, and arterial stenosis. In addition, renal scintigraphy also indicates the presence of any structural defect in the kidneys. Tumors, cysts, abscesses, infarcts, and other space-occupying lesions are seen as cold spots on the image, characterized by decreased uptake of the ^{99m}Tc-labeled compound. The viability and rejection of renal transplants are evaluated by the ^{99m}Tc-DTPA flow study and the functional study using ^{99m}Tc-MAG3. Renal artery stenosis causing renovascular hypertension can be diagnosed by captopril renography.

13.7 Skeleton

13.7.1 Anatomy and Physiology

The skeletal system serves as a framework to support the soft tissues of the body. In contrast to popular belief, the bone is a live functional tissue undergoing continuous metabolic changes. The bone serves as a storehouse for calcium and phosphorus, protects soft organs, and works as a lever for muscles.

Bone tissues consist of organic and inorganic constituents, the organic matrix accounting for almost one third of the weight of the bone and the inorganic matrix forming the rest. The inorganic matrix is called hydroxyapatite crystal and is primarily composed of calcium phosphate and, to a small extent, carbonate and hydroxide. Inorganic calcium salts deposit within the frame of the organic matrix and give strong rigidity to the bone. The blood supply is essential for the growth of new bone; a continuous exchange of minerals takes place between the bone and plasma, and the minerals are used in new bone formation. This process of mineral exchange and new bone formation, by which new bone gradually replaces old bone, is called bone accretion. A fracture repairs itself by new bone formation.

Bone metastasis of cancers occurs commonly when tumor cells move into the bone marrow compartment present in the axial skeleton. With continuous growth of the tumor, the surrounding bone tissues undergo osteoblastic transformation indicating the metastatic process. Bone imaging is ideal in accurately demonstrating the metastases of different cancers in bone and also monitoring the response of cancers to therapy.

13.7.2 Radiopharmaceuticals and Imaging Techniques

^{99m}Tc-Phosphonate Compounds

The rationale for using phosphonate compounds for bone scanning lies in the composition of the bone matrix containing calcium phosphate that can be exchanged with phosphonate compounds. Two compounds, ^{99m}Tc-MDP and ^{99m}Tc-HDP, are commercially available for bone imaging, of which ^{99m}Tc-MDP is the most commonly used.

Following IV administration, 99m Tc-MDP is cleared from the plasma with a halftime of 3–4 min. About 10% of the injected dosage remains in the blood at 1 h postinjection and less than 1% at 24 h. Urinary excretion is 50% and the remaining 50% is retained by the skeleton in 24 h.

Approximately 10–20 mCi (370–740 MBq) ^{99m}Tc-MDP or ^{99m}Tc-HDP is injected intravenously, and scanning is performed with the patient supine 2–3 h after injection. The 2- to 3-h waiting period is needed to reduce the background against the bone, and the patient is asked to void before imaging so that the bladder activity does not blur the pelvic region on the image. Whole-body scanning is performed by moving the detector from head to toe of the patient using either a single-head or a dualhead camera equipped with a low-energy, all-purpose parallel hole collimator. Static spot images are obtained with a single-head camera, whereas both anterior and posterior scans are obtained simultaneously using a dual-head whole-body camera.

To distinguish between cellulitis and osteomyelitis in the distal extremities, three-phase bone images (flow, blood pool, and bone uptake) are obtained by giving a bolus injection of 30 mCi $(1.11 \text{ GBq})^{99\text{m}}$ Tc-MDP. In the flow phase, images are obtained every 2 s for 60 s, followed by blood pool imaging immediately and bone uptake imaging at 3–5 h after injection. Due to hyperemia in cellulitis, the tracer localizes in both the flow and blood pool phases, but disappears in the delayed bone uptake phase. On the other hand, in osteomyelitis, wherein some associated hyperemia exists, the tracer uptake is seen in the flow and blood pool phases, with a further increase in localization in the bone uptake phase. In some cases, the background clearance is not optimum because of vascular insufficiency; a fourth phase bone image may be required, which is usually performed the next day to delineate bone uptake better.

Regional bone blood flow rate, bone formation rate, and extraction efficiency are the major factors that influence the bone uptake of phosphonate complexes. In general, the higher the rates of blood flow and bone formation, the greater the bone uptake of radiotracer. There are two hypotheses on the bone uptake mechanism of phosphonate compounds: hydroxyapatite uptake and collagen uptake. In the hydroxyapatite uptake theory, it has been suggested that hydroxyapatite crystal removes the phosphonate component successfully from ^{99m}Tc-phosphonate complexes, thus setting the reduced technetium free to bind independently to hydroxyapatite at another binding site. In the collagen uptake theory, it has been suggested that ^{99m}Tc-phosphonate complexes localize in both inorganic and organic matrices of bone, the latter uptake depending on the amount of immature collagen present. It has also been found that ^{99m}Tc-phosphonate complexes localize in soft tissues and tumors to a variable degree.

¹⁸F-Sodium Fluoride

¹⁸F-sodium fluoride (¹⁸F-NaF) was approved for bone imaging in 1972, but with the introduction of ^{99m}Tc-phosphonate compounds, it was discontinued in the mid-1970s

because of its high-energy photons unsuitable for scintigraphic imaging. With the advent of PET imaging, interest has again grown to use ¹⁸F-NaF for bone imaging. Studies have shown ¹⁸F-NaF to be superior to ^{99m}Tc-MDP imaging in bone imaging, but its use is somewhat limited by the higher cost of its cyclotron production.

Following IV administration of ¹⁸F-NaF, ¹⁸F⁻ rapidly equilibrates in the extracellular space and then is cleared by bone deposition and urinary excretion. It does not appear to bind to plasma proteins, and therefore the plasma clearance is very rapid with two components having half-times of 0.4 and 2.6 h. Its urinary excretion is of the order of 20% in 2 h after injection in normal subjects. The bone uptake of fluoride ions is a function of blood flow to the bone and bone extraction efficiency of the ¹⁸F⁻ ion.

Approximately 4 mCi (148 MBq) ¹⁸F-NaF is administered intravenously, and imaging is performed 15–30 min later, a shorter waiting time than ^{99m}Tc-MDP because of the rapid bone uptake of ¹⁸F⁻ ion. The patient should void before imaging to reduce the background activity in the body. If PET scanning only is performed, then a blank and a patient transmission scans are obtained with a rotating ⁶⁸Ge source for attenuation correction. In PET/CT imaging, these two scans are obtained with CT for attenuation corrected for attenuation, and then images are reconstructed by appropriate algorithm in different projections.

It is postulated that ¹⁸F⁻ retention in the bone is a two-phase process. In the first phase, ¹⁸F⁻ ions exchange with OH⁻ ions in the hydroxyapatite matrix of the bone. In the second phase, ¹⁸F⁻ ions migrate into the crystalline matrix of bone, where it remains there until the bone is remodeled.

¹⁸F-NaF demonstrates higher uptake in malignant tissues than in normal tissues providing better detection of bone metastases. Its diagnostic accuracy is higher than that of ^{99m}Tc-MDP.

13.7.3 Diagnosis

Various diseases that are diagnosed by increased uptake of ^{99m}Tc-phosphonate compounds or ¹¹⁸F-NaF include metastatic lesion, Paget's disease, fracture, osteomyelitis, bone tumor, rheumatoid arthritis, and any other disorder that results in active bone formation. A normal whole-body bone scan obtained with ^{99m}Tc-MDP is shown in Fig. 13.28. A typical whole-body bone scan obtained with ^{99m}Tc-MDP indicating metastatic lesions is presented in Fig. 13.29.

13.8 Heart

13.8.1 Anatomy and Physiology

The cardiovascular system consists of the heart and blood vessels (arteries and veins) and governs the circulation of blood in the body. The heart works as a pump and circulates the blood through blood vessels to the different parts of the body.





The heart is divided into four chambers: the right atrium, left atrium, right ventricle, and left ventricle (Fig. 13.30). Deoxygenated blood from the systemic circulation is received by the right atrium from the superior and inferior venae cavae and then passes into the right ventricle via the tricuspid valve. Blood is then pumped from the right ventricle via the pulmonary artery into the lungs, where it is oxygenated by diffusion of oxygen from the alveoli, and carbon dioxide from the blood is released. Oxygenated blood passes through the pulmonary veins into the left atrium and then to the left ventricle via the mitral valve. The left ventricle pumps the blood into the aorta, which distributes it to the systemic circulation.

The heart goes through a cycle of diastole and systole that maintains appropriate blood pressures in its four chambers as well as in the blood vessels. Diastole is the period of dilatation or expansion of the heart, and systole is the period of contraction of the heart during which blood is forced into the aorta and pulmonary artery. The passage of blood from the right atrium up to the aorta is governed by the above cardiac cycle and by a number of valves present between different atrial and
Fig. 13.29 Typical whole-body bone scan obtained with ^{99m}Tc-MDP 2 h after injection indicating metastatic lesions at various sites in the body



ventricular chambers. The valves are so constructed that only one-way passage of blood is allowed and regurgitation is prevented. The cardiac cycle is a well-coordinated function of the heart, and any deviation from it leads to a variety of cardiac abnormalities.

The cardiac output is the amount of blood pumped by the heart per unit time. It is 4–6 l/min for a man at rest. The cardiac output depends on the amount of blood the ventricles expel during systole, the heart rate, and the degree of venous filling.

The heart muscle receives its blood supply from the coronary arteries, which arise from the first part of the aorta. The coronary arteries penetrate the mass of cardiac muscle and end in capillaries. The latter connect to venules and finally to the coronary veins. About 5% of the cardiac output (200–300 ml/min) passes through the coronary circulation. However, during severe exercise the coronary blood flow may increase to 1-1.5 l/min.

The left coronary artery consists of left anterior descending (LAD) and left circumflex (LCx) arteries, whereas the right coronary artery (RCA) branches into a



Fig. 13.30 Anatomic structure of the heart showing interrelationships of the four chambers

posterior descending artery (PDA) and a posterior left ventricular branch. Coronary artery diseases (CAD) are caused by lack of optimal arterial blood supply to the heart. Atherosclerosis is a complex process of cholesterol deposition, inflammation, and plaque formation resulting in narrowing of the arteries, thus causing CAD. Complete blockage of artery causes myocardial cell death, which is termed as myocardial infarction (necrosis), whereas partial blockage leads to ischemia (reduced blood perfusion) of the tissues. Ischemic heart disease along with hypertension compromises the cardiac output and contractile function and can lead to congestive heart failure (cardiomyopathy). In such cases, the ejection fraction and wall motion of the heart will be reduced. The hibernating myocardium is a dysfunctional myocardium with ischemia, but with preserved cell viability. Myocardial perfusion imaging using SPECT and PET radiopharmaceuticals successfully identifies the infracted versus ischemic myocardium.

The heart requires constant supply of energy to sustain its pumping function, which is derived from the hydrolysis of ATP that results from the aerobic metabolism. The presence of myocardial metabolism indicated the cell viability. Both nonesterified free fatty acid and glucose are the two essential metabolic substrates to provide energy to the heart. In normal myocardium in the fasting estate, free fatty acid is the preferred substrate supplying up to 80% of the required cardiac energy, whereas in the fed state, plasma glucose and insulin level increase, and glucose becomes the predominant substrate for energy source. Based on this concept, ¹⁸F-FDG has been used as a metabolic agent to determine the myocardial viability.

13.8.2 Radiopharmaceuticals and Imaging Techniques

Various radiopharmaceuticals for myocardial imaging are listed in Table 13.6.

Myocardial Perfusion Imaging

Characteristics of different SPECT myocardial perfusion radiopharmaceuticals are given in Table 13.7.

Radionharmaceuticals	Dosage (mCi)	Dosage (MBg)	Imaging technique	Type of study
²⁰¹ TI-TICI	(IIICI) 2_3	(MDQ) 74–111	Planar or SPECT/	Perfusion
	2 3	, , , , , , , , , , , , , , , , , , , ,	CT	i citabion
^{99m} Tc-sestamibi	10-30	370-1110	SPECT/CT	Perfusion
^{99m} Tc-PYP	10-15	370-555	Planar	Infarct
99mTc-tetrofosmin	5-25	185-925	SPECT/CT	Perfusion
¹²³ I-MIBG	5-10	185–370	Planar or SPECT/ CT	Cardiac innervation
⁸² Rb-RbCl	60	2220	PET/CT	Perfusion
¹³ N-NH ₃	15-20	555-740	PET/CT	Perfusion
¹⁸ F-FDG	10-15	370-555	PET/CT	Metabolism

 Table 13.6
 Radiopharmaceuticals for myocardial imaging

 Table 13.7 Comparative characteristics of different SPECT myocardial perfusion radiopharmaceuticals

	²⁰¹ Tl	99mTc-sestamibi	99mTc-tetrofosmin
Lipophilicity (charge)	Hydrophilic	Lipophilic cation	Lipophilic cation (1 ⁺)
	cation (1^+)	(1+)	
Extraction fraction (%)	73	38	37
Capillary permeability-surface	1.30	0.44	~0.44
area product (ml/g/min)			
Blood clearance $(t_{1/2})$	Two components	Two components	Two components
	(a few minutes)	(a few minutes)	(a few minutes)
Myocardial uptake at rest (%)	4	1.0 (1 h) ^a	1.0 (2 h)
Myocardial uptake at stress (%)	-	1.4 (1 h)	1.0 (2 h)
Myocardial washout $(t_{1/2})$	4 h	Minimal	Minimal
Urinary excretion (%)	~4 (24 h) ^a	37 (48 h)	40 (48 h)
Redistribution	Yes	Unlikely	Unlikely
Lung uptake (%) (at rest)	0.9 (24 h)	2.6 (5 min)	1.7 (5 min)
Liver uptake (%) (at rest)	4–7 (24 h)	19.6 (5 min)	7.5 (5 min)

^aTime in parenthesis is the time postinjection

²⁰¹Tl-Thallous Chloride

²⁰¹Tl-thallous chloride is used for myocardial perfusion imaging. After intravenous administration, nearly 85% of the administered dosage is extracted by the myocytes during the first pass of the tracer. Blood clearance is rapid, with only 5% remaining in the blood 5 min after injection. It is mostly excreted by the kidneys and the whole-body biological half-life is about 10 days. Maximum myocardial uptake (~4%) of ²⁰¹Tl occurs about 5–10 min after injection (Atkins et al. 1977). Its myocardial washout has a $t_{1/2}$ of about 4 h. The myocardial uptake of ²⁰¹Tl is linearly proportional to the blood flow, arterial concentration of the tracer, and myocardial mass, but can be reduced at high flow rates.

Although thallium belongs to group IIIA, thallous ion behaves like K⁺, because they are both monovalent and have similar ionic radii. The extraction of thallium ions by myocytes requires that cations traverse the capillary wall, interstitial space, and myocyte membrane. The barrier at the capillary wall is blood-flow dependent, and Tl⁺ is transported through the cell membrane by active transport by the Na⁺-K⁺adenosine triphosphatase (ATPase) enzyme, which is facilitated by depolarization and repolarization of the cell membrane.

Imaging is performed under resting and stress (e.g., exercise) conditions by means of a gamma camera. Normally, the patient is asked to exercise on a treadmill or a bicycle, and 2-3 mCi (74-111 MBq)²⁰¹Tl is injected at the peak of the exercise period. Imaging of the heart is begun 5-10 min after injection and completed in about 30 min. After about 3-4 h of resting, the patient's heart is again imaged under identical conditions. The latter images are called the redistribution images. Images can be obtained either by SPECT alone or the SPECT/CT method. CT images are obtained for coregistration with as well as for attenuation correction of SPECT images. In the SPECT mode, data are collected by a multi-head camera in a 128×128 matrix at small angle intervals (3–6°) over 180° or 360° around the heart. CT data are then used for attenuation correction of SPECT data. Reconstructed images of both SPECT and CT are obtained by using appropriate algorithm in transverse, sagittal, and coronal projections. Coregistration of SPECT and CT images is accomplished manually or by software. However, there is a marked mismatch in the fusion of the two sets of images, because of respiratory and cardiac motion. This is why there is a great deal of limitation in myocardial perfusion SPECT/CT studies.

Gated SPECT can be performed by collecting the data in 15-ms to 75-ms segments during each cardiac cycle (i.e., between two consecutive R-waves). Normally for SPECT, data are acquired in 8–16 frames per cardiac cycle and over many cardiac cycles.

Since ²⁰¹Tl uptake is blood-flow dependent, during the exercise test the normal tissues accumulate more thallium (due to high blood flow) than ischemic tissues (reduced blood flow), thus the latter resulting in a defect on the stress image. In the resting period (redistribution), tissues with high ²⁰¹Tl uptake (normal) have a faster washout than those with low uptake (ischemic but viable), and tissues that have received less thallium relative to the blood concentration will continue to

accumulate ²⁰¹Tl. Furthermore, a large portion of washout thallium comes from tissues other than the cardiac tissues and is presented to myocardium for extraction. Thus, thallium ions undergo continuous exchange between extracellular and intracellular compartments, leading to what is called the redistribution of thallium. At a certain time later, there is an equilibrium between the intracellular and interstitial compartments of activity, and the defect seen in the mildly perfused areas on the stress image will disappear on the 3–4-h redistribution images. However, the initial uptake of thallium in infarcted tissues is so low that at equilibrium, the defect does not disappear on redistribution images. Thus, a defect on both stress and redistribution images indicates an infarct, whereas a defect on stress images that fills in on redistribution images suggests ischemia. Ischemic defects are mostly reversible and viable, and the patient is likely to benefit from revascularization procedures such as bypass surgery or angioplasty. Myocardial SPECT images (both normal and abnormal) obtained with ²⁰¹Tl are shown in Fig. 13.31.

Fig. 13.31 ²⁰¹TI SPECT images (transverse) of the heart during the stress (*S*) and redistribution (*R*) studies separated by 4 h. (a) Normal. (b) Ischemia (*arrow*). (c) Infarct (*arrow*)



In patients who cannot perform treadmill exercise, myocardial stress is induced by intravenous administration of a vasodilator such as dipyridamole (Persantine), lexiscan, or adenosine. The latter causes more side effects (e.g., chest pain, flushing, headache, etc.) than the former, but they are more transient. Some of these side effects can be reduced by intravenous administration of aminophylline.

It has been demonstrated that some persistent defects that are seen on the early redistribution images (3-4 h after injection) are filled in with ²⁰¹Tl on the delayed distribution images at 8–24 h (Kiat et al. 1988). Time to complete redistribution depends on the severity of stenosis and the blood concentration of ²⁰¹Tl. To elevate blood concentration of ²⁰¹Tl, it is suggested that a second injection of 1 mCi (37 MBq)²⁰¹Tl would facilitate the myocardial uptake in ischemic but viable regions that would otherwise be considered as persistent defects (Dilsizian et al. 1990). Three methods are employed: (1) reinjection after the redistribution study and imaging 15-20 min later, (2) reinjection immediately before the redistribution study and imaging 15-20 min later, and (3) reinjection immediately after stress imaging and imaging 3-4 h later. Methods 1 and 2 tend to show increased gut activity, which makes the interpretation of the images somewhat difficult. Method 3 offers the advantage of optimal clearance of the gut activity because of the longer time allowed between the reinjection and redistribution imaging. Using this reinjection technique, almost 40-45% of the 3-4 h redistribution defects were identified to be viable, which otherwise would have been considered as persistent defects, and thus these patients benefited from revascularization by coronary artery bypass graft (CABG) and angioplasty.

The radiation characteristics of ²⁰¹Tl are poor. The low-energy photons (69– 80 keV) of ²⁰¹Tl degrade the spatial resolution of the images due to scattering. The long half-life of 73 h increases the radiation dose to the patient. It is cyclotron produced and quite expensive. As substitutes for ²⁰¹Tl, two ^{99m}Tc-labeled radiopharmaceuticals (^{99m}Tc-sestamibi and ^{99m}Tc-tetrofosmin) are used for SPECT myocardial perfusion imaging. ⁸²Rb-rubidium chloride and ¹³N-ammonia are used for PET myocardial perfusion imaging.

99mTc-Sestamibi (Cardiolite)

^{99m}Tc-sestamibi is a lipophilic cationic (1⁺) complex that accumulates in the myocardium by passive diffusion, not transported by the Na⁺–K⁺–ATPase pump. It indicates the myocardial perfusion abnormalities. After intravenous administration, the blood clearance of ^{99m}Tc-sestamibi is rapid with a $t_{1/2}$ of a few minutes both at stress and rest. The first-pass extraction is almost 50–60%. Myocardial uptake is proportional to regional myocardial blood flow and amounts to about 1.4% of injected dosage during exercise and about 1.0% at rest. Almost 90% of the activity in the cell is bound to proteins in the mitochondria. The myocardial washout of the activity is slow ($t_{1/2} = 7$ h). The urinary excretion is 27% at 24 h and 37% at 48 h. ^{99m}Tc-sestamibi is not metabolized in vivo (Wackers et al. 1989). There is controversy as to whether, like thallium, ^{99m}Tc-sestamibi redistributes or not. Some investigators reported sestamibi to undergo minimal or no redistribution, while others have demonstrated partial redistribution, which is a factor of 3 lower than that of thallium. Myocardial imaging is performed by administering intravenously approximately 20 mCi (740 MBq) ^{99m}Tc-sestamibi at both rest and stress conditions. While stress imaging can be performed as early as 15 min after injection, rest imaging should be done at least 45–60 min after injection to allow sufficient clearance of the tracer from the liver. SPECT or SPECT/CT images are obtained in the same manner as in ²⁰¹Tl imaging. The predominant liver uptake contributes adversely to the images of the heart, and therefore administration of fatty meals or milk has been suggested to hasten the clearance of the hepatic activity. However, routine use of fatty meals has not been indicated.

Several imaging protocols have been advocated (Berman et al. 1994): 1-day protocol; 2-day protocol; stress first, rest second, and vice versa; and finally a dualisotope technique. In all protocols, a gamma camera equipped with a low-energy parallel hole collimator is used for imaging.

In the same-day protocol, 8–10 mCi (296–370 MBq) ^{99m}Tc-sestamibi is injected at rest and 22–30 mCi (814–1110 MBq) administered at stress 3–4 h later. This method is commonly used by many nuclear physicians. Some investigators have suggested a same-day protocol with the stress study done first, followed by the rest study. In this case, it is useful to subtract the residual background of the first injection from the image of the second.

In the 2-day protocol, stress and rest studies are performed on separate days using 20–25 mCi (740–925 MBq) ^{99m}Tc-sestamibi each. Although the detection of hibernating myocardium using this method is suboptimal because of the lack of redistribution of this agent and also because of the short period (1 h) after injection allowed for imaging, overall this protocol is better than the same-day protocol.

In the dual-isotope technique, a rest thallium study is first performed by injecting 3–3.5 mCi (111–130 MBq)²⁰¹Tl followed by imaging the heart 15 min later. Soon after the completion of the rest study, the patient is stressed and 25 mCi (925 MBq)^{99m}Tc-sestamibi is injected at peak stress. Stress imaging is performed 15–20 min after injection. This technique, although well appreciated because of the relatively short time needed for the entire protocol, suffers from the differences in physical imaging characteristics of the two tracers. Because of the poorer resolution, the ²⁰¹Tl images show smaller left ventricular cavity than the ^{99m}Tc images.

Typical examples of rest and stress SPECT images of patients with normal ischemic and infarcted myocardium obtained with ^{99m}Tc-sestamibi are shown in Fig. 13.32.

^{99m}Tc-Tetrofosmin (Myoview)

^{99m}Tc-tetrofosmin is a lipophilic cationic (1⁺) perfusion tracer that accumulates in the myocardium in proportion to blood flow. After intravenous administration, it is rapidly cleared from the blood with only less than 5% remaining by 10 min. The urinary excretion is about 9% in the resting study and about 13% in the stress study 2 h after administration. But by 48 h postinjection, the urinary excretion is approximately 40% in both conditions (Higley et al. 1993). The myocardial uptake is about 1.2% of the injected dosage at 5 min and 1% at 2 h after injection, indicating a slow clearance of the tracer from the myocardium. The cumulative fecal excretion is



Fig. 13.32 Attenuation-corrected SPECT coronal images of heart obtained with ^{99m}Tc-sestamibi after stress and at rest. **a** Normal scans of the heart. **b** Scans of the heart showing ischemia in the LAD diagonal branch area. **c** Scans of the heart showing infarcts in mid-to-distal anterior wall, apex, distal inferior wall, distal lateral wall, and distal septum

nearly 25% after exercise and 34% at rest. The liver uptake is around 1.2% at stress versus 7.5% at rest by 5 min after injection, compared to 0.5% at stress versus 2.1% at rest by 60 min after administration. The early uptake in the gallbladder and the lungs is high but diminishes with time. The fast clearance of the hepatic, lung, and gallbladder activities and the relatively slow clearance of myocardial activity provide good images of the heart. There is minimal, if any, redistribution of the tracer over time.

The myocardial uptake of tetrofosmin has been explained by a membrane potential-driven diffusion mechanism that is independent of cation channel transport but dependent on the metabolic status of the myocytes and by its relatively high lipophilicity.

Both SPECT and SPECT/CT imaging are normally performed using a same-day protocol, in which the rest study is followed by the stress study. Data collection and processing is made in the same manner as in ²⁰¹Tl imaging. At rest, 8–10 mCi

(296–370 MBq) ^{99m}Tc-tetrofosmin is administered, and the heart of the patient is imaged 45–60 min later with a gamma camera using a low-energy, all-purpose parallel hole collimator. A second injection of 15–30 mCi (555–1110 MBq) is given to the patient 4 h later at peak exercise, and imaging of the heart is performed 30–60 min after injection. Similar to ^{99m}Tc-sestamibi imaging, stress imaging with a smaller dosage followed by rest imaging with a larger dosage or a dual-isotope technique using a combination of a rest ²⁰¹Tl study and a stress ^{99m}Tc-tetrofosmin study has been reported. Typical SPECT myocardial images with ^{99m}Tc-tetrofosmin are shown in Fig. 13.33.

82Rb-Rubidium Chloride

⁸²Rb is a positron emitter ($t_{1/2} = 75$ s) and a monovalent cationic analog of potassium, and therefore it is used in PET imaging of the heart. This tracer is available from the ⁸²Sr-⁸²Rb generator discussed in Chap. 5. Because of the short half-life of ⁸²Rb, it is administered to the patient by means of an infusion system (Saha et al. 1990).

After intravenous administration, the first-pass extraction of 82 Rb by the myocardium is about 65–75% at normal blood flow. In vivo it behaves like K⁺ ion.



Fig. 13.33 Attenuation-corrected coronal (*horizontal long axis*) SPECT myocardial images of different patients obtained with ^{99m}Tc-tetrofosmin at rest and after stress. **a** Normal. **b** Apical ischemic defect. **c** Apical infarct

Myocardial uptake occurs by the active transport mechanism via the Na⁺-K⁺-ATPase pump. It is rapidly cleared from the blood, and myocardial activity can be seen in a minute after injection. Brain uptake is low because of the limited diffusion of ⁸²Rb through the blood-brain barrier. For PET studies, initially attenuation correction data are acquired before ⁸²Rb infusion by using a rotating ⁶⁸Ge transmission source or by CT scanners for PET/CT studies, in which a blank CT and a patient transmission CT scans are obtained. For the resting study, 60 mCi (2.22 GBq) ⁸²Rb is administered by the infusion pump to the subject lying supine with the heart in the field of view of the PET camera, and the data are collected by the PET camera. After completion of the resting study (4-6 min), the subject is administered dipyridamole, adenosine, lexiscan, or dobutamine to induce myocardial stress, followed by infusion of an additional 60 mCi (2.22 GBq). Data are then collected by the PET camera for stress images. All data (both resting and stress) are corrected for attenuation of 511 keV photons using the transmission data, which are then used to reconstruct the images in transverse, coronal, and sagittal projections. Fusion of PET and CT images is performed by commercial software, and then CT, PET, and PET/CT images are displayed side by side for interpretation. Patterns of images are similar to those of SPECT studies, with improved contrast resolution, and thus can delineate better between the ischemic and infarcted myocardium. Typical PET images of the heart obtained with ⁸²Rb are shown in Fig. 13.34.

Gould et al. (1991) suggested that the cell membrane must be intact for in and out transport of intracellular contents, and thus cell membrane integrity is a good



Fig. 13.34 Attenuationcorrected transverse ⁸²Rb PET images of the heart during stress (*S*) and equilibrium (*EQ*) studies. (a) Normal. (b) Posterolateral ischemia. (c) Anterior infarct. Myocardial stress was induced with dipyridamole

marker of viability of the cell. ⁸²Rb ion apparently washes out of the necrotic cells faster than out of the viable cells, and thus ⁸²Rb kinetics in myocardium provides a test for the cell membrane integrity and in turn cellular integrity.

¹³N-Ammonia

¹³N ($t_{\nu_2} = 10 \text{ min}$) is a positron emitter and is cyclotron produced. ¹³N-NH₃ is used in myocardial perfusion imaging by the PET technique. Administered intravenously, ammonia circulates as NH₄⁺, which is taken up by the myocytes via initial diffusion across the cell membrane and then through the metabolic fixation by the glutamic acid–glutamine pathway. It is cleared from the blood rapidly with less than 2% of the administered dosage remaining at 5 min after injection. The first-pass extraction is about 100% but decreased at higher flows (Schelbert et al. 1981).

Approximately 15–20 mCi (555–740 MBq) ¹³ N-NH₃ is injected intravenously, and PET/CT images are obtained in the same fashion as in ⁸²Rb PET/CT studies. Ischemia and myocardial infarcts can be detected by this technique. Because of the short half-life, repeat studies can be made in the same sitting of the patient, but the cyclotron must be in close proximity to the PET/CT scanner. The short half-life also puts limits on the logistics of production, delivery, and administration of ¹³N-NH₃ to patients.

Other Perfusion Radiopharmaceuticals

¹⁵O-H₂O has been used to measure the myocardial blood flow in patients. Because it has a short half-life ($t_{1/2} = 2 \text{ min}$) and is produced in the cyclotron, its availability is limited. The study is performed by administering online from the cyclotron with an intermediate conversion of ¹⁵O₂ to ¹⁵O-H₂O in a reaction vessel.

¹⁸F-flurpiridaz is a myocardial perfusion agent that has shown promise in detecting perfusion defects in the heart. The US FDA recently has granted Lantheus Medical Imaging approval for Special Protocol Assessment in Phase III trial of the product, which will expedite its NDA approval.

Myocardial Metabolic Imaging

¹⁸F-Fluorodeoxyglucose

As discussed before, ¹⁸F-FDG is routinely used for myocardial metabolic imaging. After intravenous administration, the blood clearance of FDG is triexponential with three components having half-times of 0.2–0.3 min, 11.6 ± 1.1 min, and 88 ± 4 min (Phelps et al. 1978). FDG crosses the cell membrane into the cell and is phosphory-lated to FDG-6-phosphate mediated by hexokinase inside the myocyte. FDG-6-phosphate is not further metabolized and therefore remains trapped in the myocardium. As mentioned under "Brain Imaging" evidence has been reported that ¹⁸F-FDG undergoes further metabolism and is incorporated into glycogen (Virkamaki et al. 1997) and also FDG metabolites diffuse into the blood pool (Dienel et al. 1993). The myocardial uptake in normal adults is 1–4%. The heart-to-lung, heart-to-blood, and heart-to-liver activity ratios are 20:1, 14:1, and 10:1, respectively.

To increase the glucose metabolism of the heart in the fasting stage so that myocardial ¹⁸F-FDG uptake is enhanced, glucose loading of the patient is recommended. The following American College of Nuclear Cardiology guideline (Dilsizian et al. 2009) is one of several suggested protocols.

If fasting blood glucose level is <250 mg/dl, give the patient 25-100 g of glucose orally and monitor the blood glucose as follows. If at 45-60 min after administration, the glucose level is

130-140 mg/dl, give 1 U regular insulin IV.

140-160 mg/dl, give 2 U regular insulin IV.

160-180 mg/dl, give 3 U regular insulin IV.

180-200 mg/dl, give 5 U regular insulin IV.

>200 mg/dl, notify physician.

If fasting blood glucose level is >250 mg/dl, no glucose loading is necessary.

Following glucose monitoring, 10–15 mCi (370–555 MBq) of the tracer is injected intravenously. For PET scanning alone, the patient is positioned in the field of view of the PET camera, and data are acquired in a 128×128 matrix. For attenuation correction, a blank scan and a patient transmission scan are acquired using a rotating ⁶⁸Ge source. For PET/CT studies, these two scans are obtained by using CT. After attenuation correction, the data are used to reconstruct the CT and PET images in different projections, which are then fused by commercial software. Three sets of images are then displayed simultaneously for interpretation.

FDG uptake is governed by five factors: myocardial blood flow, blood concentration of glucose, myocardial demand of glucose, oxygenation of myocytes, and viability of the cells (Saha et al. 1996). After glucose loading or feeding, the energy substrate shifts from fatty acid to glucose and enhances FDG uptake in the myocardium. Myocardial FDG uptake is variable in normal as well as different disease states. In mildly ischemic and hypoxic myocardium, or hibernating myocardium indicated by a defect in ⁸²Rb-equilibrium studies, glucose becomes the major energy substrate and therefore shows increased uptake in these areas relative to the normal areas. In infarcted areas, blood flow and oxygen supply are extremely restricted, and glycolysis is almost totally stopped. These areas do not show any FDG uptake, relative to the normal and mildly ischemic areas. A typical ¹⁸F-FDG PET image of the ischemic myocardium in a patient obtained after glucose loading is illustrated in Fig. 13.35.

Overall, FDG uptake in poorly perfused areas indicates compromised viability of the myocardium and thus serves as an index for the selection of patients with coronary artery diseases either to treat with medication (infarcted myocardium) or to revascularize by CABG or angioplasty (mildly ischemic but viable myocardium).

Other Metabolic Radiopharmaceuticals

¹²³I-labeled fatty acids (iodo-heptadecanoic and para-iodophenyl pentadecanoic acids) have been used for myocardial metabolic imaging. ¹¹C-palmitic acid, ¹³N-labeled amino acid (glutamic acid), and ¹¹C-acetate have been used for metabolic imaging of the heart by the PET technique. Success was limited with iodinated fatty acids because of beta oxidation and deiodination raising background activity



Fig. 13.35 Transverse, coronal, and sagittal ¹⁸F-FDG PET images displaying hibernating myocardium. The *top row* in three projections indicates posterolateral fixed defects in the heart on ⁸²Rb perfusion images, which show increased ¹⁸F-FDG uptake on FDG images. Glucose was administered 1 h before administration of ¹⁸F-FDG, and PET imaging was performed 40 min after administration

in the blood pool. While ¹¹C-palmitic acid and ¹³N-glutamic acid offer some success, ¹¹C-acetate appears to have a great potential as a metabolic marker. The latter tracer undergoes oxidative metabolism in the heart, is not influenced by the type of substrate present, and can distinguish between viable and necrotic myocardium in coronary artery diseases. ¹¹C-acetate gives a measure of oxygen consumption by the myocardium.

Myocardial Infarct Imaging

99mTc-Pyrophosphate

^{99m}Tc-pyrophosphate has been used for imaging myocardial infarcts. Its plasma clearance half-time is about 4 min, and protein-binding is higher than other phosphonates. Its urinary excretion is about 60% in 24 h. Approximately 10–15 mCi (370–555 MBq) ^{99m}Tc-pyrophosphate is injected intravenously. Imaging is performed 1–2 h after administration by means of a scintillation camera equipped with a low-energy parallel hole collimator. Anterior, left anterior oblique, and left lateral views of the heart are obtained, and myocardial infarcts are seen as areas of increased uptake of the tracer in the infarcted areas. A minimum of 12–24 h after the onset of infarction is needed for infarcts to accumulate an appreciable amount of ^{99m}Tc-pyrophosphate. Maximum uptake is obtained 24–72 h after infarction, and infarct sites remain detectable for 6–10 days. Myocardial infarct imaging with ^{99m}Tc-pyrophosphate is shown in Fig. 13.36.

The mechanism of uptake of ^{99m}Tc-pyrophosphate by the damaged myocardium is not clearly understood. Increased uptake of the tracer has been attributed to the deposition of granules in enlarged mitochondria of the damaged myocardium. The granules are composed of calcium and phosphate groups similar to the hydroxyapatite crystals in bone. Perhaps ^{99m}Tc-pyrophosphate is absorbed on the calcium phosphate groups of the granules and thus accumulates in the mitochondria. It has also been suggested that the tracer binds to various soluble proteins in the damaged myocardium. It has been found that myocardial uptake of the phosphate is inversely proportional to regional blood flow except at very low values, in which case it decreases with the decrease in blood flow.

Cardiac Innervation Imaging

¹²³I-MIBG

MIBG behaves like norepinephrine (NE) as far as the uptake and storage mechanism is concerned. Norepinephrine is synthesized in neuronal cells, stored in large and small vesicles in the heart, and released by the action of acetylcholine. As a neurotransmitter, norepinephrine mediates the function of adrenergic neurons. A rise in adrenergic neuron activity is then associated with increased NE secretion by the sympathetic terminals of the nerves and with accentuated loss of NE from the innervated tissue. In patients with congestive heart failure, the sympathetic nerve terminals in the myocardium are destroyed and the NE stores are depleted. In ischemic heart disease, and particularly in infarcts, a similar situation occurs showing decreased concentration of NE. Depletion of NE stores is also observed in heart transplants, idiopathic dilated cardiomyopathy, and hypertrophic cardiomyopathy.



Fig. 13.36 Myocardial infarct image obtained with ^{99m}Tc-pyrophosphate in different projections 2 h after injection, indicating increased uptake in the infarcted area at the anterior apical left ventricular wall. Imaging performed 24 h after onset of infarction. *LAO* left anterior oblique, *LL* left lateral

Because of similar properties, ¹²³I-MIBG has been used to image patients with diseases related to impairment in NE concentration (Sisson et al. 1987). After intravenous administration, the urinary excretion is almost 60% in 24 h and 70–90% in 48 h. The liver uptake is the highest, whereas lower uptake is seen in the lungs, spleen, salivary glands, thyroid, and skeletal muscles. Normal adrenal glands are rarely seen with faint uptake at 48–72 h postinjection in only 15% of the patients. Since free iodide can accumulate in the thyroid, the patient is given Lugol's solution orally 1 day before and for 4 days after the administration of ¹²³I-MIBG to block the thyroid uptake of iodide.

Approximately 5–10 mCi (185–370 MBq)¹²³I-MIBG is injected intravenously. SPECT images are obtained at 3, 24, and 48 h after injection using a scintillation camera with a low-energy parallel hole collimator. In patients with heart failure, transplants, cardiomyopathy, and infarcts, ¹²³I-MIBG uptake in the heart is poor relative to the normal patients. The uptake is inhibited by drugs such as imipramine and phenylpropanolamine.

Radionuclide Angiography

The application of radionuclide angiography to the determination of ejection fraction and wall motion abnormalities of the heart is well established. Two important techniques employed in these studies are (1) the first-pass method and (2) the gated equilibrium cardiac blood pool method. These methods are based on measurement of radioactivity in the left or right ventricular chamber at the end of diastole (ED) and at the end of systole (ES). The ejection fraction (EF) is calculated as

$$\mathrm{EF}(\%) = \frac{A_{\mathrm{ED}} - A_{\mathrm{ES}}}{A_{\mathrm{ED}}} \times 100 \tag{13.4}$$

where A_{ED} and A_{ES} are the maximum end-diastolic and minimum end-systolic activities, respectively.

First-Pass Method

In the first-pass technique, the transit of an injected tracer is tracked through the heart chambers that allows detection of abnormalities in transit in diseases such as congenital heart disease, shunts, and valvular insufficiency. In this technique, ^{99m}Tc-pertechnetate, ^{99m}Tc-DTPA, or any ^{99m}Tc-labeled compound can be used as the radiotracer.

The detector of the scintillation camera equipped with a high-sensitivity, parallel hole collimator is placed over the heart in the anterior position before the injection is made. Detectors capable of counting high count rates (>200,000 counts/s) are necessary for adequate image quality. Approximately 20–30 mCi (740–1110 MBq) of the radiopharmaceutical in a small volume is injected intravenously in a bolus form. After injection, the precordial activity is measured and stored in a computer during the first 40–60 s of the first pass of the tracer through the heart. A composite picture of the right or left ventricle is constructed from the stored data, and two regions of interest (ROI) are selected – one corresponding to the ventricle and the other to the background. The time–activity curves are then generated for both

regions by the computer, and the background activity is subtracted from the ventricular activity point by point on the corresponding curves. Thus, a corrected (subtracted) curve, representing the net counts within the ventricular activity, is generated. The maximum counts at end-diastole and the minimum counts at endsystole are read from the curve to calculate the ejection fraction of the ventricle by Eq. (13.4). Although the ejection fraction of both ventricles can be obtained by this technique, it is more commonly used for the right ventricles.

Gated Equilibrium Cardiac Blood Pool Method

The gated equilibrium cardiac blood pool method is also termed the multigated acquisition (MUGA) method or radionuclide ventriculography (RNV). The aim of this technique is to obtain images of the cardiac chambers and great vessels with high resolution to help evaluate the ventricular function. This technique is commonly used for the left ventricle, and the most common radiopharmaceutical is the in vivo labeled ^{99m}Tc-RBC. In in vivo labeling, the contents of a stannous pyrophosphate kit vial (containing about 1–1.5 mg of stannous ion for a 70-kg subject) are injected intravenously after reconstitution with isotonic saline, and then 20–30 mCi (740–1110 MBq) ^{99m}TcO₄⁻ is injected 30 min later. Stannous ions reduce Tc and the reduced Tc binds to hemoglobin in the red blood cells. If necessary, in vitro labeled RBCs also can be used in this method.

In the gated equilibrium study, 5-10 min is allowed after administration of 99m TcO₄⁻ for equilibrium to be achieved. Images are obtained with a scintillation camera equipped with a low-energy parallel hole collimator in the left anterior oblique position. Data are accumulated in synchronization with the R-wave of the QRS complex in the electrocardiogram and stored in a computer in 15-75-ms segments during each cardiac cycle (i.e., between two consecutive R-waves). Normally 8-16 frames per cardiac cycle are acquired. Data acquisition is continued for many cardiac cycles until counts of statistical accuracy (~100,000-300,000 counts) are accumulated in each frame. Normally, data acquisition requires about 10-15 min. Regions of interest corresponding to the left ventricle and the background are selected by the computer. Time-activity curves are then generated for both the ventricle and the background. Background activity is subtracted from ventricle activity point by point from the two curves. Thus, a time-activity curve representing the net activity in the left ventricle is obtained over a cardiac cycle. The maximum activity at end-diastole and the minimum activity at end-systole from the corrected curve are then used to calculate the ejection fraction of the left ventricle by Eq. (13.4). The scintigraphic display of a gated study is presented in Fig. 13.37.

Another application of this technique is the detection of any wall motion abnormalities by observing the difference between the end-diastole and end-systole images of the left ventricle. The images are constructed by the computer as usual, and the two images are concentric in a normal heart. An abnormal wall motion, which may result from ischemia, infarction, and other hypokinetic cardiac conditions, is manifested by eccentric differences in the end-diastole and end-systole images.



Fig. 13.37 Gated equilibrium blood pool study of the heart. **a** Left anterior oblique image of the heart at end-diastole. **b** Left anterior oblique image of the heart at end-systole. **c** Composite time–activity curve generated from counts collected over several hundred cardiac cycles from the background subtracted left ventricular region of interest

These studies can also be made by "cineangiography" a movie-type presentation of the cardiac cycle, which can be applied to both right and left ventricles.

Radionuclide Stress Ventriculography

The value of radionuclide ventriculography can be enhanced by inducing stress in patients leading to what is called stress ventriculography. Initially, a first-pass study is performed at rest using 15 mCi (555 MBq) ^{99m}Tc-DTPA. The patient is asked to exercise using a bicycle equipped with an ergometer, and a second first-pass study is obtained using 25 mCi (925 MBq) ^{99m}Tc-DTPA. The difference in wall motion

between the two studies would indicate an abnormality in the heart. The absence of activity in the abnormal hypofunctioning areas in the resting myocardium is enhanced by radionuclide stress ventriculography. In exercise, the ejection fraction increases in normal subjects. If it does not increase in a patient, it indicates abnormal ventricular function such as cardiomyopathy and heart failure.

13.8.3 Diagnosis

Perfusion imaging of the heart using ²⁰¹Tl, ^{99m}Tc-sestamibi, ^{99m}Tc-tetrofosmin, ⁸²Rb, etc. can delineate the viable ischemic areas from the nonviable infarcted areas in myocardium. ¹⁸F-FDG PET imaging is highly accurate in predicting the viability of myocardium. Myocardial infarcts (acute) are detected by ^{99m}Tc-pyrophosphate. Radionuclide angiography during rest or stress provides the ejection fraction of the right or left ventricle, which is 50–80% at rest and 55–86% at stress in normal adults. In the cases of akinesis, hypokinesis, and dyskinesis of the ventricle due to infarction or ischemia, the ejection fractions are lower than the above limits, whereas they are higher in the case of hyperkinesis.

13.9 Miscellaneous Imaging Procedures

13.9.1 Tumor Imaging

Tumors appear in different parts of the body as a result of the proliferation of abnormal cells. How this abnormal proliferation occurs is not clearly known, although several investigators propose that the high rate of DNA synthesis in the tumor cell is responsible for cell proliferation of some tumors. Various carcinogens (cancercausing agents) may initiate the increased rate of DNA synthesis. Tumors, either benign or malignant, have some characteristics that are taken advantage of in radionuclide imaging. For example, tumors have increased metabolic activity and blood flow, high vascular permeability, pinocytosis of proteins, and tumor-associated antigen. With a proper choice of radiopharmaceuticals suitable for evaluating any of these characteristics, tumor imaging can be accomplished. In this approach, tumors are seen as hot spots on the image due to increased localization of the tracer. In other cases, tumors are seen as cold spots or areas of decreased activity on the image as in necrotic tumors.

Numerous tumor imaging radiopharmaceuticals have been developed and used for clinical trials. Many of them are nonspecific; one agent may be somewhat good for one type of tumor, but of no use for other types. Several radiopharmaceuticals used for specific tumor imaging are summarized in Table 13.8.

67Ga-Citrate

Various tumors, benign or malignant, are detected by scintigraphy using ⁶⁷Ga-citrate. The biodistribution and mechanism of uptake of this tracer have been described in the section "Lung Imaging".

	Dosage	Dosage	
Radiopharmaceutical	(mCi)	(MBq)	Type of tumor
¹³¹ I-sodium iodide	0.1	3.7	Thyroid
⁶⁷ Ga-gallium citrate	10	370	Lymphoma, Hodgkin's disease, various neoplastic diseases
¹¹¹ In-capromab pendetide	5	185	Prostate cancer
¹¹¹ In-pentetreotide	3–6	111–222	Neuroendocrine tumors (carcinoid, gastroma, etc.)
⁶⁸ Ga-DOTATATE or ⁶⁸ Ga-DOTATOC	5.4	200	Neuroendocrine tumors with somatostatin receptors
¹¹¹ In-ibritumomab tiuxetan	5	185	Non-Hodgkin's lymphoma
^{99m} Tc-sestamibi	25–30	925– 1110	Breast cancer
²⁰¹ Tl-thallous chloride	5	185	Brain tumor, thyroid cancer
¹²³ I-MIBG	10	370	Pheochromocytomas, neuroblastomas, carcinoid tumors, paragangliomas
¹⁸ F-FDG	10–15	370–555	Brain tumor, breast cancer, lung tumor, head and neck cancer, esophageal cancer, melanoma, colorectal cancer, lymphoma, thyroid follicular cancer
¹⁸ F-fluciclovine	10	370	Recurrent prostate cancer
99mTc5+-DMSA	10	370	Medullary thyroid carcinoma

Table 13.8 Radiopharmaceuticals for tumor imaging

Approximately 10 mCi (370 MBq) ⁶⁷Ga-citrate is administered intravenously, and planar imaging is performed with a gamma camera using a medium- to highenergy collimator. Three separate windows for 93, 184, and 300 keV photons are preferred to one single broad-energy window for imaging, because the latter admits excessive scatter radiations and degrades image quality. Images are obtained 48–72 h after administration. Although many investigators use planar imaging, SPECT imaging has been used in delineating small and deep-seated tumors.

⁶⁷Ga is secreted by the large intestine, and the appearance of increased activity in the bowel often causes difficulty in identifying the abdominal tumors. For this reason, patients are given laxatives before scanning for effective cleansing of the bowel.

A variety of tumors are detected by ⁶⁷Ga imaging, among which lymphoma, lung tumor, melanoma, hepatoma, and head and neck tumors are the most common. Tumor masses greater than 1 cm are usually well seen by ⁶⁷Ga scintigraphy. While the sensitivity and specificity of detecting lymphoma, melanoma, and hepatoma are good, those of lung tumors are poor except for mediastinal metastatic diseases. A ⁶⁷Ga scan showing increased uptake in the lower lobe of the right lung due to squamous cell carcinoma is shown in Fig. 13.38.

^{99m}Tc-Sestamibi (Miraluma)

^{99m}Tc-sestamibi accumulates nonspecifically in various tumors, among which breast tumors, lung cancer, bone tumors, medullary thyroid cancer (MTC), and brain tumors have been documented. Approximately 15–20 mCi (555–740 MBq) ^{99m}Tcsestamibi is administered intravenously, and imaging is performed of the respective organ at different time intervals (5–60 min postinjection for breast and 20–30 min



Fig. 13.38 Abnormal whole-body ⁶⁷Ga scan 48 h after injection showing focal increased uptake in the *right lower lobe* of the lung due to squamous cell carcinoma

for MTC and brain tumors). Planar breast images are obtained in prone positions for better spatial resolution of the defects. Special cutout tables with a lead bridge separating the two breasts are available for imaging the breast in the prone position. The sensitivity and specificity of this test are 84–94% and 72–94%, respectively, for the detection of breast tumors.

SPECT imaging of brain tumors with ^{99m}Tc-sestamibi shows increased uptake in the tumor relative to the normal tissue. Some uptake in choroid plexus is also seen. Both primary and metastatic lung cancers are detected by this agent, particularly when SPECT imaging is performed. The sensitivity of detecting MTC using ^{99m}Tc-sestamibi is low at about 50%.

123I- or 131I-MIBG

Various neuroendocrine tumors and their metastases are localized and staged by MIBG scintigraphy. Common tumors in this category, among others, are pheochromocytomas, neuroblastomas, ganglioneuroblastomas, carcinoids, and medullary thyroid carcinomas. Norepinephrine is a hormone and a neurotransmitter synthesized by neuroendocrine cells such as normal adrenergic neurons and adrenal medullar cells. These cells are distributed to various sites in the body and, under circumstances, can grow into abnormal tumor cells showing increased production of norepinephrine. Since MIBG is an analog of guanethidine and structurally resembles norepinephrine, it enters the neuroendocrine cells by an active transport mechanism showing an increased uptake, thus lending itself for scintigraphic imaging. Although ¹³¹I-MIBG is cheaper, its clinical use is limited by higher radiation dose to the patient. However, ¹²³I-MIBG is more expensive because of the higher cost of production in the cyclotron.

Approximately 10 mCi (370 MBq) ¹²³I-MIBG or 0.5 mCi (18.5 MBq) ¹³¹I-MIBG is slowly injected intravenously. For pediatric patients, the dosage is adjusted according to the weight. To block the possible thyroid uptake of free iodide, Lugol's solution is given orally 1 day before and for 4 days after the administration of MIBG. Many drugs such as opioids, tramadol, tricyclic antidepressants, and antipsychotics inhibit the MIBG uptake and should be stopped 1–2 weeks prior to MIBG studies. Planar or SPECT imaging is performed at 24 and 48 h and, if needed, 72 h after injection in case of ¹³¹I-MIBG, whereas 24-h imaging is most common for ¹²³I-MIBG. While whole-body images are obtained commonly, spot views are also taken if needed. These studies show increased uptake of the tracer in neuroendocrine tumors.

²⁰¹TI-Thallous Chloride

²⁰¹Tl-thallous chloride has been used to detect brain tumors, bone tumors, MTC, and various other tumors. Approximately 2–5 mCi (74–185 MBq) ²⁰¹Tl-thallous chloride is injected intravenously, and imaging is performed 20–30 min later using a gamma camera with a low-energy parallel hole collimator.

²⁰¹Tl scintigraphy is accurate in delineating the different stages of the brain tumor, particularly when SPECT imaging is performed. Also, this technique successfully differentiates between viable tumors versus radiation necrosis, because thallium localizes avidly in viable tumors, but does not accumulate in radiation necrosis.

Bone tumors, breast cancer, and MTC are detected with variable degrees of success by this technique.

¹⁸F-FDG

The utility of ¹⁸F-FDG in the detection of various tumors is well documented. FDG uptake in tumors is based on enhanced glucose metabolism in malignant tumors compared to normal tissues. Types of tumors and their metastases that have been detected by FDG PET include lung, head and neck, breast, bladder, thyroid, colon, liver, lymphoma, musculoskeletal, brain, and many other tumors.

The physiological handling of ¹⁸F-FDG after intravenous administration has been described (see Central Nervous System above). For imaging, approximately 10–15 mCi (370–555 MBq) ¹⁸F-FDG is administered intravenously, and PET images are obtained 40–60 min later. Attenuation corrections are applied by using a rotating ⁶⁸Ge source or by CT scan.

Since the brain derives its energy solely from glucose metabolism, normal tissues exhibit FDG uptake, with gray matter accumulating more than white matter. In the case of brain tumors, the malignant areas take up more FDG than normal tissues because of the increased glycolysis in tumors. The FDG PET can differentiate between low-grade and high-grade tumors due to the difference in degree of glucose metabolism related to malignancy. The high-grade tumors show higher FDG uptake than the low-grade tumors. An FDG PET image of a patient with epilepsy caused by the hypometabolic tumor (white arrow) with a possible high-grade tumor (red arrow) is shown in Fig. 13.39.

FDG PET is accurate in the differentiation of recurrent tumors from necrosis after radiotherapy or chemotherapy, since radiation necrosis is detected as



Fig. 13.39 ¹⁸F-FDG PET images of a patient with refractory epilepsy in coronal and transverse projections showing a large area of hypometabolism (white arrow) in the temporal, frontal, parietal operculum, and adjacent insula regions of the left hemisphere, indicative of a low-grade tumor. A hypermetabolic focus (red arrow) in the left posterior, superior temporal region most likely indicates the malignant component of the tumor

TRANSVERSE

hypometabolic areas as opposed to increased uptake of the tracer in tumors. The effects of various therapies of brain tumors can be monitored by FDG PET so that the progress and prognosis of treatment can be evaluated.

¹⁸F-FDG Whole-Body Imaging

¹⁸F-FDG PET or PET/CT is very useful in the detection of a variety of tumors with high sensitivity and specificity. Because of the high accuracy of detection of tumors by this modality, the US Centers of Medicare and Medicaid (CMS) has approved reimbursement for the detection of many cancers such as lung, head and neck, breast, brain, melanoma, thyroid, lymphoma, colorectal, esophageal, and cervical cancers.

On the day of examination, the patient is asked to fast for 6 h. If the patient is diabetic and the blood sugar is higher than 200 mg/dl, the physician has to advise if the study should be continued. For insulin-dependent diabetic patients, the blood sugar is usually titrated by insulin. An IV catheter is inserted for administration of ¹⁸F-FDG and saline. For adult patients, 5–15 mCi (185–555 MBq) ¹⁸F-FDG is administered intravenously via the catheter followed by flushing with normal saline. The actual dosage is adjusted according to the body weight of the patient. The patient is asked to remain relaxed and quiet for the waiting period of 45–60 min. No metallic object stays on the patient body to avoid image artifacts. A sectional or whole-body imaging is employed depending on the regions of interest to be scanned. The patient lies supine on the bed during scanning. For head and neck imaging, the arms are held down to avoid interference in scanning, whereas for thorax, abdomen, and lower extremities, the arms are held up above the trunk.

For PET scanning alone, a blank and a patient transmission scans are obtained for attenuation correction by using a rotating 68 Ge source, whereas for PET/CT studies, these scans are acquired using CT. Then the patient is positioned in the field of view of the PET scanner, and whole-body or sectional scans are obtained by moving the bed incrementally at equally spaced positions. All data are collected and stored in a 128×128 matrix and later corrected for attenuation using 68 Ge or CT transmission data. The corrected data are used to reconstruct the transverse, coronal, and sagittal images using appropriate algorithm. The PET and CT images are then fused, and three sets of images are displayed side by side for interpretation. Typical whole-body images of CT, PET, and PET/CT are shown in Fig. 13.40. Besides detection of various types of tumors, 18 F-FDG PET/CT is also useful in monitoring the progress of treatment of these tumors.

Tumor uptake is often expressed by a widely used semiquantitative parameter, *standard uptake value* (SUV). It is defined by the tissue concentration of activity as determined in the region of interest (ROI) (tumor) on the PET image, divided by the injected dosage of the tracer, and multiplied by a calibration factor, which is basically the body weight, body surface, or body lean mass. Thus,

$$SUV = (C_{ROI} / A) \times WT$$
(13.5)

where C_{ROI} is the decay-corrected radiotracer concentration in μ Ci/g (MBq/g) of the tissue in ROI, A is the injected radiotracer dosage in μ Ci (MBq), and WT is the



Fig. 13.40 Whole-body ¹⁸F-FDG and CT images of a patient with esophageal cancer. Fusion of attenuation-corrected PET and CT images in different projections (transverse, coronal, and sagit-tal) delineates the tumor remarkably

weight in gram of the patient. The average counts or maximum counts in the ROI of the PET image are determined from the pixel size and the number of pixels in ROI, which is then corrected for decay over the uptake period. The corrected activity (μ Ci or MBq) is divided by the weight of the ROI tissue (assuming tissue density 1 g/ cm³) to obtain activity concentration (μ Ci/g or MBq/g) in ROI. The SUV is then calculated by dividing the ROI concentration activity by the administered activity (μ Ci or MBq) and multiplying it by the body weight (g) of the patient. The SUV is a unitless number and depends on several factors, namely, blood sugar particularly in diabetic patients, the uptake period, the composition of tumor tissue, excess body fat, and choice between average activity versus maximum activity (although the former is rarely used). The value of SUV for normal tissues is typically <1 for soft tissues, 1.5–2.0 for blood pool 1 h postinjection, ~2.5 for the liver, and ~3.5 for the renal cortex. The tumor SUV values can range from 2 to as high as 25 depending on the tumorigenicity of the tissue.

¹¹¹In-Pentetreotide (OctreoScan)

Pentetreotide is a DTPA conjugate of octreotide, a long-acting synthetic analog of natural somatostatin that is present in many tissues of the body. ¹¹¹In-pentetreotide binds to the somatostatin receptors in these tissues, thus showing an increased uptake.

The plasma clearance of ¹¹¹In-pentetreotide is initially rapid with 33% ID remaining at 10 min postinjection and then slowly declining to 1% at 24 h postinjection. The biological half-life of ¹¹¹In-pentetreotide is 6 h, and it is not metabolized in vivo for several hours after administration. It is mostly cleared by the kidneys with 50% excretion in 6 h and 85% in 24 h postinjection. The patient is hydrated and 6 mCi (222 MBq) ¹¹¹In-pentetreotide is injected intravenously into the patient for SPECT imaging. It should not be administered through the total parenteral nutrition (TPN) line, because a complex glycosyl octreotide conjugate may form. Imaging is performed using a gamma camera with a medium-energy parallel hole collimator at 4 and 24 h after injection.

¹¹¹In-pentetreotide localizes in various primary and metastatic neuroendocrine tumors (NETs) bearing somatostatin receptors. Gastrinomas and carcinoids are successfully diagnosed by this agent, whereas insulinomas, neuroblastomas, pituitary adenomas, and MTC are detected with limited success. Other tumors that have been successfully detected by this technique include breast cancer, lymphomas, granulomas, and sarcoidosis.

68Ga-DOTATATE (Netspot) and 68Ga-DOTATOC

Over the years, investigators have found that SPECT imaging of NETs with ¹¹¹In-octreotide is not as successful in detecting deep-seated tumors and also displays relatively intense uptake of the tracer in the spleen, liver, and kidneys obscuring the images. Also it takes 2-3 days to obtain a noise-free scan. In contrast, PET scanning with ⁶⁸Ga-DOTATATE takes only a few hours to have a good scan with increased uptake in NETs relative to ¹¹¹In-octreotide and has become the imaging method of choice for NETs. Following IV administration, ⁶⁸Ga-DOTATATE distributes to all somatostatin receptor-containing organs such as the thyroid, adrenals, pituitary, spleen, kidneys, pancreas, liver, prostate, and salivary glands to varying degrees. Lung and thymus uptake is low with no brain uptake. The blood activity appears to clear rapidly with no activity at 200 min postinjection. The liver activity reaches 8-10% ID shortly after injection disappearing to ~2% at 200 min postinjection. The initial uptake in the kidneys and spleen amounts to 2-5% ID that decreases to less than 1% at 200 min. The 4-h urinary excretion is 12% (Sandström et al. Biodistribution of ⁶⁸Ga-DOTATOC in humans is slightly different from 2013). that of ⁶⁸Ga-DOTATATE. The blood activity shows a bi-exponential decay with $t_{1/2}$ of 2 min and 48 min (Hofmann et al. 2001). Between 10 and 15 min postinjection, the uptakes in the liver and kidneys are similar and peaked, but the activity clears rapidly with time. With rapid renal clearance, the activity in all organs reaches a plateau at 40 min postinjection. No radioactive metabolites are seen in the serum within 4 h postinjection.

For PET/CT or PET/MR imaging, initially a CT or MR scan is obtained for attenuation correction and coregistration with subsequent PET image. For PET imaging, the recommended dosage of ⁶⁸Ga-DOTATATE or ⁶⁸Ga-DOTATOC for IV administration is 0.054 mCi/kg (2 MBq/kg) of body weight, up to 5.4 mCi (200 MBq). The whole-body PET image is obtained at 40 to 90 min postinjection for a period depending on the PET camera. The PET image is corrected for photon attenuation, and then the reconstructed image is obtained by applying the filtered back projection or the iterative method. The images are then displayed for interpretation in different projections. Figure 13.41a is a PET/CT fused image obtained with ⁶⁸Ga-DOTATOC illustrating NET metastasis in the liver indicated by arrow. Figure 13.41b illustrates a PET/CT fused image of pheochromocytoma obtained



Fig. 13.41 a PET/CT fused image obtained with ⁶⁸Ga-DOTATOC illustrating NET metastasis in the liver indicated by *arrow* (Reproduced from open access article by Velikyan I. *Molecules*. 2015; 20: 12,913); **b** ⁶⁸Ga-DOTATATE PET/CT fused image of a patient with right pheochromocytoma just below the liver (Kindly provided by Professor David Taïeb from La Timone University Hospital of Marseille, France)

with ⁶⁸Ga-DOTATATE showing increased uptake of the tracer. The tumor uptake is frequently quantitated by measuring the standard uptake value (SUV) (see above). Note that because many other tumors such as those derived from neural crest tissue show elevated uptake of these tracers, a positive scan does not always indicate a NET, hence requiring confirmation by other methods.

¹¹C-Choline

¹¹C-choline is approved for PET imaging of patients with suspected recurrent prostate cancer that appeared negative with bone scintigraphy, CT, and MRI. These patients have elevated prostate-specific antigen level (PSA) following initial therapy. A dosage of 10–20 mCi (370–740 MBq) ¹¹C-choline is administered IV to a patient fasting for 6 h prior to the study. The blood clearance of the radiotracer is slow with only 2% eliminated in 1.5 h postinjection. Most of the activity distributes in the pancreas, liver, kidneys, spleen, and colon. As a precursor to the biosynthesis of phospholipid on cell membrane, choline localizes in tumors due to increased phospholipid synthesis in cell proliferation.

PET/CT or PET/MR imaging is performed from the base of the skull to the base of the pelvis. Initially, CT or MR scans are obtained for attenuation correction and coregistration with PET images. Next, PET images are obtained within 15 min of injection, which are then corrected for attenuation followed by reconstruction by the filtered back projection or iterative method. Reconstructed images are then displayed in different anatomical projections for interpretation. The positive or negative scan is based on the PSA level and histopathology of the tissue, and so the test serves as an adjunct to other tests.

¹⁸F-Fluciclovine (Axumin)

¹⁸F-fluciclovine is used for the detection of recurrent prostate cancer in men by PET imaging. Approximately 10 mCi (370 MBq) of the radiopharmaceutical is injected intravenously followed by 10 ml flush of 0.9% NaCl solution into a patient who has fasted for at least 4 h and had not exercised for a day prior to the study. The blood activity is cleared by 50% in 1 h, and the urinary excretion is low with only 3% at 4 h postinjection. The initial uptakes of activity in the liver, red bone marrow, lungs, and pancreas are 14%, 11%, 7%, and 4% ID, respectively, which flatten out about 1 h postinjection. The low urinary excretion offers an advantage in PET imaging due to low background from low bladder activity (McParland et al. 2013).

The PET/CT or PET/MR protocol is followed for imaging. First, a CT or MR image is acquired with the patient in supine position for attenuation correction and coregistration with the PET image. Next, the PET image is obtained in 3D mode 3 to 5 min postinjection covering the region from the head to mid-thigh. After attenuation correction, images are reconstructed using the filtered back projection or iterative method, which are then displayed in transverse, coronal, and sagittal projections. Interpretation of images is based on comparison of a lesion uptake with the adjacent tissue background. For lesions smaller than ~1 cm in diameter, if the uptake is greater than blood pool, prostate cancer recurrence is suspected. For larger lesions, uptake equal to or greater than bone marrow is considered to indicate recurrent prostate cancer. The prostate cancer detection rate depends on the patient's PSA level, the low level tending to indicate negative scans and the higher uptake to positive scans.

Radiolabeled Antibody

Because monoclonal antibody binds to antigen, the former has been used in the radiolabeled form to detect the latter in tumors. Approximately 2–5 mCi (74–185 MBq) ¹¹¹In-labeled Mab, 0.5–1 mCi (18.5–37 MBq) ¹³¹I-labeled Mab, or 5–10 mCi (185–370 MBq) ^{99m}Tc-labeled Mab is administered intravenously to patients suspected of having tumors against which the antibody is produced. The blood clearance is usually slow and the liver uptake is prominent. Tumor uptake of the antibody is normally low with an average value of 0.005% per gram. SPECT/CT imaging of the whole body is performed at 24, 48, 72, and sometimes 120–144 h after injection in the case of ¹¹¹In- or ¹³¹I-labeled antibodies. Increased uptake of the tumor is seen at the tumor sites and depends on the specificity and concentration of the Mab.

Tumor uptake of antibody is limited by a number of factors: blood flow, vascular volume, diffusion of the antibody through the capillaries, the size of the antibody, and loss of immunoreactivity. If the tumor is more vascular and less necrotic, there will be more blood flow and hence more antibody uptake. On the other hand, antibodies are large molecules, and hence the diffusion through the capillaries is limited. Smaller fragments Fab' and $F(ab')_2$ have been used to increase the tumor uptake, but

their absolute uptake is still low due to rapid blood clearance of these fragments, although the tumor-to-background ratios improve considerably. Loss of immunoreactivity during labeling may compromise the tumor uptake of the antibodies.

A difficulty with the use of murine antibodies is human antimurine antibody (HAMA) response after their administration to humans. The severity of the HAMA response depends on the quantity of murine antibodies administered in one or more injections and the immune condition of the subject. Chimeric antibodies produced by the recombinant methods are less immunogenic and more useful than the murine types.

In vivo deiodination of radioiodinated Mab raises the blood pool background and thus makes at times the image interpretation difficult. Newer techniques of iodination using organometallic agents that give more in vivo stable iodinated compounds have been introduced. ¹¹¹In-labeled Mab accumulates largely in the liver, and tumor detection by imaging in the vicinity of the liver becomes difficult. Some investigators explained, but others disproved, that ¹¹¹In-labeled Mab breaks down in vivo and ¹¹¹In then localizes as colloid in the liver. Using GYK-DTPA, SCN-Bz-DTPA, or DOTA as the bifunctional chelator, the stability of ¹¹¹In-labeled Mab and hence success in tumor imaging with it have considerably improved. The use of ^{99m}Tc-labeled Mab significantly reduces the radiation dose to the patient, compared to ¹³¹I- or ¹¹¹In-labeled antibody. Also, the Fab' fragments of the antibody are used to reduce the radiation dose to the patient and to improve the target-to-background ratio in scintigraphic imaging.

Many antibodies have been developed against various tumors, labeled with radionuclides, and finally used for the detection of tumors. A number of Mabs have been approved by the US FDA for therapeutic use and a few for diagnostic uses, which are described briefly below.

¹¹¹In-Capromab Pendetide (ProstaScint)

This tracer is used for the detection of prostate cancer. Approximately 5 mCi (185 MBq) is injected intravenously, and planar or SPECT/CT images are obtained using a gamma camera equipped with a medium-energy parallel hole collimator at 72–120 h after injection. A cleansing enema is recommended 1 h before imaging to clear the abdominal background. The plasma clearance half-time is 67 h, and the urinary excretion is about 10% in 72 h. It primarily localizes in the liver, spleen, and bone marrow.

Prostate cancer and metastasis are detected by this agent with reasonable accuracy. A scintigraphic image obtained with ProstaScint is shown in Fig. 13.42.

¹¹¹In-Ibritumomab Tiuxetan (Zevalin)

The majority of non-Hodgkin's lymphomas (NHLs) are of B cell origin due to their abnormal growth. Ibritumomab tiuxetan and its chimeric analog rituximab are antibodies against CD20 antigen, expressed on normal B cells and most malignant B cell lymphomas, and therefore bind to the CD20 antigen and lyse the lymphoid B cells. ¹¹¹In-ibritumomab tiuxetan is used as an imaging agent prior to therapy of NHL patients with ⁹⁰Y-ibritumomab tiuxetan in order to predict the biodistribution of the therapeutic dosage.



The preparation of ¹¹¹In-ibritumomab tiuxetan is described in Chap. 7. Approximately 5 mCi (185 MBq) ¹¹¹In-ibritumomab tiuxetan is administered intravenously over a 10-min period immediately following the infusion of 250 mg/m² rituximab. The effective blood half-life of ¹¹¹In-ibritumomab tiuxetan is 27 h, and the urinary excretion is 7.3% over 7 days. The whole-body images are obtained at 2–24 h and 48–72 h and, if needed, at 90–120 h postinjection. The normal biodistribution of the tracer is demonstrated by blood pool activity on the 24-h image with high uptake in the normal liver and spleen; low uptake in the kidneys, bladder, and bowel throughout the imaging period; and increased uptake in tumor tissues. Altered biodistribution is indicated by increased lung uptake relative to the blood pool and liver and greater renal and bowel uptake than the liver uptake. If ¹¹¹In imaging shows altered rather than normal pattern of distribution, the patient does not receive the ⁹⁰Y-ibritumomab tiuxetan therapy.

13.9.2 Thrombus Detection

Hundreds of thousands of people die annually from complications of thrombosis and embolism such as heart attack, stroke, and pulmonary embolism. Whereas heart attacks and strokes are caused by arterial thrombus, pulmonary embolisms are caused by venous clots, particularly those originating from the lower extremity veins. Many other complications related to peripheral vascular diseases result from atherosclerosis and thrombosis.

A thrombus is formed in two stages. First, prothrombin reacts with Ca^{2+} to form thrombin in the presence of thromboplastin. Second, fibrinogen reacts with thrombin to form a fibrin monomer, which in turn polymerizes to form a fibrin clot. Thromboplastin is produced from platelets or damaged tissue by the action of a number of factors in the blood.

Pulmonary embolism results mainly from the release of thrombi originating in the deep veins of lower extremities, such as the iliac and femoral veins. Such thrombus formation is highly probable in postoperative patients. Therefore, early detection of actively forming deep vein thrombi is very important in these patients.

In earlier periods, ¹²⁵I-labeled fibrinogen was used to detect deep vein thrombus (DVT) in lower extremities, but it is no longer used because it is not commercially available. Since platelets are involved in thrombus formation, ¹¹¹In-labeled platelets have been used successfully to detect actively forming thrombi. The labeling technique has been described in Chap. 7. Approximately 2–4 mCi (74–148 MBq) is injected intravenously into the patient, and imaging is performed at 24, 48, and 72 h after injection using a gamma camera. Increased uptake is seen at the sites of actively forming thrombi.

Other agents such as ¹¹¹In-, ^{99m}Tc-, or ¹³¹I-labeled antifibrin antibody, streptokinase, and urokinase have been employed for detecting clots, but success in imaging is limited for various technical reasons. Also, ^{99m}Tc-labeled peptides such as P280 and P748, which bind to GPIIb/IIIa receptors in the actively forming thrombi, have been used for the detection of these thrombi.

13.9.3 Lymphoscintigraphy

The lymphatic vessels are thin-walled channels lined by endothelium and containing numerous valves preventing backflow of lymph. The lymph is similar to plasma in composition, and unlike blood, it flows slowly. The lymphatic system produces lymphocytes and monocytes, destroys aged red blood cells, and transfers a large portion of the fat absorbed in the intestine to the bloodstream. The lymphatic capillaries unite to form lymphatic ducts, which convey the lymph to lymph nodes. Other lymphatic ducts convey lymph from the nodes to the main lymphatic vessels and the thoracic duct, which then discharge it into the subclavian vein. The flow of lymph is caused by contraction of skeletal muscles, respiratory movement, heart beats, and intestinal movement.

Lymph nodes are usually small structures about 1 cm in diameter. They are usually situated at the proximal ends of the limbs and in the neck, groin, abdomen, and thorax. Lymph nodes provide protection against bacterial infection by phagocytic digestion of bacteria in the lymphatic vessels. A severely infected lymph node becomes swollen and tender.

The lymphatic system provides the paths for the spread (metastasis) of cancer from one part of the body to another. Hodgkin's disease, lymphocytic leukemia, various metastatic diseases, and many lymph node disorders can be assessed by lymphoscintigraphy. Lymph node pathology is demonstrated by diminished or absent flow of lymph.

The most common radiopharmaceuticals used for lymphoscintigraphy are 99m Tc-SC, 99m Tc-albumin colloid and 99m Tc-tilmanocept (Lymphoseek). Filtered 99m Tc-SC, described in Chap. 7, provides optimal particle size for reasonable lymphoscintigraphy. The usual dosage for administration is about 450 μ Ci (16.7 MBq) filtered

^{99m}Tc-SC or ^{99m}Tc-albumin colloid divided into one to four injections in small volume. Some investigators use a higher dosage of 1–2 mCi (37–74 MBq). Injections are given subcutaneously around the tumor site followed by gentle massage around the area.

^{99m}Tc-tilmanocept (Lymphoseek) accumulates in lymphatic tissues by binding to a receptor, a mannose-binding protein that resides on the surface of macrophage cells. For lymphoscintigraphy, four 1.0-ml, 125- μ Ci (4.6 MBq) injections of ^{99m}Tc-tilmanocept (0.25 nmol) are injected within 1 h of preparation at 4 quadrants of the suspected nodal area using the peritumoral/subepidural technique (Wallace et al. 2003).

The colloid drains out rapidly from the injection site depending on the particle size, injection site, and pathophysiologic conditions. Small particles are drained to the extent of about 40–60%, whereas the larger particles are retained at the injection site. Lymphoseek clears faster than filtered ^{99m}Tc-SC. The lymph node activity reaches a plateau in 2 h after injection for ^{99m}Tc-SC. Approximately 3% of the injected activity is retained in all visualized nodes.

Imaging is performed with a gamma camera using a low-energy parallel hole, high-resolution collimator, and time for imaging is site specific. Images are obtained immediately after injection for melanoma and at 30–40 min later in the case of breast lymphoscintigraphy. Some investigators wait for 4–24 h before breast imaging. Surgeons dissect the areas of interest after injection and explore the nodes of increased radiotracer uptake by using a handheld gamma ray probe.

For sentinel node biopsy, surgeons inject a blue dye, isosulfan blue, that concentrates in the lymph nodes. The nodes which are positive by gamma camera scanning and also by handheld probe are removed by dissection following identification by the blue color due to dye uptake. All sentinel nodes are counted and histopathology determined. The sentinel uptake is expressed in %ID. The primary sentinel node uptake is around 0.6% ID for both filtered ^{99m}Tc-SC and Lymphoseek.

Normal lymphoscintigraphy demonstrates the normal nodes in inguinal, iliac, and periaortic regions, several lymph nodes in the parasternal regions, and other lymph nodes depending on the site of injection. Sentinel nodes are easily seen by this technique. The detection rate of lymph nodes with Lymphoseek is around 98% and 2–4 nodes per patient. At times, the liver is also seen due to lymphatic blockage or poor injection. Discontinuity in the drainage may result from metastasis; increased activity in an area may be due to lymphoma, or blockage of the lymphatics. In the case of melanoma, delineation of specific sites of lymphatic drainage by lymphoscintigraphy leads to decision on the surgical removal of the involved regional lymph nodes. In breast lymphoscintigraphy, poor uptake in lymph nodes and absent distant lymphatic filling may indicate intranodal tumor in the breasts.

13.9.4 Gastric Emptying Imaging

Abnormal rates of gastric emptying are associated with many disease states, and their determination offers useful information in assessing these diseases. Radionuclidic techniques have been successfully employed in determining the gastric emptying half-time.

Various kinds of ^{99m}Tc-labeled meals in solid or liquid form have been used to measure the gastric emptying time. In one solid meal, approximately 1 mCi (37 MBq) ^{99m}Tc-SC is mixed with a bowl of oatmeal. In another type of solid meal, the same amount is cooked with scrambled eggs and given as a sandwich with bread to the patient. In a liquid meal, 1 mCi (37 MBq) ^{99m}Tc-DTPA or 0.5 mCi (18.5 MBq) ¹¹¹In-DTPA in 300 ml water solution is commonly used for drinking.

The patient is allowed after 6–12 h of fasting to take any of the above meals. In the case of solid meals, the patient is asked to drink additional 8 ounces of milk or orange juice. For dual-isotope liquid-solid gastric emptying studies, liquid meal with ¹¹¹In-DTPA and solid meal with ^{99m}Tc-SC are given to the patient simultaneously. The patient's stomach is imaged at 1 and 5 min after administration using a gamma camera with an appropriate collimator and using appropriate windows for respective photon energies and then every 5-15 min until the stomach activity reaches half its original activity. Both anterior and posterior images are obtained and 50,000 counts are collected in each image. The region of interest is drawn on each image, and the geometric mean of anterior and posterior activities of each ROI is calculated. Assuming the initial ROI activity in the stomach is 100%, the activity in each subsequent ROI can be expressed as a percentage of the initial stomach activity. From a plot of percent activity versus time, the gastric emptying half-time can be determined. The normal values are 50-80 min for solid meals and 10-15 min for liquid meals. Delayed emptying time is found in gastric ulcers, pyloric stenosis, vagotomy, and malignancies.

13.9.5 Meckel's Diverticulum Imaging

Approximately 2% of the population has Meckel's diverticulum, and symptomatic Meckel's diverticulum (i.e., rectal bleeding) is found in one fourth of this population, who are primarily young. Ectopic gastric mucosa lines the symptomatic diverticuli, and the latter are usually imaged with ^{99m}Tc-pertechnetate, which is concentrated by the gastric mucosa.

Approximately 10–15 mCi (370–555 MBq) ^{99m}Tc-pertechnetate is injected intravenously into a patient who has received 300 mg of cimetidine orally every 6 h for 1 day, or 6 μ g/kg pentagastrin 15 min before injection. Cimetidine inhibits acid secretion and thus prevents ^{99m}Tc activity from the gastric mucosa into gastric contents. This decreases the background activity. Pentagastrin stimulates pertechnetate accumulation in gastric mucosa. Imaging is performed with a scintillation camera fitted with a low-energy parallel hole collimator immediately and every 10 min for 1 h after administration. Sometimes, lateral and delayed views are obtained in equivocal situations. A persistent focal activity on the images indicates Meckel's diverticulum.

13.9.6 Gastrointestinal Bleeding Detection

Gastrointestinal (GI) bleeding is a common clinical problem. Upper GI bleeding mostly results from esophageal varices, peptic ulcers, hemorrhagic gastric ulcers,

neoplasms, and drug-induced gastric erosions. Lower GI bleeding may be caused by diverticular diseases, inflammatory bowel diseases, or neoplasms.

The success rate of detection of GI bleeding by endoscopic and other clinical methods is limited. The scintigraphic technique has gained considerable success in the detection and localization of GI bleeding. The most commonly used radiopharmaceuticals are ^{99m}Tc-SC and ^{99m}Tc-RBCs. After injection, a fraction of the activity from the circulation extravasates at the bleeding site.

Ten mCi (370 MBq) ^{99m}Tc-SC is injected intravenously, and the patient's upper and lower GI tracts are imaged with a gamma camera fitted with a low-energy parallel hole collimator at 2-min intervals for 20 min. If a bleeding site is seen, more images are taken to definitely localize the site of bleeding. Sometimes delayed images are necessary to obtain an accurate diagnosis. At times, the liver and spleen activity may blur the bleeding sites in the surrounding areas. Because of the rapid clearance of ^{99m}Tc-SC from the circulation, the background is minimal and the sites with bleeding rates as low as 0.05–0.1 ml/min can be detected by ^{99m}Tc-SC.

Most GI hemorrhages are intermittent and may be missed with ^{99m}Tc-SC because of the rapid clearance of the colloid. Several investigators argue that it is preferable to use a tracer that remains in the intravascular space for a longer period for the localization of the bleeding site. The ^{99m}Tc-RBCs labeled by the in vitro technique or by the modified in vivo technique (Chap. 7) are considered to be the agents of choice for GI bleeding imaging.

Approximately 20 mCi (740 MBq) ^{99m}Tc-RBC is administered intravenously, and the abdomen is imaged by a scintillation camera using a low-energy parallel hole collimator. Images are taken, one immediately and then every 15 min for about 1 h. Images are repeated at intervals of several hours up to 24 h if the bleeding site is not detected by the first hour. Images are considered positive when a focus of activity is noticed. Detection of bleeding sites with ^{99m}Tc-RBC is possible when the bleeding rate exceeds 6–12 ml/min.

13.9.7 Inflammatory Diseases and Infection Imaging

Inflammatory diseases and infections such as sepsis and abdominal abscesses form a group of diseases that need early detection for patient management. Most inflammatory diseases result from a response to infections, although conditions such as arthritis and synovitis also involve inflammatory processes without the presence of infections. Most of these conditions are detected by the use of ⁶⁷Ga-citrate, ^{99m}Tc-leukocytes, or ¹¹¹In-leukocytes. The techniques of labeling of leukocytes with ^{99m}Tc and ¹¹¹In have been described in Chap. 7.

⁶⁷Ga-Citrate

Gallium uptake by inflammatory diseases is explained by the formation of complexes between ⁶⁷Ga and lactoferrin released by leukocytes and between ⁶⁷Ga and siderophores. Leukocytes are attracted to infected areas in large concentrations and release lactoferrin in response to stimulation by infection. Also present in infections is a group of compounds called siderophores produced by bacteria in infections that avidly bind to gallium.

Approximately 5–10 mCi (185–370 MBq) ⁶⁷Ga-citrate is injected intravenously, and imaging is performed initially 24 h postinjection and, if necessary, later using a gamma camera with a medium-energy collimator. Gallium scan is useful in the detection of abscess, cellulitis, and peritonitis. This test is highly sensitive in the detection of osteomyelitis. Other indications for ⁶⁷Ga scanning include various lung diseases associated with inflammatory process such as asbestosis, toxicity due to chemotherapy, bacterial nephritis, and Pneumocystis carinii pneumonia in AIDS patients.

¹¹¹In- or ^{99m}Tc-Leukocytes

Leukocytes are a mixed population of polymorphonuclear granulocytes (neutrophils), lymphocytes, and monocytes, and they defend the body against infection. Neutrophils are attracted to the infected area by chemotaxis and kill microorganisms by phagocytosis. Lymphocytes and monocytes are primarily responsible for defense against infection by immune reactions. Based on these functional attributes of leukocytes, ¹¹¹In- or ^{99m}Tc-leukocytes are found useful in the detection of infections in patients.

Approximately 0.5 mCi (18.5 MBq)¹¹¹In-leukocytes containing about 10⁸ leukocytes is injected intravenously, and imaging of the whole body or the region of interest is performed 18–24 h after injection using a scintillation camera with a medium-energy collimator. At times, delayed images at 48 h are obtained for better resolution of images. The plasma disappearance half-time of the tracer is of the order of 6–7 h. Approximately 50% of the cells accumulate in the liver, ~11% in the spleen, and ~8% in the lungs.

In the case of ^{99m}Tc-leukocytes, 8–10 mCi (296–370 MBq) is injected intravenously and images are obtained 1–4 h later using a gamma camera with a lowenergy parallel hole collimator. The biodistribution of this tracer is similar to that of ¹¹¹In-leukocytes.

^{99m}Tc-sulesomab, the Fab' fragment of anti-NCA-90 antibody which is an antigranulocyte antibody, is used as an in vivo granulocyte labeling agent for imaging inflammation and infection. It is approved for clinical use in European countries but not in the USA. Approximately 10–15 mCi (370–555 MBq) is injected intravenously, and images are obtained at 1–4 h later using a gamma camera with a lowenergy parallel hole collimator. The blood clearance $t_{1/2}$ of ^{99m}Tc-sulesomab is about 23 min. Infection or inflammation is seen on the images as increased uptake of the tracer. It is interesting to note that localization in inflammation or infection does not occur by binding to circulating granulocytes. It diffuses into the affected area nonspecifically via increased vascular permeability and then binds to only activated granulocytes in inflammation or infection (Skehan et al. 2003).

Various infectious diseases are well detected by labeled leukocyte imaging. It is particularly useful in fever of unknown origin where the infected area is clinically unidentified. Osteomyelitis is correctly identified by this technique. ¹¹¹In-leukocyte imaging is preferred to ^{99m}Tc-leukocyte imaging in abdominal abscess areas. This is primarily because of the partial breakdown of ^{99m}Tc-leukocytes that leads to



increased ^{99m}Tc background in the abdominal areas. However, early imaging with ^{99m}Tc-leukocytes helps to detect inflammatory bowel disease better than ¹¹¹In-leukocytes, because of the avid accumulation of the tracer in the diseased area and less background. On the other hand, leukocyte accumulation in intraabdominal sepsis is low, and in this situation ¹¹¹In-leukocyte imaging is preferable. Bacterial endocarditis, rejection of vascular grafts, and various lung infections have been successfully documented by this technique. A typical ¹¹¹In-leukocyte image of an abscess in the pelvic area of a patient is shown in Fig. 13.43.

13.9.8 Parathyroid Imaging

There are normally four parathyroid glands (two upper and two lower) situated on the posterolateral sides of the two thyroid glands. These glands secrete parathyroid hormone (PTH), which regulates and maintains normal serum calcium level (9–11 mg/dl) by its action on the bone, the small intestine, and the kidneys. Overfunctioning of the parathyroid glands leads to hyperparathyroidism manifested by higher serum calcium level (hypercalcemia), whereas underfunctioning of the glands results in hypoparathyroidism indicated by low serum calcium level. Various disease entities such as hyperplasia, adenoma, parathyroid carcinoma, and multiple gland diseases can cause hyperparathyroidism in patients.

Several imaging protocols are in use for the diagnosis of abnormal parathyroid. In most cases, a dual-isotope technique is employed based on the principle of delineating the parathyroid from the thyroid using the two different tracers for the two types of glands. Combinations such as 99m TcO₄ / 201 Tl, 123 I/ 201 Tl, and 123 I/ 99m Tc-sestamibi are used as the dual isotopes. Inherent in these techniques is the fact that 123 I⁻ or 99m TcO₄ localizes in the thyroid, whereas 201 Tl or 99m Tc-sestamibi localizes in both the thyroid and parathyroid glands. Thus by subtracting the image of 123 I⁻ or 99m TcO₄ from the image of 201 Tl or 99m Tc-sestamibi after normalization with respect to maximum 123 I⁻ or 99m TcO₄ counts, one obtains a true image of the parathyroid glands.

In practice, 300 μ Ci (11.1 MBq) ¹²³I-NaI orally or 2 mCi (74 MBq) ^{99m} TcO₄ intravenously is administered to the patient followed by planar imaging of the glands 4 h postinjection with a gamma camera equipped with a pinhole collimator. The patient is then injected with 2 mCi (74 MBq) ²⁰¹Tl and imaged again 15 min postinjection. This procedure can be reversed with ²⁰¹Tl first and ¹²³I⁻ or ^{99m} TcO₄ next. SPECT imaging may be performed with a scintillation camera using a low-energy all-purpose parallel hole collimator. In the alternative protocol, 25–30 mCi (925–1110 MBq) ^{99m}Tc-sestamibi is substituted for ²⁰¹Tl. Some investigators use simultaneous imaging by setting two separate windows for the two isotopes. After image processing, either separately or simultaneously, the data on the ²⁰¹Tl or ^{99m}Tc⁻ or ^{99m}TcO₄ image, and the latter image is subtracted from the former. The net image gives the details of the parathyroid uptake of the tracer, which in turn indicates the presence or absence of abnormal parathyroid.

In another technique, a single dosage of 10–20 mCi (370–740 MBq) ^{99m}Tcsestamibi is injected, and the patient's parathyroid is first imaged 10–15 min postinjection and then 2–3 h later. The early image shows anatomy in and around the thyroid, and the delayed image shows increased uptake in pathologically enlarged parathyroid glands with minimal uptake in the thyroid. Because of the ease of methodology, this technique has gained wide acceptance.

Questions

- 1. What are the radiopharmaceuticals commonly used in brain imaging? What is the mechanism of localization of these tracers? Do you expect an increased or decreased uptake of radioactivity in the normal and abnormal brain?
- 2. What are the primary uses of ¹⁸F-FDG PET in brain imaging?
- In bone and brain imaging, 10–15 mCi (370–555 MBq) ^{99m}Tc-labeled compounds are injected, whereas in liver imaging, only 2–4 mCi (74–148 MBq) are injected. Why?
- 4. Name the radiopharmaceuticals for detecting Alzheimer's disease in patients. What is the mechanism of their uptake?
- 5. Elucidate the mechanism of synthesis of thyroid hormones (T3 and T4) in the thyroid.
- 6. In a 24-h iodine uptake test, the thyroid count is 34,500 cpm and the thigh count is 3020 cpm. The thyroid phantom count is 90,500 cpm, and the room background count is 200 cpm. Calculate the 24-h uptake value. Is it euthyroid, hypothyroid, or hyperthyroid?
- 7. Name various drugs that affect the thyroid uptake of ¹³¹I.
- 8. What is the mechanism of localization of ^{99m}Tc-MAA in lung imaging? How many particles are usually administered per dosage to the patient, and what fraction of the pulmonary capillaries is occluded by these particles?
- 9. A physician requests a lung scan for a patient suspected of pulmonary embolism. As a nuclear pharmacist, which radiopharmaceutical would you prepare and how much would you dispense? When is a ¹³³Xe ventilation study indicated?
- 10. When is the use of ^{99m}Tc-mebrofenin and ^{99m}Tc-sulfur colloid indicated in liver imaging? What are the plasma disappearance half-times of these two tracers? How much would you inject of each tracer?
- 11. What are the radiopharmaceuticals that are used for hepatobiliary imaging? How does bilirubin level affect the hepatic uptake of ^{99m}Tc-IDA derivatives?
- 12. Describe the method of cholescintigraphy. When is the gallbladder seen in a normal patient?
- 13. What is the effect of CCK or morphine on cholescintigraphy?
- 14. Make a table of all radiopharmaceuticals used in renal studies, including information such as the quantity of the tracer, plasma clearance half-time, urinary excretion, optimum time to begin imaging after injection, and clinical information obtained.
- 15. Discuss the three phases of a renogram in the normal and abnormal states of the kidneys.
- 16. In glomerular filtration rate measurement by the constant infusion method, the plasma concentration and urinary concentration of ¹¹¹In-DTPA are 1200 cpm/ ml and 15,600 cpm/ml, respectively. The urine flow rate is 9 ml/min. Calculate the glomerular filtration rate.
- 17. What are the different ^{99m}Tc-phosphonate compounds used in bone scintigraphy? Explain the mechanism of bone uptake of ^{99m}Tc-phosphonate compounds. Why do you have to wait 2–3 h after injection before imaging? Explain the differences in plasma clearance and urinary excretion of different ^{99m}Tc-phosphonate compounds.
- 18. In myocardial infarct imaging with ^{99m}Tc-pyrophosphate, how soon after the onset of infarction is the infarct site seen on the image? When does the maximum uptake in the myocardial infarct occur? How soon after injection can this imaging begin?
- 19. In myocardial imaging, how is the infarct seen on the image with ^{99m}Tc-pyrophosphate and ²⁰¹Tl-thallous chloride – as increased or decreased activity in the infarct? Explain the observations.
- 20. Compare the biological properties of ²⁰¹Tl, ^{99m}Tc-sestamibi, and ^{99m}Tc-tetrofosmin.
- 21. What are the salient features of difference between ²⁰¹Tl SPECT and ⁸²Rb PET imaging?
- 22. How does glucose loading help ¹⁸F-FDG uptake in the myocardium? Spell out the mechanism of myocardial uptake of ¹⁸F-FDG.
- 23. What are the agents used for the gated equilibrium blood pool study of the heart? Describe the measurement of the ejection fraction of the left ventricle by

this method. What is the normal value of the ejection fraction? What is the role of stress ventriculography?

- 24. What are the different agents of choice for tumor imaging? What is the mechanism of localization of gallium in tumor?
- 25. How would you calculate SUV for a tumor detected on a whole-body FDG scan?
- 26. An 80-kg man had a PET scan with 15 mCi (925 MBq) ¹⁸F-FDG after a wait of 40 min postinjection. A tumor was found to contain maximum activity of 8 μ Ci (296 kBq). From the assumption of pixel size, number of pixels in the tumor, and tissue density as 1 g/cm³, the tumor weight is estimated to be 3 g. Calculate the SUV of the tumor.
- 27. What is the common radiopharmaceutical for lymphoscintigraphy? What are the common diseases that can be diagnosed by lymphoscintigraphy?
- 28. What are the different radiopharmaceuticals used for (a) gastric emptying, (b) Meckel's diverticulum, (c) gastrointestinal bleeding, and (d) inflammatory diseases?
- 29. When is captopril renography indicated and how is it performed?
- 30. What is the rationale for the use of ¹²³I-MIBG in myocardial imaging?
- 31. What is the radiopharmaceutical employed for adrenal imaging.
- 32. Describe the role of radiolabeled antibodies in tumor imaging. Elucidate the different FDA approved antibodies for various tumor imaging.
- 33. Discuss the relative importance of ^{99m}Tc-sestamibi, ²⁰¹Tl, and ¹⁸F-FDG in tumor imaging. Which one is the best tracer in delineating tumors from radiation necrosis?
- 34. What are the types of tumors that are imaged with ¹¹¹In-pentetreotide and ⁶⁸Ga-DOTATATE? Which of these is better for this type of tumors?
- 35. Describe the methods of imaging parathyroids with different radiopharmaceuticals.
- 36. Why is ^{99m}Tc-RBC preferred to ^{99m}Tc-SC in GI bleeding scintigraphy?
- 37. Why is ¹²³I-MIBG taken up by neuroblastoma tumors?
- 38. How long does a patient injected with FDG have to wait before whole-body scanning?
- 39. A fixed defect on a ⁸²Rb-PET myocardial perfusion scan definitely indicates infarcted necrotic tissue. True or False?

References and Suggested Reading

Anthony CP, Thibodeau GA. Textbook of anatomy and Physiology. St. Louis: Mosby; 1979.

- Arnold RW, Subramanian G, McAfee JG, et al. Comparison of ^{99m}Tc complexes for renal imaging. J Nucl Med. 1975;16:357.
- Atkins HL, Budinger TF, Lebowitz E, et al. Thallium-201 for medical use. Part 3: human distribution and physical imaging properties. J Nucl Med. 1977;18:133.
- Barrio JR, Huang SC, Melega WP, et al. 6-[¹⁸F]fluoro-L-dopa probes dopamine turnover rates in central dopaminergic structures. J Neurosci Res. 1990;27:487.
- Berman DS, Kiat HS, Van Train KF, et al. Myocardial perfusion imaging with technetium-99msestamibi: comparative analysis of imaging protocols. J Nucl Med. 1994;35:681.

- Booij J, Busemann Sokole E, Stabin MG, et al. Human biodistribution and dosimetry of [1231] FP-CIT: a potent radioligand for imaging of dopamine transporters. Eur J Nucl Med. 1998;25:24.
- Cook GJR, Maisey MN, Britton KE, Chengazi V, editors. Clinical nuclear medicine. 4th ed. London: Hodder Arnold; 2006.
- Delbeke D, Martin WH, Patton JA, et al., editors. *Practical FDG imaging. A teaching file.* New York: Springer; 2002.
- Dienel GA, Cruz NF, Sokoloff F. Metabolites of 2-deoxy-[¹⁴C]-glucose in plasma and brain: influence on rate of glucose utilization determined with deoxyglucose method in rat brain. J Cereb Blood Flow Metab. 1993;13:315.
- Dilsizian V, Rocco TP, Freedman NMT, et al. Enhanced detection of ischemic but viable myocardium by the reinjection of thallium and stress-redistribution imaging. N Engl J Med. 1990;323:141.
- Dilsizian V, Bacharach SL, Beanlands RS, et al. Imaging guidelines for nuclear cardiology procedures: PET myocardial perfusion and metabolic clinical imaging. J Nucl Cardiol. 2009;16:651.
- Early PJ, Sodee DB, editors. Principles and practice of nuclear medicine. 2nd ed. St. Louis: Mosby; 1995.
- Ell PJ, Gambhir SS. Nuclear medicine in clinical diagnosis and treatment. 3rd ed. Edinburgh: Churchill Livingstone; 2004.
- European Medicines Agency. Vizamyl; flutemetamol (¹⁸F); Procedure No. EMEA/H/C/002553; 2014.
- Gould KL, Yoshida K, Hess MJ, et al. Myocardial metabolism of fluorodeoxyglucose compared to cell membrane integrity for the potassium analogue rubidium-82 for assessing infarct size in man by PET. J Nucl Med. 1991;32:1.
- Hauser W, Atkins HL, Nelson KG, et al. Technetium-99m-DTPA: a new radiopharmaceutical for brain and kidney imaging. Radiology. 1970;94:679.
- Henkin RE, Bara D, Dillehay GL, et al., editors. Nuclear medicine. 2nd ed. Philadelphia: Mosby-Elsevier; 2006.
- Higley B, Smith FW, Smith T, et al. Technetium-99m-1,2-bis[bis(2-ethoxyethyl)-phosphino] ethane: human biodistribution, dosimetry and safety of a new myocardial perfusion imaging agent. J Nucl Med. 1993;34:30.
- Hofmann M, Maecke H, Börner AR, et al. Biokinetics and imaging with the somatostatin receptor PET radioligand 68Ga-DOTATOC: preliminary data. Eur J Nucl Med. 2001;28:1751.
- Kiat H, Berman DS, Maddahi J, et al. Late reversibility of tomographic myocardial Tl-201 defects: an accurate marker of myocardial viability. J Am Coll Cardiol. 1988;12(6):1456.
- Leveille J, Demonceau G, DeRoo M, et al. Characterization of technetium-99m-L,L-ECD for brain perfusion imaging, part 2: Biodistribution and brain imaging in humans. J Nucl Med. 1989;30:1902.
- Lin KJ, Hsu WC, Hsiao IT, et al. Whole-body biodistribution and brain PET imaging with [18F] AV-45, a novel amyloid imaging agent- a pilot study. Nucl Med Biol. 2010;37:497.
- Lonskaya I, Hebron M, Chen W, Schackter J, et al. Tau deletion impairs intra cellular β- amyloid-42 clearance and leads to more extracellular plaque deposition in gene transfer models. Mol Neurodegener. 2014;9:46.
- McAfee JG, Grossman ZD, Gagne G, et al. Comparison of renal extraction efficiencies for radioactive agents in the normal dog. J Nucl Med. 1981;22:333.
- McParland BJ, Wall A, Johansson S. The clinical safety, biodistribution and internal radiation dosimetry of [¹⁸F]fluciclovine in healthy volunteers. Eur J Nucl Med Mol Imaging. 2013;40:1256.
- Mejia AA, Nakamura T, Masatoshi I, et al. Estimation of absorbed dose in humans due to intravenous administration of fluorine-18-fluorodeoxyglucose in PET studies. J Nucl Med. 1991;32:699.
- Mettler FA Jr, Guiberteau MJ. Essentials of nuclear medicine imaging. 5th ed. Philadelphia: Saunders; 2006.
- Narra RK, Nunn AD, Kuczynski BL, et al. A neutral technetium-99m complex for myocardial imaging. J Nucl Med. 1989;30:1830.

- Phelps ME, Hoffman EJ, Selin C, et al. Investigation of F-18-fluoro-2-deoxyglucose for the measure of myocardial glucose metabolism. J Nucl Med. 1978;19:1311.
- Ruhlmann J, Oehr P, Biersack HJ, editors. PET in oncology. Basics and clinical applications. Heidelberg: Springer; 1999.
- Sabri O, Sabbagh MN, Seibyl J, Barthel H. Florbetaben PET imaging to detect amyloid beta plaques in Alzheimer's disease: phase 3 study. Alzheimers Dement. 2015a;11:964.
- Sabri O, Seibyl J, Rowe C, et al. Beta-amyloid imaging with florbetaben. Clin Transl Imaging. 2015b;3:13.
- Saha GB, Go RT, MacIntyre WJ, et al. Use of ⁸²Sr/⁸²Rb generator in clinical PET studies. Nucl Med Biol. 1990;17:763.
- Saha GB, MacIntyre WJ, Brunken RC, et al. Present assessment of myocardial viability by nuclear imaging. Semin Nucl Med. 1996;26:315.
- Sandler MP, Coleman RE, Walkers FJT, et al., editors. Diagnostic nuclear medicine. 4th ed. Baltimore: Lippincott; 2003.
- Sandström M, Velikyan I, Garske-Román U, et al. Comparative biodistribution and radiation dosimetry of ⁶⁸Ga-DOTATOC and ⁶⁸Ga-DOTATATE in patients with neuroendocrine tumors. J Nucl Med. 2013;54:1755.
- Sapirstein LA, Vigt DG, Mandel MJ, et al. Volumes of distribution and clearances of intravenously injected creatinine in the dog. Am J Phys. 1955;181:330.
- Schelbert HR, Phelps ME, Huang SC, et al. N-13 ammonia as an indicator of myocardial blood flow. Circulation. 1981;63:1259.
- Sharp PF, Smith FW, Gemmell HG, et al. Technetium-99m HMPAO stereoisomers as potential agents for imaging regional cerebral blood flow: human volunteer studies. J Nucl Med. 1986;27:171.
- Sisson JC, Shapiro B, Meyers L, et al. Metaiodobenzylguanidine to map scintigraphically the adrenergic nervous system in man. J Nucl Med. 1987;28:1625.
- Skehan SJ, White JF, Evans JW, et al. Mechanism of accumulation of ^{99m}Tc-sulesomab in inflammation. J Nucl Med. 2003;44:11.
- Subramanian G, McAfee JG, Blair RJ, et al. Technetium 99m methylene diphosphonate a superior agent for skeletal imaging; comparison with other technetium complexes. J Nucl Med. 1975;16:744.
- Taylor A Jr, Eshima D, Christian PE, et al. Technetium-99m kit formulation; preliminary results in normal volunteers and patients with renal failure. J Nucl Med. 1988;29:616.
- Taylor A Jr, Eshima D, Fritzberg AR, et al. Comparison of iodine-131 OIH and technetium-99m MAG3 renal imaging in volunteers. J Nucl Med. 1986;27:795.
- Vallabhajosula S, Zimmerman RE, Pickard M, et al. Technetium-99m ECD: a new brain imaging agent. In vivo kinetics and biodistribution studies in normal human studies. J Nucl Med. 1989;30:599.
- Velikyan I. ⁶⁸Ga-based radiopharmaceuticals: production and application relationship. Molecules. 2015;20:12913.
- Virkamaki A, Rissanen E, Hamalainen S. Incorporation of [3-sup³H]glucose and 2-[1-sup¹⁴C] deoxyglucose into glycogen in heart and skeletal muscle in vivo: implications for the quantitation of tissue glucose uptake. Diabetes. 1997;46:1106.
- Wackers FJT, Berman DS, Maddahi J, et al. Technetium-99m hexakis 2-methoxyisobutyl isonitrile: human biodistribution, dosimetry, safety and preliminary comparison to thallium-201 for myocardial perfusion imaging. J Nucl Med. 1989;30:301.
- Wagner HN Jr, Szabo Z, Buchanan JW. Principles of nuclear medicine. 2nd ed. Philadelphia: Saunders; 1995.
- Wallace AM, Hoh CK, Vera DR, et al. Lymphoseek: a molecular radiopharmaceutical for sentinel node detection. Ann Surg Oncol. 2003;10:531.
- Weiner RE. The mechanism of 67Ga localization in malignant disease. Nucl Med Biol. 1996;23:745.

Molecular Imaging

14

Molecular imaging (MI) is a method of determining the spatial and temporal status of molecular or cellular processes in the normal or abnormal state in living organs (Thakur and Lentle 2005). The current strategy in molecular imaging is to identify a target molecule in a specific organ or its disease state in a living organism, develop a high-affinity probe for the molecule, and ultimately use the probe to detect the distribution and pharmacodynamics of the molecule. A specific disease is inherently manifested by the changes in the "molecules" of the tissue that underlie the disease, and imaging of these changes permits early detection of the disease. Molecular changes due to therapy of a disease also can be monitored by imaging leading to the assessment of the effectiveness of the treatment. MI employs a variety of techniques such as magnetic resonance imaging (MRI), optical imaging, ultrasound, Raman spectroscopy, and nuclear medicine. In the current context, only the application of MI in nuclear medicine will be discussed below.

The essential elements of MI in nuclear medicine (Weissleder and Mahmood 2001) are (1) a high-affinity probe for a molecular target responsible for the disease, (2) ability of the probes to cross the barriers (vascular, interstitial, cell membrane) to enter into the compartment of molecular changes, (3) maximization of probe localization, and (4) highly sensitive imaging techniques. Decades ago, MI was conceptually introduced in nuclear medicine with the application of monoclonal antibody and receptor imaging. Current pioneering research in genomics, proteomics, and high-affinity probes along with the development of highly sensitive detection equipment has widened the dimension and scope of molecular imaging leading to better probe–target interaction with increased uptake of the probe and improved detection of the disease. The techniques of SPECT/CT, PET/CT, and PET/MRI are state-of-the-art modalities for successful molecular imaging. Various diseases related to metabolism, apoptosis, tumors, genetics of diseases, and stem cells have been identified by molecular imaging.

14.1 Methodology of Molecular Imaging

14.1.1 Conventional Molecular Imaging

One of the most common examples of MI is the use of ¹⁸F-FDG in PET/CT imaging of the brain, heart, and tumors, which involve increased glucose metabolism. Radiolabeled substrates that interact with proteins manufactured from specific genes are used to image the receptors on the cell surface or enzymes in the cytoplasm. ¹¹C-labeled methylspiperone, for example, has been used to image the distribution of dopamine-2 receptors in the brain. MIBG behaves like norepinephrine present in the heart muscles, and ¹²³I-MIBG is used to map the concentration of norepinephrine, which is depleted in patients with congestive heart failure, infracted myocardium, and heart transplants. In ¹¹¹In-labeling of leukocytes, ¹¹¹In binds to cytoplasmic proteins by intracellular exchange reaction with ¹¹¹In-oxine. Although this type of imaging is very common in nuclear medicine, it is limited by a lack of suitable substrates for many proteins. Antibodies have been developed against many antigens (proteins) of specific genes, which are radiolabeled and used to detect the antigens in different normal and abnormal tissues in humans. However, these agents are primarily applicable to proteins on the cell surface and in the vascular compartment because antibodies rarely cross the cell membrane. Success has been achieved with radiolabeled antibodies and their fragments in detecting such cell surface proteins in many clinical situations.

14.1.2 Gene-Based Molecular Imaging

Genes are composed of deoxyribonucleic acid (DNA) molecules, which encode genetic information required to sustain life in living organisms. The genes are responsible for many diseases and therefore have been the primary target of investigation in molecular imaging. A brief description of the subject including the structures and functions of DNA molecules and genes is presented here.

DNA is made up of nucleotides, which contain a phosphate group, a sugar group, and one of the four nitrogen bases, namely, adenine (A), thymine (T), guanine (G), and cytosine (C). The structure of the DNA molecule is a ladderlike double-strand helix formed by two complementary strands of base-pair nucleotides (Fig. 14.1a). The base pairs are formed in a very specific manner: adenine pairs with only thymine, and cytosine pairs only with guanine. The base pairs form complexes with deoxyribose sugar bearing 3' hydroxyl groups and 5' phosphate groups in each strand of the DNA helix. The two strands are connected by hydrogen bonds between the bases of each strand. The order of these bases in the structure determines DNA's instructions or genetic code for production of proteins.

Somatic cells divide by a process called mitosis in which two exact daughter cells are produced. The daughter cells must have an exact number of chromosomes with the same genes, i.e., identical sequence of bases on the DNA molecules as the parent cell. During a period, called the synthetic (S) phase, prior to mitosis, the



Fig. 14.1 Replication of a DNA molecule. (a) DNA molecule before replication. Note the base pairing between *A* and *T*, and *C* and *G*. (b) Unwinding and separation of a portion of the DNA molecule resulting in unpaired bases on two strands. (c) Free available bases in the cell join appropriately with the unpaired bases on each open strand. (d) New backbones are constructed, producing two complete DNA molecules that are identical to the parent molecule. The replication continues along the DNA chain until the whole molecule is replicated. *A* adenine, *T* thymine, *C* cytosine, *G* guanine

DNA molecule must be duplicated. As seen in Fig. 14.1b, in the replication process, the double-strand DNA molecule unfolds into two separate strands that act as templates, upon which new complementary strands of DNA are synthesized (Fig.14.1c). Within the cell, there is a "storehouse" of new bases, which pair correctly with the bases on the two unfolded strands. Thus, two new DNA molecules are produced, which are exact replicas of the parent DNA molecule (Fig.14.1d).

Genes are composed of segments of DNA molecules, and many genes form a thread-like structure called the chromosome. Genes are the basic units of heredity in the cells of all living organisms. A single gene typically consists of several thousand base-pair nucleotides and occupies a fixed position (locus) on the chromosome. There are estimated 20,000–21,000 genes consisting of nearly 6 billion nucleotides (or 3 billion base pairs) in the human genome, all packaged into 23 pairs of chromosomes, half of which are derived from each parent. The information encoded within the DNA structure of a gene directs the manufacture of proteins that are essential for life-supporting activities within a cell. Structurally, a gene is arranged into segments of DNA coding sequences called exons, which are separated by noncoding sequences called introns. While the exons carry all genetic codes for making proteins, introns do not have any known genetic information.

When a gene is turned on, a protein is produced with its genetic sequences. The main mechanism of activating a gene is the binding of an inducer protein to a promoter site in the front part of the gene. Normally the gene remains in an activated state, guiding the synthesis of proteins as needed, unless some factor turns it off. Negative feedback is a mechanism to switch off the gene. In this case, the presence of excess protein from a specific gene can inactivate the gene, while a lesser amount would turn it on, thus maintaining a balanced supply of the desired protein. Another mechanism of gene regulation is external signaling, in which case an extraneous



Fig. 14.2 A genetic message starts with a double-strand DNA molecule that is read in three-letter words called "codons." When a gene is activated, the DNA molecule unfolds, and all codons in one of the strands are copied to produce mRNA, which directs the order of amino acid in a protein

molecule binds to a gene-specific protein (e.g., receptors), necessitating its replacement and thus turning on the specific gene.

The genetic message is not read as single letters but as three-letter words, which are called "codons." When a gene is activated, the two DNA strands unfold, and all codons containing the genetic message encoded in one of the strands are first copied to produce ribonucleic acid (RNA) by the enzyme, RNA polymerases, in a process called transcription (Fig. 14.2). The RNA transcript is stabilized by adding a cap of 5-methylguanine to 5' end and a cap of a series of adenines to the 3' end. This single-strand RNA is complementary to the DNA strand and differs from the DNA molecule by having uracil instead of thymine in its structure. This is called the primary transcript or the pre-messenger RNA (mRNA). The pre-mRNA molecule is released, while the two original strands of DNA recombine to form the original DNA molecule. Since introns are not needed for protein production, they are spliced out of the pre-mRNA molecule to create the so-called messenger RNA (mRNA). The mRNA molecules are typically several hundred to many thousand base-pair long. After the transcription in the nucleus, the mRNA molecule crosses the nuclear membrane and moves into the cytoplasm (Fig. 14.3). The mRNA molecule binds to polyribosome present on endoplasmic reticulum in the cytoplasm, and then the translation process takes place to produce proteins. In the translation process, each codon of mRNA attracts a specific carrier molecule, called transfer RNA (tRNA), which carries a specific amino acid. On approach to the vicinity of the mRNA molecule, the tRNAs attach the amino acids like beads on a string, one at a time, thus forming a peptide. The translation process is stopped by a stop codon at the end of the RNA molecule. Both mRNA and peptide fall off the polyribosome, followed by rapid degradation of mRNA. The peptides then aggregate to form proteins that are distributed inside and outside the cells (Fig. 14.3). The outside proteins are either bound to the cell surface or released in the vascular compartment. There are estimated 115,000 proteins that carry out all essential functions of life inside and outside cells, whereas an estimate of 250,000 to 1 million proteins also has been reported. A typical cell weighs about a nanogram and contains 1–5 picogram (pg) of DNA and 10-50 pg of total RNA that has 10,000-50,000 mRNAs; 2-4% of total RNA is mRNA. The RNA/DNA ratio in a cell is about 10.



Fig. 14.3 A schematic pathway of DNA replication to protein formation. A DNA molecule unfolds, and one of the two strands is copied to form a pre-mRNA molecule. The nonessential introns are spliced out of pre-mRNA to produce an mRNA molecule, which then directs the synthesis of a protein via a process called translation. The proteins are enzymes, receptors, etc., which are distributed inside and outside the cell to maintain essential functions of life

Alterations in the DNA molecule that predispose to diseases may exist from birth (genetic defects) or may be acquired during the course of life (mutation). The DNA molecule replicates countless times during protein synthesis, and occasional mistakes in DNA replication can cause damages to DNA. Also, extraneous factors, such as radiations, chemicals, viruses, etc., can damage the DNA molecules. These changes lead to mutations of the genes, which, at times, cannot be corrected by the cells. Consequently, gene expression is altered in the cell, resulting in specific diseases related to the mutated genes. Molecular biologists are pursuing challenging research to identify genes responsible for various diseases. Once identified, the genes can be manipulated directly by transferring new or missing genes (gene therapy). Specific therapies targeted at specific genes can be developed. Screening can be used for assessment of disease risk in groups of people with specific genetic disorder. Radiolabeled probes can be designed to detect various diseases caused by specific genes.

14.1.3 Oligodeoxynucleotide Antisense Probes to Image mRNA

As already mentioned, only one of the two DNA strands is transcribed into a singlestrand mRNA. Because the sequence of base pairs in the mRNA determines the



Fig. 14.4 A schematic representation of how radiolabeled antisense oligonucleotides (RASONs) stop the synthesis of protein by forming a complex with an mRNA molecule

series of amino acids that will string together to make proteins, the mRNA sequence is said to contain genetic message in correct "sense" orientation. A group of molecules called the "antisense" oligonucleotides (ASON) that are a complementary or genetic mirror to a portion of the much longer mRNA molecules have been developed. The ASONs are typically 15–30 base-pair-long DNA segments and bind to their complementary portions of the mRNA molecule, producing a short doublestrand sequence along the otherwise long single-strand mRNA molecule. This ASON–mRNA complex prevents the translation process and in turn the production of protein on polyribosome (Fig. 14.4). The cell considers the double-strand portion of the complex as abnormal, and so an enzyme, called ribonuclease H, degrades them, and consequently the gene expression stops. Since gene expression can be arrested by ASONs at the transcription level prior to protein synthesis in a cell, many diseases (cancer, cardiovascular diseases, etc.) can possibly be treated using an ASON for specific mRNA responsible for a disease.

Investigators have explored the use of ASONs as both therapeutic and diagnostic agents against mRNAs from various genes including those of human immunodeficiency virus (HIV). Dewanjee et al. (1994) used the radiolabeled ASON (RASON) probe for nuclear imaging of amplified c-*myc* oncogenes using ¹¹¹In-labeled phosphodiester and monothioester. However, RASON imaging has several serious limitations. The RASONs have high affinity for mRNA, but they bind to only a fraction of all base pairs (several hundreds to thousands) of mRNAs due to its secondary and tertiary structure. In vivo, the RASONs containing phosphodiester linkages are rapidly degraded by enzymes in serum resulting in low target uptake and raising the background on images. Also the plasma clearance of RASONS is slow.

14.1.4 Reporter Genes for Imaging

Measurement of gene expression is accomplished by several methods such as Southern, Northern, and Western blot methods and the hybridization technique. A new technique has been introduced to monitor gene expression using the so-called reporter genes. A reporter gene is a defined encoded nucleotide sequence that upon



Fig. 14.5 A schematic presentation of the use of a radiolabeled reporter gene probe to detect a specific gene expression

introduction into a biologic system forms proteins following its expression. Reporter genes are introduced into target cells of interest by the transfection technique. The end product (protein) of the reporter gene, after transcription and translation processes, can be detected by a number of analytical assays. Some examples of the reporter genes are glucuronidase, green fluorescent proteins (GFPs), luciferase, β -galactosidase, alkaline phosphatase, cytosine deaminase (CD), and herpes simplex virus type 1 thymidine kinase (HSV1-tk). For example, when alkaline phosphatase is introduced into a cell, the final protein produced from this gene is secreted in the blood. Similarly, if the cells are infected with a HSV1-tk reporter gene, the viral thymidine kinase is expressed, which phosphorylates pyrimidine and purine nucleoside derivatives, causing them to be trapped intracellularly.

Monitoring of the reporter gene expression can be accomplished by assaying their phenotype end products (enzymes, receptors, etc.) using a variety of methods, namely, fluorescence, chemiluminescence, absorbance, magnetic resonance imaging, and radiolabeled probes. The use of radiolabeled reporter probes to monitor and quantitate gene expression has brought considerable interest among research scientists (Fig. 14.5).

Synthetic purine nucleosides such as acyclovir and ganciclovir are used to treat herpes simplex virus infection. These analogs are phosphorylated to triphosphate analogs by various cellular enzymes, which are then incorporated into DNA to form templates that bind to and inactivate viral DNA polymerases, thus preventing the replication of the viruses. Based on this concept, ¹⁸F-labeled fluoroacyclovir (9-[2-hydroxyethoxymethyl] guanine) (FACV), fluoroganciclovir (9-[[2-hydroxy-1-(hydroxymethyl]ethoxy]methyl] guanine) (FGCV), and fluoropenciclovir (9-[4-hydroxy-3-hydroxy-methylbutyl]guanine) (FPCV) have been used as reporter gene probes to image and monitor the HSV1-tk viral expression. Two other nucleosides, 9-[(3-fluoro-1-hydroxy-2-propoxyl)methyl] guanine (FHPG) and 9-(4-fluoro-3-hydroxymethylbutyl)guanine (FHBG), both labeled with ¹⁸F, have been used as reporter probes for positron emission tomography (PET) imaging of HSV1-tk expression. Uracil nucleoside derivatives such as 5-iodo-2'-fluoro-2'-deoxy-1- β -D-arabinofuranosyluracil 2'-fluoro-5-methyl-*β*-D-(FIAU) and arabinofuranosyluracil (FMAU) labeled with ¹²⁴I, ¹²³I, and ¹³¹I have been utilized as probes to study the HSV1-tk expression. In typical studies, a virus containing HSV1-tk is introduced in vivo into animals, and 24-48 h later, the radiolabeled reporter probe is injected intravenously. The animals are then imaged 24-48 h later by SPECT or PET, and a good correlation between the level of gene expression and the uptake of the probe is obtained. The possibility of assessment of endogenous gene expression is also under investigation, provided an appropriate probe is available.

Another well-recognized reporter gene is dopamine-2 receptor (D2R) reporter gene, which is expressed mainly in the brain. Several D2R ligands labeled with ¹⁸F [e.g., 3-(2'-¹⁸F-fluoroethyl)spiperone (¹⁸F-FESP)] and with ¹²³I (e.g., ¹²³I-iodobenzamide) have been used as reporter probes to image D2R expression.

14.2 Gene Therapy

Gene therapy is one of the most rapidly evolving areas in medicine. The strategy of gene therapy is based on the understanding of different diseases caused by defects in genetic constructs. In genetic deficiency, therapy is aimed at restoring the function that is caused by genetic mutation. In oncology, appropriate genes causing the cancer can be used to modify the tumor cells to prevent their growth or to prime host cells to generate antitumor activity. Gene therapy also can be employed to delay or inhibit the progression of chronic diseases caused by specific genes.

14.2.1 Gene Delivery

Gene therapy calls for delivery of the respective gene by ex vivo or in vivo routes. Each of these methods is unique in its approach, embracing both advantages and disadvantages. In the ex vivo technique, the target cells are removed from the host, and defective genes are removed from the cells. The cells are transfected with the corrective genes and then redelivered to the host. In the in vivo technique, some carriers are used to carry the gene in vivo to the appropriate target cells. These carriers are called "vectors," in which a gene of interest is packaged for delivery to the target cells. Viruses are ideal vectors. Vectors can be either viral or nonviral, and their delivery can be made via inhalation and intramuscular or intravenous administration. Several approaches of gene delivery are briefly discussed below.

Adenoviral Vectors

Adenoviruses are viruses with a double-strand DNA that rarely integrates into the host DNA but elicits strong immune response that worsens with repeated administrations. Although various cells can be transfected by these vectors, the respiratory tract cells are most vulnerable. Genes required for replication are deleted from these viruses, and corrective genes for transfection are inserted into them, after which the infected viruses are delivered to the cells that are vulnerable to infection by adenoviruses. Genes intended for diagnosis or therapy can be delivered to the target of interest by this technique. High titers of these viruses can be produced in in vitro culture media, allowing the possibility of efficient gene transfer.

Retroviral Vectors

Retroviruses contain a single-strand RNA genome. It is converted into DNA, which, unlike adenoviruses, is incorporated into the host DNA. These viruses are replication deficient and are the widely used viruses both experimentally and clinically. Retroviral genes, namely, *gag*, *pol*, and *env*, are substituted with genes of specific interest to be delivered by the virus to the host cell. These viruses are available in high titers for efficient transfection but are limited by their small size (so large genes cannot be inserted) and by the fact that they infect only dividing cells.

A group of retroviral vectors, called lentiviruses, are used for transfecting the cells. The human immunodeficiency virus (HIV) is a lentivirus that can be used for the delivery of an intended gene. These vectors can infect both dividing and nondividing cells without any appreciable immune response.

Nonviral Vectors

One of the nonviral vector techniques is to inject DNA directly into the bloodstream. But hydrolysis of naked DNA and its degradation by serum nucleases are the major drawbacks in this approach. Plasmid vectors (an autonomously replicating molecule) have been investigated for the gene delivery but limited by the poor efficiency in transfection of the host cells. Liposomes carrying the desired gene have been prepared and used for the gene delivery but are markedly less efficient than virus-mediated transfer.

14.2.2 Specific Diseases

Cystic fibrosis is developed by mutations in the cystic fibrosis transmembrane regulator (CFTR) gene causing abnormal transmembrane conductance. The disease is characterized by increased pulmonary infections and obstructions to bowel transit due to abnormal secretions in pulmonary and gastrointestinal epithelium. Gene therapy is aimed at restoring CFTR gene expression by using liposomal and adenoviral vectors to deliver the CFTR gene to bronchial epithelium.

Severe combined immunodeficiency disorder is encountered when adenosine deaminase gene is deficient, resulting in the accumulation of a toxic level of deoxyadenosine to cause T-cell death. This disorder has been treated by injecting the adenosine deaminase gene in vivo into the peripheral blood lymphocytes.

Several malignant tumors have been treated by gene therapy by either arresting the cell proliferation or enhancing the cell apoptosis. Oncogenes are genes that promote cellular growth and proliferation. These oncogenes can be inhibited by antisense RNA, antibodies, and catalytic RNA that digest oncogene RNA. Antioncogenes, also called tumor suppressor genes, normally suppress tumor malignancy, and so their absence would result in proliferation of the malignant cells. The suppressor genes, p53, causes primary non-small cell lung carcinoma. Injection of retroviral p53 gene complexes shows tumor regression in patients having this malignancy.

Apoptosis is a normal cellular process by which cells undergo programmed death, eliminating aged or damaged cells from the system. This process keeps a balance between cell growth and cell death. It has been shown that the absence or aberration of apoptosis is responsible for the development of malignancy in several instances. The *fas* gene is involved in triggering apoptosis, and so inserting this gene can shift the balance from cell proliferation in malignancy to apoptosis. ^{99m}Tc-labeled annexin V has been used to image apoptosis in acute transplant rejection.

Another paradigm of gene therapy is the use of cytokines to increase antitumor immunity. These cytokines include interleukin-2 (IL-2), IL-4, IL-12, granulocyte–monocyte colony-stimulating factors (GM-CSFs), tumor necrosis factors (TNFs), and interferons. When appropriate genes are inserted into the peripheral blood, lymphocytes or tumor-infiltrating lymphocytes are activated, and antitumor activity is induced, inhibiting the cell growth.

Suicide genes induce production of a chemical by the tumor cell itself that turns out to be lethal to the cell. A specific example of a suicide gene is HSV1-tk that easily infects the tumor cells. If a prodrug (e.g., acyclovir or ganciclovir) is injected systematically, it is converted by cellular kinases into toxic triphosphate derivatives. The latter are incorporated into DNA that leads to DNA chain termination, causing cell death. Colon carcinoma has been treated with a suicide gene, cytosine deaminase gene, that upon expression produces 5-fluorouracil, which has antitumor activity.

Peripheral limb ischemia and atherosclerosis are caused by endothelial cell dysfunction due to lack of angiogenic factors such as vascular endothelial growth factor (VEGF). In an approach to improve blood flow by promoting angiogenesis in ischemic vessels, VEGF encoding DNA has been applied onto angioplasty catheters and a reduction in restenosis rates obtained due to early endothelialization. Similar VEGF gene therapy has also been applied to the cases of bypass grafts, where inserted genes alter the thrombogenicity of the prosthetic grafts by stimulating neoendothelialization.

The above is a brief synopsis of the tremendous potential that molecular genetics and gene therapy can offer. Many new techniques, probes for imaging, discovery of genes responsible for various diseases, and various vectors for gene delivery are only a few of the numerous issues that will unfold in the future and provide clues to solving many diagnostic and therapeutic problems related to a variety of diseases.

14.3 Nanoparticle Imaging

Nanoparticles are particles of crystal structure having at least one dimension of 100 nm or less. These particles are manufactured by using elements such as carbon, gold, cadmium, and iron. These are basically built from groups of atoms and are similar in size to virus, DNA, and protein. The use of nanoparticles is diverse with a wide range of applications in engineering, electronics, energy productions, and medicine.

The most common distinctive feature of nanoparticles is their small size at nanometer scale, which makes their characteristics uniquely different. The concept of nanotechnology was introduced by Feynman in 1959, but it was not until early 1980s that nanotechnology and nanoscience were fully started. In 1985, fullerenes were discovered and carbon nanotubes a few years later. Along the way, various semiconductor crystals were prepared by nanotechnology using metal and metal oxide nanoparticle and quantum dots.

The synthesis of nanoparticles is grouped into two general categories: "topdown" and "bottom-up" methods. The top-down method, also called attrition method" involves breakdown of bulky solid into smaller units and includes the techniques of ball milling or grinding of solid into atomic particles of various sizes followed by the separation of nanoparticles from the mixture. The latter is accomplished by a process called elutriation in which a liquid is passed up a vertical tube at a controlled velocity, while inserting the ground particles sidewise into the tube. The larger particles (size of μ m) sediment to the bottom, whereas nanoparticles (<100 nm) flow with the liquid, wherefrom they are separated by evaporation.

The bottom-up method is more popular and employs a variety of techniques such as pyrolysis and liquid phase fabrication. Pyrolysis involves forcing a vapor precursor (gas or liquid) through a small hole at high pressure and burning them, which results in solid residue (a sort of soot). Oxide particles are then recovered from byproduct gases by elutriation. Conventional pyrolysis, however, often leads to larger aggregate particles instead of single particles. So thermal plasma (temperature of 10,000 K) has been used to vaporize solid precursors, and nanoparticles are formed on cooling while exiting the plasma region.

The liquid phase fabrication includes three methods: solvothermal, sol–gel, and synthesis in structure media. In the solvothermal technique, precursors are dissolved in a solvent (e.g., butyl alcohol) under moderate to high pressure (typically between 1 and 10,000 atm) and at temperature (typically between 100°C and 1000°C) that facilitates the interaction of precursors during synthesis. Various nanoparticles of different size and shape can be prepared by this technique. Examples are gold nanoparticles and quantum dots (see below).

The sol-gel method is a liquid phase fabrication in which nanoparticles are produced by wet chemical synthesis that involves transformation from liquid precursors to a sol and finally to a network structure called a gel. A sol is formed by hydrolysis and condensation of metal alkoxide precursors but can be more generally defined as a colloidal suspension, which encompasses a wider range of systems. The sol-gel process can be summarized in the following key steps (Danks et al. 2016):

- (i) Synthesis of the 'sol' from hydrolysis and partial condensation of metal alkoxides
- (ii) Formation of the gel via polycondensation to form metal–oxo–metal or metal– hydroxy–metal bonds
- (iii) Syneresis or 'aging' where condensation continues within the gel network, often shrinking it and resulting in expulsion of solvent
- (iv) Drying the gel either to form a dense 'xerogel' via collapse of the porous network or an aerogel, for example, through supercritical drying
- (v) Removal of surface M–OH groups through calcination at high temperature up to 800°C (if required)

The sol-gel synthesis offers the most desirable properties of nanoparticles, namely, they are produced in dispersion so as to prevent their agglomeration and can be tailored to have all particles of the same size and chemical composition.

As newer and more efficient techniques are introduced, nanotechnology is progressing exponentially providing advanced applications in various fields including medicine, electronics, consumable products such as clothing and sunscreen lotion, gas and oil industry, and so on. The primary use of nanoparticles in medicine is to reveal the structure and function of the biosystem, which in turn transcends into the diagnosis and treatment of human diseases. Some important features of nanoparticles for use in medicine are:

- 1. The surface of nanoparticles can be protected with various molecules in order to prevent destruction by the immune system.
- 2. The sizes and properties of nanoparticles can be controlled to facilitate penetration into physiological barriers such as blood–brain barrier.
- 3. Nanoparticles can be used for drug delivery at the site of disease.
- 4. Nanoparticles can be made of supermagnetic materials such as iron oxide and coated with polymer for use in magnetic resonance imaging.
- 5. Ligands such as monoclonal antibodies can be attached to nanoparticles for the purpose of targeting tumors (Fig. 14.6).
- 6. Conjugated nanoparticles can be radiolabeled for nuclear imaging by attaching a radionuclide of interest to the antibody (Fig. 14.6).

A special group of materials called *quantum dots*, also known as nanocrystals, are made of various metallic compounds and possess unique properties of semiconductors. They are small in size with 2–10 nm in diameter and are collections of atoms in circular or elliptical forms with electrons and holes at the center. They are widely used in electrical circuits and optical applications. The unique property of quantum dots is the fluorescence property, i.e., when light is shone on these particles, they absorb it and reemit light of different wavelengths causing fluorescence. Colloidal quantum dots are synthesized from precursors dissolved in solutions by heating at high temperature. Examples of colloidal quantum dots are cadmium selenide, cadmium sulfide, indium arsenide, and indium phosphide. Quantum dots can be designed to bind to many proteins, gene, receptors, etc. and labeled with radionuclides for in vivo imaging.



Fig. 14.6 The surface amino acid groups of polyaspartic acid (PASP)-coated iron oxide nanoparticle are coupled to a macrocyclic chelator such as DOTA, which then binds with a radionuclide such as ⁶⁴Cu for PET imaging. This particle can also be used for MR imaging, thus serving as a dual imaging agent

However, routine clinical application of nanoparticles in nuclear medicine is limited thus far. An excellent review on clinical investigation of nanoparticles is reported by Baetke and Kiessling (2015). In the following section, only a brief description of the use of nanoparticles in nuclear medicine is presented.

Liposomes of nanoparticle structure and size have been used for drug delivery for many years. They are made of a bilayer of phospholipid surrounding a central aqueous phase. Drugs are encapsulated in the aqueous phase or in the lipid layer depending on the technique of production. To improve its bioavailability and also to minimize their toxicity and degradation, liposomes are often coated outside with polyethylene glycol (PEG). Polymeric nanoparticles are other examples that act as colloidal carriers for drugs, but they have the disadvantage of cytotoxicity for macrophages.

In nuclear medicine, ¹¹¹In-DTPA-labeled PEG-coated liposomes have been used in patients to study their biodistribution and pharmacokinetics and found to localize in tumors along with significant uptake in reticuloendothelial system. Also, it has been reported that iron oxide nanoparticles have been labeled with ¹⁸F, which were used in both PET/MRI and PET/CT studies. ⁶⁴Cu-labeled folate-conjugated nanoparticles have been used for tumor imaging (Rossin et al. 2005), and ^{99m}Tclabeled organo-germanium nanoparticles ranging in size 60–80 nm have been reported for use in spleen imaging (Park et al. 2006). Because of the size difference, the physical and chemical properties of nanoparticles differ considerably from those of bulk materials and may have harmful interactions with biological systems and environment, with potential to generate toxicity. Carbon nanotubes are shown to cause lung cancer. FDA, EPA, and OSHA are examining the safety of these nanoparticles in all aspects of their use and likely to implement appropriate regulations to restrict their use in a harmful way.

14.4 Theranostics

Theranostics is a modality in which diagnosis and therapy for a disease are combined for accurate detection and efficacious treatment of a disease, and the term is coined from these two words. It involves the administration of a diagnostic agent to localize a disease as a surrogate for a potential therapeutic agent with same or similar properties. In addition to diagnosis and treatment of a disease, it helps monitor response to therapy. Conventional treatments of diseases following traditional diagnostic methods are often nonspecific because of the heterogeneous in vivo behavior of the therapy and diagnostic agents and offer only suboptimal results. Combination of the same or similar agents for both diagnosis and treatment has evolved into a new discipline of "personalized or individualized medicine", which results in targeted treatment of the disease with high specificity and improved quality of patient care. Theranostics is cost-effective and precise and plays a strong role in the drug development.

A prime example of a theranostic agent that has been in practice for decades is ¹³¹I for diagnosis and treatment of thyroid disorder. A low dosage of ¹³¹I-NaI is used for the detection of thyroid disease, and depending on the thyroid iodine uptake value, a higher dosage is used for the treatment. Here the same tracer is being used for diagnosis and treatment resulting in good therapy and prognosis. Over the years, the principle of theranostics has diverged into a variety of fields, namely, pharmacogenetics, proteomics, biomarker profiling, nanomedicine, and oncology. Some examples of theranostic modality are presented below.

Porphyrins are molecules suited for both imaging and therapeutic applications fulfilling the theranostic principle. They have been used as contrast agents in MR imaging, and their optical properties lend themselves as fluorescent probe in optical imaging. On the other hand, they are also sensitive to light that interacts with them producing oxygen leading to photodynamic therapy (PDT). Tumors have been detected and treated by such fluorescent/photodynamic properties of porphyrins.

Theranostic approach has been successfully applied for treatment of neuroendocrine tumors (NET) in which somatostatin receptors are overexpressed. ¹¹¹In-labeled octreotide and ⁶⁸Ga-labeled DOTATOC and DOTATATE have been used to accurately detect the NETs by SPECT and PET imaging, pointing to the targeted therapy. ¹⁷⁷Lu-DOTATATE (¹⁷⁷Lu-oxodotreotide or Lutathera) and ⁹⁰Y-DOTATATE are the most successful therapeutic agents for NETs. Because diagnostic and therapeutic agents are the same, detection and cure rate of these tumors has significantly improved.

Nanoparticles (quantum dots, carbon nanotubes, liposomes, metal nanoparticles, etc.) offer as multifunctional platforms for cancer theranostics. Liposomes are very small spherical sacs of phospholipid molecules, which can be used to encapsulate

biomolecules and drugs for delivery to the target. Quantum dots are semiconductor nanocrystals made of metal (Cd, Zn) selenide or sulfide having size of 2–10 nm. When exposed to UV light, they glow and are utilized for the detection and killing of the cancer cells. However, the toxicity of nanoparticles in normal tissues is a major concern for clinical use, although effort is being made to prepare target-specific nanoparticles. A review by Xie et al. (2010) on the clinical use of nanoparticles addresses some of these issues.

The antibody ibritumomab (Zevalin) has been developed against CD20 antigens that are expressed in refractory low-grade non-Hodgkin's lymphoma and has been labeled with ¹¹¹In for diagnostic imaging (Chaps. 7 and 13). These antibodies have also been labeled with the β -emitter ⁹⁰Y for use in the treatment of CD20-positive non-Hodgkin's lymphoma (Chap. 15). Theranostic approach involves the detection and assessment of the in vivo uptake and distribution of ¹¹¹In-Zevalin to localize abnormal tissues, which is followed by subsequent therapy with administration of ⁹⁰Y-labeled Zevalin.

14.5 Translational Medicine

Translational medicine (TM) is a branch of biomedical science that deals with transfer of basic research knowledge in the laboratory to clinical uses in humans, often termed as "bench-to-bedside" strategy, and then to practice settings and communities for improved healthcare (Woolf 2008). As implied in the definition, TM entails two steps: The first step T1 involves the application of basic research information on a disease condition to clinical trials in patients. The primary criteria of T1 research is to promote the exchange of basic research information and clinical trial information for a better understanding of patient care. The second step T2 involves the transfer of clinical trial data to practice settings and communities to assess the patient outcome for improved healthcare. T2 research involves the assessment of clinical trial information in a large population to achieve its goal. Although T1 and T2 seem to be two distinct categories, they are essentially tied in a continuum and are interfaced with each other. While the discovery of a drug for a disease is an end point for T1 research, it is a starter for T2 research.

TM is an interdisciplinary field encompassing different disciplines, resources, techniques, and expertise to foster transition from basic data to clinical therapy. TM has become the cornerstone of the drug industries for efficient and successful drug discovery and delivery with substantial financial benefit. Until a decade or so ago, no cohesive effort was made for such transition causing a significant economic fallout in healthcare industry. Because TM correlates and coordinates the data from different disciplines and applies them to clinical uses without duplication of effort, it has become more cost-saving and less time-consuming.

To illustrate an example of translational medicine, one can look at a drug, metformin, which is routinely used to treat diabetes. When it was discovered, it was first tested in animals and then in limited number of patients to establish its efficacy and safety in humans (T1). Then the drug was tested in a large number of patients preferably in different countries to assess the treatment outcome (T2) in general population. In the process, input from different disciplines such as chemists, biologists, computer specialists, clinicians, epidemiologists, etc. is required. The T2 research prompts the marketing and distribution of the drug. The entire process of TM fosters the growth of drug discovery fast and cost-effectively.

In view of the cost and time-saving aspect of TM and its beneficial effect on improvement in healthcare, institutions in many countries have adopted it as a distinctly separate discipline for which programs of courses and training in TM have been established. At the same time, drug industries have devoted much resources to develop different drugs to put through translational medicine process for their own financial benefit. In 2011 in the USA, the National Institute of Health had established the National Center for Advancing Translational Science (NCATS) to expedite the translational process for speedier cure of patients. It has a Clinical and Translational Science Awards (CTSA) program that financially supports more than 65 centers across the country that are involved in translational medicine. For example, with support from NCATS' CTSA program, scientists at the University of California, Los Angeles, recently produced the clearest-ever image of telomerase, an enzyme involved in cancer and aging. This knowledge could lead to the development of anticancer and antiaging therapies (http://www.ncats.nih.gov/ctsa/about/action/2016). Parallel to the NCATS within the NIH in the USA, the European Society of Translational Medicine (EUSTM) is the organization that carries out the goals of translational medicine in the European Union.

Questions

- 1. Describe how a protein is synthesized by the activation of a gene.
- 2. What is the estimated number of genes in a human genome, and how many proteins carry out the functions of life?
- 3. Describe different methodologies used in molecular imaging, and discuss their merits and disadvantages.
- 4. Discuss different techniques of gene delivery.
- 5. Elucidate some specific diseases that can be diagnosed or treated by gene technology.
- 6. What is a nanoparticle? What are the important features of nanoparticles? How do they differ from bulk material?
- 7. What is a quantum dot? What are their unique properties?
- 8. Define theranostics and discuss its benefit in molecular imaging.
- 9. What is the essential point of translational medicine?

References and Suggested Reading

- Baetke LT, Kiessling F. Applications of nanoparticles for diagnosis and therapy of cancer. Br J Radiol. 2015;88:1054.
- Bentola LA, Ebenstein Y, Weiss S. Quantum dots for in vivo small-animal imaging. J Nucl Med. 2009;50:493.
- Blasberg R. PET imaging of gene expression. Eur J Cancer. 2002;38:2137.
- Danks DA, Hall SR, Schnepp Z. The evolution of 'sol-gel' chemistry as a technique for materials synthesis. Mater Horiz. 2016;3:91.
- Dewanjee MK, Ghafouripour AK, Kapadvanjwala M, et al. Noninvasive imaging of *c-myc* oncogene messenger RNA with indium-111-antisense probes in a mammary tumor-bearing mouse model. J Nucl Med. 1994;35:1054.
- Gambhir SS. Imaging gene expression. In: Schiepers C, editor. Diagnostic nuclear medicine. New York: Springer; 1998. p. 253.
- Gambhir SS. Molecular imaging of cancer with positron emission tomography. Nat Rev Cancer. 2002;2:683.
- Gao X, Chung LW, Nic S. Quantum dots for in vivo molecular and cellular imaging. Methods Mol Biol. 2007;374:135.
- Luker GD, Piwnica-Worms D. Beyond the genome: molecular imaging in vivo with PET and SPECT. Acad Radiol. 2001;8:4.
- National Institute of Health, National Center for Advancing Translational Science. http://www.ncats.nih.gov/ctsa/about/action/2016.
- Park SH, Gwon HJ, Shin J. Synthesis of ^{99m}Tc-labeled organo-germanium nanoparticles and their in-vivo study as a spleen imaging agent. J Labelled Comp Radiopharm. 2006;49:1163.
- Ross DW. Introduction to molecular medicine. New York: Springer; 1992.
- Rossin R, Pan D, Turner J, et al. ⁶⁴Cu-labeled folate-conjugated shell cross-linked nanoparticles for tumor imaging and radiotherapy: synthesis, radiolabeling, and biologic evaluation. J Nucl Med. 2005;46:1210.
- Sharma V, Luker GD, Piwnica-Worms D. Molecular imaging of gene expression and protein function in vivo with PET and SPECT. J Magn Reson Imaging. 2002;16:336.
- Thakur ML, Lentle B. Joint SNM/RSNA molecular imaging summit statement. J Nucl Med. 2005;46:11N.
- Urbain JLC. Reporter genes and imagene. J Nucl Med. 2001;42:106.
- Voss SD, Kruskal JB. Gene therapy: a primer for radiologists. Radiographics. 1998;18:1343.
- Weissleder R, Mahmood U. Molecular imaging. Radiology. 2001;219:316.
- Welch MJ, Hawker CJ, Wooley KL. The advantages of nanoparticles for PET. J Nucl Med. 2009;50:1743.
- Woolf SH. The meaning of translational research and why it matters. JAMA. 2008;299:211.
- Xie J, Lee S, Chen X. Nanoparticle-based theranostic agents. Adv Drug Deliv Rev. 2010;62:1064.

Therapeutic Uses of Radiopharmaceuticals in Nuclear Medicine

15

15.1 Treatment of Hyperthyroidism

Hyperthyroidism is a disease manifested by excessive thyroid hormone activity and can arise from a number of pathogenic processes. Several strategies are employed in the treatment of hyperthyroidism, e.g., the use of antithyroid drugs such as propyl-thiouracil or methimazole, thyroidectomy, and the use of ¹³¹I. Each of these methods has its own merits and disadvantages, but drug therapy and ¹³¹I treatment are the most common choices.

The rationale for radioiodine therapy is that it accumulates in the thyroid and irradiates the glands with its β^- and γ -radiations, about 90% of the total radiation dose being delivered by β^- -particles. Several methods of choosing the treatment dosage of ¹³¹I are currently used. The simplest method is to administer the same amount of ¹³¹I-NaI, nominally 3–7 mCi (111–259 MBq), to all patients having the similar clinical condition of hyperthyroidism. Almost 60% of the patients benefit from a remission of hyperthyroidism within 3–4 months, and a second treatment cures another 25–30%. This fixed activity method has limitations, because the activity administered is arbitrary and has no correlation with either the severity of the disease or the weight of the gland.

The most common method of ¹³¹I treatment is to administer a specified amount of ¹³¹I in microcuries per gram of the thyroid, based on the estimate of the 24-h thyroid uptake and the mass of the glands. An assumption is made that an average biological half-life of ¹³¹I is essentially constant for all patients. The empirical formula for this method is given by

Administered
$$\mu \text{Ci} = \frac{\mu \text{Ci} / \text{g} \times \text{mass of thyroid}(\text{g}) \times 100}{24 \text{h uptake}(\%)}$$
 (15.1)

Many clinicians use a dosage of 55–80 μ Ci (2–3 MBq) per gram for Graves' disease. If one assumes 1 μ Ci (37 kBq) deposited in the thyroid gives 1 rad (0.01 Gy) of radiation dose, then a dosage of 80 μ Ci (2.96 MBq) per gram, for example, would

G.B. Saha, Fundamentals of Nuclear Pharmacy,

https://doi.org/10.1007/978-3-319-57580-3_15

[©] Springer International Publishing AG 2018

give 6400 rad (64 Gy) to 60-g thyroid glands with 75% uptake. The mass of the thyroid is estimated by palpation or by thyroid imaging. For very enlarged glands and severely hyperthyroid patients, larger dosages of 160–200 μ Ci (5.9–7.4 MBq) per gram are given to achieve rapid response.

¹³¹I treatment is contraindicated in pregnant women because ¹³¹I crosses the placental barrier and can cause radiation damage to the fetal thyroid. The fetal thyroid starts to accumulate iodine around the 10th week of gestation, and therefore ¹³¹I treatment at or after this time should be avoided. Also, in the period before the 10th week of gestation, such treatment may give radiation exposure to the fetus and therefore should not be given. It is recommended that a pregnancy test be obtained prior to ¹³¹I treatment for all women of childbearing age. Patients treated with ¹³¹I are advised to delay conception for at least 6 months after treatment.

In Graves' disease, complete remission of hyperthyroidism is achieved in 60% of the patients after treatment. Patients with severe hyperthyroidism, particularly older patients, are treated with antithyroid drugs before ¹³¹I treatment to obtain better results following treatment.

Recurrence of hyperthyroidism after the first treatment is found in about 6–14% of the patients and requires repeat treatments with ¹³¹I. Hypothyroidism is observed in 25–40% of the patients treated, mostly in those patients treated with high dosages of ¹³¹I. To reduce the prevalence of hypothyroidism, smaller or divided dosages of ¹³¹I are given over a longer period of time. After ¹³¹I treatment, drugs such as thioamides, stable iodine, and β -adrenergic blocking agents (propranolol, metoprolol, etc.) are given to patients to control hyperthyroidism.

Toxic multinodular goiters (Plummer's disease) are highly resistant to ¹³¹I treatment and so are treated with higher and multiple dosages of ¹³¹I. The incidence of hypothyroidism is low in this group of patients, because of the resistance to treatment. These patients should be prepared for ¹³¹I therapy with prior antithyroid medication.

In a small number of patients, exacerbation of hyperthyroidism resulting in conditions such as heart failure and thyroid crisis is noted within 3–5 days after ¹³¹I treatment. This results from excessive release of T3 and T4 from the treated thyroid gland. However, the incidence of worsening of hyperthyroidism may be lessened by the use of propranolol prior to treatment.

15.2 Treatment of Thyroid Cancer

Well-differentiated thyroid cancers that include papillary and follicular cancers are treatable with ¹³¹I, because they are capable of concentrating ¹³¹I, although very little. Anaplastic and medullary thyroid cancers do not concentrate ¹³¹I, and therefore ¹³¹I therapy is of no value in the treatment of these cancers. The papillary and follicular cancers metastasize in various parts of the body, and the extent of metastasis often needs to be assessed prior to ¹³¹I treatment.

Prior to ¹³¹I treatment, most patients undergo total or near-total thyroidectomy surgically in which the cancerous tissues plus some normal tissues are removed.

The removal of normal tissues causes hypothyroidism that results in an increase in endogenous TSH, which stimulates residual cancer to localize ¹³¹I. All oral medications of thyroid hormone (T4) are stopped for 6 weeks prior to treatment to raise the level of TSH. Since stable iodine in the blood interferes with ¹³¹I accumulation, a low-iodine diet is also recommended to augment the ¹³¹I uptake by the thyroid. No radiographic contrast examination should be done 6–8 weeks prior to treatment. Sometimes lithium carbonate is administered before ¹³¹I treatment because lithium inhibits the release of ¹³¹I from thyroid cancers.

15.2.1 Whole-Body Imaging

The purpose of whole-body imaging is to detect functioning metastatic thyroid cancer and/or residual normal thyroid tissue and is accomplished by administering ¹³¹I-NaI orally. The dosage for administration is debatable, varying from 2 to 10 mCi (74–370 MBq). However, commonly a 5 mCi (185 MBq) dosage is administered, and whole-body images are obtained 24–72 h later using a gamma camera with a medium-energy parallel hole collimator. At times, spot images need to be taken, and also imaging may be extended for as long as 7 days for equivocal metastatic sites.

Interpretation of whole-body images requires experience and knowledge in the biodistribution of ¹³¹I in the body. Normally, iodide accumulates in the nose, salivary glands, mouth, esophagus, stomach, bladder, colon, and liver, and therefore hot spots in these areas should be interpreted carefully. Hair and clothes contaminated with urine may cause artifacts on the images. Residual thyroid neoplasms occasionally concentrate ¹³¹I and should be correlated with X-ray findings as well as the surgeon's report. Metastatic foci are recognized by the increased uptake of ¹³¹I.

15.2.2 Treatment with ¹³¹I

Patients for ¹³¹I treatment of thyroid cancer fall into two broad groups: those with normal residual thyroid tissue with or without occult metastases and those with functioning primary or metastatic carcinoma. The treatment of the first group is called ablation, and most physicians use 25–30 mCi (925–1110 MBq) ¹³¹I–NaI, although dosages as high as 150 mCi (5.55 GBq) have been used. For the second group of patients, most clinicians use a standard amount of activity, which varies between 100 mCi (3.7 GBq) and 200 mCi (7.4 GBq) depending on the extent of metastatic sites. Smaller dosages are given for cancer remnants in the thyroid bed or cervical lymph node metastasis, whereas larger dosages are given for lung and bone metastases.

Accurate estimation of the radiation dose to the tumor sites is impossible because of the difficulty in determining the volume of distant metastases. The size of tumors and lymph node metastases and their ¹³¹I uptake can be estimated from scintigraphic images, from which the radiation dose to the area may be calculated. Radiation dose from the common dosages of ¹³¹I ranges from 5000 to 30,000 rad (50–300 Gy).

Although radiation therapy with ¹³¹I is safe, there are complications that may be encountered after treatment with ¹³¹I. In the case of ablation of a large amount of thyroid tissues with 30 mCi (1110 MBq) ¹³¹I, acute pain and tenderness of thyroiditis are common. Occasionally, anorexia, nausea, and vomiting are seen as radiation syndromes. Apparently there has been found no increase in the incidence of infertility after treatment with ¹³¹I. Radiation pneumonitis occurs in some patients who have been treated with a high dosage of ¹³¹I for lung metastasis of thyroid cancer.

Bone marrow depression is encountered in patients treated with very high dosages of ¹³¹I. These effects are noticeable in 5–6 weeks after the administration of the dosage. The incidence of leukemia, although low in frequency, has been reported occurring between 2 and 10 years after the treatment, and repeat treatments with ¹³¹I at short intervals increase this frequency.

The parotid and salivary glands concentrate ¹³¹I and receive significantly high radiation dose during treatment. Acute inflammation of the salivary glands (sialadenitis) develops in 10% of the patients treated with ¹³¹I for thyroid cancer. This incidence is more evident with higher dosages of ¹³¹I.

The effectiveness of ¹³¹I therapy for thyroid cancer depends on the location of the metastases. Improvement was found by scanning in 68% of the patients with lymph node metastasis, in 46% of the patients with lung metastasis, and only in 7% of the patients with bone metastasis. Response to treatment is related to the mass of cancer present in a given location. While the treatment of functioning thyroid cancers is of value in the overall management of the patient, the value of ablation therapy is questionable.

Recurrence of thyroid carcinoma takes place in many patients with papillary and follicular carcinoma. For recurrent thyroid carcinoma or remnant metastasis with poor response to previous treatment, repeat treatment with ¹³¹I is given at 3-mo to 1-year intervals depending on the extent, aggressiveness, and location of the metastatic sites. Whole-body imaging should be done annually after treatment until there is no detectable tumor or metastatic uptake for two consecutive years. Other clinical indicators such as TSH, serum thyroglobulin, and radiographic imaging also are obtained to monitor the progress of the treatment. It should be noted that, according to many investigators, ¹³¹I therapy has little use for the treatment of medullary thyroid carcinoma.

15.3 Treatment of Bone Pain

A common complication in cancer patients is the spread of cancer to the bone (bone metastasis) resulting in severe pain. Osseous metastasis is found in 85% of terminally ill patients with breast, prostate, and lung cancer and to a lesser extent with other malignancies. Palliation of bone pain in these patients is the common goal to improve the quality of life. To this end, several strategies are adopted, e.g., the use of analgesics, external radiation beam therapy, and internal radionuclide therapy. The latter is discussed below.

Radionuclide therapy in bone pain palliation is based on the avidity of various radiopharmaceuticals preferentially localizing in the bone. ³²P-orthophosphate has been in use for a long time for bone pain therapy. Two current radiopharmaceuticals, ⁸⁹Sr-SrCl₂ and ¹⁵³Sm-EDTMP, have been found to be useful in palliative therapy of bone pain, because they preferentially localize in osteoblastic sites and destroy the malignant cells with radiations.

15.3.1 ³²P–Sodium Orthophosphate

Phosphorus-32 decays by β^- emission with a half-life of 14.3 days. Its maximum β^- energy is 1.70 MeV. Following intravenous administration, 85% ID is accumulated in the hydroxyapatite crystals, and the remainder localizes in the nonosseous tissues. Since it is incorporated in the structure of DNA and RNA, these structures are damaged by β^- radiations. Bone marrow is the most seriously affected tissues by ³²P radiations.

Approximately 6–12 mCi (222–444 MBq) ³²P–sodium orthophosphate is administered intravenously, and often multiple administrations are made based on the response to the initial treatment. Frequently androgen is given for a week prior to administration of ³²P to enhance the bone uptake of the tracer.

The response rate of ³²P therapy is about 80% and the mean period of response is about 5.1 ± 2.6 months. The common side effect is hematologic toxicity due to bone marrow suppression. Occasionally, an increase in bone pain (bone flare) is seen, which is primarily due to androgen given prior to ³²P administration. However, ³²P therapy has not been accepted widely for palliation of bone pain because of myelotoxicity.

15.3.2 ⁸⁹Sr-Strontium Chloride (Metastron)

Strontium-89 has a half-life of 50.6 days decaying with the emission of a β^- -particle, having a maximum energy of 1.43 MeV. After intravenous administration, it localizes in reactive bone and is excreted in the urine (80%) and feces (20%) with a biological half-life of 4–5 days. Approximately 30–35% of the injected dosage remains in normal bone for 10–14 days postinjection. However, the retention in osteoblastic areas is as high as 85–90% at 3 months postinjection.

Approximately 4 mCi (148 MBq)⁸⁹Sr-SrCl₂ is injected into patients for the relief of bone pain due to metastasis from various cancers. Injection is made slowly over a period of 1–2 min. Patients should have a platelet count of at least 60,000 and a leukocyte count of 2400 at the time of administration. Myelosuppression may occur particularly with higher dosages, thus reducing the platelet and leukocyte counts by almost 25–30%.

Initial relief of pain is usually noticed within 3 days of administration, but it may be as late as 25 days. The mean duration of pain relief is of the order of 3–6 month, and, therefore, retreatments with ⁸⁹Sr may be considered every 3–6 months.

Complete remission of pain is found in 5-20% of the patients after ⁸⁹Sr treatment, and almost 80% of the patients experience some relief of pain from osteoblastic metastasis (Robinson et al. 1995). In 10% of the patients, there is an initial increase in bone pain within ~3 days of therapy that subsides in about a week.

15.3.3 ¹⁵³Sm-EDTMP (Quadramet)

Samarium-153 is a β^- emitter with a maximum energy of 0.81 MeV and decays with a half-life of 1.9 days. It emits a γ -ray photon of 103 keV (28%) that is suitable for scintigraphic imaging. A dosage of 1 mCi/kg (37 MBq/kg) ¹⁵³Sm-EDTMP or lexidronam is administered intravenously to patients targeted for bone pain palliation. ¹⁵³Sm-EDTMP is rapidly cleared from the blood and avidly localizes in the bone. Almost 35% of the injected tracer is excreted in the urine by 6 h postinjection. It appears to be deposited as an insoluble complex on the hydroxyapatite crystals. Relief of pain is found in about 65% of the patients within 1–11 months and may last for a year (Farhanghi et al. 1992). Further relief of pain is achieved with repeat treatments. Myelotoxicity is observed in these patients and is related to the dosage administered.

15.4 Treatment of Liver Cancer

15.4.1 ⁹⁰Y–TheraSpheres

⁹⁰Y–TheraSpheres are primarily indicated for treatment of unresectable hepatocellular carcinoma (HCC) in patients who are capable of having placement of a hepatic arterial catheter. Prior to treatment, the patient is evaluated for the extent of A-V shunting to the lungs by administering 2–4 mCi (75–150 MBq) of ^{99m}Tc-MAA into the hepatic artery, followed by gamma camera imaging. In the absence of extrahepatic shunting, ⁹⁰Y–TheraSphere is administered for treatment. Administration of the tracer is carried out using the preassembled single-use administration set and monitored by a Rados Rad-60R electronic dosimeter. The microspheres are administered directly to the tumor through the hepatic artery catheter where the microspheres are trapped in the tumor and beta radiations from ⁹⁰Y kill the tumor cells along with some normal cells. The average energy of β^- radiations of ⁹⁰Y is 0.94 MeV with an average range in tissues of about 2.6 mm. Considering the half-life of 2.67 days for ⁹⁰Y, the radiation dose to the tissue from an administration of 27 mCi (1 GBq) is 5000 rad (50 Gy).

The recommended dose to the liver is between 8000 rad (80 Gy) and 15,000 rad (150 Gy). The activity required to deliver the desired dose to the liver is calculated by using the following empirical formula:

Required activity (GBq) =
$$\frac{\left[\text{Desired dose}(\text{Gy})\right]\left[\text{Liver mass}(\text{kg})\right]}{50}$$

The mass of the liver is estimated from the CT or ultrasound scan. The net activity administered is determined from the initial vial activity minus the waste activity, and then the corresponding radiation dose to the liver is calculated.

In one clinical study, 22 patients were treated with a mean activity of 105 mCi (3.9 GBq) [range, 54 mCi (2.0 GBq) to 249 mCi (9.2 GBq)] delivering a median liver dose of 10,400 rad (104 Gy) [range, 4600 rad (46 Gy) to 14,500 rad (145 Gy)]. The results showed survival of minimum 49 days to maximum 1265 days. In another study, the median survival following the treatment of HCC with TheraSphere was 3.6 months at doses <8000 rad (80 Gy) and 11.1 months at doses >8000 rad (80 Gy).

Adverse effects from the TheraSphere treatment include elevated bilirubin, SGOT/SGPT, and alkaline phosphatase, ascites, and abdominal pain.

15.4.2 ⁹⁰Y–SIR-Spheres (SIR-TeX)

⁹⁰Y–SIR-Spheres are used to treat unresectable metastatic hepatic tumor from primary colorectal cancer with adjuvant intrahepatic chemotherapy of floxuridine. The dosage is administered through the chemotherapy port placed in the hepatic artery. The distribution of the spheres in the liver is nonuniform with more tumor uptake than normal liver uptake. SIR-Spheres are neither metabolized nor excreted and are permanently lodged in the tumor cells. The β^- radiation from ⁹⁰Y effectively destroys the tumor cells.

Before the treatment is started, the extent of A-V shunt to the lungs is assessed by a lung scan using 4 mCi (150 MBq) of ^{99m}Tc-MAA injected into the hepatic artery through a preinstalled catheter. If the shunt is between 10% and 20%, the dosage is adjusted corresponding to the extent of shunt, whereas treatment is not given if the shunt is greater than 20%. ⁹⁰Y–SIR-Spheres are then administered from the single-dose vial to the tumor through the catheter. Individual dosage is calculated as follows:

For tumor involvement of >50%, the recommended dosage is 81 mCi (3 GBq); for 25–50% tumor involvement, the dosage is 68 mCi (2.5 GBq), and for <25% tumor involvement, the dosage is 54 mCi (2 GBq). Further reduction in dosage is made depending on the extent of lung shunting: 20% reduction for 10–20% shunting, 40% reduction for 15–20% shunting, and no treatment for >20% shunting. In general, 27 mCi (1 GBq) of ⁹⁰Y/kg of tissue provides approximately 5000 rad (50 Gy) radiation dose.

Complete and partial response has been reported in a 3-mo interval, and progression of the tumor is delayed significantly when floxuridine and SIR-Spheres are given together for treatment. Common adverse effects are fever, mild increase in liver enzyme and bilirubin, abdominal pain, nausea, vomiting, and diarrhea. Potential serious adverse effects due to high radiation are acute pancreatitis, radiation pneumonitis, radiation hepatitis, and acute cholecystitis.

15.5 Treatment of Non-Hodgkin's Lymphoma

15.5.1 ⁹⁰Y–Ibritumomab Tiuxetan (Zevalin)

Yttrium-90 decays by β^- emission (100%) with a half-life of 64 h. It has highenergy β^- rays with an effective path length of 5.3 mm, meaning that 90% of $\beta^$ energy is absorbed in a sphere of 5.3-mm radius. ⁹⁰Y–ibritumomab tiuxetan (Zevalin) is an anti-CD20 antibody used for the treatment of non-Hodgkin's lymphoma (NHL).

In the USA, approximately 35,000 people are diagnosed with NHL each year, and 65% of them are of the low-grade or follicular type of NHL. Patients with this type of NHL may remain in remission for years, but eventually have bouts of relapses that tend to be resistant to repeat treatments over time. ⁹⁰Y–ibritumomab tiuxetan is an optional but promising treatment of relapsed or refractory low-grade follicular or CD20 antigen-expressing, transformed B cell NHL in these patients.

Treatment of NHL patients with ⁹⁰Y–ibritumomab tiuxetan is performed only after confirmation of no altered biodistribution by ¹¹¹In-ibritumomab imaging as discussed in Chap. 13 (see Tumor Imaging). Also, the therapy must be preceded by two dosages of 250 mg/m² of rituximab – the first before imaging with ¹¹¹In and the second before the administration of ⁹⁰Y–ibritumomab. The administered dosage is based on body weight and baseline platelet counts, and a typical patient dosage range is 20–30 mCi (740–1110 MBq) with a maximum limit of 32 mCi (1184 MBq). Both rituximab and ⁹⁰Y–ibritumomab tiuxetan target the white blood cells (B cells) including malignant B cells involved in the disease, resulting in significant tumor shrinkage. The overall response rate is found to be 74–80% in about 2 months after therapy in patients who fail to respond to chemotherapy. The most common side effects are the flu-like symptoms and a marked reduction in blood cell counts.

15.6 Treatment of Polycythemia Vera and Leukemia

Polycythemia vera is a disease characterized by an increased red blood cell mass, frequently associated with bone marrow hyperactivity. ³²P–sodium orthophosphate is used for the treatment of polycythemia vera. Therapy results from radiation injury to the cell precursors and the bone marrow due to bone accumulation of ³²P.

Usually 3–4 mCi (111–148 MBq) ³²P in the form of ³²P–sodium orthophosphate is administered intravenously, and 12 weeks later the patient's response is evaluated. In the case of marked elevation of red blood cells, phlebotomy is also instituted simultaneously. If the red cell mass is not reduced sufficiently after the first treatment, a second treatment with 3 mCi (111 MBq) ³²P may be made.

Cases of leukemia have been reported in patients treated with ${}^{32}P$ -sodium orthophosphate. It has been suggested that ${}^{32}P$ should not be used for treatment if the platelet count is less than 15,000/µl. Life expectancy after ${}^{32}P$ treatment has been reported to be 10–12 years.

Leukemia is characterized by a marked increase in leukocytes and their precursors in the blood. Approximately 1–2 mCi (37–74 MBq) ³²P–sodium orthophosphate is given weekly until the white blood cell count is sufficiently decreased. Life expectancy does not increase to a large extent by this treatment.

15.7 Treatment of Prostate Cancer and Its Metastasis

Prostate cancer, if not treated early, progressively spreads over the whole-body bone surface causing the metastasis of the disease. Cancer cells initially are released in the bloodstream from the primary site of the prostate glands and randomly attach to the bone surface where the interphase between bone and red bone marrow promotes tumor cell proliferation. Such bone metastasis can be caused by other cancer cells such as breast cancer, lung cancer, etc. Intolerable bone pain results from metastasis.

Radiation therapy using particulate radiations has been employed to treat various types of cancers. Low-LET β^- -emitters (quadramet and metastron) have been used for bone pain palliation, but low energy of these particles and bone marrow toxicity have limited their use. High-LET α -emitters induce predominantly nonrepairable DNA double-strand breaks, rendering cellular repair mechanisms ineffective against this type of radiation. Because of the shorter track length of α -particle in tissues, bone marrow damage may be limited at effective therapeutic dosages.

²²³Ra-radium chloride (Xofigo) is an α-emitter (5.9 MeV) used for the treatment of castration-resistant prostate cancer and symptomatic bone metastasis. Its production and availability are described in Chaps. 4, 5, and 7. The dosage is administered based on patient body weight at 1.49 µCi (55 kBq)/kg. The treatment regimen includes six injections given at 4-week intervals. Following administration, the blood activity is 12% at 10 min postinjection, 6% 1 h postinjection, and <1% 24 h postinjection (Nilsson et al. 2005). The majority of the activity is eliminated via the intestinal route with some renal elimination. Bone metastatic uptake is demonstrated by scintigraphy. Bone and intestinal uptakes are ~61% and ~49%, respectively, 4 h postinjection.

Bone alkaline phosphatase secreted by osteoblasts serves as a biomarker for the efficacy of ²²³Ra treatment. The median relative decrease in bone alkaline phosphatase 4 weeks after the final injection was ~66% in the ²²³Ra group compared with ~9% in the placebo group. Thrombocytopenia (low platelet count) (all grades) occurred in 11.5% of patients treated with ²²³Ra compared to 5.6% of patients receiving placebo. Neutropenia (low white blood cell count) (all grades) is reported in 5% of patients treated with ²²³Ra and in 1% of patients receiving placebo. Other side effects are diarrhea, nausea, and vomiting. The updated analysis shows the ²²³Ra survival benefit of 14.9 months compared to 11.3 months, with concomitant bone pain palliation.

15.8 Pretargeted Radioimmunotherapy of Cancer

The use of radiolabeled monoclonal antibody (Mab) for the treatment of cancer has the difficulty of higher background activity in the vascular compartment that results in unnecessary radiation dose to normal tissues, particularly bone marrow. To circumvent this situation, investigators have adopted the strategy of pretargeting of tumor cells with an unlabeled Mab, followed later by the administration of a radiolabeled hapten that binds to the antibody in the tumor. The unlabeled antibody in the circulation is removed by complexation with an agent that is injected prior to the administration of the radiolabeled hapten. The complex is rapidly cleared by breakdown in the liver. A review article on this topic has been presented by Goldenberg et al. (2006).

In one common approach, pretargeting is based on the interaction between streptavidin (SA) or avidin and biotin. Avidin, a constituent of the egg white of reptiles, amphibians, and birds, is a protein that can bind up to four molecules of vitamin H, D-biotin with an affinity a million times higher than that between antigen and Mab. Streptavidin (SA) is a bacterial analog of avidin with similar characteristics. In practice, a biotinylated Mab is injected first, whereby the tumor is pretargeted with the Mab. Unlabeled avidin or streptavidin (called the "chase") is given to reduce the blood level of the biotinylated Mab. Radiolabeled avidin is then administered, which avidly binds to biotin in the tumor demonstrating increased tumor uptake with a reduced background. Similarly, tumors can be pretargeted with avidin first, followed by the administration of radiolabeled biotin next.

In another approach, Mabs developed against chelating agents such as ethylenediaminetetraacetic acid (EDTA) or dodecanetetraacetic acid (DOTA) are used to pretarget the tumor. The circulating Mab is removed by injection of transferrin substituted with multiple haptens. Radiolabeled EDTA or DOTA (e.g., ¹¹¹In-DOTA) is then injected, and it avidly binds to the tumor resulting in increased uptake. This method is further improved by using Mabs with dual specificity (called bifunctional or bispecific Mabs). Such bifunctional Mabs or fragments of Mabs have been produced by chemical cross-linking, hybridoma technology, and genetic engineering technique, by which complexes like Mab–Mab or (Fab')–(Fab') are formed. In these conjugated Mabs, one Mab may be against the tumor and the other against a chelating agent.

Tumors are pretargeted with the injection of tumor Mab (or Fab')-chelate or Mab (or Fab') bifunctional Mab (or fragments). Radiolabeled chelate such as ¹¹¹In-chelate or ⁹⁰Y-chelate is injected later, which binds to the bifunctional Mab in the tumor demonstrating increased uptake.

All of the above methods have both merits and disadvantages, and ongoing research is focused on improving each method to increase the tumor-to-background activity ratio for better delineation of tumor localization.

Questions

- 1. Describe the method of treatment with ¹³¹I of patients with hyperthyroidism. Discuss the merits and disadvantages of the method.
- 2. Why is ¹³¹I contraindicated in pregnant women? How long is it advised for the patients treated with ¹³¹I to delay conception?
- 3. What are the frequencies of recurrence of hyperthyroidism and the incidences of hypothyroidism and leukemia in patients after ¹³¹I treatment?
- 4. Describe the rationale for ¹³¹I therapy for patients with thyroid cancer. What are the different strategies for ¹³¹I therapy of thyroid cancer?

- 5. What are the complications observed from the ¹³¹I therapy of thyroid cancer?
- 6. Describe the various treatment methods for palliation of pain from bone metastasis of different cancers. What is the important physiological parameter that is to be considered before and during the treatment?
- 7. Describe the principles of pretargeted radioimmunotherapy in cancers.
- 8. What is the mechanism of ⁹⁰Y–TheraSphere treatment of the liver cancer?
- 9. What is the difference between ⁹⁰Y-labeled TheraSpheres and SIR-Spheres?
- 10. What is Zevalin? What is it used for? What is the mechanism of this treatment?

References and Suggested Reading

- Becker D, Hurley JR. Radioiodine treatment of hyperthyroidism. In: Sandler MP, Coleman RE, FJT W, et al., editors. Diagnostic nuclear medicine. 3rd ed. Baltimore: Williams and Wilkins; 1996. p. 943.
- Farhanghi M, Holmes RA, Volkert WA, et al. Samarium-153-EDTMP: pharmacokinetics, toxicity and pain response using an escalating dose schedule in treatment of metastatic bone pain. J Nucl Med. 1992;33:1451.
- Goldenberg DM, Sharkey RM, Paganelli G, et al. Antibody Pretargeting advances cancer radioimmunodetection and radioimmunotherapy. J Clin Oncol. 2006;24:823.
- Goldsmith SJ. Radioimmunotherapy of lymphoma: Bexxar and Zevalin. Semin Nucl Med. 2010;40:122.
- Hurley JR, Becker DV. Treatment of thyroid cancer with radioiodine (1311). In: Sandler MP, Coleman RE, FJT W, et al., editors. Diagnostic nuclear medicine. 3rd ed. Baltimore: Williams and Wilkins; 1996. p. 959.
- Maxon HR III, Smith HD. Radioiodine-131 in the diagnosis and treatment of metastatic welldifferentiated thyroid cancer. Endocrinol Metab Clin N Am. 1990;19:685.
- Nilsson S, Larsen RH, Foss SD, et al. First clinical experience with α -emitting radium-223 in the treatment of skeletal metastases. Clin Cancer Res. 2005;11:4451.
- Package inserts for Theraspheres and SIR-Spheres.
- Robinson RG, Preston DF, Schiefelbein M, Baxter KG. Strontium 89 therapy for the palliation of pain due to osseous metastases. JAMA. 1995;274:420.
- Salem R, Hunter RD. Yittrium-90-micrrospheres for the treatment of hepatocellular carcinoma: a review. Int J Radiat Oncol Biol Phys. 2006;66:583.

Adverse Reactions to and Altered Biodistribution of Radiopharmaceuticals

16

16.1 Adverse Reactions

An adverse reaction (or event) due to radiopharmaceutical administration is an unusual experience associated with administration of the radiopharmaceutical. Adverse reactions include sensitivity reactions and many systemic and physiologic symptoms. The most common adverse reactions are nausea, dyspnea, bronchospasm, decreased blood pressure, itching, flushing, hives, chills, coughing, bradycardia, muscle cramps, and dizziness. Some adverse reactions appear later in time than others.

The Society of Nuclear Medicine in the USA collects from its members' voluntary reports of adverse reactions due to radiopharmaceutical administration to humans. The Joint Committee on Radiopharmaceuticals of the European Nuclear Medicine Society collects reports on adverse reactions with radiopharmaceuticals in Europe. The overall incidence of adverse reactions in the USA is about 2.3 reactions per 100,000 radiopharmaceutical administrations (Silberstein 1996, 2014). However, no death has been reported, and the incidence of severe reactions has declined in recent years due to better formulation and manufacturing of radiopharmaceuticals.

The number of adverse reactions is probably not as accurate as one would expect, because many nuclear medicine institutions do not consistently report them. With a good mechanism of reporting, perhaps a reliable assessment of the safety of a radio-pharmaceutical could be made. Table 16.1 lists the adverse reactions reported for common radiopharmaceutical obtained from package inserts and literature (Silberstein 1996, 2014).

Most adverse reactions are mild in nature and require no or minimal treatment. Antihistamines are the mainstay for the treatment of severe anaphylaxis. Epinephrine is the agent of choice and is given subcutaneously or intramuscularly, whereas in severe conditions it is given intravenously. In the case of poor response to antihistamine, aminophylline may be given.

Radiopharmaceuticals	Adverse reactions
^{99m} Tc-pertechnetate	Nausea, pruritus, headache, hives, chills, chest pain
^{99m} Tc-sulfur colloid	Cardiopulmonary arrest, seizure, hypotension, dyspnea, chills,
	nausea, fever, pruritus, dizziness
^{99m} Tc-pyrophosphate	Flushing, hypotension, fever, chills, nausea, vomiting, dizziness,
	pruritus
^{99m} Tc-DTPA	Pyrogenic and allergic reactions
^{99m} Tc-MAA	Hypersensitivity to albumin
^{99m} Tc-mebrofenin	Urticaria/hives, chills, nausea
^{99m} Tc-MAG3	Nausea, dyspnea, tachycardia, itching, seizure, chills, fever,
	wheezing
99mTc-sestamibi	Headache, chest pain, angina, nausea, metallic taste
^{99m} Tc-tetrofosmin	Angina, vomiting, dyspnea, respiratory arrest, flushing,
	abdominal pain, hypotension, metallic taste
^{99m} Tc-DMSA	Nausea, rash, flushing, syncope, fever
²⁰¹ Tl-thallous chloride	Fever, rash, pruritus, tremor, dyspnea, blurred vision, diarrhea,
	sweating
¹²³ I–MIBG	Dizziness, rash, pruritus, flushing, headache
¹²³ I–ioflupane	Headache, nausea, vertigo, dry mouth, rash, pruritus
¹²³ I–NaI capsules	Pruritus, vomiting, hives, chest pain
¹³¹ I–NaI	Nausea, vomiting, chest pain, rapid heart rate, itching skin, rash
¹¹¹ In-octreotide	Fever, nausea, flushing, dizziness, headache, hypotension,
	tiredness
¹¹¹ In-DTPA	Vomiting, pruritus, headache, meningitis, pyrogen reactions
¹¹¹ In-capromab pendetide	Hypotension, hypertension, pruritus, fever, headache, increase in
	bilirubin, rash, elevated liver enzyme, asthenia, HAMA reaction,
	shortness of breath
⁶⁷ Ga-citrate	Allergic reactions, skin rash, nausea
¹⁸ F-fluorodeoxyglucose ¹	Flushing of face and trunk

Table 16.1 Reported adverse reactions from radiopharmaceuticals

¹Silberstein (2014)

Four comprehensive reviews on the adverse reactions to radiopharmaceuticals have been published by Silberstein (1996, 2014), Hesselwood et al. (1997), and Laroche et al. (2015).

16.2 latrogenic Alterations in Biodistribution of Radiopharmaceuticals

The effects of various drugs on the biodistribution of radiopharmaceuticals have long been recognized as an important factor in the interpretation of scintigraphic images. Altered biodistribution due to extraneous drugs (iatrogenic alteration) may be undesirable. In most cases, however, patients receive several medications that tend to interfere with the in vivo distribution of the radiopharmaceutical used in a subsequent nuclear medicine procedure. Some drugs enhance the localization of the radiopharmaceutical in the target organ, whereas others depress the uptake. In some cases, biodistribution is shifted to other organs. Knowledge of altered biodistribution due to other drugs helps the physician avoid misinterpretation of the scintigraphic images and thus an incorrect diagnosis. An excellent review article on this issue has been published by Hladik et al. (1987). Different imaging procedures and various drugs that alter the biodistribution of radiopharmaceuticals used in these procedures are listed in Table 16.2.

Imaging	Drug	Effect on localization
Bone imaging with ^{99m} Tc-phosphonate compounds	Melphalan	Increased bone uptake
	Chemotherapeutic agents,	Increased renal activity
	dextrose, iron	
	Cytotoxic therapy	Increased uptake in calvarium
	Meperidine	Soft tissue uptake
	Iron dextran	Increased uptake at injection site
	Phospho-soda, corticosteroid	Decreased bone uptake
RES imaging with	Al ³⁺ , Mg ²⁺	Increased lung activity
^{99m} Tc-SC	Anesthetics	Increased splenic uptake
	Estrogens	Focal areas of decreased uptake in liver
	BCNU	Decreased splenic uptake
Myocardial perfusion	Dipyridamole	Increased myocardial uptake
imaging with 201Tl	Propranolol, digital glycosides	Decreased myocardial uptake
chloride	Furosemide, isoproterenol	Increased myocardial uptake
Hepatobiliary imaging	Cholecystokinin	Increased gallbladder contraction
with 99mTc-IDA	Narcotic analgesics	Prolonged liver-to-duodenum
derivatives		transit time
	Atropine	Prolonged gallbladder activity
	Nicotinic acid	Decreased hepatic uptake
Prostate imaging with ¹¹¹ In-capromab pendetide	Androgen ablation	Decreased uptake in prostate tumor
Parkinson's disease detection with ¹²³ I–ioflupane	Amoxapine, amphetamine, benztropine, bupropion, buspirone, cocaine, selegiline mazindol, methamphetamine, sertraline, methylphenidate, norephedrine, phentermine, phenylpropanolamine	Decreased uptake
Thyroid uptake and imaging with ¹²³ I-, ¹³¹ I–NaI	TcO_4^- , Br ⁻ , ClO_4^- , SCN^- , iodide-containing preparations (Lugol's solution, SSKI, cough medicine, kelp, etc.), contrast media, antithyroid drugs (tapazole, propylthiouracil), natural or synthetic thyroid preparation (cytomel, synthyroid)	Decreased uptake

 Table 16.2
 Iatrogenic alteration in the biodistribution of common radiopharmaceuticals

(continued)

Imaging	Drug	Effect on localization
Tumor and	Iron dextran, desferoxamine	Decreased uptake
inflammatory process	(before ⁶⁷ Ga injection)	
imaging with	Iron dextran, desferoxamine	Increased uptake
⁶⁷ Ga-citrate	(after 67Ga injection)	
	Chemotherapeutic agents	Diffuse lung uptake
	Antibiotics	Uptake in colon and kidneys
	Estrogens	Uptake in mammary tissue
¹²³ I–MIBG for imaging neuroendocrine tumors	Amitryptiline and derivatives, imipramine and derivatives, antidepressants, antihypertensives, sympathomimetic, amines and	Decreased uptake in tumor
	cocaine	
In-vivo ^{99m} Tc-labeling of RBCs	Heparin, dextran, doxorubicin, penicillin, hydralazine	Poor labeling

Table 16.2 (continued)

Questions

- 1. What is an adverse reaction? What is the most common drug that is used to alleviate the effects of adverse reactions?
- 2. Enumerate the drugs that affect adversely the labeling of RBCs.
- 3. What are the common drugs or agents that affect the thyroid uptake of ¹³¹I?

References and Suggested Reading

- Hesselwood S, Leung E. Drug interactions with radiopharmaceuticals. Eur J Nucl Med. 1994;21:348.
- Hesselwood S, Keeling DH, the Radiopharmacy Committee of the European Association of Nuclear Medicine. Frequency of adverse reactions to radiopharmaceuticals in Europe. Eur J Nucl Med. 1997;24:1179.
- Hladik WB III, Ponto JA, Lentle BC, et al. Iatrogenic alterations in the biodistribution of radiotracers as a result of drug therapy: reported instances. In: Hladik III WB, Saha GB, Study KT, editors. Essentials of nuclear medicine science. Baltimore: Williams and Wilkins; 1987. p. 189.
- Laroche ML, Quelven IQ, Mazere J, Merle L. Adverse reactions to radiopharmaceuticals in France: analysis of the national pharmacovigilance database. Ann Pharmacother. 2015;49:39.
- Silberstein EB. Prevalence of adverse events to radiopharmaceuticals from 2007 to 2011. J Nucl Med. 2014;55:1308.
- Silberstein EB. Adverse reactions to radiopharmaceutical agents. In: Henkin RE, Boles MA, Dillehay GL, et al., editors. Nuclear medicine. St. Louis: Mosby; 1996. p. 485.
- Silberstein EB, Ryan J, Pharmacopeia Committee of Nuclear Medicine. Prevalence of adverse reactions in nuclear medicine. J Nucl Med. 1996;37:185; erratum, page 1064.
Appendix A: Abbreviations Used in the Text

Antibody
American College of Radiology
Alzheimer's disease
Atomic Energy Commission
Antigen
As low as reasonably achievable
Annual limit on intake
Antisense oligonucleotides
Blood–brain barrier
Bacterial endotoxin test
Bifunctional chelating agent
Beyond Used Date
Coronary artery bypass graft
Coronary artery disease
Cholecystokinin
Current good manufacturing practice
Centers for Medicare and Medicaid Services
Central nervous system
Cerebrospinal fluid
Compounded sterile preparation
Derived air concentration
Diisopropyliminodiacetic acid
Diiodotyrosine
Dimercaptosuccinic acid
Deoxyribonucleic acid
Department of Transportation
Diethylenetriaminepentaacetic acid
Deep vein thrombosis
Electron capture
Ethyl cysteinate dimer
Ethylenediaminetetraacetic acid
European Medicines Agency
Effective renal plasma flow

G.B. Saha, Fundamentals of Nuclear Pharmacy, https://doi.org/10.1007/978-3-319-57580-3

[©] Springer International Publishing AG 2018

EU	European Union, Endotoxin unit		
FDA	Food and Drug Administration		
FDG	Fluorodeoxyglucose		
GFR	Glomerular filtration rate		
GM	Geiger-Muller		
HAMA	Human antimurine antibody		
HDP	Hydroxymethylene diphosphonate		
HEDP	1-Hydroxyethylidene diphosphonate		
HIDA	N-[N' -(2, 6-Dimethylphenyl) carbamoylmethyl] iminodiacetic acid		
HIV	Human immunodeficiency virus		
HMPAO	Hexamethylpropylene amine oxime		
HSV	Herpes simplex virus		
HVL	Half-value layer		
HYNIC	Hydrazinonicotinamide		
ICANL	Intersocietal Commission for Accreditation of Nuclear Medicine		
ICDD	Laborational Committee on Padiation Protection		
ICKF	International Committee on Radiation Flotection		
	Notice of Claimed Investigational Examption for a New Drug		
	Institutional Daview Deard		
IND	Institutional Review Board		
15U IT			
	Isometric transition		
IILC			
K V koV	Kilovoli Kilo alaatron valt		
	Limulus amahasuta lusata		
	Linuus anebocyte tysate		
LEIK			
LEI	Linear energy transfer		
LSU	Lutetium oxyorinosincate		
MAA	Marcolaggregated albumin		
Mad	Monoclonal antibody		
MAG3	MercaptoacetyIglycyIglycine		
MDP	Methylene diphosphonate		
MEK	Methyl ethyl ketone		
Mev	Million electron volt		
MIRD	Medical internal radiation dose		
MIT	Monorodotyrosine		
mRNA	Messenger ribonucleic acid		
MIC	Medullary thyroid carcinoma		
MUGA	Multigated acquisition		
NARM	Naturally occurring and accelerator-produced radioactive materials		
NCA	No carrier added		
NCRP	National Council on Radiation Protection and Measurement		
NDA	New Drug Application		
NEMA	National Electrical Manufacturers' Association		

NHL	Non-Hodgkin's lymphoma
NMTCB	Nuclear Medicine Technology Certifying Board
NRC	Nuclear Regulatory Commission
PET	Positron emission tomography
PM	Photomultiplier (tube)
PTU	Propylthiouracil
MR	Magnetic resonance
QA	Quality assurance
QC	Quality control
QF	Quality factor
RASON	Radiolabeled antisense oligonucleotide
RDRC	Radioactive Drug Research Committee
R _f	Relative fraction in chromatography
RBE	Relative biologic effectiveness
RIA	Radioimmunoassay
RISA	Radioiodinated serum albumin
RPR	Responsible person for radiopharmacy
RSC	Radiation Safety Committee
RSO	Radiation Safety Officer
SOP	Standards of operational procedures
SPECT	Single photon emission computed tomography
SUV	Standard uptake value
T ₃	Triiodothyronine
T_4	Thyroxine
TBG	Thyroxine-binding globulin
TEDE	Total effective dose equivalent
TIBC	Total iron-binding capacity
TLD	Thermoluminescent dosimeter
TM	Translational medicine
TNF	Tumor necrosis factor
TSH	Thyroid-stimulating hormone
USAN	United States Adopted Names
USP	US Pharmacopeia
V	Volt
VEGF	Vascular endothelial growth factor
Wr	Radiation weighting factor
W _T	Tissue weighting factor

Appendix B: Terms Used in the Text

Absorption	A process by which the energy of
	radiation is removed by a medium
	through which it passes.
Absorption coefficient (μ)	The fraction of radiation energy absorbed
	per unit thickness (linear absorption
	coefficient) or per unit mass (mass
	absorption coefficient) of absorber.
Accelerator	A machine to accelerate charged parti-
	cles linearly or in circular paths by means
	of an electromagnetic field. The acceler-
	ated particles such as α particles, pro-
	tons, deuterons, and heavy ions possess
	high energies and can cause nuclear
	reactions in target atoms by irradiation.
Accuracy	A term used to indicate how close a mea-
	surement of a quantity is to its true value.
Aerobic	A term used to indicate the growth of
	microorganisms in the presence of
	oxygen.
Aliquot	A definite fraction of a measured sample,
*	particularly volume.
Anaerobic	A term used to indicate the growth of
	microorganisms in the absence of
	oxygen.
Annihilation radiation	Gamma radiations of 511 keV energy
	emitted at 180° after a β^+ particle is anni-
	hilated by combining with an electron in
	matter.
Antibody (Ab)	A substance that is produced in response
	to an antigen and forms a specific com-
	plex with it.

Antigen (Ag)	A substance that can induce the produc- tion of an antibody and bind with it
Atomic mass unit (amu)	specifically. By definition, one twelfth of the mass of $\frac{12}{2}$
Atomic number (Z)	${}_{6}^{*}$ C, equal to 1.66 × 10 ⁻²⁴ g or 931 MeV. The number of protons in the nucleus of
Attenuation	A process by which the intensity of radi- ation is reduced by absorption and/or scattering during its passage through
Auger electron	matter. An electron ejected from the outer elec- tron shell by a characteristic X-ray by transferring all its energy.
Average life (τ)	See mean life.
Avogadro's number	Number of molecules in 1 g-mole of any substance or the number of atoms in 1 g stars of any clament. It is equal to
	1 g-atom of any element. It is equal to 6.02×10^{23}
Becauerel (Ba)	Δ unit of radioactivity. One becauerel is
beequerer (bq)	equal to 1 disintegration per second
Rinding energy	The energy to bind two entities together
Zinanig chergy	In a nucleus, it is the energy needed to
	separate a nucleon from other nucleons
	in the nucleus. In a chemical bond, it is
	the energy necessary to separate two
	binding partners at infinite distance.
Biological half-life (T_b)	The time by which one half of an admin-
	istered dosage of a substance is elimi-
	nated by biological processes such as
	urinary and fecal excretion.
Bremsstrahlung	Gamma-ray photons produced by decel-
	eration of charged particles near the
Camion	A stable element that is added in detect
Currier	a stable element that is added in detect-
	same element usually to facilitate chem-
	ical processing of the radionuclide
Carrier-free	A term used to indicate the absence of
	any stable isotopic atoms in a radionu-
	clide sample.
Chelating agent	A compound that binds to a metal ion by
	more than one coordinate covalent bond.
Collimator	A device to confine a beam of radiation
	within a specific field of view. Collimators

	may be converging, pinhole, diverging,
	and parallel-hole types.
Colloid	A dispersion of a substance in a liquid.
	The size of the dispersed particles (col-
	loid) ranges from 10 nm to 1 μ m.
<i>Committed dose equivalent</i> ($H_{T,50}$)	The dose equivalent to organs or tissues
	of reference (T) that will be received
	from an intake of radioactive material by
	an individual during the 50-year period
	following intake.
<i>Conversion electron</i> (e ⁻)	See internal conversion.
Critical organ	See organ, critical.
Cross section (σ)	The probability of occurrence of a
	nuclear reaction or the formation of a
	radionuclide in a nuclear reaction. It is
	expressed in a unit termed barn: 1 barn
	$=10^{-24} \text{ cm}^2$
Curie (Ci)	A unit of activity A curie is defined as
	3.7×10^{10} disintegrations per second
Decay constant (λ)	The fraction of atoms of a radioactive
Decay constant (it)	element decaying per unit time. It is
	expressed as $\lambda = 0.693/t_{\rm exp}$ where $t_{\rm exp}$ is
	the half-life of the radionuclide
Deen-dose equivalent (H.)	Dose equivalent at a tissue denth of 1 cm
Deep ubse equivalent (11d)	(1000 mg/cm^2) due to external whole-
	hody exposure
Dosage	A general term for the amount of a radio-
Dosuge	pharmaceutical administered in micro-
	curies or millicuries or becauerels
Dose equivalent (H _r)	Dose equivalent (H_{r}) is the product of
Dose equivalent (Π_T)	absorbed dose in tissue quality factor
	and all other modifying factors at the
	location of interest
DNA	Deoxyribonucleic acid is a double-strand
	belical molecule made of base pairs
	between adenine and thymine and gua
	nine and cytosine. The base pairs in the
	two strands are connected by hydrogen
	honds DNA molecules imprint the char
	acteristics of living subjects
Dosa	The energy of radiation absorbed by any
Dosc	matter
Dosimatar	An instrument to measure the cumulative
Dosinicici	dose of radiation received during a period
	of radiation exposure
	or radiation exposure.

Dosimetry	The calculation or measurement of radi- ation absorbed doses.
Effective dose equivalent (H_E)	Effective dose equivalent (H_E) is the sum of the products of the weighting factors applicable to each of the organs or tissues that are irradiated and the dose equivalent
Effective half-life (T _e)	to the corresponding organ or tissue. This is simply called the effective dose. Time required for an initial administered dosage to be reduced to one half due to both physical decay and biological elim- ination of a radionuclide. It is given by $T_0 = (T_0 \times T_0)/(T_0 + T_0)$, where T_0 is the
<i>Electron</i> (e ⁻)	effective half-life, and T_p and T_b are the physical and biological half-lives, respectively. A negatively charged particle circulating
	around the atomic nucleus. It has a charge of 4.8×10^{-10} electrostatic units and a mass of 9.1×10^{-28} g, equivalent to 0.511 MeV, or equal to 1/1836 of the
Electron capture (EC)	A mode of decay of a proton-rich radio- nuclide in which an orbital electron is captured by the nucleus, accompanied by emission of a neutrino and a charac- teristic X-ray
Electron volt (eV)	The kinetic energy gained by an electron when accelerated through a potential dif- ference of 1 V
Elution	A method of "washing off" an adsorbed substance from a solid-adsorbing matter
Embolus	A relatively large blood clot released from a blood vessel and lodged in a smaller vessel so as to obstruct blood circulation.
Erg	The unit of energy or work done by a force of 1 dyne through a distance of 1 cm.
Erythropoiesis	The process of formation of red blood cells.
Fission (f)	A nuclear process by which a heavy nucleus divides into two nearly equal smaller nuclei, along with the emission of two to three neutrons.

Free radical	A highly reactive chemical species that has one or more unpaired electrons.
Genes	Genes are composed of segments of DNA molecules and are the basic units
Generator, radionuclide	A device in which a short-lived daughter is separated chemically and periodically from a long-lived parent adsorbed on adsorbent material. For example, ^{99m} Tc is separated from ⁹⁹ Mo from the Moly gen- erator by eluting with saline.
Gray (Gy)	The unit of radiation dose in SI units. One gray is equal to 100 rad
Half-life (t _{1/2})	A unique characteristic of a radionu- clide, defined by the time during which an initial activity of a radionuclide is reduced to one half. It is related to the decay constant λ by $t_{1/2} = 0.693/\lambda$.
Half-value layer (HVL)	The thickness of any absorbing material required to reduce the intensity or expo- sure of a radiation beam to one half of the initial value when placed in the path of the beam.
Hematocrit	The fractional volume in percentage of red blood cells in the total blood.
Hydrolysis	A process in which a compound splits into two components by reacting with water when water is used as the solvent.
Infarct	An area of dead tissue due to a complete lack of blood circulation.
Internal conversion	An alternative mode to γ ray decay in which nuclear excitation energy is trans- ferred to an orbital electron which is then ejected from the orbit.
Ion	An atom or group of atoms with a posi- tive charge (cation) or a negative charge (anion).
Ionization chamber	A gas-filled instrument used to measure radioactivity or exposure in terms of ion pairs produced in gas by radiations.
Ischemia	A condition in which a region of tissue has a deficiency in blood supply.
Isobars	Nuclides having the same mass number, that is, the same total number of neutrons and protons. Examples are ${}^{57}_{23}$ Fe and ${}^{57}_{27}$ Co.

Isomeric transition (IT)	Decay of an excited state of a nuclide to another lower excited state or the ground
Isomers	state. Nuclides having the same atomic and
	mass numbers but differing in energy and spin of the nuclei. For example, ⁹⁹ Tc and ^{99m} Tc are isomers.
Isotones	Nuclides have the same number of neutrons in the nucleus. For example, ${}^{131}_{53}$ I and 132 Va are isotopes
Isotopes	Nuclides having the same atomic number, that is, the same number of protons in
K capture	the nucleus. Examples are ${}_{6}^{4}C$ and ${}_{6}^{12}C$. A mode of radioactive decay in which an electron from the <i>K</i> shell is captured by the nucleus
Labeled compound	A compound whose molecule is tagged with a radionuclide.
$LD_{50/60}$	A dosage of a substance that, when administered to a group of any living spe-
Linear energy transfer (LET)	Energy deposited by radiation per unit length of the matter through which the
Lyophilization	A process by which a liquid substance is rapidly frozen and then dried or dehy-
Mass defect	The difference between the mass of the nucleus and the combined masses of individual nucleons of a nuclide
Mass number (A)	The total number of protons and neu- trons in the nucleus of a nuclide
Mean life (τ)	The period of time a radionuclide exists on the average before disintegration. It is related to the half-life and decay con- stant by $c = 1/2 = 1.44$ t
Metastable state (m)	An excited state of a nuclide that decays to another excited state or the ground state with a measurable half-life
Molarity (M)	Number of g·moles of a solute in 1000 ml of a solution.
mRNA	Messenger ribonucleic acid carries out the production of proteins, when a gene is activated to do so through transcrip- tion and translation.

Neutrino (v)	A particle of no charge and mass emitted with variable energy during β^- , β^+ , and
	electron capture decays of radionuclides.
<i>No carrier added</i> (NCA)	A term used to characterize the state of a
	radioactive material to which no stable
	isotope of the compound has been added
	purposely.
Normality (N)	A unit of concentration of a solution. A
	1 N solution contains 1 g equivalent
	weight of a substance in 1000 ml of solu-
	tion. One equivalent weight of a sub-
	stance is defined by the weight of the
	substance that releases or reacts with 1
N7 1	molecule of hydrogen or hydroxyl ion.
Nucleon	A common term for neutrons or protons
	in the nucleus of a nuclide.
Organ, critical	the body and receives the highest rediction
	dose after administration of radioactivity
Organ target	The organ intended to be imaged and
Organ, iurgei	expected to receive a high concentration
	of administered radioactivity
Oxidation	A chemical process by which an atom or
C.Maullon	a group of atoms loses electrons to
	become more positively charged.
Parenteral	A term indicating the route of drug admin-
	istration other than oral or alimentary
	canal. Examples are intrathecal, intrave-
	nous, interstitial, and intramuscular.
pН	The unit of hydrogen ion concentration.
	It is given by the negative common loga-
	rithm of the hydrogen ion concentration
	in a solution: $pH = -\log_{10}[H^+]$.
Phagocytosis	A process by which phagocytes remove
	foreign particulate matter from blood
	circulation. Colloidal particles are
	removed by phagocytes in the liver.
Phantom	A volume of material artificially made to
	simulate the property of an organ or part
\mathbf{D}	of the body when exposed to radiation.
Physical half-life (1 _p)	See nair-life.
r mocylosis Pracision	Ausorphon of indicate the repreducibil
1 recision	ity of the measurement of a quantity
	when determined repeatedly
	when acternined repeateury.

Quality factor (QF)	A factor dependent on linear energy transfer that is multiplied by absorbed doses to calculate the dose equivalents in rem. It is used in radiation protection to take into account the relative radiation damage caused by different radiations. It is 1 for x, γ -, and β -rays and 10 for some
Rad	neutrons and protons. The unit of radiation absorbed dose. One rad is equal to 100 ergs of radiation energy deposited per gram of any matter or 10^{-2} J/kg of any medium.
Radiation weighting factor (W_{\star})	See quality factor.
Radiochemical purity	The fraction of the total radioactivity in the desired chemical form. If ^{99m} Tc- MAA is 90% pure, then 90% of the radioactivity is in the ^{99m} Tc-MAA form.
Radiolysis	A process by which radiolabeled com- pounds are broken up by radiations from the radionuclide in labeled molecules
Radionuclidic purity	The fraction of the total radioactivity in the form of the stated radionuclide. Any extraneous radioactivity such as ⁹⁹ Mo in ^{99m} Tc-radiopharmaceuticals is an
Radiopharmaceutical	impurity. A radioactive drug that can be adminis- tered safely to humans for diagnostic and therapeutic purposes
Reduction	A chemical process by which an atom or a group of atoms gains electrons to become more negatively charged.
Relative biological effectiveness (RBE)	A factor used to calculate the dose equiv- alent in rem from rad. It is defined as the ratio of the amount of a standard radia- tion that causes certain biological dam- age to the amount of radiation in question
Rem	A dose equivalent defined by the absorbed dose (rad) times the relative biological effectiveness or quality factor or radiation weighting factor of the radi- ation in question.
Roentgen	The quantity of x or γ radiations that pro- duces one electrostatic unit of positive or negative charge in 1 cm ³ of air at 0 °C

л	n	1
4	υ	I.

Scintillation scanning or imaging	and 760 mmHg pressure (STP). It is equal to 2.58×10^{-4} C/kg air. Recording of the distribution of radioac- tivity in the body or a section of the body with the use of a detector
Sequestration	A process of separation of cells, such as removal of aged red blood cells by the spleen.
Shallow-dose equivalent (H _s)	Dose equivalent at a tissue depth of $0.007 \text{ cm} (7 \text{ mg/cm}^2)$ averaged over an area of 1 cm^2 due to external exposure to the skin.
Sievert (Sv)	The unit of dose equivalent and equal to 100 rem.
Specific activity	The amount of radioactivity per unit mass of a radionuclide or labeled compound.
Thermal neutron	Neutrons of thermal energy 0.025 eV.
Thrombus	A blood clot that remains attached at the point of its formation on a blood vessel.
Tissue weighting factor (W_T)	A factor related to the radiosensitivity of different tissues in living systems.
Tracer	A radionuclide or a compound labeled with a radionuclide that may be used to follow its distribution or course through a chemical physical or metabolic process
Vectors	Vectors are carriers of genes for in vivo delivery into living systems. Viruses are examples of vectors to deliver genes.

Appendix C: Units and Constants

Energy	
1 electron volt (eV)	$= 1.602 \times 10^{-12} \text{ erg}$
1 kiloelectron volt (keV)	$= 1.602 \times 10^{-9} \text{ erg}$
1 million electron volts (MeV)	$= 1.602 \times 10^{-6} \text{ erg}$
1 joule (J)	$= 10^7 \text{ ergs}$
1 watt (W)	$= 10^7 \text{ ergs/s}$
	= 1 J/s
1 rad	$= 1 \times 10^{-2} \text{ J/kg}$
	= 100 ergs/g
1 gray (Gy)	= 100 rad
	= 1 J/kg
1 sievert (Sv)	= 100 rem
	= 1 J/kg
1 horsepower (HP)	= 746 W
1 calorie (cal)	= 4.184 J
Charge	
1 electronic charge	$= 4.8 \times 10^{-10}$ electrostatic unit
	$= 1.6 \times 10^{-19} \mathrm{C}$
1 coulomb (C)	$= 6.28 \times 10^{18}$ charges
1 ampere (A)	= 1 C/s
Mass and energy	1 66 10 24
1 atomic mass unit (amu)	$= 1.66 \times 10^{-24} \text{ g}$
	= $1/12$ the atomic weight of 12 C
	= 931 MeV
l electron rest mass	= 0.511 MeV
l proton rest mass	= 938.78 MeV
I neutron rest mass	= 939.07 MeV
1 pound	= 453.6 g
Length	
1 micrometer or micron (μ m)	$= 10^{-6} \mathrm{m}$
	$= 10^4 \text{ Å}$
1 nanometer (nm)	$= 10^{-9} \text{ m } 1 \text{ angstrom } (\text{\AA})$
	$= 10^{-8} \text{ cm}$
1 fermi (F)	$= 10^{-13} \text{ cm}$
1 inch	= 2.54 cm

© Springer International Publishing AG 2018 G.B. Saha, *Fundamentals of Nuclear Pharmacy*, https://doi.org/10.1007/978-3-319-57580-3

Activity	
1 curie (Ci)	= 3.7×10^{10} disintegrations per second (dps)
	= 2.22×10^{12} disintegrations per minute (dpm)
1 millicurie (mCi)	$= 3.7 \times 10^7 \mathrm{dps}$
	$= 2.22 \times 10^9 \text{ dpm}$
1 microcurie (μ Ci)	$= 3.7 \times 10^4 \mathrm{dps}$
	$= 2.22 \times 10^{6} \text{ dpm}$
1 becquerel (Bq)	= 1 dps
	$= 2.703 \times 10^{-11} \text{ Ci}$
1 kilobecquerel (kBq)	$= 10^3 dps$
	$= 2.703 \times 10^{-8} \text{ Ci}$
1 megabecquerel (MBq)	$= 10^{6} \text{dps}$
	$= 2.703 \times 10^{-5} \text{ Ci}$
1 gigabecquerel (GBq)	$= 10^9 \text{dps}$
	$= 2.703 \times 10^{-2} \text{ Ci}$
1 terabecquerel (TBq)	$= 10^{12} dps$
	= 27.03 Ci
Constants	
Avogadro's number	$= 6.02 \times 10^{23}$ atoms/g·atom
	$= 6.02 \times 10^{23}$ molecules/g·mole
π	= 3.1416
e	= 2.7183

Appendix D: Radioactive Decay of ^{99m}Tc

Time	Percentage remaining	Time	Percentage remaining
0 h	100		
10 min	98.1	4 h	63.0
20	96.2	10	61.8
30	94.4	20	60.6
40	92.6	30	59.4
50	90.8	40	58.3
1 h	89.1	50	57.2
10	87.4	5 h	56.1
20	85.7	10	55.0
30	84.1	20	54.0
40	82.5	30	53.0
50	80.9	40	51.9
2 h	79.4	50	50.9
10	77.8	6 h	50.0
20	76.4	20	48.1
30	74.9	40	46.3
40	73.5	7 h	44.6
50	72.1	8 h	39.7
3 h	70.7		
10	69.3		
20	68.0		
30	66.7		
40	65.5		
50	64.2		

The decay factor is $e^{-\lambda t}$. The decay constant λ is calculated as (0.693/6) h⁻¹. The percentage remaining is calculated as $100 \times e^{-\lambda t}$.

Appendix E: Radioactive Decay of ¹³¹I

The decay factor is $e^{-\lambda t}$. The decay constant λ is calculated as (0.693/8) d⁻¹. The percentage remaining is calculated as $100 \times e^{-\lambda t}$.

Percentage remaining
91.8
84.1
77.1
70.7
64.8
59.5
54.5
50.0
45.8
42.1
38.6
35.4
32.4
29.7
27.3
25.0
22.9
21.0
19.3
17.7

Appendix F: Radioactive Decay of ¹⁸F

The decay factor is $e^{-\lambda t}$. The decay constant λ is calculated as (0.693/110) min⁻¹. The percentage remaining is calculated as $100 \times e^{-\lambda t}$.

Percentage remaining
93.7
88.1
82.8
77.7
73.0
68.5
64.3
60.4
56.7
53.3
50.0
47.0
44.1
41.1
38.9
36.5
34.3
32.2
30.2
28.4

Appendix G: Answers to Questions

Chapter 1

11. (a) 513.9 MeV (b) 7.7 MeV

Chapter 2

- 5. 170 keV
- 6. 76.3%
- 7. (a) 9.3 × 10¹¹ dpm (b) 0.42 Ci (15.5 GBq)
- 8. (a) 1.73 × 10¹³ atoms (b) 2.84 ng
- 9. (a) 135 mCi (5.0 GBq) (b) 60 mCi (2.22 GBq)
- 11. 71.8 mCi (2.66 GBq)
- 12. 13.7 d
- 13. 4.61 d
- 14. 130 mCi (4.81 GBq)
- 15. 859 d
- 16. 88.2 min
- 18. 63%
- 19. 12 h
- 20. (a) 1033 ± 9.3 cpm (b) 983 ± 10.5 cpm
- 21. 10,000
- 22. 2 standard deviations
- 23. 1111 counts

Chapter 4

- 6. (a) 4.30 mCi (159 MBq)
 (b) 1.09 × 10¹³ atoms
 (c) 3.14 mCi (116 MBq)
 7. 1.25 × 10⁵ mCi (mg ¹³), or
- 7. 1.25×10^5 mCi/mg 131 I or 4.63×10^3 GBq/mg 131 I 5.27×10^6 mCi/mg 99m Tc or 1.95×10^5 GBq/mg 99m Tc 2.85×10^5 mCi/mg 32 P or 1.05×10^4 GBq/mg 32 P 6.0×10^5 mCi/mg 67 Ga or 2.22×10^4 GBq/mg 67 Ga
- 10. 74.3 h

Chapter 5

- 4. (a) 550.9 mCi (20.4 GBq) (b) 477.1 mCi (17.7 GBq)
- 7. (a) 0.50 ml (b) 0.30 ml
 - (c) 0.20 ml
- 10. 351 mCi (13.0 GBq)

Chapter 7

 2.3×10^5 particles

Chapter 8

6. Yield: 91.6% Impurity: 8.4%

Chapter 10

- 2. 269 mrad $(2.69 \times 10^{-3} \text{ Gy})$
- 3. 25 rad (0.25 Gy)
- 4. 200 rem (2 Sv)
- 7. (b)

Chapter 11

- 5. (a) 89 mR/h
 - (b) 22.2 mR/h
- 6. 37.5 mR/h

Chapter 12

- 5. 3852 ml
- 6. 12 d

Chapter 13

- 5. 34.9%
- 15. 117 ml/min
- 26. 18.3
- 39. True

Index

A

Absorbed dose annual limit on intake (ALI) 232 committed dose equivalent (H_{T50}) 232 deep-dose equivalent (H_d) 232 derived air concentration (DAC) 232 dose equivalent 232 effective dose equivalent (H_E) 232 radiation weighting factor (W_r) 204 shallow-dose equivalent (H_s) 232 tissue weighting factor (W_T) 214 total effective dose equivalent (TEDE) 233 Accuracy 28, 393 Activity 18 specific, of radionuclides 72-73 Additives and preservatives in labeled compounds 119-120 Adenosine deaminase gene 363–364 Adenovirus 363 Adverse reactions to radiopharmaceuticals 385-386 Aerosol ^{99m}Tc 292–293 Agreement states 229 ALARA program 235 Albumin, human serum 125I-albumin 136 99mTc-macroaggregated albumin 124 Alpha (α) decay 12 Alumina (Al₂O₃) 60, 80, 87 Aluminum breakthrough test 87 Annihilation radiations 14, 393 Annual limit on intake (ALI) 232 Antibody labeling with 111In 146-147 99mTc 147-149 90Y 158 monoclonal production 144-146 structure 144

© Springer International Publishing AG 2018 G.B. Saha, *Fundamentals of Nuclear Pharmacy*, https://doi.org/10.1007/978-3-319-57580-3

radiolabeled antibody 341-343 in tumor imaging 342 Antigen (Ag) 143-145, 261-264, 394 Antineutrino 12 Antisense oligonucleotides (ASON) 360 Antisense probes 359-360 Apoptosis 364 Apyrogenicity 179-180 Area monitor 35, 186 ASON. See Antisense oligonucleotides (ASON) Atom chemical bonds of complex formation 5-6 coordinate covalent 5 covalent 4-5 electrovalent or ionic 4 electronic structure of 1-2structure of nucleus of 6-8 Atomic mass unit 7, 394, 403 Atomic number 2, 6, 394 Auger electron 18 Auger process 18 Authorized nuclear pharmacist 200, 247 Authorized user, training and experience 246 Autoclaving for sterilization 177 Avogadro's number 18, 22, 66, 394, 404 Azimuthal quantum numbers 1

B

Bacterial endotoxin test (BET) 179–180, 257 BBB. See Blood-brain barrier (BBB) Becquerel (Bq) 21 Beta (β^-) decay 12–14 Beyond Use Date (BUD) 190 Bifunctional chelating agents (BFC) 102, 146–148 Binding energy 8, 11, 16 of nucleus 7–8, 394 Bioassay 242, 251 Biological tests, radiopharmaceuticals 177-181 Biosynthesis 102, 140, 340 Blood-brain barrier (BBB) 271-273, 324.366 Blood volume, methods for measuring application ⁵¹Cr-labeled red blood cell 265 iodinated serum albumin 265 Bohr's atomic theory 1 Bone imaging. See Skeleton Bone pain, treatment of ³²P-sodium orthophosphate 377 153Sm-EDTMP (Ouadramet) 378 ⁸⁹Sr-strontium chloride (Metastron) 377-378 Brain anatomy and physiology 269-271 diagnosis 283 radiopharmaceuticals and imaging techniques diffusible radiopharmaceuticals 271 18F-FDG 275-278 ¹⁸F-florbetaben (Neuroceq) 281 ¹⁸F-florbetapir (Amyvid) 278–279 18F-fluorodopa 278 ¹⁸F-flutemetamol (Vizamyl) 279-281 interventional studies 282 non-diffusible radiopharmaceuticals 271 ^{99m}Tc-ethyl cysteinate dimer (ECD) (Neurolite), 271-273 99mTc-hexamethylpropylene amine oxime (HMPAO) (Ceretec) 273 - 274Bremsstrahlung 13, 45, 197, 237, 394 BUD. See Beyond Use Date (BUD)

С

Captopril renography 309–310 Carbon-11 (¹¹C) 56, 69 production of 56 Carbon-14 (¹⁴C) 69 Cardiolite 132, 210, 215, 217, 320–321 myocardial imaging 320–321 Carrier 57 Carrier-free 51, 72, 394 Caution signs and labels 233 ¹¹C-choline 154, 340–341 Central nervous system (CNS) anatomy and physiology 269–271 diagnosis 283 radiopharmaceuticals and imaging techniques

brain imaging 271-283 cisternography 282-283 Cerebrospinal fluid (CSF) 128, 282-283 Ceretec brain imaging 273-274 leukocytes labeling 132,143 Cesium-137 (137Cs) 26, 36, 59, 175, 192, 236, 243 Chart of the nuclides 8-9 Chelating agent 6, 98, 101-102, 112-114, 117-118.394 Chelation 6, 102, 112, 118 Chemical bonds of atom complex formation 5-6 coordinate covalent 5 coordination number 6 covalent 5 electrovalent or ionic 4 Chemical purity of radiopharmaceuticals 173 - 174Chloramine-T method of iodination 107 Chromatography high-performance liquid 172-173 instant thin-layer, 166-170 paper 166-170 Chromium-51 (51Cr) 62, 140 Cisternography 282-283 111In-DTPA 282 CNS. See Central nervous system (CNS) Cobalt-57 (57Co) 68, 102, 140, 174, 192, 236, 253.264 Cobalt-58 (58Co) 69, 140, 264 Cobalt-60 (60Co) 69, 102, 204, 243 Collimator 39-41, 394 Colloid(s) and labeled particles 118-119 liver imaging 297 spleen imaging 126, 297-298, 302 Committed dose equivalent $(H_{T,50})$ 232, 395 Compatibility of radiopharmaceutical components 98 Complex formation 5-6 Compounded sterile preparations (CSPs) 190-191 Computer, digital 42 Conjugation method 108 Consent for drug investigations in humans 220 Conversion electron 16-17, 398 Coordinate covalent bonds 5-6 Coordination number 6, 124–117 Copper-62 (62Cu) 57, 69 Copper-64 (64Cu) 55, 70 Copper-67 (67Cu) 70 Counting

differential 38 error, accuracy, and precision 28 integral 38 propagation of errors 30-31 standard deviation 28-29 standard deviation of count rate 30 statistics of 27-31 Covalent bonds 4-5 ⁵¹Cr-labeled red blood cell blood volume measurement 264 survival measurement 264-265 Cross section 66, 395 CSF. See Cerebrospinal fluid (CSF) ¹¹C-sodium acetate 156 Curie (Ci) 21, 395 Cyanocobalamin 57Co-, 101, 140 Schilling test 264 Cyclotron, radionuclide production 49-57 Cystic fibrosis transmembrane regulator (CFTR) gene 363

D

Decay constant (λ) 18, 21, 395 Decay energy 12 Decay method, dose calibrator quality control 175-176 Decay of ideal radiopharmaceutical by electron capture or isomeric transition 96 Decay of radionuclides alpha (α) 12 beta (β) 12–14 constant (See Decay constant (λ)) electron capture 14-15 characteristic x-ray 15 equations general 18-19 half-life and mean-life 19-21 successive 23-27 iodine-131 (131I) 13 isometric transition (IT) 15-18 gamma ray emission (γ) 16 internal conversion 16, 18 positron (β^+) 14 schemes 13-17 secular equilibrium 26 spontaneous fission 11-12 transient equilibrium 24-26 units of radioactivity 21 Deep-dose equivalent (H_d) 232, 395 Demetallation method 108 Denaturation or alteration of labeled compounds 103

Deoxyribonucleic acid (DNA) 356-359,395 Department of Transportation (DOT) 250-253 Derived air concentration (DAC) 232 Design of new radiopharmaceuticals 97-100 Detectors gas-filled detectors dose calibrators 33-35 Geiger-Müller counters 35-36 NaI(Tl) detectors 36-37 scintillation detectors 36, 41 Diethylenetriaminepentaaceticacid(DTPA),111Incisternography 282-283 gastric emptying 345-346 molecular structure of 6 99mTckidney imaging 308- 309 lung ventilation imaging 292-293 Differential counting 38 Digital image formation 42-43 Diisopropyliminodiacetic acid (DISIDA) ^{99m}Tc-, 129–130, 168, 249, 296- 298 Disintegration rate 18, 21 Dispensing radiopharmaceuticals 197-198, 257 Display and storage 38-39, 43 DNA. See Deoxyribonucleic acid (DNA) Dosages 174, 395 pediatric 216-217 Do's and don'ts in radiation protection 242 Dose calibrators accuracy 174-175 constancy 174 geometry 176 linearity 175-176 Dose equivalent 204, 214, 232, 395 Dosimeter film badge 240-242 pocket 240-241 thermoluminescent 240-241 Dosimetry. See Internal radiation dosimetry DOT. See Department of Transportation (DOT) DTPA. See Diethylenetriaminepentaacetic acid (DTPA)

Е

EC. *See* Electron capture (EC) Effective dose equivalent 214–215, 232, 396 Effective half-life (T_e) 94–95, 207, 248, 396 Effective renal plasma flow (ERPF) 307–309, 389 Efficiency of labeling 103 Electrolytic method of iodination 106 Electron 1–7, 396, 403 Electron capture (EC) characteristic x-ray 17-18 decay by 14 decay of ideal radiopharmaceutical by 96 Electronic structure of atom 1-2 Electrovalent bond 4-5 Energy orbits (shells) of atom 1 Enzymatic method of iodination 107-108 Equilibrium dose constant 206 ERPF. See Effective renal plasma flow (ERPF) European rules governing radiopharmaceuticals 253-258 drug registration 254-255 European pharmacopoeia 255-256 good manufacturing practice 255 guidelines for small-scale radiopharmaceutical preparation 268-269 radiation protection 257-258 Exploratory IND 222-224 Exposure rate constant (Γ) 235-236

F

fas gene 364 FDA. See Food and Drug Administration (FDA) FDA regulations for nuclear pharmacies 225-228 ¹⁸F-florbetaben (Neuraceq) 153–154, 212, 215, 281 brain imaging 281 ¹⁸F-florbetapir (Amyvid) 152–153, 212, 215, 271, 278-279 brain imaging 271 ¹⁸F-fluciclovine (Axumin) 152, 169, 212, 215, 333, 341 prostate imaging 341 ¹⁸F-fluorodeoxyglucose (FDG) brain imaging 275-278 heart imaging 325-326 radiation dose 212 tumor imaging 335-337 whole body imaging 337-338 ¹⁸F-fluorodopa 151, 157, 271, 278 brain imaging 271, 278 ¹⁸F-fluorothymidine (FLT) 157 ¹⁸F-flutemetamol 153, 212, 215, 279–281 brain imaging 271 Film badge for personnel monitoring 240-241 Fission radionuclide production 59-65 spontaneous 11-12, 57 Fluorescence yield 18 Fluorine-18 (18F) decay scheme of 14-15 production of 57

Food and Drug Administration (FDA) drug quality and security act 226 expanded access IND 221-222 exploratory IND (eIND) 222-223 investigational new drug 220-221 Modernization Act 221 new drug application 221 PET radiopharmaceuticals 225-226 Radioactive Drug Research Committee (RDRC) 223-224 regulations for nuclear pharmacies 225-226 state boards of pharmacy 228 Foreign label, introduction of 101–102 Free radical 82, 104, 112, 125, 131, 135, 165, 397 ¹⁸F-sodium fluoride 151, 212, 215, 217, 225, 312-313

G

Gallium-67 (67Ga) 52, 70 production of 52 Gallium-67 (67Ga)-citrate 138-139 inflammatory diseases and infection 139, 292-294, 347-348 liver imaging 300 lung imaging 332-333 tumor imaging 333 Gallium-68 (68Ga) 54 68Ga-DOTATATE 155-156 neuroendocrine tumor imaging 156 Gamma camera. See Scintillation camera Gas-filled detectors 33 Gastric emptying 126, 217, 345-346 Gastrointestinal (GI) bleeding 346–347 Gaussian distribution 28-29 68Ge-68Ga generator 54, 88, 191 Geiger-Müller (GM) counters 33.35-36 Gel chromatography 170-171 Gene delivery 362-363 Generator eluate, log sheet for 195 Generators, radionuclide $^{227}Ac \rightarrow ^{227}Th \rightarrow ^{223}Ra 90-91$ 68Ge-68Ga 88 99Mo-99mTc 77-88 aluminum breakthrough 87 liquid column 79-80 ⁹⁹Mo breakthrough 86-87 solid column 80-82 principles of 77-78 82Sr-82Rb 89-90 90Sr-90Y 88 62Zn-62Cu 89

Gene therapy362 gene delivery 362–363 adenoviral vectors 363 nonviral vectors 363 retroviral vectors 363 specific diseases 363–364 cystic fibrosis 363 immunodeficiency disorder 363 peripheral limb ischemia and atherosclerosis 364 tumor malignancy 364 Germanium-68 (⁶⁸Ge) 27, 53–54, 70, 79, 88 Gray (Gy) 203–204, 397

H

³H (tritium) 69, 238–239 Half-life 19-20 Effective 94-95, 207, 396 Half-value layer (HVL) 236-237, 397 HAMA. See Human antimurine antibody (HAMA) HDP. See Hydroxymethylene diphosphonate (HDP) Heart anatomy and physiology 313-317 cardiac innervation imaging 328-329 123I-MIBG 328-329 diagnosis 332 ejection fraction (EF) 329-332 metabolic imaging 325-327 ¹⁸F-fluorodeoxyglucose (¹⁸F-FDG) 325-326 myocardial infarct imaging 327-328 99mTc-pyrophosphate 327-328 perfusion imaging 18F-flurpiridaz 325 ¹³N-ammonia 325 15O-H2O 325 82Rb-rubidium chloride 323-325 99mTc-sestamibi (Cardiolite) 320-321 ^{99m}Tc-tetrofosmin (Myoview) 321-323 ²⁰¹Tl-thallous chloride 318-320 radionuclide angiography first-pass method 329-331 gated equilibrium cardiac blood pool method 330-331 radionuclide stress ventriculography 331-332 Hepatocytes 295-296 High-performance liquid chromatography (HPLC) 172-173, High radiation area 233 HSV1-tk, suicide gene 361-362, 364

Human antimurine antibody (HAMA) 145 342, 390 Hydrazinonicotinamide (HYNIC) 148–149 Hydrolysis of reduced ^{99m}Tc 112, 113 Hydrolysis of stannous ion 85, 112–114 Hydroxymethylene diphosphonate (HDP) 112, 390 bone imaging 312 HYNIC. *See* Hydrazinonicotinamide (HYNIC) Hyperthyroidism, treatment of dosages 373–374 empirical formula 373 ¹³¹I method 373–374

I

Iatrogenic alterations in biodistribution of radiopharmaceuticals different imaging procedures 387-388 drug effects 386 Iodine-123 (123I) 52-53, 71, 135-136 Iodine-124 (124I) 53, 71, 136 Iodine-125 (125I) 62, 71, 136 Iodine-131 (131I) 61, 71, 135 decay scheme of, 13 production of, 61 Iminodiacetic acid (IDA) derivative 129-130 99mTc-liver imaging 296-297 ¹¹¹In-capromab pendetide, 147, 169, 211, 333, 342-343, 386-387 Indium-111 (111In) decay scheme of, 16 production of, 54 ¹¹¹In-DTPA 95, 98, 137–138, 169, 282–283, 346, 386 Infectious waste disposal 200 Inflammatory diseases and infection 67Ga-citrate 347-348 ¹¹¹In-leukocytes 348-349 99mTc-leukocytes 348-349 ¹¹¹In-ibritumomab tiuxetan 158, 169, 333, 342-343 111In-labeled compounds antibody 146-147, 342 capromab pendetide (ProstaScint) 147 342 DTPA 137-138, 169, 282-283, 346 ibritumomab tiuxetan (Zevalin) 342-343 leukocytes 141-142 pentetreotide (Octreoscan) 147 platelets 141-143 111In-oxine 141, 356 Instant thin-layer chromatography (ITLC) 166-170 Institutional review board (IRB) 220

Internal conversion 16-18 Auger process 17-18 characteristic X-rays 16 conversion electron 16 fluorescence vield 16 in isomeric transition 16 Integral counting 38 Internal radiation dosimetry absorbed doses 205-208 absorbed fraction 206 cumulated activity (Å) 207 effective dose 214-215 equilibrium dose constant 206 mean absorbed dose per cumulated activity (S) 207radiation dose in SI units 208-213 radiation units 203-205 Investigational New Drug (IND) 220-221 In vitro tests, iodinated radiopharmaceuticals. See Radioiodinated radiopharmaceuticals (123I) Iodine monochloride (ICl) method 107 Iodo-bead method 109 Iodogen method 109, 136 Ion exchange chromatography 171-172 Ionic bond 4 Ionization chamber 33, 397 Iron-59 (59Fe) 69, 229-230 Isobars 8, 397 Isomeric states of nucleus 16 Isomeric transition (IT) 16-17, 398 decay of ideal radiopharmaceutical by 96 gamma ray emission (γ) 12,16 internal conversion 16-17 Isomers 8, 398 Isotones 8, 398 Isotope effect in labeled compounds 101, 103 Isotope exchange method of labeling 101 Isotopes 8, 398 ITLC. See Instant thin-layer chromatography (ITLC)

K

Kidneys anatomy and physiology 303–304 diagnosis 311 radiopharmaceuticals and imaging techniques captopril renography 309–310 effective renal plasma flow (ERPF) 307–308 glomerular filtration rate (GFR) 308 ^{99m}Tc-DMSA 309–310 ^{99m}Tc-DTPA 308–309 ^{99m}Tc-MAG3, 306–307 Kits for ^{99m}Tc-labeling 114, 117–118

L

Labeling of vials and syringes 246 Labeling, specific methods of. See also Radiolabeling Lactoferrin 294 LD_{50/60}, 181, 398 Lead barrier shield in nuclear pharmacy 187 Lead-shield syringe holder in nuclear pharmacy 188 Lentivirus 363 LET. See Lin 6ear energy transfer (LET) Leukemia 380-381 radionuclide therapy for 380 Leukocytes 140-143, 348 111In-labeled 141-142 Licenses, radiopharmaceuticals usage broad scope 230 general domestic license 229 specific licenses 230 Ligand exchange 113-114, 132-134 Ligands 6, 113-117, 132-134, Limulus amebocyte lysate (LAL) test 179-180 Linear amplifier 38 Linear energy transfer (LET) 204, 398 Liquid column generator 79-80 Liver anatomy and physiology 294-295 diagnosis 300-301 radiopharmaceuticals and imaging techniques ⁶⁷Ga-gallium citrate 300 99mTc-albumin colloid 301 99mTc-labeled IDA derivatives 296-297 99mTc-sulfur colloid 297-301 Liver cancer ⁹⁰Y-SIR-Spheres (SIR-TeX) 379 90Y-TheraSpheres 378-379 ¹⁷⁷Lu-DOTATATE 156, 368 Lungs anatomy and physiology 287-289 diagnosis 294 radiopharmaceuticals and imaging techniques nonembolic lung diseases 292-294 perfusion imaging 289-290 ventilation studies 290-292 Lutetium-177 (177Lu) 63, 71, 155-156, 368 Lymphoscintigraphy 126, 344-345 Lyophilization 118, 398

Μ

Macroaggregated albumin. See Albumin, human serum Magic numbers 7 Magnetic quantum number 2 Mass defect in nucleus 8, 398 Mass number (A) 6, 8, 73, 103, 398 Mean-life (τ) 19–21, 398 Meckel's diverticulum 346 Medical event, report and notification 247-248 Medical uses of radioactive materials 242-249 Membrane filtration for sterilization 177–178 Messenger ribonucleic acid (mRNA) 358-360, 390.398 Metastable state of nucleus (m) 16, 398 Metastron 139, 213, 377 in treatment of bone pain 377 Miraluma breast tumor imaging 333-334 preparation of 132 Mobile nuclear medicine service 244 Moderators in reactor 58 Molecular imaging (MI) conventional 356 gene-based 356-358 codons 358 DNA molecule replication 357 exons 357 introns 357, 359 transcription process 358 translation process 359-360 gene therapy gene delivery 362-363 specific diseases 363-364 nanoparticle quantum dots 365-366 synthesis 365-366 uses 365 oligodeoxynucleotide antisense probes 359-360 reporter genes dopamine-2-receptor (D2R) 362 radiolabeled reporter probe 361-362 Molecular structure(s) of DTPA 6, 389 18F-FDG 152 ¹⁸F-florbetaben (Neuraceq) 152 ¹⁸F-florbetapir (Amyvid) 152 ¹⁸F-fluciclovine (Axumin) 152 18F-fluorodopa 155 ¹⁸F-flutemetamol 152 68Ga-DOTATATE 155 ⁶⁸Ga-DOTATOC 155 IDA derivatives 130

phosphate and phosphonate compounds 125 99mTc-ECD 131 99mTc-HMPAO 131 99mTc-MAG3 131 99mTc-sestamibi 131 99m Tc-tetrofosmin 131 ⁹⁹Mo-^{99m}Tc generator 79–88 aluminum breakthrough 87 liquid column 79-80 99Mo breakthrough 86-87 Monoclonal antibody. See Antibody MR imaging 46 mRNA. See Messenger ribonucleic acid (mRNA) Multichannel pulse height analyzer 38 Multigated acquisition (MUGA) 231, 330-331 Myoview 134, 209, 217, 321-323 in myocardial imaging 321-328

Ν

NaI(Tl) detectors 41 ¹³N-ammonia heart imaging 325 production of 56 Nanocoll 127 Nanoparticle imaging 365-368 quantum dots 366-367 NARM, radiation protection activity 237 ALARA program 235 caution signs and labels 233 distance 235-236 do's and don'ts in 242 occupational dose limits 233-235 personnel monitoring 240-241 principles 235-237 Radiation Safety Committee (RSC) 230, 235.243 Radiation Safety Officer (RSO) 235, 240, 243-244, 246-247 radioactive spill 239-240 radioactive waste disposal 238-239 receiving and monitoring, radioactive packages 237-238 shielding 237 time 235 Naturally occurring and accelerator-produced radioactive materials (NARM). See No carrier added (NCA) NCA. See No carrier added (NCA) NDA. See New Drug Application (NDA) Nephron 303, 305

Neurolite 133, 210, 217 brain imaging 271-273 Neutrino 14-15, 396, 399 Neutrons capture reaction 61–62 fast 58 thermal 58-59, 401 New Drug Application (NDA) 221, 225 NHL. See Non-Hodgkin's lymphoma (NHL) Nitrogen-13 (13N) 56, 69, 177 production of 56 No carrier added (NCA) 51, 59, 73, 399 Non-Hodgkin's lymphoma (NHL) 158, 342-343, 369, 380 ⁹⁰Y-ibritumomab tiuxetan (Zevalin) 158, 342-343 NRC. See Nuclear Regulatory Commission (NRC) Nuclear force 7-8 Nuclear medicine. See Radiopharmaceuticals, therapeutic uses Nuclear model liquid drop 7 shell 7 Nuclear pharmacy Centralized 200-201 advantages 201 location and authorization 201-202 compounded sterile preparations (CSPs) 190-191 concept 185 design of 185-190 equipment 186, 192 laboratory area 186 location 201 software packages 187, 190 operation of 192-200 FDA regulations for, operation dispensing 197–198 infectious waste disposal 200 preparation of 192-196 quality control 197 radioactive waste disposal 198 receiving and monitoring, radioactive packages 192 storage 197 Nuclear reactions 50-51, 59, 393, 395 Nuclear reactor 57-58 Nuclear Regulatory Commission (NRC) accreditation criteria 230-231 agreement states 229 licenses 229-230 medical uses of radioactive materials ambient radiation exposure rate 246

applications, amendments, and notifications 243 authority and responsibilities of 243 - 244bioassav 242 calibration, transmission, and reference sources 245 dosage measurement 245 mobile nuclear medicine service 244 radiopharmaceuticals administered patients release 248-250 record keeping 250 report and notification of medical event247-248 report and notification of dose to fetus and nursing child 248 sealed sources possession requirement 245 supervision 244 training and experience requirements for 246-247 vials and syringe labeling 246 written directives 244 Nucleons 1 Nucleus of atom, structure of 6-8 Nuclides 8-9, 398-399 chart of the nuclides 8-9

0

Occupational dose limits 233–235, 241 Octet rule 4 Oligodeoxynucleotide antisense probes 359–360 Oncogenes 364 Opsonin 300 ¹⁵O-water 57, 156, 281, 325 Oxidation states of ^{99m}Tc in ^{99m}Tc-radiopharmaceuticals 115–117 Oxotechnetium core 115 Oxygen-15 (¹⁵O) 56–57

P

Parallel hole collimators 39–41 Parathyroid imaging 349–350 Particle emission and ideal radiopharmaceutical 95–96 Pediatric dosages 216–217 Periodic table of elements 3 Personnel monitoring 240–241, 258 PET. *See* Positron emission tomography (PET) PET/CT 45–46 PET/MR 45–46 PHA. See Pulse height analyzer (PHA) Phagocytes 295, 297-298, 300, 399 Phosphorus-32 (³²P) 62, 69, 139, 197, 253, 377.380-381 Photomultiplier tubes 37 Pinhole collimators 39-40 Platelets and leucokocytes ¹¹¹In-labeled 141–143 99mTc-labeled 143 Pocket dosimeter 240-241 Polyacrylamide gel electrophoresis, radiochemical purity 171 Polycythemia vera and leukemia 380-381 Positron (β^+) decay 14 Positron emission tomography (PET) 44-46 Preamplifier 37-38 Precision 28, 263 Pretarget d radioimmunotherapy of cancer 381-382 Principal quantum number 1 Propagation of errors 30-31 Prostate imaging with ¹⁸F-fluciclovine 387 Protein binding 99 Proton 1, 6-8 32P-sodium orthophosphate in treatment of bone pain 377 in treatment of polycythemia vera and leukemia 380-81 Pulse height analyzer (PHA) 38, 42 Purification and analysis of labeled compounds 104-105 Pyrogens 179-180 Pyrogen testing 179-180 Pyrophosphate. See 99mTc-labeled radiopharmaceuticals

Q

Q energy 50 QF. See Quality factor (QF) Quadramet 139, 213, 378, 381 in treatment of bone pain 376–377 Quality control of ^{99m}Tc eluate 86–88 Quality control of radiopharmaceuticals biological tests apyrogenicity 179–180 sterility 178 toxicity 181 in nuclear pharmacy 167 physicochemical tests chemical purity 173–174 pH and ionic strength 164 physical characteristics 164 radioassay 174–176 radiochemical purity 165–173 radionuclidic purity 164–165 record keeping 181 Quality factor (QF) 204- 205, 395, 400 Quantum dots 366–368 Quantum number of energy shells 1–2

R

Radiation absorbed dose (RAD) 203, 205-213.400 Radiation area 233 Radiation caution signs 233-234 Radiation detection and measurement gas-filled detectors dose calibrators 33-35 Geiger-Müller counters 35-36 scintillation camera 39-43 collimator of 39-41 detectors 41 digital image formation 42-43 display and storage 43 electronics diagram of 40 photomultiplier tube 37 pulse height analyser 42 X, Y positioning circuit 41-42 tomographic imagers MR 45-46 PET 44-45 SPECT 44 Radiation protection, NRC ALARA program 235 caution signs and labels 233 definitions 232-233 distance 235-236 do's and don'ts in 242-243 occupational dose limits 233-235 personnel monitoring 240-241 principles 235-237 radioactive spill 239-240 radioactive waste disposal 238-239 receiving and monitoring, radioactive packages 237-238 shielding 237 time 235 training and experience 246-247 Radiation Safety Committee (RSC) 230, 235, 243.391 Radiation safety officer (RSO) 200, 230, 243, 247, 391 Radiation units 203-205 Radiation weighting factor (W_r) 204, 391, 400 Radioactive decay alpha (α) 12 beta (β^{-}) 12–14 calculations 22-23 electron capture 14-15 half-life and mean-life 19-21 isometric transition 15–18 positron (β^+) 14 spontaneous fission 11-12 statistics of counting error, accuracy and precision 28 Gaussian distribution 28-29 propagation of errors 30 standard deviation 28-29 standard deviation of count rates 30 Radioactive decay equations general 18-23 successive decay 23-27 secular equilibrium 26-27 transient equilibrium 24-26 Radioactive Drug Research Committee (RDRC) 223-224, 391 Radioactive packages, receiving and monitoring 237-238 Radioactive spill 239-240 Radioactive waste disposal decay-in-storage 238 incineration 238-239 release into sewerage system 238-239 transfer to authorized recipient 239 Radioactivity calculations related to 22-23 decay equations 18-23 definition 18 successive decay equations 23-27 units of 21 Radioassay, radiopharmaceuticals dose calibrator quality control accuracy 174-175 constancy 174 geometry 176 linearity 175-176 radioactivity measurement 176 Radiochemical purity, quality control analytical methods distillation 173 gel chromatography 170-171 high-performance liquid chromatography (HPLC) 172-173 ion exchange 171-172 paper and ITLC 166-170 paper/polyacrylamide gel electrophoresis 171 precipitation 166 solvent extraction 172 definition of 165

Radiochemicals, radioimmunoassay (RIA) application 263-264 methodology 262-263 principle 261-262 sensitivity and specificity 263 Radioiodinated compounds 100, 109 Radioiodinated radiopharmaceuticals (123I) metaiodobenzvlguanidine (MIBG) 137, 211, 215, 217, 317, 333-335, 386, 388 cardiac innervation imaging 328-329 sodium iodide 135-137, 211 thyroid imaging 136, 211, 285-286 Radioiodinated radiopharmaceuticals (125I) albumin 109, 136 sodium iothalamate 137 Radioiodinated radiopharmaceuticals (131I) metaiodobenzylguanidine (MIBG) 137, 211 sodium iodide hyperthyroid treatment 373-374 thyroid cancer treatment 374-376 thyroid imaging 135-136 Radioiodination methods of chloramine-T 107 conjugation 108 demetallation 108 electrolytic 107 enzymatic 107-108 iodine monochloride 107 iodo-bead 109 iodogen 109 triiodide method 106-107 principles of 106 Radiolabeling important factors carrier-free or NCA 103 chemical stability 103 denaturation/alteration 103 efficiency of labeling process 103 isotope effect 103 purification and analysis 104-105 radiolysis 104 shelf life 105 specific activity 104 storage conditions 103-104 kits for 99mTc-labeling 117-118 methods of with bifunctional chelating agents 102 biosynthesis 102 foreign label 101-102 isotope exchange reactions 101 radioiodination 105-109 with 99mTc 110-114 Radiolysis 82, 104, 165, 400 Radionuclides characteristics of commonly used 69-71

cyclotron-produced 49-57 definition of 8 equation for production of 65-71 exposure rate constant (Γ) 236 generators 77 production of 49-73 reactor-produced 57-65 specific activity of 72-73 Radionuclidic purity, quality control definition 164 determination 165 Radiopharmaceuticals additives and preservatives 119-120 adverse reactions 385-386 colloids and labeled particles 118-119 definition of 93-94 design of 97-100 diagnostic uses of, nuclear medicine brain 271-281 central nervous system 269-283 cisternography 282-283 gastric emptying 345-346 gastrointestinal bleeding 346-347 heart 313-332 inflammatory diseases and infection 347-349 kidneys 303-311 liver 294-301 lungs 287-294 lymphoscintigraphy 344-345 Meckel's diverticulum 346 parathyroid 349-350 skeleton 311-315 spleen 302-303 thrombus detection 343-344 thyroid 283-287 tumor 332-343 factors influencing design of biodistribution 100 charge of molecule 99 compatibility of components 99 protein binding 99 size of molecule 99 solubility 99-100 stability 100 stoichiometry 98 iatrogenic alterations in biodistribution 386-388 ideal characteristics of decay by EC/IT 96 easy availability 94 high target-to-nontarget activity ratio 97 no particle emission 95-96 short effective half-life 94-95

oxidation states of 99mTc 115-117 preparation of, in nuclear pharmacy 192, 194-196 radiation dose of 205-214 radiolabeled peptides 150 therapeutic uses of, in nuclear medicine bone pain 376-378 hyperthyroidism 373-374 liver cancer 378-379 non-Hodgkin's lymphoma 380 polycythemia vera and leukemia 380-381 pretargeted radioimmunotherapy of cancer 381-382 prostate cancer 381 thyroid cancer 374-376 Radium-223 (223Ra) 79, 90-91, 159 Radium chloride (223Ra) 90-91, 159, 213.381 prostate cancer treatment 381 RBE. See Relative biological effectiveness (RBE) RDRC. See Radioactive Drug Research Committee (RDRC) Reactor 57-58 Receiving and monitoring of radioactive packages 237-238 Record keeping 181, 187, 250 Red blood cells ⁵¹Cr-labeled 140, 265, 266 survival measurement 266 99mTc-labeled gastrointestinal bleeding 347 spleen imaging 151 Reduction of technetium 111-113 Relative biological effectiveness (RBE) 204, 391,400 Release of patients administered with radiopharmaceuticals 248-249 REM. See Roentgen equivalent man (REM) Renal transit time 306 Reporter genes 360-362 dopamine-2-receptor (D2R) 362 radiolabeled reporter probe 361-362 Restricted area 233 Retrovirus 363 Rhenium-186 (186Re) 64 Roentgen 204-204, 400 REM 204, 400 RSC. See Radiation Safety Committee (RSC) RSO. See Radiation safety officer (RSO) Rubidium chloride (82Rb) 154, 212, 215, 225 myocardial perfusion imaging 323-325

S

Schilling test 264 Scintillation camera 36-43 Scintillation detecting instruments 36-39 Scintillation detectors 33 Sealed sources 245, 251 Secular equilibrium 26 Shallow-dose equivalent (Hs) 232, 234, 401 Shelf life of labeled compounds 105 Shielding and radiation protection 237 Shielding method 176 linearity of dose calibrators 175-176 Sievert (Sv) 204, 401, 403 Single-channel pulse height analyzer 38 Single-photon emission computed tomography (SPECT) 40 Size of colloid particles 119, 298 Skeleton anatomy and physiology 311 diagnosis 313-315 radiopharmaceuticals and imaging techniques 18F-NaF 312-313 99mTc-phosphonate compounds 311-312 153Sm-EDTMP treatment of bone pain 376–377 Sn2+ ion, reducing agent 111 Sodium iodide (123I-) 135-137, 211 123I thyroid imaging 283-286 Sodium iodide (131I-) ¹³¹I thyroid imaging 285, 287 hyperthyroid treatment 373-374 thyroid cancer treatment 374-376 Sodium orthophosphate 32Pin treatment of bone pain 376-377 in treatment of polycythemia vera and leukemia 380-381 Sodium pertechnetate 99mTc Meckel's diverticulum 123, 346 thyroid imaging 286-288 Solid column generator 80-82 Solubility of radiopharmaceutical 99-100 Solvent extraction, in radiochemical purity 172 Specific acivity of labeled compounds 72-73, 104, 401 of radionuclides 72-73, 401 SPECT. See Single-photon emission computed tomography (SPECT) SPECT/CT 45-46 Spin quantum number 2 Spleen anatomy and physiology 302 diagnosis 302

radiopharmaceuticals and imaging techniques 99mTc-albumin colloid 302 99mTc-labeled red blood cells 302 99mTc-sulfur colloid 302 Spontaneous fission 11-12 82Sr-82Rb generators 54, 89-90, 154, 323 ⁸⁹Sr-strontium chloride (Metastron) 139, 213, 377-378 in treatment of bone pain 378 90Sr-90Y generators 88 Stability in labeling 100, 103 Standard deviation. See Counting, statistics of Stannous ion 111-113 State boards of pharmacy 228 Statistics of counting. See Counting, statistics of Sterility tests 178 Sterilization methods autoclaving 177 membrane filtration 177-178 Storage conditions 103-104 Strontium-82 (82Sr) 54, 154, 251 Strontium-89 (89Sr) 62, 87 Strontium-90 (90Sr) 87-88 Successive decay equations 23-27 Sulfur colloid, 99mTc gastric emptying 345-346 gastrointestinal bleeding 346-347 liver imaging 297 preparation of 125-126 spleen imaging 302 Survey meters 35-36, 237, 246, 251 Surveys of ambient radiation exposure rate 246 Syringe shield 187, 237, 246 System Internationale unit (SI) 21,

Т

Target and its processing 65 ^{99m}Tc. *See* Technetium (^{99m}Tc) ^{99m}Tc-dimercaptosuccinic acid (DMSA) 115, 134, 168, 210, 215–216, 287, 305, 309–310, 333, 386 renal imaging 309 ^{99m}Tc-labeled radiopharmaceuticals aerosol in lung ventilation studies 128 albumin colloid liver imaging 295–296 spleen imaging 126 antibody labeling direct method 147 indirect method 148–149

208 - 213

dimercaptosuccinic acid (DMSA) 115, 134, 168, 210, 215-216, 287, 305, 309-310, 333, 386 renal imaging 309 DTPA (pentetate) 127-128 brain imaging 271 gastric emptying 345-346 lung imaging 292 kidney imaging 308-309 renal imaging 308-309 ethylcysteinate dimer (ECD) 133, 210, 271 - 273brain imaging 271-273 hexamethylpropylene amine oxime (HMPAO) 130-132, 210, 215, 273 - 274brain imaging 273-274 iminodiacetic acid (IDA) 129-130 liver imaging 296-297 kits for production of 117-118 leukocytes 140-143, 348-349 inflammatory diseases and infections imaging 348-349 macroaggregated albumin (MAA) 119, 124, 168, 209, 215, 217, 249, 289-291, 378-379, 386 lung imaging 290 mercaptoacetylglycylglycylglycine (MAG3) 132-133, 306-307 captopril renography 309-310 oxidation states of 99mTc 115-117 pertechnetate Meckel's diverticulum 346 Parathyroid imaging 350 thyroid imaging 286-287 phosphonate compounds 124-125, 311-313 bone imaging 311-312 pyrophosphate 124-125, 386 myocardial infarct imaging 124-125, 327-328 red blood cells (RBC) gastrointestinal bleeding 346-347 in vitro method 128 in vivo method 128, 129 spleen imaging 302 sestamibi breast imaging 132, 333-334 heart imaging 321 structure of oxotechnetium core 114-115 sulfur colloid gastric emptying 345-346 gastrointestinal bleeding 346-347 liver imaging 297

preparation of 125-126 spleen imaging 126 technegas 134-135 lung ventilation studies 292 tetrofosmin 131, 134, 168, 209, 317, 386 heart imaging 321-323 Technetium (99mTc) chemistry of 110-111 decay scheme of 17 general properties of 110 hydrolysis of reduced 112-113 labeling with 110-114 ligand exchange 113-114 quality control of pertechnetate eluate 86 ⁹⁹Mo-, generator 60, 62, 78-86, 195, 198 oxidation states of 115-117 radioactive decay of 405 reduction of 111 yield from new generator 82-85 TEDE. See Total effective dose equivalent (TEDE) Thallium-201 (201Tl) 55, 138 heart imaging 317-320 production of 55 Theranostics 368–369 Thermoluminescent dosimeter (TLD) 241 Thrombus detection 343-344 Thyroid anatomy and physiology 283-285 diagnosis 287 radiopharmaceuticals and imaging techniques cancer, treatment of 374-376 hyperthyroidism, treatment of 373-374 imaging 285-287 ¹²³I-sodium iodide 285–286 131I-sodium iodide 285-286 99mTc-sodium pertechnetate 286-287 uptake 285 whole-body imaging 375 Thyrotropin or thyroid-stimulating hormone(TSH) 284, 375 Tissue weighting factor (WT) 214-215,401 201Tl-thallous chloride heart imaging 212, 317-320 parathyroid imaging 349-350 tumor imaging 332-333 Tomographic imagers PET 44-45 SPECT 44 Total effective dose equivalent (TEDE) 233, 249 Toxicity 181 Transchelation 99, 113 Transcription in gene 358–359

Transient equilibrium 24-26, 80, 83-84 Transition energy 12, 17 Translation 358-361 Translational medicine (TM) 369-370 Transportation of radioactive materials, regulations for 252-253 Transport index (TI) 252 Tricine 149 Triiodide method of iodination 106-107 Tritium (3H) 69, 229 Tumor imaging 11Choline 340-341 18F-FDG 335-338 ¹⁸F-flucoclovine (Axumin) 341 67Ga-citrate 332-333 68Ga-DOTATATE 339-340 123I-MIBG 334-335 131I-MIBG 334-335 ¹¹¹In-capromab pendetide (ProstaScint) 342 ¹¹¹In-ibritumomab tiuxetan (Zevalin) 342-343 ¹¹¹In-pentetreotide (Octreoscan) 338-339 radiolabeled antibody 341-343 99mTc-sestamibi (Miraluma) 333-334 ²⁰¹Tl-thallous chloride 335 Tungsten-188 (188W) 64, 71

U

Units and constants 403–404 Units of radioactivity 21 Unrestricted area 233 USP Chapter <797>, 191

V

Valence electrons 4 Valence of element 4 Vascular endothelial growth factor (VEGF) 364 Vectors 362 Ventilation studies (lungs) 61, 290–292 Verificatin card for radioactive patients 250 Vitamin B_{12} (cyanocobolamin) 102, 140 Schilling test 264

W

Waste disposal, radioactive 198, 238–239 Written directives 244–245

Х

Xenon-133 (¹³³Xe) gas 61, 71, 138, 213, 253, 281, 290 in lung ventilation studies 292–293 Xofigo 90–91, 159, 213, 381 X, Y positioning circuit 41–42

Y

⁹⁰Y-ibritumomab tiuxetan (Zevalin) 158, 213 in therapy of non-Hodgkin's lymphoma 380
⁹⁰Y-SIR-Spheres (SIR-TeX) 159 in treatment of liver cancer 379
⁹⁰Y-TheraSphere 158–159 in treatment of liver cancer 378–379 Yttrium-90 (⁹⁰Y) 59–60, 88

Z

Zevalin in therapy of non-Hodgkin's lymphoma 380 Zinc-62 (⁶²Zn) 57, 70 Zirconium-89 (⁸⁹Zr) 55–56 ⁶²Zn–⁶²Cu generators 57, 89 Z pulse 42